


FUJIFILM
instax SQUARE SQ 40
INSTANT CAMERA




User's Guide/Safety Precautions





1




2




3







1



2




3







1





2




3






2




3




● For how to insert batteries and how to insert and remove an instax SQUARE film pack, see pages 2 to 5.

Names of Parts

Front



Back




- 1 Flash lampface
- 2 Film ejection slot
- 3 Flash charging lamp
- 4 Viewfinder
- 5 Shutter button
- 6 Lens ring / Power
- 7 AE light sensor
- 8 Flash light sensor
- 9 Lens barrel
- 10 Selfie mirror
- 11 Lens cover / Lens
- 12 Strap eyelet
- 13 Back cover lock
- 14 Film confirmation window
- 15 Back cover
- 16 Film counter
- 17 Battery lid
- 18 Viewfinder eyepiece

Taking Pictures

Do not open the back cover until you have used up the film. Otherwise, the rest of the film will become exposed and turn white, and can no longer be used.

1 Turn on the camera by rotating the lens ring to ON.

The lens barrel extends and the flash charging lamp blinks and then lights up. (Blinking indicates that the flash is charging.)




2 Hold the camera, look through the viewfinder of the camera to frame your desired composition, and press the shutter button.

* The shutter button cannot be pressed while the flash is charging.




3 When the sound of the film being ejected stops, grasp the edge of the ejected film and take the film out.



The film counter decreases in numerical order, counting down from "10" with each photo taken. "0" will be displayed when the film is finished and after the last photo has been taken.

4 When you have finished taking photos, turn off the camera by rotating the lens ring to OFF.




If the camera malfunctions, remove the batteries while the power is on and then reinsert them to reset the camera.

Taking a Photo in Selfie Mode


Taking a picture of yourself

If you shoot in selfie mode, you can take a picture of yourself using the selfie mirror on the front of the camera to confirm your exposure.


- 1 Rotate the lens ring to SELFIE and pull out the lens to the selfie mode.



- 2 Hold the camera securely with both hands so that your face is 30 to 50 cm away from the end of the lens.




- 3 Confirm the composition using the selfie mirror, then push the shutter to take the photo.



Taking a closeup

If you shoot in selfie mode, you can move the camera close to the subject and take a closeup.

- 1 Rotate the lens ring to SELFIE and pull out the lens to the selfie mode.
- 2 Hold the camera so that the  mark in the viewfinder sits slightly to the upper right of the center of the subject, then press the shutter button to take a photo.



Precautions for Taking Photos

Precautions for Holding the Camera



Correct way to hold



Do not cover the flash lampface with a finger



Do not cover the flash light sensor and AE light sensor with a finger

- Take care that a finger or the strap does not cover the flash light sensor, AE light sensor, flash lampface, lens, or film ejection slot.
- Hold the camera so that the flash lampface is at the top when taking a horizontal picture.
- Do not take pictures in locations where flash photography is forbidden.
- Do not grasp the lens barrel when holding the camera. The finished photos may be adversely affected.
- Look into the viewfinder so that the  mark in the viewfinder appears in the center.
- Be careful not to touch the lens when you press the shutter button.

Distances for Normal Mode and Selfie Mode

- In normal mode, take a picture at a distance of at least 0.5 m from the subject. The effective flash range is up to approximately 2.2 m.
- When holding the camera closer than 0.5 m from the subject, use the selfie mode. Use the selfie mode to capture a closeup within the range of 30 to 50 cm.

Flash charging lamp states and error solutions

Flash charging lamp state	Description
Lit	Ready to take a photo.
Off	Camera is off.
Flashing slowly	Charging the flash. Please wait until the flash charging lamp lights. Charging normally takes 3 to 10 seconds to complete.
Flashing quickly	An error has occurred.

Main errors	Cause and solution
Battery check failed	The flash cannot be charged because the battery voltage is insufficient. Replace the batteries with new ones.
Film jammed	Do not forcibly pull out the film. Removing and reinserting the batteries while the power is on may enable the film to be ejected.

Safety Precautions

- **Do not use this product and its accessories for a purpose other than taking photos.**
- **This product has been designed with safety in mind, but please read the following safety precautions carefully and then use the product correctly.**
- **After reading this User's Guide, be sure to keep it in an easy-to-access place where you can refer to it whenever necessary.**

WARNING

This indicates a matter that may lead to death or serious injury if ignored or incorrectly handled.

-  Do not disassemble this product. Electric shock may occur.
-  Do not touch this product if the inside of it becomes exposed due to dropping, etc. This product has high-voltage circuitry that may cause electric shock.
-  If you notice anything abnormal, such as the camera (batteries) becoming hot, emitting smoke, or making a burning smell, remove the batteries immediately. Fire or burns may occur (be careful not to burn yourself when removing the batteries).
-  Never take flash photographs of people riding bicycles, driving cars, skateboarding, riding a horse and the like. The flash can be startling, distract, frighten animals, and otherwise cause an accident.
-  If you drop the camera in water or if water or a piece of metal or other foreign object gets inside, remove the batteries immediately. Heat generation or fire may occur.
-  Do not use this camera in places where there is flammable gas or near open gasoline, benzene, paint thinner or other unstable substances which can give off dangerous vapors. Failure to do this could result in explosion or fire.
-  Keep the product out of the reach of infants and small children. Injury may occur.
-  Do not disassemble, heat the batteries, throw them in a fire, or put them in an electrical short circuit. The batteries may rupture.
-  Use only CR2 batteries. Heat generation or fire may occur if other batteries are used.

-  Keep batteries out of the reach of infants. An infant may accidentally swallow a battery. In the event that a battery is swallowed, seek medical attention immediately.

CAUTION

This indicates a matter that may lead to injury or physical damage if ignored or incorrectly handled.

-  Do not get this product wet or handle it with wet hands. Electric shock may occur.
-  Using a flash too close to a person's eyes may for the short term affect their eyesight. Take care when taking pictures of infants and young children.
-  Take care not to make a mistake with the $\oplus$ and $\ominus$ polarities when inserting the CR2 batteries. Damages to the surroundings may occur due to the camera being damaged or its battery fluid leaking out.
-  Do not touch moving parts inside the camera. You may be injured.

Handling

■ Handling of Camera

1. The camera is a precision instrument, so do not get it wet, drop it, or subject it to shock. Also, do not place the camera where it will be exposed to sand.
2. Before using a commercially available strap, check the strength of the strap. Be especially careful when using a strap for mobile phones and smartphones because such straps are made for lightweight devices.
3. If you are not using your camera for a long interval, unload the batteries and keep it where it will avoid heat, dust and moisture.
4. Remove soil and dust from the viewfinder window, etc. with an air blower and by wiping gently with a piece of soft cloth.
5. Do not use solvent such as thinner or alcohol to wipe off dirt.
6. Do not leave the camera in a closed motor vehicle, another hot place, a humid place, on the beach, etc. for any period of time.
7. Moth repellent gas such as naphthalene will adversely affect the camera and film. Avoid keeping the camera and film in a chest of drawers, etc. with mothballs.
8. The operating temperature range of this camera is +5°C to +40°C.
9. This camera may occasionally malfunction because it is controlled by a micro computer. If it malfunctions, remove and then reinsert the batteries to reset the camera.

■ Handling of instax SQUARE Film and Photos

For details on the handling of film and photos, see the instructions of FUJIFILM instax SQUARE instant film.

1. Keep film a cool place. In particular, do not leave film in an extremely hot place, such as in a closed motor vehicle, for a long period of time.
2. Use film as soon as possible after inserting it in the camera.
3. If film has been kept in a place where the temperature is extremely low or high, allow it to become accustomed to a normal temperature before taking pictures.
4. Use film before the film expiration date referenced on the package.
5. Avoid airport checked luggage inspection and other strong X-ray exposure. Unused film is susceptible to the effect of fogging, etc. We recommend that you carry film onto aircraft in carry-on luggage (check with the relevant airport for more information).
6. Avoid exposing photos to strong light, and store them in a cool and dry place.
7. Do not make a hole in film or tear or cut film. Do not use film that is damaged.
8. Do not cut or disassemble the film for this camera as it contains black caustic alkali paste. Be especially careful not to let infants or pets put the film into their mouths. Also take care that the paste does not come into contact with skin and clothes.
9. If you accidentally touch the paste of unused film, immediately wash it off with plenty of water. If the paste comes into contact with the eyes or mouth, wash the area and then seek medical attention. The alkalinity of this film will weaken approximately 10 minutes after the photo is ejected from the camera.

■ Cautions on Handling of Film and Finished Photos

For details, see the instructions of FUJIFILM instax SQUARE instant film.



The "CE" mark certifies that this product satisfies the requirements of the European Union (EU) regarding safety, public health, environment, and consumer protection. ("CE" is the abbreviation of Conformité Européenne.)



The "UKCA" mark certifies that this product satisfies the requirements of Great Britain (England, Scotland, Wales) regarding safety, public health, environment and consumer protection.

*UKCA: UK Conformity Assessed.

■ **Legally required regulation compliance displays are located on the inside of the back cover of the camera.**



Disposal of Electric and Electronic Equipment in Private Households
Disposal of used Electrical & Electronic Equipment

(Applicable in the European Union and other European countries with separate collection systems)

This symbol on the product, or in the manual and in the warranty, and/or on its packaging indicates that this product shall not be treated as household waste. Instead it should be taken to an applicable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences to the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. The recycling of materials will help to conserve natural resources. For more detailed information about recycling of this product, please contact your local city office, your household waste disposal service or the shop where you have purchased the product.

In Countries outside of EU: If you wish to discard this product, please contact your local authorities and ask for the correct way of disposal.



This Symbol on the batteries or accumulators indicates that those batteries shall not be treated as Household waste.

For customers in Turkey:

EEE Complies with Directive.

Specifications

Film	FUJIFILM instax SQUARE instant film
Photo Picture Size	62 mm × 62 mm
Lens	2 components, 2 elements, f = 65.75 mm, 1:12.6
Viewfinder	Reverse Galilean finder, 0.4x, with target spot
Shooting Range	0.3 m and beyond (use selfie mode for 0.3 m to 0.5 m)
Shutter	Programmed electronic shutter 1/2 to 1/400 sec. Slow synchro for low light
Exposure Control	Automatic, Lv 5.0 to 15.5 (ISO 800)
Film Ejection	Automatic
Film Developing Time	Approx. 90 seconds (varies depending on the ambient temperature)
Flash	Constant firing flash (automatic light adjustment), recycle time: 7.5 seconds or less (when using new batteries), effective flash range: 0.3 to 2.2 m
Power Supply	Two lithium batteries (CR2), capacity: approx. 30 instax SQUARE film packs (under FUJIFILM test conditions)
Auto Power Off Time	After 5 minutes
Other	Includes film counter and film pack confirmation window
Dimensions	134.2 mm × 120.2 mm × 60.5 mm
Weight	453 g (without batteries, strap, and film)

Information for traceability in Europe

Manufacturer: FUJIFILM Corporation

7-3, Akasaka 9-Chome, Minato-ku, Tokyo
Japan

Authorized representative in Europe: FUJIFILM Europe GmbH

Balcke-Duerr-Allee 6, 40882 Ratingen
Germany

EU Importer: FUJIFILM Europe B.V.

Oudenstaart 1, 5047 TK Tilburg
The Netherlands

UK Importer: FUJIFILM UK Limited

Fujifilm House, Whitbread Way,
Bedford, Bedfordshire, MK42 0ZE
UK

[**en**] If you have any inquiries about this product, please contact a FUJIFILM authorized distributor or dealer, or access the website below.

[**de**] Wenn Sie Fragen zu diesem Produkt haben, wenden Sie sich bitte an einen von FUJIFILM autorisierten Händler oder Vertriebspartner oder besuchen Sie die untenstehende Website.

[**fr**] Si vous avez des questions concernant ce produit, veuillez contacter un distributeur ou un revendeur FUJIFILM agréé ou visitez le site Internet suivant.

[**es**] Si tiene alguna pregunta sobre este producto, póngase en contacto con un vendedor o un distribuidor de FUJIFILM autorizados o acceda al sitio web siguiente.

[**zht**] 如果對本產品有任何疑問，請與經過授權的 FUJIFILM 的分銷商或經銷商取得聯繫，或訪問以下網站聯繫我們。

[**ko**] 이 제품에 관한 문의 사항은 FUJIFILM 공식 대리점 또는 판매점에 문의하시거나 아래의 웹사이트를 방문하십시오.

[**pt**] Caso tenha alguma questão acerca deste produto, por favor, contacte um distribuidor ou revendedor autorizado FUJIFILM, ou acesse ao website abaixo.

[**ru**] Если у Вас есть любые вопросы относительно этого изделия, обратитесь к авторизованному дистрибьютору или дилеру FUJIFILM, либо посетите следующий веб-сайт.

[**it**] In caso di domande relative al prodotto, contattare un rivenditore o un distributore autorizzato FUJIFILM o accedere al sito web riportato di seguito.

[**nl**] Als u vragen heeft over dit product, neem dan contact op met een geautoriseerde FUJIFILM-distributeur of -dealer, of ga naar onderstaande website.

[**pl**] Jeśli masz jakieś pytania dotyczące tego produktu, skontaktuj się z autoryzowanym dystrybutorem lub sprzedawcą FUJIFILM, albo odwiedź witrynę internetową podaną poniżej.

[**cs**] Máte-li jakékoli dotazy týkající se tohoto výrobku, obraťte se prosím na oprávněného distributora či prodejce společnosti FUJIFILM nebo navštivte níže uvedené webové stránky.

[**sk**] Ak máte akékoľvek otázky týkajúce sa tohto výrobku, kontaktujte autorizovaného distribútora alebo predajcu výrobkov od spoločnosti FUJIFILM, alebo si pozrite nižšie uvedenú webovú stránku.

[**hu**] A termékkel kapcsolatos bármely kérdésével kérjük, keresse fel a FUJIFILM egyik hivatalos forgalmazóját vagy kereskedőjét, vagy látogasson el az alábbi weboldalra.

[**uk**] Якщо маєте якісь запитання щодо цього виробу, будь ласка, зверніться до вповноваженого представника чи дилера FUJIFILM або завітайте на сайт, указаний далі.

<https://www.fujifilm.com/>

FUJIFILM

FUJIFILM Corporation

7-3, AKASAKA 9-CHOME, MINATO-KU, TOKYO 107-0052, JAPAN