

FP FLASHPOINT



Zoom
TTL Flash **R2**
for Sony

FPLFSMZSO

Thank you for choosing Flashpoint!

The new Flashpoint Zoom TTL Speedlight for Sony with Integrated R2 Radio Transceiver is a hotshoe speedlight which is fully compatible with the Sony TTL system. The incredible amount of power contained in these compact and lightweight units as well as their integrated functions and features make them the first choice of professional photographers. If you have any questions or concerns, please feel free to contact us at Brands@Adorama.com


Features

- Extremely Powerful Flash with a GN of 127
- Complete Compatibility with The Sony TTL System
- Fully Compatible with All On Camera iTTL Controls Including Automatic TTL Exposure Control, Exposure Bias, Bracketing, Second Curtain Sync, HSS, EXIF Recording, and Modeling Flash
- Optical iTTL Communication with Sony Flashes as a Master or Slave
- Manual Control of Two Different Wireless Groups by Using the Sony TTL Optical System
- Remote TTL and Manual Power Control with the Integrated R2 Radio System's Built In Transmitter and Receiver
- Industry benchmark range and interference avoidance with the new INTEGRATED 2.4 GHz R2 Radio System
- Zooming Head for Even Coverage with automatic zoom or manual control
- HSS for Shutter Speeds Up To 1/8000 Second
- Regular and Intelligent Optical Slave Modes
- Backwards Compatible with The Flashpoint R1 Radio Control System for Manual Output Control and Triggering
- 360 degree rotation and 90+ degree tilt
- Stable color temperature at 5600±200K over the entire power range
- Backlit Matrix LCD
- Multipurpose Buttons with Digital Marking for Faster Navigation
- Perfect for On and Off Camera Use
- Faster Recycle with the Flashpoint Blast Pack BP-960 with Canon cord
- Laser AF Assist Lamp with Crisscross Pattern for Instant Autofocus Even In Complete Dark On Low Contrast Surfaces
- 1 Year Warranty

For Your Safety


- Always keep this product dry.
Do not use in rain or in damp conditions.
- This product contains high-voltage electronic parts. Touching the high-voltage circuit inside it may result in electric shock. Do not disassemble. Should repairs become necessary, this product must be sent to an authorized maintenance center.
- Stop using this product if it breaks open due to internal shifting, falling or strong impact. STRONG electric shock may occur if you touch the components inside it. You might DIE. Don't risk it. Reincarnation is not covered by the warranty.
- Do not fire the flash directly into the eyes (especially those of babies and pets) within short distances. Otherwise visual impairment may occur. When taking pictures for babies, keep the flash unit at least 1 meter (3.3 feet) away from them. Using bounce flash to reduce light intensity is also recommended. Plus it will make them look cuter. Because it creates softer light, and larger catchlights in the eyes. And makes them look more angelic. Which is good. Cause they are babies. They are SUPPOSED to look angelic! Also you won't get hard shadows from that ridiculous gigantic bow they decided to stick on the baby's head if you bounce your light.
- Do not use the flash unit in the presence of flammable gases, chemicals and other similar materials. In certain circumstances, these materials may be sensitive to the strong light emitting from this flash unit and fire may result. A whole new meaning to "Flashpoint".
- Do not leave or store the flash unit if the ambient temperature reads over 50°C (e.g. in automobile in the sun). Otherwise the electronic parts may be damaged.
- Do not use any power supply other than the intended one to power the unit.
- Do not insert metal parts into any lighting equipment.
- Do not touch the electrical contacts on the flash or battery or contact them with any conductive materials.
- This flash has an over-heat protection circuit, rapid continuous firing will cause the flash to slow operation and trigger a "cool down" period. After this period, the flash will resume normal operation. You may also reboot the flash by cycling the power off and then on.
- Do not use selective coloring.
- Do not use the flash to support other equipment. For example, do not lift your camera by the flash.
- The flash has a locking pin to ensure secure operation. To avoid damage, completely unscrew the locking ring before removing the flash.
- In case of abnormal function, sparks, excessive heat, flames or smoke, immediately power off the unit and disconnect the battery if safely possible. Have it checked by an authorized technician.
- Store the flash with the batteries removed. Storing the flash with the batteries in it can lead to battery leakage.

Name of Parts



Body

- | | |
|-------------------------------------|------------------------------------|
| 01. Retractable Bounce Card | 08. Hotshoe |
| 02. Retractable Wide Angle Diffuser | 09. Dot-matrix LCD Panel |
| 03. Flash Head | 10. Lock Ring |
| 04. Optical Control Sensor | 11. Battery Compartment |
| 05. Focus Assist Beam | 12. USB Port for Firmware Upgrades |
| 06. R1 Wireless Control Port | 13. Slave Flash Ready Indicator |
| 07. Sync Cord Jack | 14. External Power Supply Socket |




Control Panel

- | | |
|---|--|
| 15. < MODE > Mode Selection Button / Lock Button | 20. < ⚡ > Test Button / Flash Ready Indicator |
| 16. < ↔ > Wireless Selection Button | 21. Function Button 1 |
| 17. Select Dial | 22. Function Button 2 |
| 18. < SET > Set Button | 23. Function Button 3 |
| 19. ON / OFF Power Switch | 24. Function Button 4 |


LCD Panel

(1) TTL Autoflash




- The display will only show the settings currently applied.
- The functions displayed above buttons 1 to 4, such as **SYNC** and **±**, change according to settings' status.
- When a button or dial is operated, the LCD panel is illuminated.

(2) M Manual Flash




(3) Multi Flash




(4) Radio Transmission Shooting/Optical Transmission Shooting

• Master Unit



• Slave Unit



• Included Accessories

1. Flash Unit
2. Mini Stand
3. Protective Case
4. Instruction Manual

• Accessories

R2 Radios



R1 Radios



Flashpoint Blast Power Pack BP-960 with Canon Cord FPPPBP960CA



Flashpoint Grid for Speedlight FPLFSMX02



Flashpoint Flash Diffuser FAFD60




Hexapop/Parapop rapid deployment Softboxes




Flashpoint Speedlight Reflector FPLFSMX01




Attaching to a Camera



- 1 Attach the Camera Flash.**
Slip the camera flash's mounting foot into the camera's hotshoe all the way.



- 2 Secure the Camera Flash.**
Rotate the lock ring on the mounting foot until it is secure.



- 3 Detach the Camera Flash.**
Rotate the lock ring on the mounting foot until it is fully loosened.

Power Management

Use ON/OFF Power Switch to power the flash unit on or off. Turn off the unit if it will not be used for an extended period of time. Set as a master flash, it will turn the power off automatically after approx. 90 seconds of idle use. Pressing the camera shutter halfway or pressing any flash button will wake up the flash unit. Set as a slave flash, it will enter sleep mode after a certain period (adjustable, 60 minutes by default) of idle use. Pressing any flash button will wake it up.

- ① C.Fn** Disabling Auto Power Off function is recommended when the flash is used off camera. See the [Custom Function Menu](#) section.
- C.Fn** Slave Auto Power Off Timer is set to 60 minutes by default. Another option "30 minutes" is available. See the [Custom Function Menu](#) section.

Flash Mode – TTL Autoflash

This flash has three flash modes: **TTL**, Manual (**M**), and **RPT** (Stroboscopic). In **TTL** mode, the camera and the flash will work together to calculate the correct exposure for the subject and the background. In this mode, multiple TTL functions are available: FEC, HSS, second curtain sync, etc.

* Press < **MODE** > Mode Selection Button and three flash modes will display on the LCD panel one by one with each press.

TTL Mode


Press < **MODE** > Mode Selection Button to enter TTL(Automatic) mode.



- Press the camera release button halfway to focus. The aperture and effective flash range will be displayed in the viewfinder.
- When the shutter button is fully pressed, the flash will fire a pre-flash that the camera will use to calculate exposure and flash output the instant before the photo is taken.


FEC: Flash Exposure Compensation

With FEC function, this flash can bias the flash output from -3 to +3 in 1/3rd stops. It is useful in situations where minor adjusting of the TTL system is needed based on the environment.


Setting FEC:



- 1 Press Function Button 2 <  >. The icon <  > and flash exposure compensation amount will be highlighted on the LCD panel.




- 2 **Set the flash exposure bracketing amount.**
 - Turn the Select Dial to set the amount.
 - “0.3” means 1/3 stop.
 - “0.7” means 2/3 stop.
 - To cancel the flash exposure compensation, set the amount to “+0”.




- 3 Press < **SET** > button again to confirm the setting.

High-Speed Sync

High Speed Sync (FP flash) enables the flash to synchronize with all camera shutter speeds. This is convenient when you want to use aperture priority for fill-flash portraits.



As high-speed sync setting is determined by Sony camera's shutter, please refer to your camera's manual to ensure proper activation of this feature.

-  With high-speed sync, the faster the shutter speed, the shorter the effective flash range.
- Stroboscopic mode cannot be set in high-speed sync mode.
- Over-heat protection may be activated after 10 consecutive high-speed sync flashes


Second-Curtain Sync

With a slow shutter speed, you can create a light train following the subject. The flash fires right before the shutter closes.


- Set the camera to Rear curtain mode to activate rear curtain sync.

Flash Mode – M: Manual Flash


The flash output is adjustable from 1/1 full power to 1/128th power in 1/3rd stop increments. To obtain a correct flash exposure, use a hand-held flash meter to determine the required flash output.



- 1 Press **< MODE >** button so that **< M >** is displayed.



- 2 Turn the Select Dial to choose a desired flash output amount.



- 3 Press **< SET >** button again to confirm the setting.

Flash Output Levels

The following table makes it easier to see how the display changes in terms of f/stop when you increase or decrease the flash output. For example, when you decrease the flash output to 1/2, 1/2-0.3, or 1/2-0.7, and then increase the flash output to more than 1/2, 1/2+0.3, 1/2+0.7, and 1/1 will be displayed.

Figures displayed when reducing flash output level →

1/1	1/1-0.3	1/1-0.7	1/2	1/2-0.3	1/2-0.7	1/4
	1/2+0.7	1/2+0.3		1/4+0.7	1/4+0.3	

← Figures displayed when increasing flash output level

Optical Slave S1

In M manual flash mode, press **< S1/S2 >** button so that this flash can be triggered as an optical slave. With this function, the flash will fire simultaneously when the main flash fires. Use this mode when firing another manual powered flash, and in areas where no one else is doing flash photography.

Intelligent Optical Slave S2

Press **< S1/S2 >** button so that this flash can be triggered as an intelligent optical slave. This is useful when triggering with a TTL flash. In this mode, the flash will ignore a single “preflash” from the main flash and will only fire in response to the second, actual flash from the main unit. Use this mode when firing a TTL speedlight, and in areas where no one else is doing flash photography.


Manual Off Camera High-speed Setting

In M manual flash mode, press **< SYNC >** button to select high-speed mode and **< H >** is displayed.

- S1 and S2 optic triggering and off camera high-speed mode are only available in M manual flash mode.


Flash Mode – MULTI: Stroboscopic Flash

With stroboscopic flash, a rapid series of flashes is fired. It can be used to capture multiple images of a moving subject in a single photograph. You can set the firing frequency (number of flashes per sec. expressed as Hz), the number of flashes, and the flash output.




1 Press < **MODE** > button so that < **MULTI** > is displayed.

2 Turn the Select Dial to choose a desired flash output.



3 Set the flash frequency and flash times.

- Press Function Button 3 < **MULTI** > button to select the setting to change.
- Turn the Select Dial to set the number and press Function Button 4 < **Hz** > button again to confirm. The next item to be set will blink. (Hz=FPS)
- After you finish the setting, press < **SET** > button and all the settings will be displayed.




Calculating the Shutter Speed

During stroboscopic flash, the shutter should remain open until the firing stops. Use the formula below to calculate the shutter speed and set it with the camera.

Number of Flashes / Flash Frequency = Shutter Speed

For example, if the number of flashes is 10 and the firing frequency is 5 Hz, the shutter speed should be at least 2 seconds.

 To avoid overheating and deteriorating the flash head, do not use stroboscopic flash more than 10 times in succession. After 10 times, allow the camera flash to rest for at least 15 minutes. If you try to use the stroboscopic flash more than 10 times in succession, the firing might stop automatically to protect the flash head. If this happens, allow at least 15 minutes' rest for the camera flash.

- Stroboscopic flash is most effective with a highly reflective or light colored subject against a dark background.
- Using a tripod and a remote control is recommended.
- A flash output of 1/1 and 1/2 cannot be set for stroboscopic flash.
- Stroboscopic flash can be used with "bulb".
- If the number of flashes is displayed as "--", the firing will continue until the shutter closes or the battery is exhausted. The number of flashes will be limited as shown by the following table.

Maximum Stroboscopic Flashes:

Flash Output \ Hz	1	2	3	4	5	6-7	8-9
1/4	7	6	5	4	4	3	3
1/8	14	14	12	10	8	6	5
1/16	30	30	30	20	20	20	10
1/32	60	60	60	50	50	40	30
1/64	90	90	90	80	80	70	60
1/128	90	90	90	90	90	90	80


Flash Output \ Hz	10	20-50	60-199			
1/4	2	2	2			
1/8	4	4	4			
1/16	8	8	8			
1/32	20	16	12			
1/64	50	30	20			
1/128	70	40	40			

Wireless Flash Shooting: Optical Transmission

This product is compatible with Sony Wireless Lighting System (WL). It can function as either an optical wireless master or slave flash. As a master unit, it can control Sony speedlights e.g. HVL-F60M, HVL-F43M and HVL-F32M via optical wireless. As a slave unit, it can be controlled by optical wireless signals of Sony speedlights and pop-up flash commanders of Sony cameras.

- Master unit only has TTL and OFF mode. And M flash mode can only be set on the slave unit.
- Optical wireless lighting system (WL) does not have Multi mode.
- When setting the slave unit to M mode, please set the group of the master unit to TTL mode.

Slave/Master Unit's Positioning and Operation Range




- Even with multiple slave units, the master unit can control all of them via optical wireless.
- In this user manual, "master unit" refers to the speedlight on a camera and "slave unit" will be controlled by the master unit.

1. Wireless Settings

You can switch between normal flash and wireless flash. For normal flash shooting, be sure to set the wireless setting to OFF.


Master Unit Setting



Press **< CTRL+ >** button so that **< CTRL+ >** is displayed on the LCD panel.
The backlight turns green now.


- Note: In the master unit mode **< CTRL+ >**, you should set the camera to wireless flash mode (WL) when attaching the camera flash to the camera. If the camera is not set to WL mode, a note "SET YOUR CAMERA" will be displayed on the flash. For instructions on setting your camera to wireless lighting mode (WL), please refer to the camera's manual.

Slave Unit Setting



Press **< CTRL+ >** button again so that **< CTRL+ >** and **< SLAVE >** are displayed on the LCD panel.
The backlight turns orange now.

2. Making Adjustments



Setting Master Unit's Flash Mode


Press Function Button 4 **< Gr >** to choose the "M" group from M/A/B/C. Then, press Function Button 3 **< MODE >** so that the master unit can work in OFF / TTL flash mode. Choose one of them as the flash mode of master unit.

Adjusting the Output of Remote Groups

- Press Button 4 **< Gr >** to cycle through the groups.
- Press Button 3 **< MODE >** to choose TTL or OFF.
- In TTL mode, press Button 2 **< +/- >** to change the TTL Exposure Bias.

3. Setting the Communication Channel

If there are other wireless flash systems nearby, you can change the channel IDs to prevent signal interference. The channel IDs of the master unit and the slave unit(s) must be the same.



- Press Function Button 3 **< CH >** and turn the Select Dial to choose a channel ID from 1 to 4.
- Press the **< SET >** button to confirm.

- The Sony optical lighting system (WL) provides limited functions. For additional features, use the R2 (2.4ghz) integrated radio and R2 compatible strobes.

Wireless Flash Shooting: Radio (2.4G) Transmission


- You can set up three slave groups for TTL autoflash shooting. With TTL autoflash, you can easily create various lighting effects.
- Any flash setting for the slave units on the master flash in TTL mode will be automatically sent to the slave units. So the only thing you need to do is to set the master unit for each slave group without any operation for the slave units at all during the shooting.
- This flash can work in TTL/M/Multi/OFF flash modes when set as a master unit.

- Even with multiple slave units, the master unit can control all of them via wireless.
- In this user manual, “master unit” refers to the camera flash on a camera and “slave unit” will be controlled by the master unit.

1. Wireless Settings

You can switch between normal flash and wireless flash. For normal flash shooting, be sure to set the wireless setting to OFF.


Master Unit Setting



1 Press < **WIRELESS** > button so that < **WIRELESS** > is displayed on the LCD panel. If < **WIRELESS MULTI** > is displayed, it means Multi mode is ON.

2 The backlight turns green.

Slave Unit Setting




1 Press < **WIRELESS** > button so that < **WIRELESS** > and < **SLAVE** > are displayed on the LCD panel.


2 The backlight turns orange.

3 The slave unit can be set as group A/B/C.

2. Setting Each Unit's Flash Mode Using the Master




1 Press Function Button 4 < **Gr** > to choose the group from M/A/B/C. Then, press Function Button 3 < **MODE** > so that the group unit can work in OFF/TTL/M flash mode. Choose one of them as the flash mode of each unit.



2 Adjusting the Output of Remote Groups

1. Press **Button 4** < **Gr** > to cycle through the groups.
2. Press **Button 3** < **MODE** > to choose TTL, Manual or OFF < --- >.
3. In TTL mode, press **Button 2** < +/- > to change the TTL Exposure Bias by scrolling the wheel.
4. In Manual mode, press **Button 2** < +/- > to change the power output by scrolling the wheel.




3 Press < **MODE** > button to switch to Multi mode.


All changes made on the master unit will automatically change on the slave unit.

3. Setting the Communication Channel

If there are other wireless flash systems nearby, you can change the channel IDs to prevent signal interference. The channel IDs of the master unit and the slave unit(s) must be set to the same.




1 Press Function **Button 3** < **CH** > and turn the Select Dial to choose a channel ID from 1 to 32.



2 Press the < **SET** > button to confirm.

4. TTL: Fully Automatic Wireless Flash Shooting


Autoflash Shooting with One Slave Unit



Master Unit Setting

- Attach a Zoom speedlight flash on the camera and set it as the master unit.
- M/A/B/C can be set as TTL mode independently.

Multi: Manual Wireless Flash Shooting



1 Setting < Multi > stroboscopic flash.

- Press < **MODE** > button so that < **MULTI** > is displayed.
- Set the stroboscopic flash settings, and choose which groups will be active during the exposure using Buttons 2, 3, and 4 to navigate between the menus and options.
- The screen will display the Power, Frequency, and number of flashes, as well as which group are On and Off.

Auto Focus Assist Beam

In poorly-lit or low-contrast shooting environments, the built-in auto focus assist beam will automatically activate to make it easier for autofocus. The beam will activate only when autofocus is difficult and turn off as soon as the autofocus is achieved.

If you want to turn off the auto focus assist beam, set the "AF" to "OFF" in the C.Fn settings.


i If you find the auto focus assist beam does not light up, this is because the camera has achieved autofocus.

Position	Effective Range
Center	0.6~10m / 2.0~32.8 feet
Periphery	0.6~5m / 2.0~16.4 feet

Bounce Flash

By pointing the flash head toward a wall or ceiling, the flash will bounce off the surface before illuminating the subject. This can soften shadows behind the subject for a more natural-looking shot. This is called bounce flash.

To set the bounce direction, hold the flash head and turn it to the desired angle.






- If the wall or ceiling is too far away, the bounced flash might be too weak and result in underexposure.
- The wall or ceiling should be a plain, white color for high reflectance. If the bounce surface is not white, a color cast may appear in the picture.


Creating a Catchlight

With the catchlight panel, you can create a catchlight in the subject's eyes to add life to the facial expression.



1 Point the flash head upward to 90°.

2 Pull out the wide angle diffusion panel. The catchlight panel will come out at the same time.



3 Push the wide angle diffusion panel back in.


- Push in only the wide angle diffusion panel.
- Follow the same procedures as for bounce flash.



- Point the flash head straight ahead and then upward to 90°. The catchlight will not appear if you swing the flash head left or right.
- For best catchlight effect, stay 1.5m/4.9ft away from the subject.

ZOOM: Setting the Flash Coverage and Using the Wide Angle Diffusion Panel

The flash coverage can be set automatically or manually. It can be set to match the lens focal length from 20mm to 200mm. Also, with the built-in wide angle diffusion panel, the flash coverage can be expanded for 14mm wide-angle lenses.




In Manual Zoom mode, press the < ZOOM/C.FN > button.

- Turn the Select Dial to change the flash coverage.
- If < **A** > is displayed, the flash coverage will be set automatically.




If you set the flash coverage manually, make sure it covers the lens focal length so that the picture will not have a dark periphery.




Using the Wide Angle Diffusion Panel

Pull out the wide angle diffusion panel and place it over the flash head as shown. The flash coverage will then be expanded to 14 mm.

- The catchlight panel will come out at the same time. Push the catchlight panel back in.
- The **< ZOOM/C.FN >** button will not work.



Low Battery Warning

If the battery power is low,  will appear and blink on the LCD panel. Please replace the batteries immediately.

C.Fn: Setting Custom Functions


The following table lists the available and unavailable custom functions of this flash.

C.Fn Custom Functions			
Custom Function Signs	Function	Setting No.	Settings & Descriptions
m/ft	Distance indicator	m	meters
		ft	feet
APO	Auto power off	ON	ON
		OFF	OFF
AF	AF-assist beam	ON	ON
		OFF	OFF
Sv APOT	Slave auto power off timer	60min	60min
		30min	30min
BEEP	Audible ready alert	ON	ON
		OFF	OFF
LIGHT	Backlighting time	12sec	Off in 12 sec.
		OFF	Always off
		ON	Always lit
LCD	LCD contrast ratio	0~9	10 levels

1. Press **< Zm/C.Fn >** Backlight/Custom Setting Button for 2 seconds or longer until C.Fn menu is displayed. The “Ver x.x” in the top-right corner refers to the software version.
2. Select the Custom Function No.
 - Turn the Select Dial to choose the Custom Functions.
3. Change the Setting.
 - Press **< SET >** button and the Setting No. blinks.
 - Turn the Select Dial to set the desired number. Pressing **< SET >**
4. In the C.Fn mode, long press the “Clear” button for 2 seconds until “OK” is displayed on the panel, which means the values in C.Fn can be reset.

Protection Function

1. Over-Temperature Protection

- To avoid overheating and deteriorating the flash head, do not fire more than 20 continuous flashes in fast succession at 1/1 full power. After 20 continuous flashes, allow a rest time of at least 10 minutes.
- If you fire more than 20 continuous flashes and then fire more flashes in short intervals, the inner over-heat protection function may be activated and make the recycling time over 10 seconds. If this occurs, allow a rest time of about 10 minutes, and the flash unit will then return to normal.
- When the over-heat protection is started,  is shown on the LCD display.

Number of flashes that will activate over-temperature protection:

Power Output Level	Number of Flashes
1/1	30
1/2 +0.7	40
1/2 +0.3	50
1/2	60
1/4 (+0.3,+0.7)	100
1/8 (+0.3,+0.7)	200
1/16 (+0.3,+0.7)	300
1/32 (+0.3,+0.7)	500
1/64 (+0.3,+0.7)	1000
1/128 (+0.3,+0.7)	

Number of flashes that will activate over-temperature protection in high-speed sync triggering mode:

Power Output	Times
1/1	15
1/2 (+0.3,+0.7);	20
1/4 (+0.3,+0.7)	
1/8 (+0.3,+0.7);	
1/16 (+0.3,+0.7)	40
1/32 (+0.3,+0.7);	
1/64 (+0.3,+0.7);	
1/128 (+0.3,+0.7);	50

2. Other Protections

The system provides real-time protection to secure the device and your safety. The following lists prompts for your reference:

Prompts on LCD Panel	Meaning
E1	A failure occurs on the recycling system so that the flash cannot fire. Please restart the flash unit. If the problem still exists, please send this product to a maintenance center.
E2	The system gets excessive heat. Please allow a rest time of 10 minutes.
E3	The voltage on two outlets of the flash tube is too high. Please send this product to a maintenance center.
E9	There are some errors occurred during the upgrading process. Please use the correct firmware upgrade method.


Technical Data

Model	FPLFSMZSO	
• Type		
Compatible cameras	Sony Multi Interface Hotshoe Cameras	
Guide no. (1/1 output @ 200mm)	127 Ft, 34 Meters @ ISO 100 200mm zoom	
Flash coverage	20 to 200mm (14mm with wide Angle Diffusion panel)	
	• Auto zoom (Flash coverage set automatically to match the lens focal length and sensor size)	
	• Manual zoom	
	• Rotating/tilting flash head (bounce flash): 0 to 360° horizontally and -7° to 90° vertically	
Flash duration	1/300 to 1/20000 second	
• Exposure Control		
Exposure control system	TTL autoflash and manual flash	
Flash exposure compensation (FEC)	Manual. FEB: ±3 stops in 1/3 stop increments (Manual FEC and FEB can be combined.)	
Sync mode	High-speed sync (up to 1/8000 seconds), first-curtain sync, and second-curtain sync	
Stroboscopic mode	Provided (up to 90 times, 100Hz)	
• Wireless Flash (Optic transmission and 2.4G transmission)		
Wireless flash function	Master, Slave, Off	
Controllable slave groups	3 (A, B, and C)	
Transmission range (approx.)	Optical	Indoors: 12 to 15 m / 39.4 to 49.2 ft.
		Outdoors: 8 to 10 m / 26.2 to 32.8 ft.
	Master unit reception angle: ±40° horizontally, ±30° vertically	
	2.4G	100m
Channels	Optical	4 (1, 2, 3, and 4)
	2.4G	32 (1~32)
Slave-ready indicator	Two red blinking indicators	
Modeling flash	Fired with camera's depth-of-field preview button	
• Auto Focus Assist Beam		
Effective range (approx.)	Center: 0.6~10m / 2.0~32.8 feet	
	Periphery: 0.6~5m / 2.0~16.4 feet	
• Power Supply		
AA batteries 1.5v	Ni-MH batteries (recommended) or 4*LR6 alkaline batteries	
Recycle time	Approx. 0.1-2.6 seconds	
Full power flashes	Approx. 230 (2500mA Ni-MH batteries)	
Power saving	Power off automatically after approx. 90 seconds of idle operation. (60 minutes if set as slave)	
External power	Flashpoint Blast Power Pack BP-960 with Canon Cord FPPPBP960CA	
• Sync Triggering Mode	Hotshoe, 3.5mm sync line, R1 Wireless control port	
• Color Temperature	5600±200k	
• Dimensions		
W x H x D	64 x 76 x 190 mm	
Weight without battery	410g	
Weight with battery	530g	

Troubleshooting

If there is a problem, refer to this Troubleshooting Guide.

The Camera Flash cannot be charged.

- The batteries are installed in the wrong direction.
→ Install the battery is in the correct direction.
- The camera flash's internal battery is exhausted.
→ If  appears and blinks on the LCD panel, replace the batteries immediately.

The Camera Flash does not fire.

- The camera flash is not attached securely to the camera.
→ Attach the flash's mounting foot securely to the camera.
- The electrical contacts of the Camera Flash and camera are dirty.
→ Clean the contacts with an eraser.

The power turns off by itself.

- After 90 seconds of idle operation, auto power off takes effect if the flash is set as master.
→ Press the shutter button halfway or press any flash button to wake up.
- After 60 minutes (or 30 minutes) of idle operation, the flash unit will enter sleep mode if it is set as slave.
→ Press any flash button to wake up.

Auto zoom does not work.

- The camera flash is not attached securely to the camera.
→ Attach the camera flash's mounting foot to the camera.

The flash exposure is underexposed or overexposed.

- You used high-speed sync.
→ With high-speed sync, the effective flash range will be shorter. Make sure the subject is within the effective flash range displayed.
- You used Manual Flash mode.
→ Set the flash mode to **TTL** or modify the flash output.

Photos have dark corners or only parts of the target subject are illuminated.

- The focal length of lens is wider than the flash zoom setting.
→ Check the flash coverage you set. This flash unit has the flash coverage between 20 and 200mm, which fits medium-format cameras. Pull the wide Angle Diffusion panel out to extend the flash coverage.

Firmware Upgrade

This flash supports firmware upgrade through the USB port. Update information will be released on our official website.



USB connection line is not included in this product. The USB port is a standard Micro USB socket.

Maintenance

- Shut down the device immediately should abnormal operation be detected.
- Avoid sudden impacts, and the product should be dusted regularly.
- It is normal for the flash tube to be warm when in use. Avoid continuous flashes if possible.
- Maintenance of the flash must be performed by an authorized maintenance department which can provide original accessories.
- This product, except consumables e.g. flash tube, is supported with a one-year warranty.
- Unauthorized service will void the warranty.
- If the product had failures or was wet, do not use it until it is repaired by professionals.
- Changes made to the specifications or designs may not be reflected in this manual.

For assistance, you can always email Brands@Adorama.com