


ILLUMINE REVERB

USER GUIDE

v. 1.1.0




Key Features	1
Quick Start	1
Connectors	2
User Interface	6
Knobs	6
Footswitches	9
Presets & Editing	11
Changed Preset Flag	11
Save Menu	12
Edit the Preset Name	13
Factory Presets	14
Effect	16
Parameters	22
Footswitch Recalls/Skips Preset	26
Setup Menus	26
Expression Control Engine	27
Expression Controller Inputs	27
Expression Controller Setup	30
A/B Exp Setup	30
Adding Parameters to Expression Control	31
Selecting the Midpoint	32
A►B and A◄B Time	32
MIDI	33
Global Setup	37
Exp Source	37
Cal Pedal / Exp Screens	37
MIDI Setup	39
Bypass Type & Trails	39
Effect Routing	40
Effect Loop Type	41
Wet/Dry Mode	42
Right Footswitch	43
Preset Switching	43
Mix Sum Type	44
Gain Structure	45
FX Sidechain In	46
Noise Reduction	47
User Interface Options	47
Preset Manager Software	49
How to Update the ILLUMINE Reverb's Firmware	50
Troubleshooting Guide	53
Specifications	55
Legal	56

KEY FEATURES

- 17 stereo reverb effects
- 50 user presets
- MIDI input and thru/out with simple controller
- Powerful and flexible expression control engine
- Analog dry signal path
- Pedalboard-friendly design with rear connectors and low power usage

QUICK START



CONNECTORS

POWER


Power is supplied with a standard pedal power supply:

- 9 V to 12 V regulated DC
- 100 mA or greater
- center-negative (tip-negative) barrel connector, 5.5 mm OD x 2.1 mm ID



Grounding

The screw next to the power connector connects to chassis ground. In cases where the entire rig “floats” (does not connect to earth ground through an amp, audio interface or mixer), this screw may be used to connect a ground wire. Make sure this screw is securely fastened, and do not use ILLUMINE with this screw removed or loose.




Do not use a power supply greater than 12 V DC.



Use only a linear regulated power supply.

SIGNAL INPUT / OUTPUT




A mono input can be connected with a stereo output, or a stereo input can be connected with a mono output, in which case the two channels will be summed.

EXPRESSION INPUT / OUTPUT


A 3.5 mm (1/8") TRS Expression input may be used to connect an expression pedal or volume pedal with the appropriate cable. Only TRS connections (not TS) are supported.



A 3.5 mm-to-¼" adapter is required to connect a standard expression pedal.




To connect a volume pedal, use a 3.5 mm to dual ¼" TS (stereo breakout) cable, such as a Hosa CMP-153. Connect as follows:




The volume pedal must be passive (unpowered).

The EXP input may be driven with a 0 V - 3.3 V control voltage (CV). Use only a TRS connector, and leave the ring contact unconnected.



MIDI

MIDI connects using two 2.5 mm TRS jacks. Adapter cables are required for connecting 5-pin circular DIN plugs. These connectors are wired according to MIDI's recommendation (Type A) as follows:



The MIDI INPUT is isolated and may be used in a daisy-chain connection.

The MIDI OUTPUT may be configured as either a hardware THRU or an OUTPUT:

- When configured as THRU, the MIDI INPUT is echoed to THRU with no latency.
- When configured as OUTPUT, the MIDI INPUT is not echoed. In this case, ILLUMINE functions as a simple controller and sends program change and control change messages.

For detailed information, see the MIDI section of this User Guide.

USER INTERFACE

Key:

SCREEN NAME


Selection Name

KNOBBS


In general terms, the top knob navigates through the menu, and the bottom knob changes the currently displayed item.

Top Knob

Turning the top knob moves through the current menu. If a sub-menu is available, ▼ is displayed on the right of the top line. Pressing the knob enters this sub-menu.




If ▲ is displayed, pressing the top knob returns to the top-level menu. When the arrow is not displayed, pressing the top knob will jump to the **PRESET** screen.




Bottom Knob


Turning the bottom knob changes the displayed parameter or item. In the top-level menu, pressing the bottom knob enters the Save Preset menu.



When ▼ is displayed on the right of the bottom line, pressing the bottom knob will invoke the currently displayed selection.



Menu Map



FOOTSWITCHES

The left-side footswitch cycles up to the next preset in the Footswitch Recall list. Presets are added/removed from this list from the “**FOOTSWITCH**” screen in the top menu.

Recalling a preset from the left footswitch displays the preset name in double-high characters for easier viewing at a distance.



A long-press (>650 ms) of the left footswitch toggles between A and B parameter sets, if the A/B switch is selected as the Expression Input (see Expression Control Engine).




The function of the right-side footswitch depends on the **RIGHT FOOTSWITCH** configuration in the **GLOBAL SETUP** menu (see Right Footswitch):

- Engage-only mode — the right footswitch toggles Engage with no long-press function.
- Preset+Engage mode — the right footswitch cycles down to the previous preset in the Footswitch Recall list. A long-press of the right footswitch toggles Engage.

The LED illuminates to indicate when the pedal is engaged.

ENGAGE
ONLY
MODE



Actuation

Since each footswitch has an optional long-press secondary function, whether the primary function is actuated upon press or release depends on whether the secondary function is enabled.

- If the secondary function is disabled, the primary function occurs when the footswitch is depressed.
- If the secondary function is enabled, ILLUMINE waits to see if you release the footswitch within 650 ms (the long-press threshold). If so, the primary function is performed; otherwise the secondary function is performed at 650 ms.

	Left Footswitch	Right Footswitch
Primary Function (secondary function disabled)	Preset Up	Engage
Primary/Secondary Functions (secondary function enabled)	Preset Up / A/B Switch	Preset Down / Engage

If **PRESET SWITCHING** is set to **Delayed**, preset changes occur 1 second after the last press of the footswitch (see Preset Switching).

See Right Footswitch under Global Setup for more information.

PRESETS & EDITING

ILLUMINE contains 50 user presets and 50 factory presets. After a factory reset, the user presets will be a copy of the factory presets.

Any of the 50 user presets may be edited and saved into any user preset number. The 50 factory presets may be edited, but must be saved into a user preset. In other words, the factory presets are always available, should you choose to use one as a starting point for a user preset.


A preset consists of the selections in the top-level menu, including the following:

- Preset name
- Effect
- 5 parameters — Mix, 3 effect-dependent parameters, and Level
- If the preset will be recalled by the footswitch

If an Expression controller is active, two parameters — one for each end of the expression controller's range — are displayed and included in the preset. See Expression Control Engine for more information.


CHANGED PRESET FLAG

If a preset is changed and not saved, a “≠” (not equal) character will appear before the preset name as a reminder to save the preset, if desired. You may navigate away from this preset without losing these changes. Only upon powering the unit off will these changes be lost, unless you save the preset.



SAVE MENU

From most screens in the top menu, pressing the bottom knob enters the **SAVE PRESET** menu.



If the preset has changed, “Yes” will be the default option; otherwise, “No” is the default option.



The **SAVE PRESET** menu options are as follows:


- **Yes** — save the preset now
- **No** — do nothing and exit
- **Compare/Revert** — the previously-saved preset may be heard when this option is showing, select to revert to these settings
- **Save to (User Preset number)** — do nothing to the current preset and save this preset to the Preset number indicated

EDIT THE PRESET NAME


On the **PRESET** screen, pressing the top knob enters the **EDIT NAME** menu:

- Turning the top knob selects the character to be changed
- Turning the bottom knob changes the character
- Pressing the top knob returns to the **PRESET** screen
- Pressing the bottom knob enters the **SAVE PRESET** menu

Preset names are limited to 14 characters in length.



Character Set



FACTORY PRESETS

#	Name	Description
0	Illuminate Me	big dark reverb*
1	Wet Plugin	Wet Reverberator plugin example*
2	Immerse W3T	W3T in Immerse Mk II pedal
3	Wet Stereo v1	Wet Stereo Reverb pedal
4	Studio Room	very small damped room*
5	Small Darkroom	small, dark boomy room*
6	Basement	medium, dark reflective room*
7	Empty Club	medium lively room*
8	Medium Hall	medium hall
9	On the Stage	large lively room*
10	Parking Garage	huge lively space*
11	Lovely Hall	large damped hall*
12	Big Brite Hall	large lively hall*
13	Small Plate	small bright plate reverb*
14	Predelay Plate	medium plate with predelay*
15	Big Hair Plate	large plate reverb*
16	Gated Plate	short gated plate reverb*
17	Small Digiverb	very small digital reverb*
18	Cybernetic	medium digital reverb
19	Electric Cloud	large modulated digital reverb
20	Spring Is Here	medium spring reverb*
21	Twerpitude	large bright spring reverb
22	Dwell-O-Spring	high-dwell spring reverb*
23	Slap Happy	slapback echo with a hint of reverb*
24	EchoVerb120bpm	120 bpm echo with a hint of reverb*
25	Into the AByss	A:large reverb B:echoverb
26	500ms Ekoplux	500 ms dark modulated echo*


#	Name	Description
27	Big Echo Verb	big echo with a hint of reverb*
28	Derecho	huge, dark swirly echoverb
29	Long Tapeloop	high-regen long echo*
30	Chorus Air	small-room chorus*
31	ShABby Chic	A:large reverb B:+detune
32	Vibro Room	small-room vibrato*
33	Hi Short Shmr	short, resonant shimmer*
34	ABsynth Pad	A:large reverb B:shimmer
35	Iridescence	ambient reverb with a hint of shimmer
36	I'm Shimmering	large shimmer reverb*
37	WannABe Chime	A:large reverb B:+octaves
38	Slo Ghost Wind	octave-up reverb*
39	Octal Void	octave-up/down reverb*
40	Avalanche Fall	deep rumble reverb*
41	King Gong	gong-like reverb
42	LAByrinthine	A:large reverb B:+low overtones
43	FreezABLE	A:large reverb ► B:freeze+reverb
44	SustainABLE	A:almost infinite B:sustain
45	SwellABLE	A:medium reverb B:large swell reverb
46	OK Bloomer	medium bloom reverb*
47	Bloom In Time	large bloom reverb*
48	Ambient Plug	ethereal ambient reverb*
49	Torn Texture	big drone reverb*

*Factory Presets with an asterisk were created by Drew Schlesinger, a professional synthesist, sound designer and composer. Drew's legacy of unique sound development started in the 1980's. He has worked with many leading effect and synthesizer manufacturers and created some extremely well known sounds. We are most grateful for Drew's contribution to ILLUMINE's presets. <https://www.instagram.com/drewschlesinger/>

EFFECT

Turning the bottom knob changes the algorithm used to create the reverberation effect.

Pressing the top knob enters the Options sub-menu, which allows for further tweaking of the algorithm.



Changing between presets that use the same Effect and Options will result in a seamless transition. However, when the Effect or Options are different between presets, changing between them will briefly mute the sound in the wet signal path only.

The Reverb Effects

Wet Plugin

This algorithm matches the Neunaber Wet Reverberator software plugin as closely as possible given hardware constraints. The only significant difference from the plugin is that this version has fewer adjustable parameters.

The Wet Plugin reverb was designed to work well with a variety of instruments, but it really shines with voiced (non-percussive) instruments. Like all of the Wet Reverb algorithms, it is known for its open, natural sound, which complements the source signal without masking it.

Wet v3

The Wet v3 reverb was designed to work well with voiced instruments, in particular guitar and other stringed instruments. Like all of the Wet Reverb algorithms, it is known for its open, natural sound, which complements the source signal without masking it.

This is the same as the W3T reverb in the Immerse Mk II. It is the same core algorithm as the Wet Plugin, with different tone shaping and lower initial reflection density.

Wet v1

This is the original reverb from the Wet Stereo Reverb pedal. The Wet v1 reverb was designed to work well with stringed instruments and guitar, in particular. Like all of the Wet Reverb algorithms, it is known for its open, natural sound, which complements the source signal without masking it.

Plate

A studio plate reverb is a large, suspended metal plate connected with transducers at the input and output. It is known for its highly diffuse, metallic sound. This reverb has high input diffusion, giving it the dense, metallic quality of a studio plate. Plate reverbs work well on a variety of audio sources, especially percussive sounds.

Hall

Emulating the sound of a well-designed concert hall, this reverb is large and expansive. This is version 2 of our hall reverb algorithm. Hall reverbs sound great on a variety of audio sources, especially voiced instruments.

Vintage Digital

Designed in the style of a vintage rack unit, this reverb sounds diffuse and synthetic, but not metallic like a plate. It sounds super spacey on synths.

Spring

A spring reverb consists of springs suspended between transducers, and its sound has a distinctive “twerp.” Try increasing the modulation rate for a classic vibrato-spring reverb sound. This is version 3 of our spring reverb algorithm.

Shimmer

Shimmer is a reverb effect reminiscent of a synth pad that follows what your instrument plays. This is version 2 of our shimmer reverb algorithm.

Rumble

Rumble creates a low-frequency drone for a deep, cavernous reverb sound. It sounds neat on synths.

Octaves

This effect combines the Wet v3 Reverb with a dual octave generator, one up and one down. Each octave is mixed with the original signal prior to the reverb in any proportion you desire.

Wet+Echo

This effect adds the Wet v3 Reverb and stereo echo. The Depth parameter controls both reverb and echo decay.

Wet+Detune

This effect adds the Wet v3 Reverb and a detune effect. Detune is an effect that pitch-transposes a signal slightly downward, which creates a thick, chorus-like effect without the warble of a traditional chorus.

Bloom

This reverb is based on our Vintage Digital algorithm. It builds more slowly than a typical reverb. Increasing the Pre-Delay will delay the “bloom” even further.

Swell

This effect is typically used with the Mix set to 100%. If the Mix Sum Type is configured as Unity Dry, the Swell reverb effect may not operate as expected.

Swell reverb places a slow-attack, fast-release gate before a Wet v3 Reverb. This emulates placing a volume pedal before a reverb to swell in reverb pads. Playing a note or chord triggers the swell. Muting resets the swell, so it is ready for the next note or chord.

TIP:

Increase the Sensitivity (see Options) if the swell does not trigger; decrease it if the swell does not reset between notes. Remember that you need to sufficiently mute the note to reset.

Infinite Hold

Infinite Hold combines the Wet v3 Reverb with a hold (“freeze”) function. The hold function captures and repeats a 100 ms loop, just enough for a single note or chord.

The hold is triggered by the Latch/Blend parameter, so you will need to use an expression controller — either the A/B Footswitch or an expression pedal.

With **LATCH/BLEND** at 0%, the hold is reset. Increasing from 0% latches the

signal, looping it indefinitely. This parameter also sets the amount of the hold signal and reverb as follows:

- 0% Latch/Blend — 0% hold, 100% reverb
- 50% Latch/Blend — 50% hold, 50% reverb
- 100% Latch/Blend — 100% hold, 0% reverb

Set up your expression controller with one end of Latch/Blend at 0% and the other at the Blend value of your choice.

To use the Infinite Hold effect, start with your expression controller at 0%. Play the note or chord that you want to hold, then increase the expression controller to latch. When the hold is active, you may adjust the expression controller to fine-tune the blend between hold and reverb. To stop the hold and reset, return the expression controller to 0%.

Sustain

Built on the Wet v3 Reverb, Sustain is a magical effect that can be configured as a sustain effect or virtually infinite reverb. What you play is recycled in an infinite loop during a hold phase, then decays out during a release phase.

TIP:

Increase the Sensitivity (in Options) if the sustain effect does not trigger; decrease it if the sustain does not release when you want it to.

Gated Plate

This is our Plate reverb with infinite depth and gated by the input level. This effect works best on percussive sounds and may be used to artificially lengthen the sustain of the sound's envelope.

The Time parameter determines how long the gate stays open after the input level has dropped below the threshold, which is based on the Sensitivity setting (see Options). The Release parameter determines how abruptly the gate closes.

Options

Options alter the algorithm itself, and as a result, the audio will mute briefly between changes. Not all Options are available for each Effect.

Option	Description
Pre-Delay	Length of time between the dry signal and onset of reverb. A little pre-delay adds separation, but too much causes an audible delay.
Modulation Width	amount of variation in the reverb’s acoustic path lengths
Modulation Rate	speed of variation in the reverb’s acoustic path lengths
High-Pass Filter	The frequency of the reverb’s high-pass (low cut) filter. Raise to reduce boominess or increase tightness. Lower to increase fullness.
Low-Pass Filter	The frequency of the reverb’s low-pass (high cut) filter. Lower to reduce harshness, increase mellowness, or for a darker tone. Raise for more sparkle, to increase openness or airiness.
High-Frequency Damping	The frequency of the low-pass (high cut) filter in the reverb’s regeneration paths. This filter emulates the high-frequency absorption of sound in air, and 10 kHz is similar to what is heard in nature under typical conditions.
Sensitivity	How sensitive the effect is to the level of the signal. Increase if the effect does not trigger; decrease if the effect does not release/reset.

Effect	Pre-Delay	Mod-ulation Width	Mod-ulation Rate	High-Pass Filter	Low-Pass Filter	Hi-Freq Damp-ing	Sens-itivity
Wet Plugin	✓		✓	✓	✓	✓	
Wet v3	✓		✓			✓	
Wet v1			✓			✓	
Plate	✓		✓	✓	✓	✓	
Hall	✓		✓	✓	✓	✓	
Vintage Digital	✓		✓	✓	✓	✓	
Spring		✓	✓	✓	✓	✓	
Shimmer		✓	✓	✓	✓		
Rumble		✓	✓	✓	✓	✓	
Octaves		✓	✓	✓	✓	✓	
Wet+Echo		✓	✓	✓	✓	✓	
Wet+Detune		✓	✓	✓	✓	✓	
Bloom	✓		✓	✓	✓	✓	
Swell		✓	✓	✓	✓	✓	✓
Infinite Hold		✓	✓	✓	✓	✓	
Sustain		✓	✓	✓	✓		
Gated Plate	✓	✓	✓	✓	✓	✓	✓

PARAMETERS

Each preset has 5 parameters: Mix, Level, and 3 effect-dependent parameters. Turning the bottom knob while the parameter is displayed changes the parameter.


Parameter	Description
Mix	ratio of reverb and dry (input) signals
Level	overall level of the output signal
Depth	length of the reverb tail, decay time
Tone	frequency shape of the reverb signal
Tone Tilt	tilt of the reverb's frequency spectrum
Modulation Width	amount of variation in the reverb's acoustic path lengths
Modulation Rate	speed of variation in the reverb's acoustic path lengths
Shimmer Level	amount of shimmer added to the reverb
Frequency (Shimmer)	center frequency of the spectrum accentuated by the shimmer effect
Frequency (Rumble)	frequency range of emphasis for the low octaves
+1/-1 Octave Mix (Octaves)	amount of octave added to the reverb in proportion to the input signal
Blend	amount of the secondary effect in proportion to the reverb
Echo Time	length of delay time, from 50 to 674 ms
Echo Subdivision	When synchronizing to a MIDI beat clock, this parameter sets the echo subdivisions*
Detune	amount of pitch transposition, from 0 to 20 cents (0.2 semitone)
Attack (Swell)	amount of time for the reverb to ramp up
Latch/Blend (Infinite Hold)	Latches the hold effect and sets the blend of hold and reverb. See the Infinite Hold effect description for more information.

Parameter	Description
Hold Time (Sustain)	length of time for the effect to hold
Time (Gated Plate)	length of time for the gate to remain open
Release	length of time for the reverb to decay after the hold or gate time has expired
Sensitivity	How sensitive the effect is to the level of the signal. Increase if the effect does not trigger; decrease if the effect does not release/reset.

Mix

The **MIX** control changes the balance between the dry and wet (effect) signals.

The change in effect level is approximately linear in dB above 20%. Below 20%, the effect level accelerates downward, so that it is muted at 0%. How the Mix control affects the dry signal depends on the **MIX SUM TYPE** selection in the **GLOBAL SETUP** menu.



Effect-Dependent Parameters

Effect	Parameter 1	Parameter 2	Parameter 3
Wet Plugin	Depth	Tone Tilt	Mod Width
Wet v3	Depth	Tone	Mod Width
Wet v1	Depth	Tone	Mod Width
Plate	Depth	Tone	Mod Width
Hall	Depth	Tone	Mod Width
Vintage Digital	Depth	Tone	Mod Width
Spring	Depth	Tone	Mod Rate
Shimmer	Depth	Shim Level	Frequency
Rumble	Depth	Rumble Mix	Frequency
Octaves	Depth	-1 Oct Mix	+1 Oct Mix
Wet+Echo	Depth	Echo Time or Subdivision*	Blend
Wet+Detune	Depth	Detune	Blend
Bloom	Depth	Tone	Mod Width
Swell	Depth	Tone	Attack
Infinite Hold	Depth	Tone	Latch/Blend
Sustain	Release	Hold Time	Sensitivity
Gated Plate	Time	Tone	Release

*Echo Subdivision available only when synchronizing to MIDI beat clock

***Echo Subdivisions**

When a MIDI beat clock is present, the echo time may be synchronized to the MIDI beat clock, or quarter note tempo. In this case, the Echo Time parameter changes to Echo Subdivision and specifies one of several divisions of the echo time that synchronize with the tempo:

Echo Subdivision	# Repeats	Per # Beats	Description	Common Value
1:1 - qtr note	1	1	quarter note	✓
6:5	6	5	6:5 polyrhythm	
5:4 - 5tpl qtr	5	4	quintuplet quarter note	
4:3 - dot 8th	4	3	dotted eighth note	✓
3:2 - 3tpl qtr	3	2	triplet quarter note	
5:3	5	3	5:3 polyrhythm	
7:4 - 7tpl qtr	7	4	septuplet quarter note	
2:1 - 8th note	2	1	eighth note	✓
7:3	7	3	7:3 polyrhythm	
5:2 - 5tpl 8th	5	2	quintuplet eighth note	
8:3 - dot 16th	8	3	dotted sixteenth note	
3:1 - 3tpl 8th	3	1	triplet eighth note	✓
7:2 - 7tpl 8th	7	2	septuplet eighth note	
4:1 - 16th note	4	1	sixteenth note	

Level

The **LEVEL** control allows the output level to be adjusted in 0.2 dB increments, from -10 dB to as much as +10 dB, depending on the **GAIN STRUCTURE** global setting.

FOOTSWITCH RECALLS/SKIPS PRESET

This selection determines if a preset will be recalled when pressing the footswitch. Presets are recalled in order of preset number and will loop back around to the first after the last preset has been recalled.

Let's say you select **FOOTSWITCH Recalls Preset** only on presets 1, 3 and 5. Pressing the **▲PRESET** footswitch results in the presets being recalled as follows:

Preset 1 ► Preset 3 ► Preset 5 ► Preset 1 ► Preset 3 ► Preset 5 ► ...

If you want presets to be recalled in a different order, then move the presets so that they are in numerical order using the **Save to (Preset #)** option in the **SAVE PRESET** menu.

SETUP MENUS

From the top-level menu, press the top button to enter the setup menu. Pressing the top button at any screen in the setup menu will return to the top-level menu.

In the **A/B | EXP SETUP** menu, pressing the bottom button at any screen will display the **SAVE PRESET** menu.

In the **GLOBAL SETUP** menu, pressing the bottom button has no effect EXCEPT when ▼ is displayed. In this case, pressing the bottom button performs the displayed action.

EXPRESSION CONTROL ENGINE

ILLUMINE’s Expression Control Engine allows for up to five parameters to be controlled simultaneously by one controller. In addition, the trajectory along the controlled range, or “skew,” may be specified for each parameter. The number of parameters, ranges and skew of these controlled parameters is configurable by preset.

The Expression Control Engine accepts one of four inputs as a controller. This selection is global and applies to all presets:


- 1. **A/B Footswitch**
- 2. **Expression Pedal**
- 3. **Volume Pedal**
- 4. **MIDI CC #** (control change message)

EXPRESSION CONTROLLER INPUTS

The expression controller input is selected from the **EXP SOURCE** screen in the **GLOBAL SETUP** Menu.

A/B Footswitch

The **A/B Footswitch** selection allows for expression control without additional hardware. The A/B Footswitch is not a continuous controller; rather, it transitions between an “A” and “B” set of parameters over a selectable time period. This feature effectively doubles the number of presets.



The A/B Footswitch or other expression controller is required for the Infinite Hold effect, because it is used to switch the **LATCH/MIX** parameter, triggering the hold.

Long-press (hold for 650 ms) the A/B Footswitch to toggle between A and B parameter sets. A screen appears to show the current status of the transition.

LONG
PRESS
FOR A/B




ABsynth Pad
A-----B

If the A/B Footswitch is long-pressed during a transition, the parameters will turn around and traverse a reverse path to the original state. If the A/B Footswitch is short-pressed during a transition, the parameters will jump to the destination state, effectively cancelling the transition period.

TRANSITION
FROM A TO B
IN PROGRESS




LONG PRESS
TO REVERSE



ABsynth Pad
A-----B

TRANSITION
FROM A TO B
IN PROGRESS

SHORT PRESS
TO JUMP TO
DESTINATION



Expression Pedal

An expression pedal with a TRS connector may be used as the expression controller. Connect the expression pedal via a TRS cable to the 3.5 mm EXP input. A 6.35 mm to 3.5 mm ($\frac{1}{4}$ " to $\frac{1}{8}$ ") adapter may be required.

Volume Pedal

A passive (unpowered) volume pedal may be used as the expression controller. The resistance of the volume pedal is not critical. Use a 3.5 mm TRS to dual $\frac{1}{4}$ " TS cable — also called an “insert” or “stereo breakout” cable — such as a Hosa CMP-153.

ILLUMINE will linearize the volume pedal's sweep (see Setup).

MIDI Control Change

MIDI control change message 11 (CC 11) may be used as the expression controller. This is particularly useful in the following cases:

- Controlling multiple parameters with a single MIDI CC message.
- Controlling multiple units from one expression controller. Configure the “control” unit as a MIDI Controller, **EXP→MIDI CC OUT = Enabled**, Channel 11. Connect the control unit’s MIDI OUT to slave’s MIDI IN. On the slave units, Select **EXP SOURCE = MIDI CC 11**.

EXPRESSION CONTROLLER SETUP

First, select your controller type from the **EXP SOURCE** screen in the **GLOBAL SETUP** menu.

Nomenclature

Naming may change based on the type of Exp Source.

Exp Source	Setup Menu	Low Parameter Suffix	High Parameter Suffix
None	N/A	N/A	N/A
A/B Footswitch	A/B Setup	.A	.B
Expression Pedal	Exp Setup	.heel	.toe
Volume Pedal	Exp Setup	.heel	.toe
MIDI CC 11	Exp Setup	.min	.max

A/B | EXP SETUP


In the top-level menu, navigate to the **A/B SETUP** or **EXP SETUP** menu (depending on which **EXP SOURCE** you selected).

Note that the settings in the **A/B | EXP SETUP** menu may be different for each preset, whereas the **EXP SOURCE** selection applies to all presets.

ADDING PARAMETERS TO EXPRESSION CONTROL

In the **A/B | EXP SETUP** menu, you may select which of the 5 preset parameters are controlled by the expression controller. In addition, you may select the “skew” of the control:

- **Off** — expression controller does not change the parameter
- **25% Midpoint** — expression controller controls parameter, the midpoint of the controller range maps to 25% of the range between minimum and maximum
- **50% Midpoint** — expression controller controls parameter, the midpoint of the controller range maps to 50% of the range between minimum and maximum
- **75% Midpoint** — expression controller controls parameter, the midpoint of the controller range maps to 75% of the range between minimum and maximum



When you select an option other than **Off**, the parameter will display two screens in the top-level menu, one for each end of the expression controller range.

A/B SWITCH

Mix.A
0 %

Mix.B
50 %

EXPRESSION /
VOLUME PEDAL

Mix.heel
0 %

Mix.toe
50 %

MIDI CC

Mix.min
0 %

Mix.max
50 %

SELECTING THE MIDPOINT

If you are using an expression or volume pedal controller...

1. Start with **50% Midpoint**.
2. Go to the top-level menu and set your two parameter values to define the range.
3. Return to the **EXP SETUP** menu, and listen to the 3 different skew options while you sweep the controller.
4. Select the option that most closely matches how you want this parameter to sound while sweeping the controller.
5. Repeat for each controlled parameter.

If you are using the A/B Footswitch...

1. Set the **A►B TIME** and **A◄B TIME** to a convenient value such as **4.0 s**.
2. Start with **50% Midpoint**.
3. Go to the top-level menu and set your two parameter values to define the range.
4. Activate the A/B Footswitch and listen to the transition.
5. If the A/B transition sounds like too much of the change occurs in the first second, change the skew to **25% Midpoint**.
6. If the A/B transition sounds like too much of the change occurs in the last second, change the skew to **75% Midpoint**.
7. Repeat for each controlled parameter.
8. When finished, set the **A►B TIME** and **A◄B TIME** to the desired values.

A►B AND A◄B TIME

These screens allow you to select the transition times between A and B parameters in each direction. Values are limited to approximate factors-of-2 between 0.5 s and 60 s. These screens are only available when using the A/B switch as the expression controller.

MIDI

MIDI is accessible via two 2.5 mm TRS connectors. Adapter cables may be required.

Select the MIDI channel under **GLOBAL SETUP ► MIDI CHANNEL**. The MIDI channel applies to both receive and transmit if MIDI Controller mode is selected.

MIDI IN

Program Change (PC)

PC messages recall presets according to the following table:

PC	Action
0-49	Recall User Preset 0-49
50-99	Recall Factory Preset 0-49
100-123	ignored
124	Decrement footswitch preset list (same as Preset Down footswitch)
125	Increment footswitch preset list (same as Preset Up footswitch)
126	Decrement preset number by 1
127	Increment preset number by 1

Control Change (CC)

Two-byte CC values are accepted (MSB and LSB). The LSB is not required. Parameters 1, 2 and 3 are defined under “Effect-Dependent Parameters.”

Parameter	CC Number	Detail
Level or Level.B / toe / max	7	MSB
	39	LSB
Expression Input	11	MSB
	43	LSB

Parameter	CC Number	Detail
Mix or Mix.B / toe / max	16	MSB
	48	LSB
Parameter 1 or Parameter 1.B / toe / max	17	MSB
	49	LSB
Parameter 2 or Parameter 2.B / toe / max	18	MSB
	50	LSB
Parameter 3 or Parameter 3.B / toe / max	19	MSB
	51	LSB
Level.A / heel / min	20	MSB
	52	LSB
Mix.A / heel / min	21	MSB
	53	LSB
Parameter 1.A / heel / min	22	MSB
	54	LSB
Parameter 2.A / heel / min	23	MSB
	55	LSB
Parameter 3.A / heel / min	24	MSB
	56	LSB
Engage	80	0-63 = bypass, 64-127 = engage
Sync Echo Time to Beat Clock	81	0-63 = do not sync, 64-127 = sync

Level Controllers

The level controller range is limited.

- Minimum = 27
- Maximum depends on the Gain Structure selection:
 - Low Noise = 127
 - Balanced = 122
 - High Headroom = 92

The Level in dB, x , may be set by sending controller value = $(5x)+77$.

MIDI OUT/THRU

The MIDI OUT/THRU connector may function as one of two modes, depending on the selection under **GLOBAL SETUP ► MIDI OUT**.

- **THRU** mode — MIDI IN is echoed to MIDI OUT/THRU.
- **Controller** mode — ILLUMINE functions as a simple MIDI controller.

MIDI THRU Mode

Messages received on MIDI IN are echoed on MIDI OUT/THRU. There is no latency between IN and OUT/THRU. Use this mode to daisy-chain multiple devices with an external MIDI controller.

MIDI Controller Mode

ILLUMINE functions as a simple MIDI controller, sending Program Change (PC) and Control Change (CC) messages on MIDI OUT/THRU.

A MIDI PC message is sent only when the preset is changed via the footswitch. The PC number will correspond to the preset number recalled.

MIDI CC messages corresponding to the value of the expression controller may also be sent. This function is enabled and the CC number set as follows:

- **GLOBAL SETUP ► EXP►MIDI CC OUT = Enabled**
- **GLOBAL SETUP ► EXP►MIDI CC # = CC number to transmit**

If CC number 0-31 is selected, the value is sent as 2 bytes: MSB on the selected CC number and LSB on CC number + 32. For any other CC number, the value will be sent as 1 byte only.

Although Controller mode would not typically be used with an external controller, MIDI IN messages will be processed but not echoed to MIDI OUT/THRU.

MIDI BEAT CLOCK

ILLUMINE can synchronize the echo time for the Wet+Echo effect to a MIDI beat clock. The usable range of beat clock synchronization is approximately 23-230 BPM (beats per minute).

The current beat clock frequency is displayed in **GLOBAL SETUP ► MIDI BEAT CLK RX**. This screen displays the status of the MIDI beat clock received at the MIDI Input:

- BPM (beats per minute) — if a beat clock is received
- “none” — if no beat clock is received
- “too slow” — if the BPM is below the usable limit

Beat clock synchronization is enabled on power up. To ignore the beat clock and use the preset echo time instead, use CC 81 (see table above).

Because the echo time in the Wet+Echo effect is limited, BPMs lower than 88 may require the echo time to be divided to remain synchronized. If the subdivided echo time is greater than the maximum echo time, it will be divided by 2 or by 4 and the Echo Subdivision parameter will be displayed with the suffix “double time” or “quad time,” respectively.

GLOBAL SETUP

Global Parameters are automatically saved after exiting the Global Setup menu.

EXP SOURCE

See Expression Control Engine section.

CAL PEDAL / EXP SCREENS

These screens allow you to calibrate the minimum and maximum values of an expression controller when an expression pedal, volume pedal or MIDI controller is selected as the expression source.

Exp Source	Minimum Calibration Screen	Maximum Calibration Screen	Middle Calibration Screen
A/B Footswitch	(not available)	(not available)	(not available)
Expression Pedal	Cal Pedal Heel	Cal Pedal Toe	(not available)
Volume Pedal	Cal Pedal Heel	Cal Pedal Toe	Cal Pedal Middle
MIDI CC 11	Cal Exp Min	Cal Exp Max	(not available)

When these screens are first displayed, they will show the calibration value. Once the expression source is changed, they will show the actual expression value.


In addition, the calibration value may be adjusted using the bottom knob. This is useful in the following situations:

- To add a “dead zone” to ensure that the full extent of the controlled parameter is reached
- To set the range of a MIDI or LFO (low-frequency oscillator) controller

Press the bottom knob to set the calibration value.


Cal Pedal Heel / Exp Min

This screen allows you to calibrate the minimum or “heel down” setting on the expression pedal to 0%. To perform the calibration, set the expression pedal to the heel down position and press the bottom knob.



Cal Pedal Toe / Exp Max

This screen allows you to calibrate the maximum or “toe down” setting on the expression pedal to 100%. To perform the calibration, set the expression pedal to the toe down position and press the bottom knob.



Cal Pedal Middle

Volume pedals typically have an audio-taper sweep, which changes slowly in the lower portion of the sweep, then quickly in the upper portion. ILLUMINE will compensate for this sweep, making it appear like a linear expression pedal. This screen allows you to calibrate the middle point of the sweep for a more accurate conversion.

If your volume pedal has a selection switch for the taper: set the treadle to the middle position and select the switch position that results in the higher expression value on the screen.

By default, ILLUMINE is calibrated for an Ernie Ball VP-JR with the taper switch in the up position.

There are two methods to calibrate your pedal:

- Easy but less accurate — set the volume pedal’s treadle to the halfway point between heel down and toe down. Press the bottom knob.
- Difficult but more accurate — slowly sweep the volume pedal while watching the change in expression value. You will notice a breakpoint at which the value changes accelerate. This value is typically around 15-25%. Set the treadle to this breakpoint and press the bottom knob.

MIDI SETUP

See the MIDI section for details.

BYPASS TYPE & TRAILS

There are 3 bypass options:

- True bypass — entire circuit is bypassed using relays
- Buffered bypass without trails — signal is buffered when bypassed, and the reverb tail cuts off when bypassed
- Buffered bypass with trails — signal is buffered when bypassed, and the reverb trail persists when bypassed

True Bypass and Trails are mutually exclusive. You must select **BYPASS TYPE = Buffered** to enable the **BYPASS TRAILS** screen, or you must select **BYPASS TRAILS = No** to enable the **BYPASS TYPE** screen.

	Bypass Type Screen	Bypass Trails Screen
True Bypass	True	not available
Buffered Bypass, no Trails	Buffered	No
Buffered Bypass w/ Trails	not available	Yes

In addition, true bypass and parallel loop mode are mutually exclusive. You must select **BYPASS TYPE = Buffered** to enable the **EFFECT LOOP TYPE** screen, and you must select **EFFECT LOOP TYPE = Serial** to enable the **BYPASS TYPE** screen.

Attributes of Bypass Types

	Advantages	Disadvantages
True Bypass	• Lowest noise	• Downstream effects may load upstream devices when bypassed, causing a change in tone • Non-silent switching • Reverb cuts off abruptly
Buffered Bypass, no Trails	• Low noise • Silent switching • No loading issues	• Reverb cuts off abruptly
Buffered Bypass w/ Trails	• Reverb trails naturally when bypassing • Silent switching • No loading issues	• Noisier than other types • Reverb persistence may be unwanted in some cases

EFFECT ROUTING

This selects the routing of the dry and effect signals.

- **Stereo Mix** — Stereo effect is mixed with the input(s). For a mono output, a mono effect is mixed with the input(s).
- **Separate Wet/Dry** — Dry signal is sent to the left output and Wet signal to the right output. The effect signal is generated from an input sum according to the **FX SIDECHAIN IN** global setting. This setting has two options as described by **WET/DRY MODE** below.

EFFECT LOOP TYPE

This menu selects the type of effects loop in which ILLUMINE is installed. It is displayed only when **EFFECT ROUTING = Stereo Mix**.

- **Serial** — a serial effects loop or serial signal chain. This is the most common configuration.
- **Parallel** — a parallel effects loop or sidechain: a signal path that is split from the main signal path, processed with effects, then summed back into the main signal path. This setting is equivalent to “Kill Dry” on other Neunaber products. If chaining more than one effect processor in a parallel loop, select **Serial** instead.

IMPORTANT!

The **Parallel** option is available only when **BYPASS TYPE** is **Buffered**, because true bypass defeats ILLUMINE’s ability to mute the dry signal when bypassed. When **BYPASS TYPE** is **True**, the **EFFECT LOOP TYPE** menu is not displayed and defaults to **Serial**.

Which Type of Effect Loop Do I Have?

Pedalboards: effects in a single mono or stereo chain after the instrument is a serial configuration.

Amps/preamps: an effects loop that is not explicitly labeled is typically a serial loop. Parallel effects loops are explicitly labeled as such.

Mixers: an auxiliary bus or effects send/return is a parallel configuration. A channel insert is a serial configuration.

How to Set Up Multiple Effects in a Parallel Loop

The Parallel setting does not pass the dry signal to other effects in the local chain, which will reduce the number of effect layers. Instead, use the Serial setting and follow this procedure to minimize the dry signal through the effects loop:

- Set your loop’s return level fairly high (you want to really hear the effects) and all your effects to the even wet/dry mix point. This may or may not be 50% on the Mix knob — check the effect’s User Guide if you’re not sure where this is.


- For the effect that you want to be the most prominent, leave it's Mix knob at the even wet/dry mix point.
- For effects that you want lower in the mix, lower their Mix knobs. Here you want to listen for relative effect level. This is the level of each effect relative to one another, not to the dry signal.
- Once your relative effect levels are fairly close, reduce the loop return level to balance the overall effect level with the dry signal.
- At this point, you can tweak your effects' Mix levels, but remember to leave the most prominent effect at the even wet/dry mix point.

Note: this procedure will not work if any effect in the parallel chain digitizes the dry signal (the dry signal for each effect must be analog).


WET/DRY MODE

This menu selects the signal flow configuration for Wet/Dry Effect Routing. It is displayed only when **EFFECT ROUTING = Separate Wet/Dry**.

- **Multiple Effects** — ILLUMINE is part of a signal chain with multiple effects in the wet signal path. Connect the dry input to ILLUMINE's left input and wet input to ILLUMINE's right input. The left/dry channel will not have the effect added, while a mono effect is added to the right/wet channel.



- **ILLUMINE Only** — ILLUMINE is the only effect in the wet signal chain and will create a wet/dry output from a dry input. The mono/dry input is sent to the left output, and the wet signal is sent to the right output.



IMPORTANT!

The **ILLUMINE Only** option is available only when **BYPASS TYPE** is **Buffered**, because true bypass will pass the dry signal through the wet channel. When **BYPASS TYPE** is **True**, the **WET/DRY MODE** menu is not displayed and defaults to **Multiple Effects**.

RIGHT FOOTSWITCH

There are 2 options for the function of the right-side footswitch:

- **Is Engage** — footswitch is engage only
- **Preset+Engage** — footswitch is preset down on short-press, engage on long-press

TIP:

You may want to use **Is Engage** if you are using only a few presets or a MIDI controller.

If, however, you recall many presets from ILLUMINE's footswitches and/or rarely, if ever, bypass the pedal, **Preset+Engage** may work better for you.

PRESET SWITCHING

This option determines when a preset change occurs after turning the knob or pressing a footswitch. Preset changes via MIDI always occur immediately.

- **Immediate** — the change occurs immediately
- **Knob/Long Press** — a change occurs only after pressing a knob or long-pressing a footswitch (see below)
- **Delayed** — a change occurs 1 second after you stop turning the knob or pressing the footswitch, allowing you to scroll without changing to every intermediate preset

Knob/Long Press Option

When changing the preset, the display will blink to indicate that the change is pending. If the original preset is re-selected, blinking will stop and the pending change is cancelled.

Pressing either knob or long-pressing the Preset footswitch will load the selected preset. You may long-press the right-side footswitch only if it is configured as Preset+Engage.



Since this option adds a secondary long-press function to the Preset footswitch, changes will occur upon switch release (see Actuation, p. 10).

MIX SUM TYPE

This option determines how the reverb and dry signals are summed as the Mix control changes.

- **Unity RMS** — Dry and effect levels are summed so that the RMS (root-mean-square) equals 1. This works well for signals with a fairly constant level, such as synthesizers and distorted guitar.
- **Unity RMQ** — Dry and effect levels are summed so that the RMQ (root-mean-quad) equals 1. This works well for highly dynamic signals, such as uncompressed, clean electric guitar or acoustic guitar.
- **Unity Dry** — The level of the dry signal does not change.

Comparison of Mix Sum Types

Mix Sum Type	Equal Level Point	Attenuation @ Equal Level	Dry Level @ 100% Mix
Unity RMS	75%	3 dB	none
Unity RMQ	75%	1.5 dB	none
Unity Dry	100%	0 dB	unity

The Swell reverb effect is typically configured with 100% Mix (no dry signal). If the **MIX SUM TYPE** is configured as **Unity Dry**, the Swell reverb effect may not operate as expected.

GAIN STRUCTURE

This selection allows you to optimize ILLUMINE’s gain structure for your system. Proper gain structure allows the signal level to be as high as possible to minimize noise but also avoid distortion.

- **Low Noise** — Designed for low instrument-level signals, such as a guitar with its volume control turned down with no level boost before ILLUMINE.
- **Balanced** — Designed for typical instrument-level signals, such as a guitar with passive pickups, guitar volume at full and no electronic boost before ILLUMINE.
- **High Headroom** — Designed for high instrument-level or line level signals. If you hear distortion when using other settings, or if the reverberated signal sounds compressed or attenuated, choose this setting.

As with all audio electronic devices, there is a tradeoff between noise and headroom. Increasing headroom also increases noise, and reducing noise also reduces headroom.

The Gain Structure selection also limits the maximum Level control.

Gain Structure	Maximum Level
Low Noise	+10 dB
Balanced	+9 dB
High Headroom	+3 dB

FX SIDECHAIN IN

The input to the effect processor sidechain blends the two input signals. Most users should leave this setting at its default value of **Balanced Mix**, which works well in the vast majority of cases.

This setting should only be changed if the input is stereo and not mono-compatible — in other words, summing the stereo input signal causes full or partial cancellation of the signal. In rare cases, we encounter an effect pedal or processor that produces a mono-incompatible stereo signal. If you are unlucky enough to encounter such an abomination, we encourage you to immediately pull it from your signal chain and chuck it into a wood chipper. Seriously though, if you must leave this device in your signal chain, we allow for a few ways to mitigate this issue:

- **Unbalanced Mix** — a compromise that reduces the issues caused by mono-incompatible signals while still allowing partial mixing of the inputs
- **Left Only** — derive the effect from only the left input signal
- **Right Only** — derive the effect from only the right input signal

These settings do not repair the original signal's problem, they only reduce or eliminate its effect on ILLUMINE.

DESIGNER'S NOTE:

Good practice and common sense dictates that effect designers and sound engineers create audio that is mono-compatible, which means that the stereo signal may be summed to mono without any unwanted issues. Sometimes a stereo signal may be reproduced as mono due to system or venue limitations. Even with stereo playback through co-located speakers, there will be some acoustic summing. Just think about how many little Bluetooth speakers are either mono or co-located stereo. Therefore, it is of paramount importance for audio professionals to ensure that stereo signals are mono-compatible.

NOISE REDUCTION

Most of the effects in ILLUMINE have built-in noise reduction, which is highly transparent in most cases. We strongly encourage you to set this to “On.”

If the level of your input signal is very low, you may notice the effect of the noise reduction as a periodic absence or cut off of the effect signal. In this case, you should first change the **GAIN STRUCTURE** setting to **Low Noise**. If this does not alleviate the issue, then you may turn the **NOISE REDUCTION** = **Off**. Note, however, that this may increase the noise level of the system.

USER INTERFACE OPTIONS

OLED Brightness

This setting determines the brightness of the OLED display.

LED Brightness

This setting determines the brightness of the Engage LED.

Text Display

This setting selects whether the text is displayed as left-justified or centered.



Show % Values As

This setting selects whether percent values are displayed as numerical text or a horizontal bar.



Power Supply Voltage

There is no adjustment on this screen; it simply displays the power supply voltage for informational or diagnostic purposes. The voltage should be between 9.0 V and 12.0 V for proper operation.

If at any time the power supply voltage exceeds 13.0 V, a warning screen will be displayed. You will not be able to dismiss this warning until the issue is resolved.

Reset Parameters

Two screens allow you to reset the global and/or preset parameters to factory defaults:

- **RESET ALL GLOBAL PARAMETERS** — reset all global (non-preset) parameters to factory defaults
- **RESET ALL PRESET PARAMETERS** — reset all presets to factory default settings

To perform a full factory reset, reset both global and preset parameters.

PRESET MANAGER SOFTWARE

ILLUMINE Preset Manager software for Windows and macOS is available at neunaber.net. A USB-MIDI adapter is required to use the software.

This software allows you to manage your presets as follows:

- Import/export single presets
- Backup/restore all presets and global configuration settings
- Rename presets
- View preset parameters and global configuration settings

ILLUMINE Preset Manager does not allow editing of preset parameters, except for the preset name.

USER INTERFACE

All active parameters for the currently-selected preset are displayed. Inactive parameters are not shown.

Export Preset — Exports the currently selected preset to a file.

Import Preset — Imports a single preset into the one currently selected.

Backup — Creates a backup file of all presets and global parameters.

Restore — Restores all presets and global parameters from a backup file.

About — Shows software/firmware version and global parameters.


Preset Selector— Selects the current preset.

Preset Name — Displays the name of the selected preset. Editing this field will overwrite the name of the preset in ILLUMINE. Only the first 14 characters are accepted. Only the following characters can be translated between ILLUMINE and Preset Manager software, and all others will be ignored:

a b c d e f g h i j k l m n o p q r s t u v w x y z
A B C D E F G H I J K L M N O P Q R S T U V W X Y Z
"!#\$%&'()*+,-./:;<=>?0123456789

HOW TO UPDATE THE ILLUMINE REVERB'S FIRMWARE

1	You will need a USB-MIDI interface and a macOS or Windows PC. Visit neunaber.net for a list of recommended USB-MIDI interfaces. The use of any other USB-MIDI interface is not recommended. Connect the USB-MIDI interface between your computer and ILLUMINE, using the 2.5mm adapters included with ILLUMINE.
2	Power up your ILLUMINE Reverb.
3	Download ILLUMINE Preset Manager software and extract it from the .zip file. Close all other applications, then open ILLUMINE Preset Manager software. Do NOT run Preset Manager from within the .zip file.
4	Select your USB-MIDI interface from the Interface dropdown box.
5	Click the About button. If a firmware update is available, the Update Firmware button will appear at the bottom. Click it. Confirm that you wish to proceed by clicking Yes when prompted to continue. The firmware update process will automatically backup and restore your presets and settings. It will leave a copy of the backup file on your desktop.
6	Wait for the Success message. Click OK. The firmware update is now complete.



TROUBLESHOOTING

Problem

An error occurred during the firmware update.

Solution

Use one of the USB-MIDI interfaces recommended at neunaber.net.

If possible, connect the USB-MIDI interface directly to your computer, not to a USB hub.

Launch Preset Manager Software, wait for it to detect that the prior attempt failed, then repeat the firmware update. The software will attempt to restore your previous backup if possible.

If Preset Manager does not automatically detect that the prior attempt failed, you may manually restart the firmware update as follows:

- Ensure Preset Manager has focus by clicking on the ILLUMINE Preset Manager logo.
- Press option-command-u (macOS) or Ctrl-Alt-u (Windows)

Problem

Preset Manager Software cannot connect to ILLUMINE to start the update, despite being able to connect previously.

Solution

If your ILLUMINE appears to be operating properly, then check the following:

- Is your USB-MIDI interface connected to your computer and ILLUMINE?
- Is your USB-MIDI interface connected OUT to MIDI IN and IN to MIDI OUT?
- Is ILLUMINE powered on?

If ILLUMINE is not operating properly, then you may perform the following recovery procedure in firmware version 1.0.2 or later. ***This procedure will erase all of your User Presets and Global Settings.***

- Close Preset Manager Software.
- Remove the power plug from ILLUMINE.
- Hold down the top knob and right-side footswitch while reinserting the power plug. The display should remain blank.
- Connect a USB-MIDI interface between ILLUMINE and your computer.
- Relaunch Preset Manager Software.
- When the Cannot Connect window appears, click Update Firmware.
- After the update is complete, you will need to restore your settings from a previous backup file.

If you have firmware version 1.0.1 or earlier, please contact Neunaber Support.

TROUBLESHOOTING GUIDE

Condition	Cause	Solution
Hum or buzz	Ground loop caused by having no connection to earth ground through an amp, interface, mixer, or power supply	Connect a ground wire (see Grounding).
	Power supply noise caused by the use of an unregulated power supply	Use a linear (non-switching) regulated power supply
Tone change when enabling or bypassing	True bypass	Go to GLOBAL SETUP ► BYPASS TYPE , select Buffered
Volume drop with Mix around 75%	Inappropriate MIX SUM TYPE for your input signal	Go to GLOBAL SETUP ► MIX SUM TYPE , select Unity RMQ
Volume increase with Mix around 75%	Inappropriate MIX SUM TYPE for your input signal	Go to GLOBAL SETUP ► Mix Sum Type , select Unity RMS
Mix does not go to full 100% wet signal	MIX SUM TYPE set to Unity Dry	Go to GLOBAL SETUP ► MIX SUM TYPE , select Unity RMS or Unity RMQ
Signal is noisy	NOISE REDUCTION is off	GLOBAL SETUP ► NOISE REDUCTION select on
	Inappropriate GAIN STRUCTURE setting	GLOBAL SETUP ► GAIN STRUCTURE , select Balanced or Low Noise

Condition	Cause	Solution
Reverb compresses or does not get louder when input level increases	Inappropriate GAIN STRUCTURE setting for your input signal	Go to GLOBAL SETUP ► GAIN STRUCTURE , select High Headroom
Only when using a stereo input, reverb is very quiet or nonexistent	Prior effect in chain produces a stereo output that is not mono-compatible	Go to GLOBAL SETUP ► FX SIDECHAIN IN , select Unbalanced Mix . If problem persists, select Left Only or Right Only
Reverb cuts out	Input signal is too low	Go to GLOBAL SETUP ► GAIN STRUCTURE , select Low Noise . If problem persists, go to GLOBAL SETUP ► NOISE REDUCTION , select Off
BYPASS TYPE screen is missing	Bypass trails are enabled, or Parallel Effect Loop type is selected, or Wet/Dry Effect Routing is selected	Go to GLOBAL SETUP ► BYPASS TRAILS , select No , ► EFFECT LOOP TYPE , select Serial , ► EFFECT ROUTING , select Stereo Mix
BYPASS TRAILS or EFFECT LOOP TYPE or EFFECT ROUTING screen is missing	True bypass is enabled	Go to GLOBAL SETUP ► BYPASS TYPE , select Buffered
Display reads: Power Supply > 13 V !	The power supply voltage is too high	Replace the power supply with one that produces between 9 V and 12 V.

SPECIFICATIONS

Nominal Input Level	-10 dBV, instrument / consumer line level	
Maximum Input Level (4)	9.5 dBV	
Input Impedance	500 k Ω mono	1 M Ω stereo
Output Impedance	50 Ω mono	100 Ω stereo
Signal-to-Noise Ratio, A-weighted, buffered bypass w/o trails (1, 4)	118 dB mono	115 dB stereo
Signal-to-Noise Ratio, A-weighted, engaged or trails bypass (1, 2, 4)	113 dB mono	110 dB stereo
Total Harmonic Distortion+Noise -10 dBV input, 22 Hz - 22 kHz (1)	< 0.005% (3)	
Frequency Response	20 Hz - 40 kHz, +0/-1 dB (3)	
Level Matching, Mix @ 0% vs. bypassed	+/-0.04 dB	
Level Matching, left to right channels	+/-0.02 dB	
Recommended Headphone Impedance	30 Ω - 50 Ω	
Power		
Supply voltage	regulated 9 V - 12 V DC	
Current consumption	85 mA typical	
Recommended supply current	100 mA or greater	
Connector polarity	center-negative (tip-negative)	
Connector type	5.5 mm OD x 2.1 mm ID	
Dimensions	121 x 99 x 62 mm / 4.8 x 3.9 x 2.6 in	
Weight	415 g / 14.6 oz	

¹ noise reduction enabled

² parameters @ 50%

³ dry signal or bypassed

⁴ 12 V supply, High Headroom setting

LEGAL

© 2021-2022 Neunaber Technology LLC. All Rights Reserved.

Neunaber®, ILLUMINE™ and Wet™ are trademarks of Neunaber Technology LLC. All other trademarks are the property of their respective owners.

Some reverb algorithms are protected by US Patent #8204240 and China Patent #CN101689840B.

neunaber.net

