

FJ80-SE Series Speedlight

User Manual

v 1.3.0
05/01/2024



CONTENTS

CONTENTS	1
Introduction	3
Components (Included)	4
Important things to know before starting...	4
Reviewing Firmware Files	4
TTL ± 3 Flash Exposure Compensation	4
Canon Continuous Mode	4
FJ80-SE Speedlight: Overview	5
FJ80-SE Speedlight: Display & Menus	6
FJ80-SE Speedlight: Warnings	7
Caution	7
FJ80-SE Heat Protection System	7
FJ80-SE Speedlight: Firmware Updates	8
FJ80-SE Speedlight: Getting Started	8
Charging the FJ80-SE Lithium-ion Battery	8
Battery Charger LED Indicator Lights	8
Powering On	8
FJ80-SE Speedlight: Mounting	9
FJ80-SE Speedlight: Powering & Testing	9
FJ80-SE Speedlight: Attaching & Removing Accessories	9
FJ80-SE Cold Shoe Stand: Mounting & Removing	9
FJ80-SE Speedlight: Speedlight <i>On-camera</i> Operation	10
Enable SPEEDLIGHT Mode	10
SPEEDLIGHT: Digital Screen Button Selections	10
Auto-Focus (AF) Assist Beam	10
FJ80-SE Speedlight: <i>HOST</i> Wireless Operation	11

HOST: Enable HOST Mode	11
HOST: Digital Screen Button Selections	11
FJ80-SE Speedlight: <i>CLIENT</i> Wireless Operation	12
CLIENT: Enable CLIENT Mode	12
CLIENT: Enable Group SLP (Sleep) Mode	12
CLIENT: Digital Screen Button Selections	12
Full-stop Increments in Manual Mode with the FJ Wireless Trigger	13
FJ80-SE Speedlight: SYNC Functions	13
Enabling Front or Rear Curtain Sync	13
Enabling HSS (High-speed Sync)	13
Enabling Freeze Sync	13
FJ80-SE Speedlight: ZOOM Control	14
FJ80 Series: Remote ZOOM Control [Single Group]	14
FJ80 Series: Remote ZOOM Control [All Groups]	14
FJ80-SE: Settings Menu	14
SETTINGS Menu: Locating	14
FJ80-SE Battery: Performance and Care	14
FJ80-SE Battery Performance	14
FJ80-SE Charging & Life Expectancy	14
FJ80-SE Speedlight: Technical Specifications	15
Warranty Information	17
Legal Information	17

Introduction

Thank you for purchasing the Westcott FJ80-SE Speedlight. The FJ80-SE is the perfect addition to the growing family of FJ Series Wireless products; FJ400 Strobe, FJ200 Strobe, FJ80 Speedlights, FJ Wireless Triggers, and FJ-XR Wireless Receiver (*all sold separately*). The original FJ80 was the industry's first-round head speedlight and transceiver equipped with multi-brand compatibility and controls.

The FJ80-SE provides an experience, unlike any other flash. The round head provides a more natural light output mimicking the sun, leading to more appealing catchlights in your subject's eyes and evenly filling up cylindrical modifiers from the center to the edge. It's compact, lightweight, and performance-driven, which makes it perfect for on-camera and off-camera photography.

The FJ80-SE also doubles as a transceiver, meaning the ability to send and receive wireless communication with select FJ devices. With the ability to receive wireless communications from the FJ80 II, FJ80, FJ-X Triggers and Canon RT devices, the compact FJ80-SE allows you to squeeze into the smallest spaces or reach new heights to achieve your desired lighting effect.

One last thing, and this is the important one. Don't forget that Westcott HQ is based in Maumee, OH, and our team's available to answer your questions, Monday-Friday 9 am-5 pm ET. We also have a community of loyal Westcott users who are ready to share their tips and tricks via the Westcott Lighting Community on Facebook during the week or on the weekend.

We hope you're excited to get started with your new lighting tool because we're excited to see what you create.

Thank you for your business.

-Team Westcott

Components (Included)

- FJ80-SE Speedlight
- FJ80-SE Rechargeable Lithium-ion Battery
- FJ80-SE Battery Charger, USB Cable & AC Adapter
- FJ80-SE Twist Lock Adapter Ring
- FJ80-SE Color Correction Gel
- FJ80-SE Shoe Stand
- FJ80-SE Travel Case

Important things to know before starting...

Reviewing Firmware Files

Firmware updates will be made available on the Westcott Firmware Update page: (<https://www.fjwestcott.com/firmware>.) Firmware updates often improve the overall performance of the device or allows for minor updates to the GUI of the FJ Wireless product. Please review ALL documentation included with each firmware download to ensure all of the necessary preparation steps are complete before installing the firmware.

TTL ± 3 Flash Exposure Compensation

± 3 TTL Flash Exposure Compensation (FEC) on FJ Wireless Triggers or host FJ80 Speedlights (*when used as a transmitter*) is independent of the Flash Exposure Compensation (FEC) displayed on FJ Wireless lights (*when used as a client*). Meaning, a change of the FEC ± 3 on FJ Wireless Triggers or a host FJ80-SE Speedlight will adjust the light output in TTL mode; however, a client FJ80-SE's will not visually indicate the FEC changes made on an FJ Wireless Trigger or host FJ80-SE Speedlight. FJ80-SE Speedlight's FEC can be further adjusted ± 3 on the client light directly.

Canon Continuous Mode

When photographing in Canon Continuous Mode, two overlapping squares will be visible on FJ Wireless Triggers & FJ80 Speedlight displays.


Note: When Canon Continuous Mode is enabled, the FJ80SE will do 20 FPS (dependant on camera model) at power level 4 and below. Choosing a power level above 4 or using TTL can cause misfires if the FJ80SE is not allowed to fully recycle.

FJ80-SE Speedlight: Overview



FJ80-SE Speedlight: Display & Menus

Host Menu




- A:** Camera Brand, Standby/Link, Channel, Zoom, Battery
- B:** Group, Mode, Power, Modeling Lamp
- C:**
 - Menu 1: Mode, Power Output, Zoom
 - Menu 2: Sync, Speedlight Enable/Disable, Modeling Lamp
 - Menu 3: FJ Wireless Enabled, Channel, Standby On/Off
- D:** Continuous Capture, Lock, Overheat, Sync Mode

Client Menu




- A:** Group, Channel, Zoom
- B:** Mode, Client Mode Indicator, Power
- C:**
 - Menu 1: Group, Channel, FJ Wireless Enabled
 - Menu 2: Mode, Zoom, Modeling Lamp
- D:** Continuous Capture, Lock, Overheat, Sync Mode

Speedlight Menu



- A:** Camera Brand, Standby/Link, Zoom
- B:** Mode, Power
- C:**
 - Menu 1: Mode, Sync, Zoom
 - Menu 2: Modeling Lamp, Standby
- D:** Continuous Capture, Lock, Overheat, Sync Mode

Settings Menu



FJ80-SE Speedlight: Warnings

Caution

- **IMPORTANT:** During operation, the temperature of the speedlight lens and various components of the FJ80-SE speedlight may increase. Please use caution while using to avoid severe burns or injuries.
- Do not touch the speedlight lens after immediate use to avoid potential injury.
- Use only with the Westcott FJ80-SE Lithium-ion Battery and Charging Base.
- Always confirm proper installation, locking, and unlocking when adding or removing from the camera hot shoe. (NOTE: Failure to completely rotate the dial to lock and unlock could permanently damage the locking pin.)
- Always remove the FJ80-SE Lithium-ion Battery from the FJ80-SE Speedlight during travel/storage to avoid accidental operation, which could lead to overheating or permanent damage.
- Do not force adjust or add excessive weight to the speedlight head.
- Only use the FJ80-SE Speedlight with compatible FJ80 mounts, brackets, modifiers, and/or accessories.
- Avoid drastic temperature changes before, during, or after use.
- The operating temperature range is 14°~131°F / (-10~55°C).
- Never leave unattended around children and/or pets.
- Keep away from fire, water, and moisture.
- Do not submerge in water.
- Do not attempt to disassemble or modify any Westcott products. Contact Westcott for assistance.

FJ80-SE Heat Protection System

The FJ80-SE is equipped with a self-monitoring system ensuring safe operation during continued full-power use during a short timeframe.

Stage 1: Once the speedlight reaches an internal operating temperature of 185°F (85°C), the screen will display [OH]. The recycle time will also increase by 3.2 seconds in an effort to cool the unit while allowing for continued operation.

Stage 2: Once the speedlight reaches an internal operating temperature of 215°F (102°C), the screen will display [OH]. The recycle time will also increase by an additional 3 seconds in an effort to cool the unit while allowing for continued operation.

Stage 3: Once the speedlight reaches an internal operating temperature of 221°F (105°C), the screen will display [OH]. The recycle time will also increase by an additional 8 seconds in an effort to cool the unit while allowing for continued operation.

NOTE: The LED modeling lamp will be disabled during OH to assist in minimizing the internal temperature.

FJ80-SE Speedlight: Firmware Updates

The FJ80-SE Speedlight is designed with a USB-C port to allow for firmware updates only. Future firmware updates will result in performance enhancements, modified menu options, and improved menu layouts. Please visit <https://www.fjwestcott.com/firmware> to confirm your speedlight has the latest firmware before using it.

FJ80-SE Speedlight: Getting Started

Charging the FJ80-SE Lithium-ion Battery

1. Ensure the FJ80-SE is powered off by sliding the **Power** slider down until the screen turns off.
2. Remove the battery by locating and pressing the release button on the left side of the device.
3. Gently pull the battery away from the FJ80-SE battery well.
4. Connect one end of the USB cable to the battery charger.
5. Connect the other end into the AC adapter.
6. Plug the AC adapter into a wall outlet.
7. Align the gold contacts on the back of the FJ80-SE battery with the contacts on the FJ80-SE charger.
8. Carefully insert the battery into the charger and gently press until it locks into place, causing the LED indicator to start blinking red.
9. You can safely remove the battery from the charger once the LED indicator light turns solid green.
10. Remove the battery from the charger by gently pulling it upwards.
11. Reinsert the charged battery by aligning the gold contacts on the battery with those in the battery bay. Gently press the battery back into the FJ80-SE.

Battery Charger LED Indicator Lights

- **Blinking Green Indicator LED**
 - **No Battery Inserted:** The charger is connected to a power outlet and is prepared to charge the FJ80-SE Lithium-ion Battery.
- **Solid Green Indicator LED**
 - **Battery Inserted:** The FJ80-SE Battery is fully charged and can be removed from the charger.
- **Solid Yellow Indicator LED**
 - *Battery Inserted:* The FJ80-SE Battery is correctly inserted and at 50% charge level.
- **Solid Red Indicator LED**
 - **Battery Inserted:** The FJ80-SE Battery is correctly inserted and is currently charging.

Powering On

1. Verify that the FJ80-SE battery is fully charged.
2. Ensure the battery is securely inserted to the FJ80-SE battery bay.
3. Turn the speedlight **ON** by sliding the physical power slider upwards. The FJ80-SE will power on and a start-up screen will appear.

NOTE: The FJ80-SE LCD screen may have a removable clear screen protector. You can remove this protector at your convenience by gently pulling it away from the display.

NOTE: The FJ80-SE is capable of 550+ full-power flashes with the modeling lamp disabled and screen brightness set to Minimum Brightness (1).

FJ80-SE Speedlight: Mounting

Mounting to a Camera

1. Confirm the FJ80-SE is **OFF**.
2. While looking at the display screen, rotate the FJ80-SE's locking dial clockwise (left to right) to loosen.
3. Slide the base of the FJ80-SE into the camera's hot shoe with the display facing the same direction as the rear of the camera.
4. Rotate the FJ80-SE locking dial counterclockwise (right to left) until its securely mounted to the camera.
5. Turn the camera on and lightly press the shutter release button. The Link icon () will display on the speedlight screen under the selected camera brand, signifying the proper connection between the camera and the speedlight.

NOTE: FJ80SE-M (#4660) is compatible with Sony Cameras in Manual Mode. The Adapter for Sony cameras (#4711) sold separately, allows for TTL and HSS. Dedicated FJ80-SE for Sony cameras also available (#4664).

Detaching from a Camera

1. Confirm the FJ80-SE is OFF.
2. Rotate the FJ80SE's locking dial clockwise (left to right).
3. Securely grasp the sides of the FJ80-SE Speedlight, gently slide the speedlight towards the rear of the camera to remove it from the hot shoe.

IMPORTANT: *Ensure the locking pin is fully retracted before inserting or removing the FJ80-SE from a camera, shoe stand, or any brackets to avoid damaging the locking pin.*

FJ80-SE Speedlight: Powering & Testing

- **Powering On:** Slide the Power slider upwards, the screen will illuminate and the FJ80-SE start-up screen will appear.
- **Test Fire:** Quick-press the white Test button [backlit green] once to test-fire the FJ80-SE. When the Test button is pressed, the backlit button may illuminate red until the speedlight has recycled and is ready for the next burst.
- **Powering Off:** Slide the Power slider down to power OFF.

FJ80-SE Speedlight: Attaching & Removing Accessories

FJ80-SE Cold Shoe Stand: Mounting & Removing

1. While looking at the display screen, rotate the FJ80-SE's locking dial clockwise (left to right) to loosen.
2. Slide the metal base of the FJ80-SE into the cold shoe stand with the display facing the same direction as the channel opening on the back of the shoe stand.
3. Rotate the FJ80-SE locking dial counterclockwise (right to left) until it's securely mounted to the cold shoe stand.
4. Remove the FJ80-SE Speedlight by rotating the FJ80-SE locking dial clockwise (left to right).

5. Securely grasp the sides of the FJ80-SE Speedlight, gently slide the speedlight towards the rear of the cold shoe stand, and remove it from the cold shoe stand.

FJ80 Series Twist Lock Modifiers: Attachment and Removal

1. Ensure that the FJ80-SE's articulating flash head and lens are clear of any obstructions.
2. Align the four tabs on the modifier with the slots on the face of the FJ80-SE. Gently insert and twist clockwise until it locks into place. (Some modifiers may require an adapter ring.)
3. To remove the modifier, twist it counterclockwise until it is fully unlocked. Pull the modifier away from the speedlight head.

Note: Make sure the FJ80-SE has cooled down before adding or removing modifiers.

FJ80-SE Speedlight: Speedlight *On-camera* Operation

Enable SPEEDLIGHT Mode

1. Quick-press the Mode button (**M**) to toggle between the different shooting modes.
2. To enable speedlight mode, press the **M** button until only the camera brand of your choosing, the mode type, the zoom setting, and the battery are displayed at the top of the screen.
3. Adjust the speedlight settings by rotating the round scroll wheel at the base of the FJ80-SE.

SPEEDLIGHT: Digital Screen Button Selections

Menu 1 Options

- MENU 1
- MODE
- SYNC [Front Curtain Sync, Rear Curtain Sync, High-speed Sync (HSS)]
- ZOOM [A 24MM – 200MM]

Menu 2 Options

- Menu 2
- Modeling Lamp [OFF, AUTO, 1-3]
- STDBY

Auto-Focus (AF) Assist Beam

The FJ80-SE is equipped with an integrated AF Assist Beam which is compatible with various camera models. Review your camera's owner's manual and familiarize yourself with the settings that need to be adjusted to take advantage of this feature.

1. Press and hold the two round buttons indicated by a gear symbol directly below the LCD screen.
2. Rotate the control dial and locate the AF Beam option.
3. Quick-press the center dial button and rotate the dial to toggle the Auto-Focus beam selection to **ON** or **OFF**.
4. Short press the center dial button to select the desired setting.
5. Press the button that corresponds to the Return icon to return to the previous mode screen.

*NOTE: When the AF selection is turned to **AUTO**, it will lock the FJ80-SE's shutter speed at 1/200th of a second. It's important to note that this will disable HSS. This setting is best used in scenarios with little ambient light.*

*NOTE: When the AF selection is turned **OFF**, the HSS functionality will perform as normal and will allow you to change your shutter speed higher than 1/200th of a second. Please note that the HSS functionality depends on whether your camera is listed on the compatibility chart. <https://www.fjwestcott.com/wireless-compatibility>.*

NOTE: AF Assist Beam functionality is not compatible with all cameras. Review your camera's owner's manual and familiarize yourself with the settings that need to be adjusted to take advantage of this feature with compatible cameras.

FJ80-SE Speedlight: *HOST* Wireless Operation

HOST: Enable HOST Mode

1. Quick-press the physical **M** button to toggle between the different shooting modes.
2. Enable Host mode by pressing the physical **M** button until three groups of letters between A-F appear on the display.
3. Adjust the settings using one of the following methods:
 - a. Method 1:
 - i. Quick-press the center dial button on the desired group.
 - ii. Depending on the mode selected, the light output or exposure compensation will begin to blink.
 - iii. Rotate the dial to change the number.
 - iv. Press the center button again to lock in your settings or wait four seconds until the number stops blinking.
 - b. Method 2:
 - i. Quick-press the button directly under the +/- icon.
 - ii. Depending on the mode selected, the light output or exposure compensation will begin to blink.
 - iii. Rotate the dial to change the number.
 - iv. Press the center button again to lock in your settings or wait four seconds until the number stops blinking.

HOST: Enable Group SLP (Sleep) Mode

FJ Wireless flashes can be placed into **SLP** (sleep) mode from any FJ Transmitter, disabling the unit's ability to flash while other flash groups continue operating normally.

1. Determine the Group [A-F] that the CLIENT FJ Wireless Flash Device is assigned to.
2. Quick-press the corresponding MODE button icon continuously until **SLP** (sleep) appears on the display. (Note: Any flash units assigned to this Group will also enter into **SLP** (sleep) mode.)
3. Exit the **SLP** (sleep) mode by pressing the corresponding MODE button icon until the screen displays **TTL** or **M**.

NOTE: Ensure the Exposure Mode type is updated from the HOST FJ80-SE; otherwise, the CLIENT flash unit(s) will re-enter SLP (sleep) mode once the HOST FJ80-SE transmits the next signal to the CLIENT devices.

HOST: Digital Screen Button Selections

Menu 1 Options

- MENU 1
- MODE
- +/- [Power Adjustment Icon]
- ZOOM [A, 24MM – 200MM]

Menu 2 Options

- MENU 2
- SYNC [Front Curtain Sync, Rear Curtain Sync, High-speed Sync (HSS)]
- [FLASH ICON] [Enables or Disables the FJ80-SE from firing on Camera]
- Modeling Lamp [OFF, AUTO, 1-3]

Menu 3 Options

- MENU 3
- TTL-ALL/C-RT [Wireless Radio Frequency]
- CH [CHANNELS 1-31]
- STDBY

NOTE: The Modeling Lamp control button for each group serves two functions for assigned HOST and CLIENT units:

- Function 1: Adjusting the output settings Minimum [1] ~ Maximum [3] will control the HOST FJ80-SE's modeling lamp brightness.
- Function 2: The modeling lamp of FJ CLIENT flash/strobe units assigned to the same Group(s) as the HOST FJ80-SE can also be controlled via this control button. However, the modeling lamp output of CLIENT units are limited, meaning the light output can only be set to OFF [0] or ON [1~3].

FJ80-SE Speedlight: CLIENT Wireless Operation

CLIENT: Enable CLIENT Mode

1. Quick-press the physical M button to toggle between the different shooting modes.
2. Enable Client mode by pressing the physical M button until the Client symbol () appears on the FJ80-SE's digital screen.

NOTE: It's important that the desired power settings are updated from the transmitter; otherwise, the flash unit(s) will default to the selected power on the transmitter when the next transmission signal is received.

CLIENT: Enable Group SLP (Sleep) Mode

FJ Wireless Flashes can be placed into **SLP** (sleep) mode from any FJ transmitter device. This disables the unit's ability to flash while other flash groups continue operating normally.

1. Determine the Group [A-F] that the FJ Wireless Flash Device is assigned to.
2. Press the corresponding FJ Wireless Triggers Group Selection Button or the MODE Function icon [HOST mode] continuously until **SLP** (sleep) appears on the transmitter and the connected FJ80SE next to the Group display. [Note: Flash units assigned to this Group will also enter **SLP** (sleep) mode.]
3. Exit the **SLP** (sleep) mode by pressing the corresponding FJ Wireless Triggers Group Selection Button or MODE Function icon [HOST mode] until the screen displays **TTL** or **M**.

NOTE: It's important that the Exposure Mode type is updated from the transmitter; otherwise, the flash unit(s) will re-enter SLP (sleep) mode when the next transmission signal is received from an FJ transmitter.

CLIENT: Digital Screen Button Selections

Menu 1 Options

- MENU 1
- GR [Group Selection]
- CH [Channel Selection]
- TTL-ALL/C-RT [Wireless Radio Frequency]

Menu 2 Options

- MODE
- ZOOM

- Modeling Lamp Button: [OFF, AUTO, 1-3]

Full-stop Increments in Manual Mode with the FJ Wireless Trigger

NOTE: Please refer to your specific FJ Wireless Trigger manual to learn how to utilize this feature.

FJ80-SE Speedlight: SYNC Functions

Enabling Front or Rear Curtain Sync

Front or Rear Curtain Sync is ideal in normal scenarios and when color consistency (6500°K ±200), full-power output (80 Ws), and the fastest recycling are essential.

1. Press the **Sync** selection button repeatedly until three arrows appear at the bottom right of the screen.
2. Front Curtain will show three arrows, with the first arrow filled in black.
3. Rear Curtain will show three arrows, with the third arrow filled in black.

NOTE: Utilize HSS (see below) when choosing to use shutter speeds above your camera's maximum normal sync speed (typically: 1/200s, 1/250s, or 1/320s).

Enabling HSS (High-speed Sync)

High-speed Sync is ideal for mixing a substantial amount of available light and flash when proper exposure with a shallow depth of field/wide aperture requires a flash sync speed above the camera's maximum normal sync speed (typically: 1/200s, 1/250s or 1/320s). HSS allows compatible cameras to achieve flash sync speed up to 1/8000s.

1. Press the Sync Selection button repeatedly until an  appears at the bottom right of the screen.

NOTE: HSS requires an FJ-X Transmitter or FJ80 Series Speedlight.

Enabling Freeze Sync

Freeze Sync is ideal for freezing fast-moving objects lit by the speedlight. *[Available in Manual Mode only.]*

1. Press and hold the two round buttons indicated by a gear symbol directly below the LCD screen.
2. Rotate the control dial and locate the Freeze option.
3. Quick-press the center dial button and rotate the dial to toggle the Freeze selection to **ON** or **OFF**.
4. Press the return icon located at the bottom right corner of the screen to return to the main screen.
5. Freeze flash is now enabled; a freeze icon will appear at the bottom right of the screen.

NOTE: Freeze flash will only work in Front and Rear Curtain Sync.

Freeze Sync Flash Durations

Flash Duration (t0.1)

- Normal: 1/266~1/3,300s
- Freeze: 1/500~1/16,670s

Flash Duration (t0.5)

- Normal: 1/800~1/10,000s
- Freeze: 1/1500~1/50,000s

FJ80-SE Speedlight: ZOOM Control

FJ80 Series: Remote ZOOM Control [Single Group]

NOTE: Please refer to the Remote ZOOM section in your FJ Wireless Trigger manual to learn how to use this feature.

FJ80 Series: Remote ZOOM Control [All Groups]

NOTE: Please refer to the Remote ZOOM section in your FJ Wireless Trigger manual to learn how to use this feature.

FJ80-SE: Settings Menu

SETTINGS Menu: Locating

1. Press and hold the two round buttons indicated by a gear symbol directly below the LCD screen.
2. Navigate the **Settings** menu by using the control dial.
3. Rotate the dial to scroll through the settings.
4. Quick-press the dial center button to highlight the setting in black, allowing you to change your setting by rotating the dial.
5. Quick-press the center button again to lock in your selection.
6. Quick-press the button directly below the return icon to return to the main screen.

SETTINGS Menu: Selectable Options

- Camera: Canon, Nikon, Sony, Fuji, Olympus, Lumix
- RT ID#: [00-99]
- Screen: [MIN,MID,MAX]
- Auto-Off: [OFF, 5 minutes, 15 minutes, 30 minutes]
- X-Sync: [OFF,ON]
- Beep: [OFF,ON]
- Freeze: [OFF,ON]
- Display: [DECIMAL (1.0), FRACTION (1/256)]
- AF Beam: [OFF,ON]
- Reset
- Return

FJ80-SE Battery: Performance and Care

FJ80-SE Battery Performance

The FJ80-SE Lithium-ion Battery (7.4V 18.5Wh, 2500mAh) is capable of 550+ full-power flashes with the modeling lamp disabled and screen brightness set to Minimum Brightness (1).

FJ80-SE Charging & Life Expectancy

- The average charge time is ~3 hours from complete discharge.
- The FJ80-SE Lithium-ion Battery (7.4V 18.5Wh, 2500mAh) will achieve at least 200 full-charge cycles (@80% capacity after 200). Usage beyond charge cycles may result in diminished performance and the ability to hold a charge for extended periods.
- Avoid charging and using the battery outside of the stated operating temperatures (14~131°F / -10~55°C) as it will affect the overall performance of the battery and speedlight.
- Preserve the battery's longevity by storing at roughly ~40% capacity at room temperature in a dry environment and recharge to this capacity at least once every three months when not being used.

FJ80-SE Speedlight: Technical Specifications

FJ80-SE: Speedlight	
Maximum Power (Ws)	80 Ws
Energy Range (Power Output)	9 f-stop (0.3Ws to 80 Ws)
Flash Duration (t0.1)	Normal: 1/266-3,300s Freeze: 1/500-16,670s
Flash Duration (t0.5)	Normal: 1/800-10,000s Freeze: 1/500-1/50000s
Recycle Time	.05s - 1.8s (DC Battery)
Color Temperature Stability	Normal/TTL/HSS: 6500K±200 Freeze: 6500K ±400K (E.R. 1-9)
Mounting System	FJ80 Twist Lock
Auto Multi-Voltage	Yes
Flash Increments	0.1-stop; 1.0-stop
Flash Modes	Manual / TTL
Continuous Capture	20 fps (Camera Model & Speedlight Settings Dependent)
IGBT	Yes
Flash Exposure Compensation (FEC)	±3
Modeling Lamp (Output)	LED 3 Watts (4600K ±200K)
Flash Tube	Line; 120° Beam Angle
Sync Functions	Normal, HSS, Freeze
Sync Speed	Normal: 1/250s HSS: 1/8000s
Wireless Radio Frequency	2.4GHz
Wireless Channels	01-31
Wireless Groups	16 [A, B, C, D, E, F, G, H, I, J, L, O, P, Q, S, U]
Wireless Range	Up to 328' (100m)

Power Source	FJ80-SE Battery
Battery Type	Lithium-ion
Battery Capacity	18.5Wh, 2500mAh
Voltage	7.4V
Charger Voltage	8.4V
Continuous Discharge Current	10A
Charge Current	≤ 1.5A
Charge Temperature	32° to 113° F / 0° to 45° C
Discharge Temperature	14° to 131° F / -10° to 55° C
Flashes Per Charge	550+ at Full Power
Recharge Time	≤3 hours
Battery Charge Cycles	200 (@80% after 200)
FJ80-SE: General	
Display	LCD Display
Mount	Hot Shoe
Auto-Dump	Yes
Cooling	Passive
Voltage Stabilization	Yes
Firmware Port Type	USB-C (Firmware)
Auto Memory Recall	Yes
Test Button	Yes
Auto-Power Off	Yes
Audible Beep Control	Yes
Optical Slave	N/A
FJ80-SE: Dimensions & Weight	
Weight (FJ80 with Battery)	1.21 lbs (0.55kg)
Length	7.68 in (19.5cm)
Height	3.10 in (7.9cm)
Operating Temp	14° - 131°F / -10° - 55°C

NOTE: Speedlight performance, available features, and menu items are subject to change without notice with future firmware updates or physical product changes during manufacturing. Information and specifications found in this document may change without notice.

Warranty Information

Westcott's warranty obligations for this product are limited to the following terms.

The F.J. Westcott Co. ("Westcott") warrants this Westcott branded product against defects in materials and workmanship under normal use for a period of **ONE (1) YEAR** from the date of retail purchase from Westcott or an authorized retailer by the original end-user purchaser ("Warranty Period"). If a defect arises and a valid claim is received within the Warranty Period, at its option and to the extent permitted by law, Westcott will either (1) repair the defect at no charge, using new or refurbished replacement parts, or (2) exchange the product with a product that is new or which has been manufactured from new or serviceable used parts and is at least functionally equivalent to the original product. This Limited Warranty applies only to products manufactured by or for Westcott that can be identified by the Westcott trademark, trade name, or logo affixed to them.

This warranty does not apply to; (a) damage caused by accident, abuse, misuse, flood, fire, earthquake, mold, or other external causes; (b) damage caused by operating the product outside the permitted or intended uses described by Westcott; (c) a product or part that has been modified to alter functionality or capability without the written permission of Westcott; or (d) cosmetic damage, including but not limited to scratches, dents, and broken plastic.

Disclaimer: By purchasing, borrowing, and/or using this product for any event, both public or private, you, the customer, accepts all responsibility and releases Westcott, and its associates, of any and all liability in the event of manufacturer's defect, malfunction or misuse of the product which may lead to further injuries or complications unforeseen by the user. Westcott is not responsible for any potential or incurred damage caused by failure to properly mount, hang, or store the product, which includes, but is not limited to damage to cameras, electronics, electrical equipment, buildings, building materials, personal injury, death, or disability, fire damage, or any and all other damage not mentioned previously.

Please contact Westcott's Repair Department for a Return Authorization Number "RMA" prior to requesting warranty service. This RMA must be clearly written on the outside of the box to the left of the shipping label. Items sent in without pre-authorization or that do not fall under the limited warranty will be returned at the sender's expense.

Repair Department: 419-243-7311

Email: service@fjwestcott.com

Shipping: F.J. Westcott Co, 1425-B Holland Rd. Maumee, OH 43537

Legal Information

Westcott products are made to the company's traditionally high standards of quality and comply with all applicable government safety regulations and requirements. In an effort to provide the best quality products possible, we periodically make product modifications. Actual products may not be identical to the items pictured. Future firmware updates may result in performance enhancements, removal of features to achieve optimal performance, and modified menu options and layouts.

Made in the China. ©F.J. Westcott Co. All rights reserved.