

VERSION 2.1  
AUGUST 2022  
702P08892

# Xerox® B225/B235 Multifunction Printer

User Guide

© 2022 Xerox Corporation. All rights reserved. Xerox® is trademark of Xerox Corporation in the United States and other countries.

Adobe®, Adobe PDF logo, Adobe® Reader®, Adobe® Type Manager®, ATM®, Flash®, Macromedia®, Photoshop®, and PostScript® are trademarks or registered trademarks of Adobe Systems, Inc.

Apple®, Bonjour®, EtherTalk®, TrueType®, iPad®, iPhone®, iPod®, iPod touch®, AirPrint® and the AirPrint Logo®, Mac®, Mac OS®, and Macintosh® are trademarks or registered trademarks of Apple Inc. in the U.S. and other countries.

Gmail® webmail service, and Android® mobile technology platform are trademarks of Google, Inc.

HP-GL®, HP-UX®, and PCL® are registered trademarks of Hewlett-Packard Corporation in the United States and/or other countries.

IBM® and AIX® are registered trademarks of International Business Machines Corporation in the United States and/or other countries.

McAfee®, ePolicy Orchestrator®, and McAfee ePO® are trademarks or registered trademarks of McAfee, Inc. in the United States and other countries.

Microsoft®, Windows Vista®, Windows®, Windows Server®, and OneDrive® are registered trademarks of Microsoft Corporation in the United States and other countries.

Mopria is a trademark of the Mopria Alliance.

PANTONE® and other Pantone, Inc. trademarks are the property of Pantone, Inc.

UNIX® is a trademark in the United States and other countries, licensed exclusively through X/ Open Company Limited.

Linux® is a registered trademark of Linus Torvalds.

Wi-Fi CERTIFIED Wi-Fi Direct® is a trademark of the Wi-Fi Alliance.

PCL® is a registered trademark of the Hewlett-Packard Company. PCL is a designation of a set of printer commands (language) and functions included in its printer products. This printer is intended to be compatible with the PCL language. This means the printer recognizes PCL commands used in various application programs, and that the printer emulates the functions corresponding to the commands.

All other trademarks are the property of their respective owners.

# Contents

1 Safety .....	11
Conventions .....	12
Product Statements .....	13
Maintenance Safety .....	16
Consumable Information.....	17
2 Learn about the printer .....	19
Printer configuration .....	20
Using the control panel .....	21
Non-touch Screen Model.....	21
Touch Screen Model.....	22
Customizing the home screen.....	23
Changing the language of the keyboard on the display.....	24
Understanding the status of the power button and indicator light.....	25
Selecting paper .....	26
Paper guidelines .....	26
Paper characteristics.....	26
Unacceptable paper.....	27
Selecting preprinted forms and letterhead.....	27
Storing paper.....	28
Supported paper sizes .....	28
Supported paper types .....	30
Supported paper weights .....	31
3 Set up, install, and configure.....	33
Selecting a location for the printer.....	34
Attaching cables .....	36
Finding the IP Address of the Printer .....	38
Setting up the printer to fax .....	39
Setting up the fax function.....	39
Setting up fax using a standard telephone line.....	40
Setting Up Fax in Countries or Regions with Different Telephone Wall Jacks and Plugs.....	41
Connecting to a distinctive ring service .....	43
Setting the fax date and time .....	43
Configuring daylight saving time .....	43
Configuring the fax speaker settings.....	44
Configuring Device Sounds Settings.....	45
Configuring the Email SMTP Settings .....	46
Using the Email Setup Wizard in the Printer.....	46
Using the Settings Menu in the Printer.....	46
Using the Embedded Web Server.....	46
Email Service Providers .....	47
Loading paper and specialty media .....	55

Setting the Paper Size and Type .....	55
Configuring Universal paper settings .....	55
Loading the Tray .....	55
Loading the Manual Feeder .....	57
Installing and updating software, drivers, and firmware .....	58
Installing the Software .....	58
Updating Software .....	61
Exporting or importing a configuration file .....	62
Xerox® Easy Assist App .....	63
Connecting to the Xerox® Easy Assist App for Installed Printers .....	65
Networking .....	67
Connecting the Printer to a Wi-Fi Network .....	67
Connecting the printer to a wireless network using Wi-Fi Protected Setup (WPS) .....	67
Configuring Wi-Fi Direct .....	68
Connecting a Mobile Device to the Printer .....	69
Connecting a Computer to the Printer .....	69
Deactivating the Wi-Fi network .....	70
Checking the printer connectivity .....	70
Printing the Menu Settings Page .....	71
4 Secure the printer .....	73
Erasing printer memory .....	74
Restoring factory default settings .....	75
Statement of Volatility .....	76
5 Print .....	77
Printing from a Computer .....	78
Printing from a Mobile Device .....	79
Printing from a Mobile Device Using Mopria™ Print Service .....	79
Printing from a Mobile Device Using AirPrint® .....	79
Printing from a Mobile Device Using Wi-Fi Direct® .....	79
Printing from a flash drive .....	80
Supported flash drives and file types .....	81
Flash drives .....	81
File types .....	81
Configuring confidential jobs .....	82
Using the Control Panel .....	82
Using the Embedded Web Server .....	82
Printing confidential and other held jobs .....	83
For Windows users .....	83
For Macintosh users .....	83
Printing a font sample list .....	85
Placing separator sheets between copies .....	86
Canceling a print job .....	87
From the printer control panel .....	87

From the computer .....	87
Adjusting toner darkness .....	88
6 Copy .....	89
Using the automatic document feeder and scanner glass .....	90
Making Copies .....	91
Copying photos .....	92
Copying on letterhead .....	93
Copying on Both Sides of the Paper .....	94
Reducing or enlarging copies .....	95
Copying multiple pages onto a single sheet .....	96
Collating copies .....	97
Copying cards .....	98
Creating a copy shortcut .....	99
7 Email .....	101
Using the automatic document feeder and scanner glass .....	102
Sending an Email .....	103
Using the Control Panel .....	103
Using a Shortcut Number .....	103
8 Fax .....	105
Using the automatic document feeder and scanner glass .....	106
Sending a Fax .....	107
Using the Control Panel .....	107
Scheduling a fax .....	108
Creating a fax destination shortcut .....	109
Changing the fax resolution .....	110
Adjusting the fax darkness .....	111
Printing a fax log .....	112
Blocking junk faxes .....	113
Holding a fax .....	114
Forwarding a fax .....	115
Using the control panel .....	115
Using the Embedded Web Server .....	115
9 Scan .....	117
Using the automatic document feeder and scanner glass .....	118
Scanning to a Computer .....	119
For Windows users .....	119
For Macintosh users .....	119
Scanning to a flash drive .....	120
Scanning to an FTP server .....	121

Scanning to a network folder .....	122
10 Use printer menus .....	123
Menu Map .....	124
Device .....	126
Preferences .....	126
Eco-Mode .....	128
Remote Operator Panel .....	129
Notifications .....	129
Power Management .....	131
Restore Factory Defaults .....	132
Maintenance .....	132
Visible Home Screen Icons .....	135
About This Printer .....	135
Print .....	137
Layout .....	137
Setup .....	138
Quality .....	139
PDF .....	139
PostScript .....	140
PCL .....	140
Image .....	142
Paper .....	143
Tray Configuration .....	143
Media Configuration .....	143
Copy .....	146
Copy Defaults .....	146
Fax .....	148
Fax Defaults .....	148
E-mail .....	155
E-mail Setup .....	155
E-mail Defaults .....	156
FTP .....	160
FTP Defaults .....	160
USB Drive .....	164
Flash Drive Scan .....	164
Flash Drive Print .....	166
Network/Ports .....	168
Network Overview .....	168
Wireless .....	169
Wi-Fi Direct .....	172
AirPrint .....	172
Mobile Services Management .....	173
Ethernet .....	174
TCP/IP .....	175
SNMP .....	178

IPSec.....	180
802.1x.....	181
LPD Configuration .....	181
HTTP/FTP Settings.....	182
USB .....	183
Restrict external network access .....	184
Universal Print.....	184
Security .....	187
Login Methods .....	187
Certificate Management.....	190
Confidential Print Setup .....	190
Schedule USB Devices .....	191
Login Restrictions.....	191
Erase Temporary Data Files .....	192
Solutions LDAP Settings .....	192
Miscellaneous .....	192
Reports.....	194
Menu Settings Page .....	194
Device .....	194
Print.....	194
Shortcuts.....	194
Fax.....	195
Network.....	195
Supplies Plan .....	196
Plan Activation.....	196
Plan Conversion.....	196
Subscription Service .....	196
Troubleshooting.....	197
11 Maintain the Printer .....	199
Checking the Status of Supplies .....	200
Configuring Supply Notifications .....	201
Setting up e-mail alerts .....	202
Viewing reports.....	203
Ordering Supplies .....	204
Using Genuine Xerox Supplies.....	204
Replacing Supplies.....	205
Replacing the Toner Cartridge .....	205
Replacing the imaging unit.....	208
Cleaning printer parts .....	210
Cleaning the printer .....	210
Cleaning the touch screen.....	210
Cleaning the Scanner .....	211
Saving energy and paper .....	213
Configuring power save mode settings .....	213
Adjusting the brightness of the display.....	213

Conserving supplies.....	213
Moving the Printer to Another Location .....	214
12 Troubleshoot a problem.....	215
Print quality problems .....	216
Printing problems .....	217
Print quality is poor .....	217
Print jobs do not print.....	249
Job prints from the wrong tray or on the wrong paper.....	250
Slow printing .....	250
The printer is not responding.....	254
Unable to read flash drive.....	256
Enabling the USB port.....	257
Network connection problems .....	258
Cannot open Embedded Web Server .....	258
Cannot connect the printer to the Wi-Fi network .....	259
Issues with supplies .....	261
Replace cartridge, printer region mismatch — Use 708699.....	261
Non-Xerox Supplies .....	261
Clearing Jams.....	262
Avoiding Jams.....	262
Identifying Jam Locations .....	263
Paper Jam in the Tray.....	264
Paper Jam in the Front Door .....	265
Paper Jam in the Rear Door .....	268
Paper Jam in the Duplex Unit.....	269
Paper Jam in the Standard Output Tray .....	270
Paper Jam in the Manual Feeder .....	270
Paper Jam in the Automatic Document Feeder.....	270
Paper feed problems .....	273
Envelope seals when printing .....	273
Collated printing does not work.....	274
Paper frequently jams.....	275
Jammed pages are not reprinted.....	276
E-mailing problems.....	277
Disabling the SMTP server not set up error Message .....	277
Cannot send e-mails.....	277
Faxing problems.....	278
Cannot send or receive faxes .....	278
Can receive but not send faxes.....	281
Can send but not receive faxes.....	282
Poor fax print quality .....	283
Scanning problems .....	284
Cannot scan to a computer .....	284
Cannot scan to a network folder.....	285
Partial copies of document or photo.....	287



Scan job was not successful.....	288
Poor copy quality.....	289
Vertical dark streaks on output when scanning from the ADF.....	289
Scanner does not close .....	290
Scanning takes too long or freezes the computer.....	290
Scanner does not respond.....	291
Adjusting scanner registration.....	291
Adjusting ADF registration.....	292
Contacting Customer Support.....	293
<b>A Regulatory Information .....</b>	<b>295</b>
Basic Regulations .....	296
Noise Emission Levels .....	296
European Union Lot 19 Ecodesign Directive.....	296
Static Sensitivity Notice .....	296
ENERGY STAR .....	296
Temperature Information.....	297
Información de la energía de México .....	297
Laser Notice .....	297
Power .....	297
Telecommunication Regulatory Notices .....	299
Regulatory Notices for Wireless Products.....	301
Federal Communications Commission (FCC) Compliance Information Statement.....	303
Innovation, Science and Economic Development Canada Compliance Statement .....	304
Germany.....	304
Turkey RoHS Regulation .....	304
Ukraine RoHS Compliance .....	304
Copy Regulations .....	305
United States.....	305
Canada.....	306
Other Countries.....	307
Material Safety Data Sheets.....	308
<b>B Recycling and Disposal .....</b>	<b>309</b>
Product Disposal and Recycling .....	310
North America .....	311
Xerox Green World Alliance .....	312
Waste from Electrical and Electronic Equipment (WEEE) Directive.....	313
India E-Waste notice .....	313



## Safety

This chapter contains:

Conventions.....	12
Product Statements.....	13
Maintenance Safety .....	16
Consumable Information .....	17

Your printer and the recommended supplies have been designed and tested to meet strict safety requirements. Attention to the following information ensures the continued safe operation of your Xerox printer.

## Conventions



Note: A note identifies information that could help you.



**Warning:** A warning identifies something that could damage the product hardware or software.



**Caution:** A caution indicates a potentially hazardous situation that could injure you.

Different types of statements include:



**CAUTION—POTENTIAL INJURY:** Indicates a risk of injury.



**CAUTION—SHOCK HAZARD:** Indicates a risk of electrical shock.



**CAUTION—HOT SURFACE:** Indicates a risk of burn if touched.



**CAUTION—PINCH HAZARD:** Indicates a risk of being caught between moving parts.



**CAUTION—MOVING PARTS:** Indicates a risk of laceration or abrasion injuries from rotating parts.

## Product Statements



**CAUTION—POTENTIAL INJURY:** To avoid the risk of fire or electrical shock, connect the power cord to an appropriately rated and properly grounded electrical outlet that is near the product and easily accessible.



**CAUTION—POTENTIAL INJURY:** To avoid the risk of fire or electrical shock, use only the power cord provided with this product or the manufacturer authorized replacement.



**CAUTION—POTENTIAL INJURY:** Do not use this product with extension cords, multi-outlet power strips, multi-outlet extenders, or UPS devices. The power capacity of these types of accessories can be easily overloaded by a laser printer and may result in a risk of fire, property damage, or poor printer performance.



**CAUTION—POTENTIAL INJURY:** Do not use this product with an inline surge protector. The use of a surge protection device may result in a risk of fire, property damage, or poor printer performance.



**CAUTION—POTENTIAL INJURY:** To reduce the risk of fire, use only a 26 AWG or larger telecommunications RJ-11 cord when connecting this product to the public switched telephone network. For users in Australia, the cord must be approved by the Australian Communications and Media Authority.



**CAUTION—SHOCK HAZARD:** To avoid the risk of electrical shock, do not place or use this product near water or wet locations.



**CAUTION—SHOCK HAZARD:** To avoid the risk of electrical shock, do not set up this product or make any electrical or cabling connections, such as the power cord, fax feature, or telephone, during a lightning storm.



**CAUTION—POTENTIAL INJURY:** Do not cut, twist, bind, crush, or place heavy objects on the power cord. Do not subject the power cord to abrasion or stress. Do not pinch the power cord between objects such as furniture and walls. If any of these things happen, a risk of fire or electrical shock results. Inspect the power cord regularly for signs of such problems. Remove the power cord from the electrical outlet before inspecting it.



**CAUTION—SHOCK HAZARD:** To avoid the risk of electrical shock, make sure that all external connections, such as Ethernet and telephone system connections, are properly installed in their marked plug-in ports.



**CAUTION—SHOCK HAZARD:** To avoid the risk of electrical shock, if you are accessing the controller board or installing optional hardware or memory devices sometime after setting up the printer, then turn the printer off, and unplug the power cord from the electrical outlet before continuing. If you have any other devices attached to the printer, then turn them off as well, and unplug any cables going into the printer.



**CAUTION—SHOCK HAZARD:** To avoid the risk of electrical shock, do not use the fax feature during a lightning storm.



**CAUTION—SHOCK HAZARD:** To avoid the risk of electrical shock when cleaning the exterior of the printer, unplug the power cord from the electrical outlet and disconnect all cables from the printer before proceeding.



**CAUTION—POTENTIAL INJURY:** If the printer weight is greater than 20kg (44lb), then it may require two or more people to lift it safely.



**CAUTION—POTENTIAL INJURY:** When moving the printer, follow these guidelines to avoid personal injury or printer damage:

- Make sure that all doors and trays are closed.
- Turn off the printer, and then unplug the power cord from the electrical outlet.
- Disconnect all cords and cables from the printer.
- If the printer has separate floor-standing optional trays or output options attached to it, then disconnect them before moving the printer.
- If the printer has a caster base, then carefully roll it to the new location. Use caution when passing over thresholds and breaks in flooring.
- If the printer does not have a caster base but is configured with optional trays or output options, then remove the output options and lift the printer off the trays. Do not try to lift the printer and any options at the same time.
- Always use the handholds on the printer to lift it.
- Any cart used to move the printer must have a surface able to support the full footprint of the printer.
- Any cart used to move the hardware options must have a surface able to support the dimensions of the options.
- Keep the printer in an upright position.
- Avoid severe jarring movements.
- Make sure that your fingers are not under the printer when you set it down.
- Make sure that there is adequate clearance around the printer.



**CAUTION—HOT SURFACE:** The inside of the printer might be hot. To reduce the risk of injury from a hot component, allow the surface to cool before touching it.



**CAUTION—PINCH HAZARD:** To avoid the risk of a pinch injury, use caution in areas marked with this label. Pinch injuries may occur around moving parts, such as gears, doors, trays, and covers.



**CAUTION—MOVING PARTS:** Indicates a risk of laceration or abrasion injuries from rotating parts.



**CAUTION—POTENTIAL INJURY:** This product uses a laser. Use of controls or adjustments or performance of procedures other than those specified in the User Guide may result in hazardous radiation exposure.



**CAUTION—POTENTIAL INJURY:** The lithium battery in this product is not intended to be replaced. There is a danger of explosion if a lithium battery is incorrectly replaced. Do not recharge, disassemble, or incinerate a lithium battery. Discard used lithium batteries according to the manufacturer instructions and local regulations.

This product is designed, tested, and approved to meet strict global safety standards with the use of specific manufacturer components. The safety features of some parts may not always be obvious. The manufacturer is not responsible for the use of other replacement parts.

Refer service or repairs, other than those described in the user documentation, to a service representative.

This product uses a printing process that heats the print media, and the heat may cause the media to release emissions. You must understand the section in your operating instructions that discusses the guidelines for selecting print media to avoid the possibility of harmful emissions.

This product may produce small amounts of ozone during normal operation, and may be equipped with a filter designed to limit ozone concentrations to levels well below the recommended exposure limits. To avoid high ozone concentration levels during extensive usage, install this product in a well-ventilated area and replace the ozone and exhaust filters if instructed to do so in the product maintenance instructions. If there are no references to filters in the product maintenance instructions, then there are no filters requiring replacement for this product.

**SAVE THESE INSTRUCTIONS.**

## Maintenance Safety

Do not carry out any maintenance on this product that is not described in the customer documentation.



**CAUTION—POTENTIAL INJURY:** Do not use aerosol cleaners. Aerosol cleaners can be explosive or flammable when used on electromechanical equipment.

Use supplies and cleaning materials only as directed.

Do not remove the covers or guards that are fastened with screws. Customer service items are not located behind these covers.

In case of a Dry Ink or Toner Spill, use a broom or a wet cloth to wipe off spilled dry ink or toner. Sweep slowly to minimize generation of dust during clean up. Avoid using a vacuum. If a vacuum must be used, the unit should be designed for combustible dusts, having an explosion rated motor and non-conductive hose.



**CAUTION—HOT SURFACE:** The metallic surfaces in the fuser area are hot. Use caution when you remove paper jams from this area and avoid touching any metallic surfaces.



## Consumable Information



**CAUTION—POTENTIAL INJURY:** When handling cartridges such as ink or fuser, avoid skin or eye contact. Eye contact can cause irritation and inflammation. Do not attempt to disassemble the cartridge. This can increase the risk of skin or eye contact.

Store all consumables in accordance with the instructions given on the package or container.

Keep all consumables away from the reach of children.

Never throw dry ink/toner, print cartridges, or dry ink/toner containers into an open flame.

For information on Xerox® supplies recycling programs, go to: <https://www.xerox.com/recycling>.




## Learn about the printer

This chapter contains:

Printer configuration .....	20
Using the control panel.....	21
Customizing the home screen .....	23
Changing the language of the keyboard on the display .....	24
Understanding the status of the power button and indicator light .....	25
Selecting paper.....	26

## Printer configuration




- |                                    |                   |
|------------------------------------|-------------------|
| 1. Automatic document feeder (ADF) | 5. Power button   |
| 2. ADF input tray                  | 6. Manual feeder  |
| 3. ADF output tray                 | 7. 250-sheet tray |
| 4. Standard output tray            | 8. Control panel  |



Note: The appearance may vary depending on your printer model.

## Using the control panel


### NON-TOUCH SCREEN MODEL



NUMBER	CONTROL PANEL PART	FUNCTION
1	Display	<ul style="list-style-type: none"> <li>View printer messages and supply status.</li> <li>Set up and operate the printer.</li> </ul>
2	Left arrow button	<ul style="list-style-type: none"> <li>Scroll through menus or move between screens and menu options.</li> <li>Decrease the numeric value of a setting.</li> </ul>
3	Select button	<ul style="list-style-type: none"> <li>Select a menu option.</li> <li>Save the changes in a setting.</li> </ul>
4	Right arrow button	<ul style="list-style-type: none"> <li>Scroll through menus or move between screens and menu options.</li> <li>Increase the numeric value of a setting.</li> </ul>
5	Indicator light	Check the status of the printer.
6	Home button	Go to the home screen.
7	Stop or Cancel button	Stop the current job.
8	Back button	Return to the previous screen.
9	Start button	Start a job, depending on which mode is selected.
10	Menu button	Access the printer menus.
11	Shortcuts button	Access shortcuts to frequently used functions with previously saved settings.
12	Email button	Enter Email mode.

NUMBER	CONTROL PANEL PART	FUNCTION
13	Copy button	Enter Copy mode.
14	Numeric keypad	Enter numbers or symbols in an input field.

## TOUCH SCREEN MODEL



NUMBER	CONTROL PANEL PART	FUNCTION
1	Home button	Go to the home screen.
2	Back button	Return to the previous screen.
3	Start button	Start a job, depending on which mode is selected.
4	Indicator light	Check the status of the printer.
5	Display	<ul style="list-style-type: none"> <li>View printer messages and supply status.</li> <li>Set up and operate the printer.</li> </ul>

## Customizing the home screen

1. From the control panel, touch **Settings** > **Device** > **Visible Home Screen Icons**.
2. Select the icons that you want to appear on the home screen.
3. Apply the changes.

## Changing the language of the keyboard on the display



Note: You can only change the language of the keyboard in printer tasks that require alphanumeric input such as e-mail or scan.

1. Touch the input field.
2. On the keyboard, touch and hold the language key.
3. Select a language.



## Understanding the status of the power button and indicator light

POWER BUTTON LIGHT	PRINTER STATUS
Off	The printer is off, ready, or processing data.
White	The printer is in Sleep mode.

### Non-touch Screen Model

INDICATOR LIGHT	PRINTER STATUS
Off	The printer is off or in Sleep mode.
Green	The printer is on or ready.
Blinking green	The printer is processing data.
Blinking red	The printer requires user intervention.

### Touch Screen Model

INDICATOR LIGHT	PRINTER STATUS
Off	The printer is off or in Sleep mode.
Blue	The printer is on or ready.
Blinking blue	The printer is processing data.
Blinking red	The printer requires user intervention.

## Selecting paper

### PAPER GUIDELINES

Use the appropriate paper to prevent jams and help ensure trouble-free printing.

- Always use new, undamaged paper.
- Before loading paper, know the recommended printable side of the paper. This information is usually indicated on the paper package.
- Do not use paper that has been cut or trimmed by hand.
- Do not mix paper sizes, types, or weights in the same tray; mixing results in jams.
- Do not use coated papers unless they are specifically designed for electrophotographic printing.

### PAPER CHARACTERISTICS

The following paper characteristics affect print quality and reliability. Consider these factors before printing on them.

#### Weight

The tray can feed paper weights from 60 to 105g/m<sup>2</sup> (16 to 28 lb) grain long paper. Paper lighter than 60g/m<sup>2</sup> (16lb) may not be stiff enough to feed properly, and may cause jams.

#### Curl

Curl is the tendency for paper to curl at its edges. Excessive curl can cause paper feeding problems. Curl can occur after the paper passes through the printer, where it is exposed to high temperatures. Storing paper unwrapped in hot, humid, cold, or dry conditions can contribute to paper curling before printing and can cause feeding problems.

#### Smoothness

Paper smoothness directly affects print quality. If paper is too rough, toner cannot fuse to it properly. If paper is too smooth, it can cause paper feeding or print quality issues. We recommend the use of paper with 50 Sheffield points.

#### Moisture content

The amount of moisture in paper affects both print quality and the printer ability to feed the paper correctly. Leave paper in its original wrapper until you use it. Exposure of paper to moisture changes can degrade its performance.

Store paper in its original wrapper in the same environment as the printer for 24 to 48 hours before printing. Extend the time several days if the storage or transportation environment is very different from the printer environment.

Thick paper may also require a longer conditioning period.

### Grain direction

Grain refers to the alignment of the paper fibers in a sheet of paper. Grain is either *grain long*, running the length of the paper, or *grain short*, running the width of the paper.

For 60–105g/m<sup>2</sup> (16–28-lb) paper, grain long paper is recommended.

### Fiber content

Most high-quality xerographic paper is made from 100% chemically treated pulped wood. This content provides the paper with a high degree of stability, resulting in fewer paper feeding problems and better print quality. Paper containing fibers such as cotton can negatively affect paper handling.

### UNACCEPTABLE PAPER

The following paper types are not recommended for use with the printer:

- Chemically treated papers used to make copies without carbon paper, also known as carbonless papers, carbonless copy paper (CCP), or no carbon required (NCR) paper
- Preprinted papers with chemicals that may contaminate the printer
- Preprinted papers that can be affected by the temperature in the printer fuser
- Preprinted papers that require a registration (the precise print location on the page) greater than  $\pm 2.3$  mm ( $\pm 0.9$  in.), such as optical character recognition (OCR) forms

In some cases, registration can be adjusted with a software application to successfully print on these forms.

- Coated papers (erasable bond), synthetic papers, thermal papers
- Rough-edged, rough or heavily textured surface papers, or curled papers
- Recycled papers that fail EN12281:2002 (European)
- Paper weighing less than 60 g/m<sup>2</sup> (16 lb)
- Multiple-part forms or documents

### SELECTING PREPRINTED FORMS AND LETTERHEAD

- Use grain long paper.
- Use only forms and letterhead printed using an offset lithographic or engraved printing process.
- Avoid paper with rough or heavily textured surfaces.
- Use inks that are not affected by the resin in toner. Inks that are oxidation-set or oil-based generally meet these requirements; latex inks might not.
- Print samples on preprinted forms and letterheads considered for use before buying large quantities. This action determines whether the ink in the preprinted form or letterhead affects print quality.
- When in doubt, contact your paper supplier.
- When printing on letterhead, load the paper in the proper orientation for your printer. For more information, see the Paper and Specialty Media Guide.

## STORING PAPER

Use these paper storage guidelines to help avoid jams and uneven print quality:

- Store paper in its original wrapper in the same environment as the printer for 24 to 48 hours before printing.
- Extend the time several days if the storage or transportation environment is very different from the printer environment. Thick paper may also require a longer conditioning period.
- For best results, store paper where the temperature is 21°C (70°F) and the relative humidity is 40 percent.
- Most label manufacturers recommend printing in a temperature range of 18–24°C (65–75°F) with relative humidity between 40 and 60 percent.
- Store paper in cartons, on a pallet or shelf, rather than on the floor.
- Store individual packages on a flat surface.
- Do not store anything on top of individual paper packages.
- Take paper out of the carton or wrapper only when you are ready to load it in the printer. The carton and wrapper help keep the paper clean, dry, and flat.

## SUPPORTED PAPER SIZES

- Paper less than 210 mm (8.3 in.) wide always prints at reduced speed.
- Use the manual feeder when printing on paper less than 105 mm (4.1 in.) wide.
- The minimum paper dimension supported for two-sided printing is 210 x 279.4 mm (8.3 x 11 in.).
- The maximum paper length supported by the scanner glass is 297 mm (11.7 in.).
- For two-sided printing on letter-, legal-, Oficio-, or folio-size paper, make sure that the paper size setting in the duplex unit is set to Letter.

PAPER SIZE	250-SHEET TRAY	MANUAL FEEDER	TWO-SIDED PRINTING	SCANNER GLASS	AUTOMATIC DOCUMENT FEEDER
<b>A4</b> 210 x 297 mm (8.27 x 11.7 in.)	✓	✓	✓	✓	✓
<b>A5 (short edge feed)</b> 148 x 210 mm (5.83 x 8.27 in.)	✓	✓	X	✓	✓
<b>A5 (long edge feed)</b> 210 x 148 mm (8.27 x 5.83 in.)	✓	✓	X	✓	✓
<b>A6</b> 105 x 148 mm	✓	✓	X	✓	✓

PAPER SIZE	250-SHEET TRAY	MANUAL FEEDER	TWO-SIDED PRINTING	SCANNER GLASS	AUTOMATIC DOCUMENT FEEDER
(4.13 x 5.83 in.)					
<b>JIS B5</b> 182 x 257 mm (7.17 x 10.1 in.)	✓	✓	X	✓	✓
<b>Oficio (Mexico)</b> 215.9 x 340.4 mm (8.5 x 13.4 in.)	✓	✓	✓	X	✓
<b>Hagaki</b> 100 x 148 mm (3.94 x 5.83 in.)	X	✓	X	✓	X
<b>Statement</b> 139.7 x 215.9 mm (5.5 x 8.5 in.)	✓	✓	X	✓	✓
<b>Executive</b> 184.2 x 266.7 mm (7.25 x 10.5 in.)	✓	✓	X	✓	✓
<b>Letter</b> 215.9 x 279.4 mm (8.5 x 11 in.)	✓	✓	✓	✓	✓
<b>Legal</b> 215.9 x 355.6 mm (8.5 x 14 in.)	✓	✓	✓	X	✓
<b>Folio</b> 215.9 x 330.2 mm (8.5 x 13 in.)	✓	✓	✓	X	✓
<b>Universal</b> 98 x 148 mm (3.9 x 5.8 in.) to 216 x 356 mm (8.5 x 14 in.)	X	✓	X	✓	✓
<b>Universal</b> 105 x 148 mm (4.1 x 5.8 in.) to 216 x 356 mm (8.5 x 14 in.)	✓	✓	X	✓	✓

PAPER SIZE	250-SHEET TRAY	MANUAL FEEDER	TWO-SIDED PRINTING	SCANNER GLASS	AUTOMATIC DOCUMENT FEEDER
<b>7 3/4 Envelope (Monarch)</b> 98.4 x 190.5 mm (3.875 x 7.5 in.)	X	✓	X	✓	X
<b>9 Envelope</b> 98.4 x 225.4 mm (3.875 x 8.9 in.)	X	✓	X	✓	X
<b>10 Envelope</b> 104.8 x 241.3 mm (4.12 x 9.5 in.)	X	✓	X	✓	X
<b>DL Envelope</b> 110 x 220 mm (4.33 x 8.66 in.)	X	✓	X	✓	X
<b>C5 Envelope</b> 162 x 229 mm (6.38 x 9.01 in.)	X	✓	X	✓	X
<b>B5 Envelope</b> 176 x 250 mm (6.93 x 9.84 in.)	X	✓	X	✓	X
<b>Universal Envelope</b> 98.4 x 162 mm (3.87 x 6.38 in.) to 176 x 250 mm (6.93 x 9.84 in.)	X	✓	X	✓	X

## SUPPORTED PAPER TYPES



Note: Labels, envelopes, and card stock always print at reduced speed.

PAPER TYPE	250-SHEET TRAY	MANUAL FEEDER	TWO-SIDED PRINTING	AUTOMATIC DOCUMENT FEEDER
<b>Plain paper</b>	✓	✓	✓	✓
<b>Card stock</b>	X	✓	X	X
<b>Labels</b>	X	✓	X	X

PAPER TYPE	250-SHEET TRAY	MANUAL FEEDER	TWO-SIDED PRINTING	AUTOMATIC DOCUMENT FEEDER
Bond	✓	✓	✓	✓
Envelope	X	✓	X	X
Letterhead	✓	✓	✓	✓
Preprinted	✓	✓	✓	✓
Colored paper	✓	✓	✓	✓
Light	✓	✓	✓	✓
Heavy	✓	✓	✓	✓
Recycled	✓	✓	✓	✓

#### SUPPORTED PAPER WEIGHTS

250-SHEET TRAY	MANUAL FEEDER	TWO-SIDED PRINTING	AUTOMATIC DOCUMENT FEEDER
60–105g/m <sup>2</sup> (16–28-lb bond)	60–200g/m <sup>2</sup> (16–54-lb bond)	60–105g/m <sup>2</sup> (16–28-lb bond)	60–105g/m <sup>2</sup> (16–28-lb bond)

[Learn about the printer](#)



## Set up, install, and configure

This chapter contains:

Selecting a location for the printer .....	34
Attaching cables .....	36
Finding the IP Address of the Printer .....	38
Setting up the printer to fax .....	39
Configuring Device Sounds Settings .....	45
Configuring the Email SMTP Settings .....	46
Loading paper and specialty media .....	55
Installing and updating software, drivers, and firmware .....	58
Xerox® Easy Assist App .....	63
Networking .....	67
Printing the Menu Settings Page .....	71

## Selecting a location for the printer

- Leave enough room to open trays, covers, and doors and to install hardware options.
- Set up the printer near an electrical outlet.




**Warning:** To avoid the risk of fire or electrical shock, connect the power cord to an appropriately rated and properly grounded electrical outlet that is near the product and easily accessible.



**CAUTION—SHOCK HAZARD:** To avoid the risk of electrical shock, do not place or use this product near water or wet locations.

- Make sure that airflow in the room meets the latest revision of the ASHRAE 62 standard or the CEN Technical Committee 156 standard.
- Provide a flat, sturdy, and stable surface.
- Keep the printer:
  - Clean, dry, and free of dust
  - Away from stray staples and paper clips
  - Away from the direct airflow of air conditioners, heaters, or ventilators
  - Free from direct sunlight and humidity extremes
- Observe the recommended temperatures and avoid fluctuations.
  - Ambient temperature: 10 to 32.2°C (50 to 90°F)
  - Storage temperature: -40 to 43.3°C (-40 to 110°F)
- Allow the following recommended amount of space around the printer for proper ventilation:




1. Top: 360 mm (14 in.)
2. Rear: 260 mm (10 in.)
3. Right side: 200 mm (8 in.)


4. Front: 550 mm (22 in.)


The minimum space needed in front of the printer is 76 mm (3 in.).


5. Left side: 200 mm (8 in.)


Attaching cables


**CAUTION—SHOCK HAZARD:** To avoid the risk of electrical shock, do not set up this product or make any electrical or cabling connections, such as the power cord, fax feature, or telephone, during a lightning storm.

**CAUTION—POTENTIAL INJURY:** To avoid the risk of fire or electrical shock, connect the power cord to an appropriately rated and properly grounded electrical outlet that is near the product and easily accessible.

**CAUTION—POTENTIAL INJURY:** To avoid the risk of fire or electrical shock, use only the power cord provided with this product or the manufacturer's authorized replacement.

**CAUTION—POTENTIAL INJURY:** To reduce the risk of fire, use only a 26 AWG or larger telecommunications (RJ-11) cord when connecting this product to the public switched telephone network. For users in Australia, the cord must be approved by the Australian Communications and Media Authority.

**Warning:** To avoid loss of data or printer malfunction, do not touch the USB cable, any wireless network adapter, or the printer in the areas shown while actively printing.



NUMBER	PRINTER PORT	FUNCTION
1	EXT port	Connect more devices (telephone or answering machine) to the printer and the telephone line. Use this port if you do not have a dedicated fax line for the printer and if this connection method is supported in your country or region.
2	LINE port	Connect the printer to an active telephone line through a standard wall jack (RJ-11), DSL filter, or VoIP adapter, or any other adapter that allows you to access the telephone line to send and receive faxes.

NUMBER	PRINTER PORT	FUNCTION
3	Ethernet port	Connect the printer to a network.
4	USB printer port	Connect the printer to a computer.
5	Power cord socket	Connect the printer to a properly grounded electrical outlet.

## Finding the IP Address of the Printer

To view the IP address of the printer, open the Home Screen. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.

If you are using a proxy server, temporarily disable it to load the Web page correctly.

## Setting up the printer to fax

### SETTING UP THE FAX FUNCTION

- Some connection methods are applicable only in some countries or regions.
- If the fax function is enabled and not fully set up, then the indicator light may blink red.
- If you do not have a TCP/IP environment, then use the control panel to set up fax.



**Warning:** To avoid loss of data or printer malfunction, do not touch cables or the printer in the area shown while actively sending or receiving a fax.



### Using the fax setup wizard in the printer

- The setup wizard is available only if analog fax is not set up.
  - This wizard only sets up the analog fax. To setup other fax modes, go to **Settings > Fax > Fax Setup**.
  - These instructions apply only to some printer models.
  - Before using the wizard, make sure that the printer firmware is updated. For more information, see [Using the fax setup wizard in the printer](#).
1. From the home screen, touch **Fax**.
  2. Touch **Set up now**.
  3. Type the fax name, and then touch **Next**.
  4. Enter the fax number and then touch **Done**.


### Using the Settings menu in the printer


1. From the control panel, navigate to:  
**Settings > Fax > Fax Setup > General Fax settings**  
 For non-touch-screen printer models, press **OK** to navigate through the settings.
2. Configure the settings.


## Using the Embedded Web Server

1. Open a web browser, and then type the printer IP address in the address field.
  - View the printer IP address on the home screen. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.
  - If you are using a proxy server, then temporarily disable it to load the web page correctly.
2. Click **Settings > Fax > Fax Setup > General Fax Settings**.
3. Configure the settings.
4. Apply the changes.


## SETTING UP FAX USING A STANDARD TELEPHONE LINE

 **CAUTION—SHOCK HAZARD:** To avoid the risk of electrical shock, do not set up this product or make any electrical or cabling connections, such as the power cord, fax feature, or telephone, during a lightning storm.

 **CAUTION—SHOCK HAZARD:** To avoid the risk of electrical shock, do not use the fax feature during a lightning storm.

 **CAUTION—POTENTIAL INJURY:** To reduce the risk of fire, use only a 26 AWG or larger telecommunications (RJ-11) cord when connecting this product to the public switched telephone network. For users in Australia, the cord must be approved by the Australian Communications and Media Authority.

### Setup 1: Printer is connected to a dedicated fax line




1. Connect one end of the telephone cable to the line port of the printer.
2. Connect the other end of the cable to an active analog wall jack.




- You can set the printer to receive faxes automatically (set Auto Answer to **On**) or manually (set Auto Answer to **Off**).
- If you want to receive faxes automatically, then set the printer to pick up on a specified number of rings.

## Setup 2: Printer is sharing the line with an answering machine

 **Note:** If you subscribe to a distinctive ring service, then make sure that you set the correct ring pattern for the printer. Otherwise, the printer does not receive faxes even if you have set it to receive faxes automatically.

### Connected to different wall jacks



1. Connect one end of the telephone cable to the line port of the printer.
  2. Connect the other end of the cable to an active analog wall jack.
- If you have only one telephone number on your line, then set the printer to receive faxes automatically.
  - Set the printer to pick up calls two rings after the answering machine. For example, if the answering machine picks up calls after four rings, then set the printer Rings to Answer setting to **6**.

## SETTING UP FAX IN COUNTRIES OR REGIONS WITH DIFFERENT TELEPHONE WALL JACKS AND PLUGS



**CAUTION—SHOCK HAZARD:** To avoid the risk of electrical shock, do not set up this product or make any electrical or cabling connections, such as the power cord, fax feature, or telephone, during a lightning storm.




**CAUTION—SHOCK HAZARD:** To avoid the risk of electrical shock, do not use the fax feature during a lightning storm.




**Warning:** To reduce the risk of fire, use only a 26 AWG or larger telecommunications (RJ-11) cord when connecting this product to the public switched telephone network. For users in Australia, the cord must be approved by the Australian Communications and Media Authority.

The standard wall jack adopted by most countries or regions is RJ11. If the wall jack or equipment in your facility is not compatible with this type of connection, then use a telephone adapter. An adapter for your country or region may not come with your printer, and you may need to purchase it separately.

There may be an adapter plug installed in the telephone port of the printer. Do not remove the adapter plug from the telephone port of the printer if you are connecting to a serial or cascaded telephone system.




### Connecting the printer to a non-RJ11 wall jack



1. Connect one end of the telephone cable to the line port of the printer.
2. Connect the other end of the cable to the RJ11 adapter, and then connect the adapter to the wall jack.
3. If you want to connect another device with a non-RJ11 connector to the same wall jack, then connect it directly to the telephone adapter.

## Connecting the printer to a wall jack in Germany

The German wall jack has two kinds of ports. The N ports are for fax machines, modems, and answering machines. The F port is for telephones. Connect the printer to any of the N ports.



1. Connect one end of the telephone cable to the line port of the printer.
2. Connect the other end of the cable to the RJ11 adapter, and then connect the adapter to an N port.
3. If you want to connect a telephone and answering machine to the same wall jack, then connect the devices as shown.

## CONNECTING TO A DISTINCTIVE RING SERVICE

A distinctive ring service lets you have multiple telephone numbers on one telephone line. Each telephone number is assigned a different ring pattern.

1. From the control panel, navigate to:  
**Settings > Fax > Fax Setup > Fax Receive Settings > Admin Controls > Answer On**

For non-touch-screen printer models, press **OK** to navigate through the settings.

2. Select a ring pattern.
3. Apply the changes.

## SETTING THE FAX DATE AND TIME

1. From the control panel, navigate to:  
**Settings > Device > Preferences > Date and Time > Configure**

For non-touch-screen printer models, press **OK** to navigate through the settings.

2. Configure the settings.

## CONFIGURING DAYLIGHT SAVING TIME

1. From the home screen, navigate to **Settings > Device > Preferences > Date and Time > Configure**.

For non-touch-screen printer models, press **OK** to navigate through the settings.

Set up, install, and configure

2. In the Time Zone menu, select **(UTC+user) Custom**.
3. In the UTC Offset menu, set the daylight saving time offset.

## CONFIGURING THE FAX SPEAKER SETTINGS

1. From the control panel, navigate to:

**Settings > Fax > Fax Setup > Speaker Settings**

For non-touch-screen printer models, press  to navigate through the settings.

2. Do the following:
  - Set Speaker Mode to **Always On**.
  - Set Speaker Volume to **High**.
  - Enable Ringer Volume.

## Configuring Device Sounds Settings



Note: The Device Sounds icon is available only in some printer models.

1. From the control panel, touch the **Device Sounds** icon.

The Status/Supplies screen appears.

2. At the Status/Supplies screen, touch **Device Sounds: On**.

The Device Sounds screen appears.

3. From the Device Sounds screen, you can enable or disable the following sound settings:

- Mute All Sounds
- Button Feedback
- Access Device Feedback
- Volume
- ADF Loaded Beep
- Alarm Control
- Cartridge Alarm
- Speaker Mode
- Ringer Volume

## Configuring the Email SMTP Settings

Configure the Simple Mail Transfer Protocol (SMTP) settings to send a scanned document through e-mail. The settings vary with each service provider. For more information, refer to [Email Service Providers](#).

Before you begin, make sure that the printer is connected to a network and that the network is connected to the Internet.

### USING THE EMAIL SETUP WIZARD IN THE PRINTER

- Before using the wizard, make sure that the printer firmware is updated. For more information, see [Updating Software](#).
- For non-touch-screen printer models, press **OK** to navigate through the settings.
- 1. From the home screen, touch **E-mail**.
- 2. Touch **Set up now**, and then type your e-mail address.
- 3. Type the password.
  - Depending on your e-mail service provider, type your account password, app password, or authentication password. For more information on the password, refer to [Email Service Providers](#), and then look for Device Password.
  - If your provider is not listed, then contact your provider and ask for the Primary SMTP Gateway, Primary SMTP Gateway Port, Use SSL/TLS, and SMTP Server Authentication settings.
- 4. Touch **OK**.

### USING THE SETTINGS MENU IN THE PRINTER

1. From the home screen, touch **Settings > E-mail > E-mail Setup**.
2. Configure the settings.
  - For more information on the password, refer to [Email Service Providers](#).
  - For e-mail service providers that are not on the list, contact your provider and ask for the settings.
  - For non-touch-screen printer models, press **OK** to navigate through the settings.

### USING THE EMBEDDED WEB SERVER

1. Open a web browser, and then type the printer IP address in the address field.
  - a. To view the printer IP address, go to the printer home screen.  
The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.
  - b. If you are using a proxy server, then temporarily disable it to load the web page correctly.
2. Click **Settings > E-mail**.
3. From the E-mail Setup section, configure the settings.
4. Click **Save**.
  - a. For more information on the password, refer to [Email Service Providers](#).

- b. For e-mail service providers that are not on the list, contact your provider and ask for the settings.

## EMAIL SERVICE PROVIDERS

To determine the SMTP settings of your email service provider, use the following tables.





Note: For each Email Service Provider, the port number can be different according to the Primary SMTP Gateway.

### Gmail®




Note: Make sure that two-step verification is enabled on your Google account.

To enable two-step verification, go to the [Google Account Security](#) page, log in to your account, then from the Signing in to Google section, click **2-Step Verification**.

SETTING	VALUE
Primary SMTP Gateway	smtp.gmail.com
Primary SMTP Gateway Port	587  Note: The port number can be different according to the Primary SMTP Gateway. For example, it can be 25, 465 or 587.
Use SSL/TLS	Required
Require Trusted Certificate	Disabled
Reply Address	Your email address
SMTP Server Authentication	Login/Plain
Device-Initiated E-mail	Use Device SMTP Credentials
Device UserID	Your email address
Device Password	App password  Note: To create an app password, go to the <a href="#">Google Account Security</a> page, log in to your account, and from the Signing in to Google section, click <b>App passwords</b> .

### Yahoo!® Mail

SETTING	VALUE
Primary SMTP Gateway	smtp.mail.yahoo.com
Primary SMTP Gateway Port	587
Use SSL/TLS	Required

SETTING	VALUE
Require Trusted Certificate	Disabled
Reply Address	Your email address
SMTP Server Authentication	Login/Plain
Device-Initiated E-mail	Use Device SMTP Credentials
Device UserID	Your email address
Device Password	App password  Note: To create an app password, go to the <a href="#">Yahoo Account Security</a> page, log in to your account, and then click <b>Generate app password</b>

### Outlook Live


These settings apply to outlook.com and hotmail.com email domains.

SETTING	VALUE
Primary SMTP Gateway	smtp.office365.com
Primary SMTP Gateway Port	587
Use SSL/TLS	Required
Require Trusted Certificate	Disabled
Reply Address	Your email address
SMTP Server Authentication	Login/Plain
Device-Initiated E-mail	Use Device SMTP Credentials
Device UserID	Your email address
Device Password	Account password or app password <ul style="list-style-type: none"> <li>For accounts with two-step verification disabled, use your account password.</li> <li>For accounts with two-step verification enabled, use an app password. To create an app password, go to the <a href="#">Outlook Live Account Management</a> page, then log in to your account.</li> </ul>

### AOL Mail

SETTING	VALUE
Primary SMTP Gateway	smtp.aol.com
Primary SMTP Gateway Port	587




SETTING	VALUE
Use SSL/TLS	Required
Require Trusted Certificate	Disabled
Reply Address	Your email address
SMTP Server Authentication	Login/Plain
Device-Initiated E-mail	Use Device SMTP Credentials
Device UserID	Your email address
Device Password	App password  Note: To create an app password, go to the <b>AOL Account Security</b> page, log in to your account, then click <b>Generate app password</b> .

### iCloud Mail



Note: Make sure that the two-step verification is enabled on your account.

SETTING	VALUE
Primary SMTP Gateway	smtp.mail.me.com
Primary SMTP Gateway Port	587
Use SSL/TLS	Required
Require Trusted Certificate	Disabled
Reply Address	Your email address
SMTP Server Authentication	Login/Plain
Device-Initiated E-mail	Use Device SMTP Credentials
Device UserID	Your email address
Device Password	App password  Note: To create an app password, go to the <b>iCloud Account Management</b> page, log in to your account, then from the Security section, click <b>Generate Password</b> .

### Comcast Mail

SETTING	VALUE
Primary SMTP Gateway	smtp.comcast.net
Primary SMTP Gateway Port	587

SETTING	VALUE
Use SSL/TLS	Required
Require Trusted Certificate	Disabled
Reply Address	Your email address
SMTP Server Authentication	Login/Plain
Device-Initiated Email	Use Device SMTP Credentials
Device UserID	Your email address
Device Password	Account password

**Mail.com**

SETTING	VALUE
Primary SMTP Gateway	smtp.mail.com
Primary SMTP Gateway Port	587
Use SSL/TLS	Required
Require Trusted Certificate	Disabled
Reply Address	Your email address
SMTP Server Authentication	Login/Plain
Device-Initiated E-mail	Use Device SMTP Credentials
Device UserID	Your email address
Device Password	Account password

**Zoho Mail**

SETTING	VALUE
Primary SMTP Gateway	smtp.zoho.com
Primary SMTP Gateway Port	587
Use SSL/TLS	Required
Require Trusted Certificate	Disabled
Reply Address	Your email address
SMTP Server Authentication	Login/Plain
Device-Initiated E-mail	Use Device SMTP Credentials


SETTING	VALUE
Device UserID	Your email address
Device Password	<p>Account password or app password</p> <ul style="list-style-type: none"> <li>For accounts with two-step verification disabled, use your account password.</li> <li>For accounts with two-step verification enabled, use an app password. To create an app password, go to the <a href="#">Zoho Mail Account Security</a> page, log in to your account, then from the Application-Specific Passwords section, click <b>Generate New Password</b>.</li> </ul>

## QQ Mail



Note: Make sure that the SMTP service is enabled on your account.

To enable the service, from the QQ Mail home page, click **Settings > Account**, then from the POP3/IMAP/SMTP/Exchange/CardDAV/CalDAV Service section, enable either **POP3/SMTP service** or **IMAP/SMTP service**.


SETTING	VALUE
Primary SMTP Gateway	smtp.qq.com
Primary SMTP Gateway Port	587
Use SSL/TLS	Required
Require Trusted Certificate	Disabled
Reply Address	Your email address
SMTP Server Authentication	Login/Plain
Device-Initiated E-mail	Use Device SMTP Credentials
Device UserID	Your email address
Device Password	<p>Authorization code</p> <p> Note: To generate an authorization code, from the QQ Mail home page, click <b>Settings &gt; Account</b>, then from the POP3/IMAP/SMTP/Exchange/CardDAV/CalDAV Service section, click <b>Generate authorization code</b></p>

## NetEase Mail (mail.163.com)



Note: Make sure that the SMTP service is enabled on your account.


To enable the service, from the NetEase Mail home page, click **Settings > POP3/SMTP/IMAP**, and then enable either **IMAP/SMTP service** or **POP3/SMTP service**.

SETTING	VALUE
Primary SMTP Gateway	smtp.163.com
Primary SMTP Gateway Port	465
Use SSL/TLS	Required
Require Trusted Certificate	Disabled
Reply Address	Your email address
SMTP Server Authentication	Login/Plain
Device-Initiated Email	Use Device SMTP Credentials
Device UserID	Your email address
Device Password	Authorization password  Note: The authorization password is provided when IMAP/SMTP service or POP3/SMTP service is enabled.

**NetEase Mail (mail.126.com)**

Note: Make sure that the SMTP service is enabled on your account.

To enable the service, from the NetEase Mail home page, click **Settings > POP3/SMTP/IMAP**, then enable either **IMAP/SMTP service** or **POP3/SMTP service**.


SETTING	VALUE
Primary SMTP Gateway	smtp.126.com
Primary SMTP Gateway Port	465
Use SSL/TLS	Required
Require Trusted Certificate	Disabled
Reply Address	Your email address
SMTP Server Authentication	Login/Plain
Device-Initiated Email	Use Device SMTP Credentials
Device UserID	Your email address
Device Password	Authorization password  Note: The authorization password is provided when IMAP/SMTP service or POP3/SMTP service is enabled.

### NetEase Mail (mail.yeah.net)



Note: Make sure that the SMTP service is enabled on your account.

To enable the service, from the NetEase Mail home page, click **Settings > POP3/SMTP/IMAP**, and then enable either **IMAP/SMTP service** or **POP3/SMTP service**.

SETTING	VALUE
Primary SMTP Gateway	smtp.yeah.net
Primary SMTP Gateway Port	465
Use SSL/TLS	Required
Require Trusted Certificate	Disabled
Reply Address	Your email address
SMTP Server Authentication	Login/Plain
Device-Initiated Email	Use Device SMTP Credentials
Device UserID	Your email address
Device Password	Authorization password
	 Note: The authorization password is provided when IMAP/SMTP service or POP3/SMTP service is enabled.


### Sohu Mail



Note: Make sure that the SMTP service is enabled on your account.

To enable the service, from the Sohu Mail home page, click **Options > Settings > POP3/SMTP/IMAP**, and then enable either **IMAP/SMTP service** or **POP3/SMTP service**.

SETTING	VALUE
Primary SMTP Gateway	smtp.sohu.com
Primary SMTP Gateway Port	465
Use SSL/TLS	Required
Require Trusted Certificate	Disabled
Reply Address	Your email address
SMTP Server Authentication	Login/Plain
Device-Initiated Email	Use Device SMTP Credentials


SETTING	VALUE
Device UserID	Your email address
Device Password	Independent password  Note: The independent password is provided when IMAP/SMTP service or POP3/SMTP service is enabled.

## Sina Mail



Note: Make sure that the POP3/SMTP service is enabled on your account.

To enable the service, from the Sina Mail home page, click **Settings > More settings > User-end POP/IMAP/SMTP**, and then enable **POP3/SMTP service**.

SETTING	VALUE
Primary SMTP Gateway	smtp.sina.com
Primary SMTP Gateway Port	587
Use SSL/TLS	Required
Require Trusted Certificate	Disabled
Reply Address	Your email address
SMTP Server Authentication	Login/Plain
Device-Initiated Email	Use Device SMTP Credentials
Device UserID	Your email address
Device Password	Authorization code  Note: To create an authorization code, from the email home page, click <b>Settings &gt; More settings &gt; User-end POP/IMAP/SMTP</b> , and then enable <b>Authorization code status</b> .

- If you encounter errors using the settings provided, then contact your email service provider.
- For email service providers that are not on the list, contact your provider and ask for the settings.

## Loading paper and specialty media

### SETTING THE PAPER SIZE AND TYPE


1. From the control panel, navigate to **Settings****Paper****Tray Configuration****Paper Size/Type**, then select a paper source.  
For non-touch-screen printer models, to navigate through the settings, press **OK**.
2. Set the paper size and type.
  - For two-sided printing on A4-size paper, make sure that the paper size setting in the duplex unit is set to A4.
  - For two-sided printing on letter-, legal-, Oficio-, or folio-size paper, make sure that the paper size setting in the duplex unit is set to Letter.

### CONFIGURING UNIVERSAL PAPER SETTINGS


1. From the control panel, navigate to:  
**Settings > Paper > Media Configuration > Universal Setup**  
For non-touch-screen printer models, press **OK** to navigate through the settings.
2. Configure the settings.

### LOADING THE TRAY


1. Remove the tray.




2. Adjust the paper guides to match the size of the paper that you are loading.



3. Flex, fan, and align the paper edges before loading.



4. Load the paper stack with the printable side facedown, and then make sure that the side guides fit snugly against the paper.



- Load letterhead facedown with the top edge of the sheet toward the front of the tray for one-sided printing.
- Load letterhead faceup with the bottom edge of the sheet toward the front of the tray for two-sided printing.
- Do not slide paper into the tray.
- To avoid paper jams, make sure that the stack height is below the maximum paper fill indicator.




5. Insert the tray.


If necessary, set the paper size and paper type from the control panel to match the paper loaded.

### LOADING THE MANUAL FEEDER

1. Open the manual feeder.



2. Adjust the guide to match the size of the paper that you are loading.



3. Load a sheet of paper with the printable side faceup.
  - Load letterhead with the printable side faceup and the top edge entering the printer first for one-sided printing.
  - Load letterhead with the printable side facedown and the top edge entering the printer last for two-sided printing.
  - Load envelope with the flap side down and against the left side of the paper guide.



**Warning:** To avoid paper jams, do not force paper into the manual feeder.

## Installing and updating software, drivers, and firmware

### INSTALLING THE SOFTWARE

Before you install the print driver software, verify that the printer is plugged in, powered on, connected correctly, and has a valid IP address. The IP address usually appears in the upper right corner of the control panel.

To view the IP address of the printer, refer to [Finding the IP Address of the Printer](#).



Note: If the *Software and Documentation disc* is not available, download the latest drivers from [www.xerox.com/drivers](http://www.xerox.com/drivers).

### Operating System Requirements

- Windows 7 SP1, Windows 8, Windows 8.1, Windows 10, Windows 11, Windows Server 2008 R2, Windows Server 2012, Windows Server 2016, Windows Server 2019, and Windows Server 2022.
- MacOS version 10.14 and later.
- UNIX and Linux: Your printer supports connection to various UNIX platforms through the network interface.

### Installing the Print Drivers for a Windows Network Printer

1. Insert the *Software and Documentation disc* into the appropriate drive on your computer. If the installer does not start automatically, navigate to the drive, then double-click the **Setup.exe** installer file.
2. Click **Xerox Smart Start — Driver Installer (Recommended)**.
3. At the License Agreement, click **Agree**.
4. From the list of discovered printers, select your printer.  
When you install print drivers for a network printer, if your printer does not appear in the list, click **Don't See Your Printer?**, then enter the IP address for your printer.

To view the IP address of your printer, refer to [Finding the IP Address of the Printer](#).

5. Click **Quick Install**.

A message appears that confirms that the installation is successful.

6. To complete the installation and close the Installer window, click **Done**.

### Installing the Windows Print Driver .zip File

You can download print drivers from Xerox.com in a .zip file, then use the Windows Add Printer Wizard to install the print drivers on your computer.

To install the print driver from the .zip file:

1. Download, then extract the required .zip file to a local directory on your computer.
2. At your computer, open the **Control Panel**, then select **Devices and Printers > Add a Printer**.
3. Click **The printer that I want isn't listed**, then click **Add a local printer or network printer with manual settings**.

4. To use a previously established port, select **Use an existing port**, then from the list, select a Standard TCP/IP Port.
5. To create a Standard TCP/IP port:
  - a. Select **Create a New Port**.
  - b. For Type of port, select **Standard TCP/IP Port**, then click **Next**.
  - c. In the Hostname or IP address field, type the printer IP address or host name.
  - d. To disable the feature, clear the check box for **Query the printer and automatically select the driver to use**, then click **Next**.
6. Click **Have Disk**.
7. Click **Browse**. Browse to, then select the driver.inf file for your printer. Click **Open**.
8. Select your printer model, then click **Next**.
9. If a prompt appears because the print driver was installed previously, click **Use the driver that is currently installed (recommended)**.
10. In the Printer name field, type a name for your printer.
11. To install the print driver, click **Next**.
12. If needed, set the printer as the default printer.



Note: Before you select **Share Printer**, contact your system administrator.

13. To send a test page to the printer, click **Print a test page**.
14. Click **Finish**.

### Installing the Print Drivers for a Windows USB Printer

1. Connect the B end of a standard A/B USB 2.0 or USB 3.0 cable to the USB Port on the back of the printer.
2. Connect the A end of the USB cable to the USB port on the computer.
3. If the Windows Found New Hardware Wizard appears, click **cancel**.
4. Insert the *Software and Documentation disc* into the appropriate drive on your computer. If the installer does not start automatically, navigate to the drive, then double-click the **Setup.exe** installer file.
5. Click **Xerox Smart Start — Driver Installer (Recommended)**.
6. At the License Agreement, click **Agree**.
7. From the list of discovered printers, select your printer, then click **Quick Install**.  
A message appears that confirms that the installation is successful.
8. To complete the installation and close the Installer window, click **Done**.

### Installing the Printer as a Web Service on Devices

Web Services on Devices (WSD) allows a client to discover and access a remote device and its associated services across a network. WSD supports device discovery, control, and use.

### Installing a WSD Printer Using the Add Device Wizard

1. At your computer, click **Start**, then select **Printers and Scanners**.
2. To add the required printer, click **Add a Printer or Scanner**.
3. In the list of available devices, select the device that you want to use, then click **Next**.



Note: If the printer that you want to use does not appear in the list, click **Cancel**. To add the printer manually, use the IP address of the printer. For details, refer to [Installing the Windows Print Driver .zip File](#).

4. Click **Close**.

### Installing the Drivers and Utilities for MacOS

1. Download the latest print driver from <https://www.xerox.com/office/drivers>.
2. Open the Xerox® Print Drivers 5.xx.x.dmg or .pkg as needed for your printer.
3. To run Xerox® Print Drivers 5.xx.x.dmg or .pkg, double-click the appropriate file name.
4. When prompted, click **Continue**.
5. To accept the license agreement, click **I Agree**.
6. To accept the current installation location, click **Install**, or select another location for the installation files, then click **Install**.
7. If prompted, enter your password, then click **OK**.
8. From the list of discovered printers, select your printer, then click **Next**.
9. If your printer does not appear in the list of discovered printers:
  - a. Click the **Network Printer Icon**.
  - b. Type the IP address of your printer, then click **Continue**.
  - c. Select your printer in the list of discovered printers, then click **Continue**.
10. If your printer was not detected, verify that the printer is powered on and that the Ethernet or USB cable is connected properly.
11. To accept the print queue message, click **OK**.
12. Select or clear the **Set Printer as Default** and **Print a Test Page** check boxes.
13. Click **Continue**, then click **Close**.

### Adding the Printer for MacOS

For networking, set up your printer using Bonjour® (mDNS), or for an LPD, LPR connection, connect using the IP address of your printer. For a non-network printer, create a desktop USB connection.

For more information, go to the Online Support Assistant at: <https://www.xerox.com/support>.

### Adding the Printer Using Bonjour

To add the printer using Bonjour®:

1. From the computer Applications folder or from the dock, open **System Preferences**.

2. Click **Printers & Scanners**.

The list of printers appears on the left of the window.

3. For the list of printers, click the Plus icon (+).
4. At the top of the window, click the **Default** icon.
5. Select your printer from the list, then click **Add**.



Note: If your printer is not detected, verify that the printer is powered on and that the Ethernet cable is connected properly.

### Adding the Printer by Specifying the IP Address

To add the printer by specifying the IP address:

1. From the computer Applications folder or from the dock, open **System Preferences**.
2. Click **Printers & Scanners**.  
The list of printers appears on the left of the window.
3. In the list of printers, click the Plus (+) icon.
4. Click **IP**.
5. From the Protocol list, select the protocol.
6. In the Address field, enter the IP address of the printer.
7. In the Name field, enter a name for the printer.
8. From the Use list, choose **Select a driver to use**.
9. From the printer software list, select the print driver for your printer model.
10. Click **Add**.

### Installing Print Drivers and Utilities for UNIX and Linux

For more information on installing print drivers and utilities for UNIX and Linux, refer to <https://www.xerox.com/office/drivers>.

### UPDATING SOFTWARE

Some applications require a minimum device software level to operate correctly.

For more information on updating the device software, contact your customer service representative.

1. Open a web browser, then type the printer IP address in the address field.
  - View the printer IP address on the printer home screen. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.
  - If you are using a proxy server, then temporarily disable it to load the web page correctly.
2. Click **Settings > Device > Software Update**.

3. Choose one of the following:

- Click **Check for updates > I agree, start update**.

- To upload the software file, perform the following steps:

To get the latest software, go to [www.xerox.com](http://www.xerox.com), and search for your printer model.

1. Browse to the software file.



Note: Make sure that you have extracted the software.zip file.

2. Click **Upload > Start**.

## EXPORTING OR IMPORTING A CONFIGURATION FILE

You can export the configuration settings of your printer into a text file, and then import the file to apply the settings to other printers.

1. Open a Web browser, then type the printer IP address in the address field.
  - View the printer IP address on the printer home screen. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.
  - If you are using a proxy server, temporarily disable it to load the Web page correctly.
2. From the Embedded Web Server, click **Export Configuration** or **Import Configuration**.
3. Follow the instructions on the screen.
4. If the printer supports applications, then do the following:
  - a. Click **Apps**, select the application, then click **Configure**.
  - b. Click **Export** or **Import**.

## Xerox® Easy Assist App

To access the printer from your smartphone, download and install the Xerox Easy Assist app to your mobile device. By installing the Xerox Easy Assist app on your smartphone, you can setup your new printer easily, manage its configuration, view alerts indicating supply requirement and order them, and get live troubleshooting support for your printer.

The Xerox Easy Assist App has instructions and video links that helps you to unpack the printer from its shipping box. To install the Xerox Easy Assist app on your smartphone, you need to scan a QR Code. There are two types of QR Codes:

- The first QR Code is for the initial installation of the app. You can find this QR Code on the packaging box or the Installation Guide that comes with the printer. To install the Xerox Easy Assist app for the first time, you are required to scan this QR Code with your smartphone camera.
- The second QR Code is to setup a Wireless network connection between the smartphone and the printer. For example, connection to Wi-Fi Direct. For the printers with touchscreen User Interface or bigger than 2-line display interface, you can find this QR Code at the control panel of the printer. For more information, refer to [Connecting to the Xerox® Easy Assist App for Installed Printers](#). You are required to scan the second QR Code through the Xerox Easy Assist app.

To install and use the Xerox Easy Assist app, do the following:

1. To watch a helpful video to unpack your printer, scan the QR Code from the packaging box or the Installation Guide that came with your printer, with your smartphone camera.

Based on your smartphone, you are prompted to download the app from Apple App Store or Google Play Store. Accept the End-User License Agreement (EULA), then follow the instructions that appear on the app.

2. For initial setup when the printer is powered on for the first time, the initial setup wizard appears. At the printer control panel, do the following:

- a. Select your **Language**, then touch **Next**.

The Xerox Easy Assist Mobile App screen appears.

- b. To use your mobile device to set up and manage your printer, touch **Yes**.

Get the App screen appears to confirm the type of your mobile device. Choose any one option:

- **iOS:** To install the Xerox Easy Assist app for your iPhone, select this option.
  - **Android:** To install the Xerox Easy Assist app for your Android mobile device, select this option.
  - **I have the App:** If you have installed Xerox Easy Assist app on your mobile device already, select this option.
3. If you have selected iOS or Android option, a screen appears to help you download the app. At the control panel, touch **Show QR Code** option.

A screen appears with the QR Code. To install the app, scan the QR Code with your smartphone camera.

4. Download and install the Xerox Easy Assist app on your smartphone:
  - For Android phones: Go to Google Play Store, then search for Xerox Easy Assist app.
  - For iOS or iPhones: Go to Apple App Store, then search for Xerox Easy Assist app.
5. When you install the app for the first time on your smartphone, for End-User License Agreement (EULA), touch **I Agree**.
6. Follow the instructions that appear on the app. To connect your smartphone with the printer, touch **Connect To My Printer**.
7. At the printer control panel, to connect to the app, touch **Show QR Code** option. The second QR Code appears.



Important: For the printers with 2-line display interface, there is no QR Code on the control panel. To connect the printer to your mobile device, follow the instructions that appear on the control panel. When prompted, type the Wi-Fi Direct SSID Name and Password for your printer. The printer and the app are connected through Wi-Fi Direct.

8. Scan the second QR Code through the Xerox Easy Assist app. Follow the instructions that appear on the app.

When the connection is configured, your smartphone and the printer share the same Wireless network, temporarily.

9. With the support of Xerox Easy Assist app, complete the general settings and register the printer on the network.  
General settings include Admin Password, Connectivity, Measurements, Date and Time, Sound, Power Saver settings, and more.



Note: Ensure that your smartphone is connected to the same Wireless or wired network as the printer and they can communicate after the setup is complete.

10. To complete the initial setup in the app, type the necessary information for your printer, then touch **Complete Setup**.

The Welcome screen appears.



11. When the initial setup is complete, with the Xerox Easy Assist app, you can perform the following:

#### Set Up a New Printer

If you have the QR Code or IP Address available, you can set up a new Xerox printer with the help of Xerox Easy Assist app. On My Printers screen in the app, touch the **+** icon, then touch **Set Up a New Printer**. Follow the instructions from the app.

#### Printer Status

The status displays the printer information, such as readiness of the printer, toner level, and paper tray status for each tray. You can order parts and supplies through the Xerox Easy Assist app. If the toner level appears to be low, to order a new toner, select the **Toner** icon, then touch **Reorder**.

#### Alerts

The Xerox Easy Assist app can notify you of any errors or problems in the printer. To view the error statement, touch the **Bell** icon.

#### Print

You can perform a print job through the Xerox Easy Assist app. In the app, select your printer, then touch **Print**. Select the document that you need to print from your mobile device, confirm the print settings, then touch **Print**.

#### Device Settings

You can view and edit your printer settings from the **Device Settings** tab. If you have not setup a password during the initial setup, to view or edit existing printer settings, you need to set up the password.

#### Support

You can request support and find solutions for printer related problems through the Xerox Easy Assist app. In the app, select your printer, then touch **Support**. It connects you to Xerox's Support Agent Live Chatbot.

#### Print and Scan Drivers

You can download Print and Scan Drivers for your printer through Xerox Easy Assist app. In the app, select your printer, then touch **Print and Scan Drivers**. In the Email field, type your registered email address, then touch the **+** icon to add your email. To download and install the Print and Scan Drivers, the app sends a Quick Link to your email address.

#### Print Test Page


To confirm that all settings are correct, you can print a test page. In the app, select your printer, then touch **Print Test Page**.

#### Remove a Printer

You can remove a printer from the Xerox Easy Assist app. On your app, select a printer, then touch **Remove**.

### CONNECTING TO THE XEROX® EASY ASSIST APP FOR INSTALLED PRINTERS

To install and use the Xerox Easy Assist (XEA) app for a printer that does not require initial installation setup, you can find the QR Code from the control panel **Notification Center > Connected to Network > Connect to Xerox Easy Assist App > Show QR Code**. Scan the QR Code, then follow the instructions that appear on the control panel and your mobile device:

- Based on your smartphone, to install the app for the first time, you are prompted to download the app from Apple App Store or Google Play Store.
  - If you have the app installed already, to access Xerox Easy Assist features, connect to the printer with your smartphone.
-  Important: For the printers with 2-line display interface, there is no QR Code on the control panel. To connect the printer to your mobile device, follow the instructions that appear on the control panel. When prompted, type the Wi-Fi Direct SSID Name and Password for your printer. The printer and the app are connected through Wi-Fi Direct.

If your printer is already set up on your network and the Initial Setup Wizard is complete, through the XEA app you can add the printer directly to the list of My Printers. You can see the printer status, get print drivers, and get Chatbot support. To add a printer that is on the network, open the XEA app Home page. On the My Printers screen, touch the + icon. The app looks for nearby printers on the network:

- If the app finds your printer, you can select and add the printer directly.
- If the app is unable to find the printer you are looking for, then you can add the printer by typing its IP address.

If the printer and mobile device cannot communicate, ensure that they are on the same network.

## Networking

### CONNECTING THE PRINTER TO A WI-FI NETWORK

Before you begin, make sure that:

- Active Adapter is set to Auto. From the control panel, navigate to **Settings > Network/Ports > Network Overview > Active Adapter**.

For non-touch-screen printer models, press **OK** to navigate through the settings.

- The Ethernet cable is not connected to the printer.

#### Using the Wireless Setup Wizard in the Printer

- These instructions apply only to some printer models.
  - Before using the wizard, make sure that the printer firmware is updated. For more information, see [Updating Software](#).
1. From the home screen, touch **Wi-Fi** icon, then touch **Set up now**.
  2. Select a Wi-Fi network, and then type the network password.
  3. Touch **Done**.

#### Using the Settings Menu in the Printer

1. From the control panel, navigate to:  
**Settings > Network/Ports > Wireless > Setup On Printer Panel**

For non-touch-screen printer models, press **OK** to navigate through the settings.

2. Select a Wi-Fi network, and then type the network password.



Note: For Wi-Fi-network-ready printer models, a prompt to set up the Wi-Fi network appears during initial setup.

### CONNECTING THE PRINTER TO A WIRELESS NETWORK USING WI-FI PROTECTED SETUP (WPS)

Before you begin, make sure that:

- The access point (wireless router) is WPS-certified or WPS-compatible. For more information, see the documentation that came with your access point.
- A wireless network adapter is installed in your printer. For more information, see the instructions that came with the adapter.
- Active Adapter is set to Auto. From the control panel, navigate to:  
**Settings > Network/Ports > Network Overview > Active Adapter**

For non-touch-screen printer models, press **OK** to navigate through the settings.

### Using the Push Button method

1. From the control panel, navigate to:

**Settings > Network/Ports > Wireless > Wi-Fi Protected Setup > Start Push Button Method**

For non-touch-screen printer models, press  to navigate through the settings.

2. Follow the instructions on the display.

### Using the personal identification number (PIN) method

1. From the control panel, navigate to:

**Settings > Network/Ports > Wireless > Wi-Fi Protected Setup > Start PIN Method**

For non-touch-screen printer models, press  to navigate through the settings.

2. Copy the eight-digit WPS PIN.
3. Open a web browser, and then type the IP address of your access point in the address field.
  - To know the IP address, see the documentation that came with your access point.
  - If you are using a proxy server, then temporarily disable it to load the web page correctly.
4. Access the WPS settings. For more information, see the documentation that came with your access point.
5. Enter the eight-digit PIN, and then save the changes.

## CONFIGURING WI-FI DIRECT

Wi-Fi Direct is a Wi-Fi-based peer-to-peer technology that allows wireless devices to connect directly to a Wi-Fi Direct-enabled printer without using an access point (wireless router).

1. From the control panel, navigate to:

**Settings > Network/Ports > Wi-Fi Direct**

For non-touch-screen printer models, press  to navigate through the settings.

2. Configure the settings.
  - **Enable Wi-Fi Direct**—Enables the printer to broadcast its own Wi-Fi Direct network.
  - **Wi-Fi Direct Name**—Assigns a name for the Wi-Fi Direct network.
  - **Wi-Fi Direct Password**—Assigns the password for negotiating the wireless security when using the peer-to-peer connection.
  - **Show Password on Setup Page**—Shows the password on the Network Setup Page.

- **Auto-Accept Push Button Requests**—Lets the printer accept connection requests automatically.



Note: Accepting push-button requests automatically is not secured.

- By default, the Wi-Fi Direct network password is not visible on the printer display. To show the password, enable the password peek icon. From the control panel, navigate to **Settings > Security > Miscellaneous > Enable Password/PIN Reveal**.
- To know the password of the Wi-Fi Direct network without showing it on the printer display, from the control panel navigate to **Settings > Reports > Network > Network Setup Page**.

## CONNECTING A MOBILE DEVICE TO THE PRINTER

Before connecting your mobile device, make sure that Wi-Fi Direct has been configured. For more information, see [Configuring Wi-Fi Direct](#).

### Connecting Using Wi-Fi Direct



Note: These instructions apply only to Android mobile devices.

1. From the mobile device, go to the settings menu.
2. Enable **Wi-Fi**, and then tap **Wi-Fi Direct**.
3. Select the printer Wi-Fi Direct name.
4. Confirm the connection on the printer control panel.

### Connecting Using Wi-Fi

1. From the mobile device, go to the settings menu.
2. Tap **Wi-Fi**, and then select the printer Wi-Fi Direct name.



Note: The string DIRECT-xy (where x and y are two random characters) is added before the Wi-Fi Direct name.

3. Enter the Wi-Fi Direct password.

## CONNECTING A COMPUTER TO THE PRINTER

Before connecting your computer, make sure to do the following:

- Enable Wi-Fi Direct in the printer. From the control panel, navigate to:  
**Settings > Network/Ports > Wi-Fi Direct > Enable Wi-Fi Direct > On**
- Take note of the Wi-Fi Direct name. From the control panel, navigate to:  
**Settings > Network/Ports > Wi-Fi Direct > Wi-Fi Direct Name**
- Take note of the Wi-Fi Direct password. From the control panel, navigate to:  
**Settings > Network/Ports > Wi-Fi Direct > Wi-Fi Direct Password**
-

Set up, install, and configure



Note: You can also configure the Wi-Fi Direct name and password.

For non-touch-screen printer models, press **OK** to navigate through the settings.

### For Windows Users

1. Open **Printers & scanners**, and then click **Add a printer or scanner**.
2. Click **Show Wi-Fi Direct printers**, and then select the printer Wi-Fi Direct name.
3. From the printer display, take note of the eight-digit PIN of the printer.
4. Enter the PIN on the computer.



Note: If the print driver is not already installed, then Windows downloads the appropriate driver.

### For Macintosh Users

1. Click the wireless icon, and then select the printer Wi-Fi Direct name.



Note: The string DIRECT-xy (where x and y are two random characters) is added before the Wi-Fi Direct name.

2. Type the Wi-Fi Direct password.



Note: Switch your computer back to its previous network after disconnecting from the Wi-Fi Direct connection.

## DEACTIVATING THE WI-FI NETWORK

1. From the printer control panel, navigate to:  
**Settings > Network/Ports > Network Overview > Active Adapter > Standard Network**

For non-touch-screen printer models, press **OK** to navigate through the settings.

2. Follow the instructions on the display.

## CHECKING THE PRINTER CONNECTIVITY

1. Print the Network Setup Page.

From the control panel, navigate to:

**Settings > Reports > Network > Network Setup Page**

For non-touch-screen printer models, press **OK** to navigate through the settings.

2. Check the first section of the page and confirm that the status is connected.

If the status is not connected, then the LAN drop may be inactive or the network cable may be unplugged or malfunctioning. Contact your administrator for assistance.

## Printing the Menu Settings Page

From the control panel, navigate to:

**Settings > Reports > Menu Settings Page**

For non-touch-screen printer models, press  to navigate through the settings.

Set up, install, and configure



## Secure the printer

This chapter contains:

Erasing printer memory .....	74
Restoring factory default settings .....	75
Statement of Volatility .....	76

## Erasing printer memory

To erase volatile memory or buffered data, turn off the printer.

To erase non-volatile memory or individual settings, device and network settings, security settings, and embedded solutions, do the following:

1. From the control panel, navigate to:

**Settings > Device > Maintenance > Out of Service Erase > Sanitize all information on nonvolatile memory**

For non-touch-screen printer models, press  to navigate through the settings.

2. Select either **Start initial setup** or **Leave printer offline**.

## Restoring factory default settings

1. From the control panel, navigate to:

**Settings > Device > Restore Factory Defaults**

For non-touch-screen printer models, press  to navigate through the settings.

2. Select **Restore all settings**.

## Statement of Volatility

Your printer contains various types of memory that can store device and network settings, and user data.

TYPE OF MEMORY	DESCRIPTION
Volatile memory	Your printer uses standard <i>random access memory</i> (RAM) to temporarily buffer user data during simple print jobs.
Non-volatile memory	Your printer may use two forms of non-volatile memory: EEPROM and NAND (flash memory). Both types are used to store operating system, device settings, and network information.

Erase the content of any installed printer memory in the following circumstances:

- The printer is being decommissioned.
- The printer is being moved to a different department or location.
- The printer is being serviced by someone from outside your organization.
- The printer is being removed from your premises for service.
- The printer is being sold to another organization.

## Print

This chapter contains:

Printing from a Computer .....	78
Printing from a Mobile Device .....	79
Printing from a flash drive.....	80
Supported flash drives and file types .....	81
Configuring confidential jobs .....	82
Printing confidential and other held jobs .....	83
Printing a font sample list .....	85
Placing separator sheets between copies.....	86
Canceling a print job .....	87
Adjusting toner darkness .....	88

## Printing from a Computer



Note: For labels, card stock, and envelopes, set the paper size and type in the printer before printing the document.

1. From the document that you are trying to print, open the Print dialog.
2. If necessary, adjust the settings.
3. Print the document.

## Printing from a Mobile Device

### PRINTING FROM A MOBILE DEVICE USING MOPRIA® PRINT SERVICE

Mopria Print Service is a mobile printing solution for mobile devices running on Android™ version 5.0 or later. It allows you to print directly to any Mopria-certified printer.



Note: Make sure that you download the Mopria Print Service application from the Google Play™ store and enable it in the mobile device.

1. From your Android mobile device, launch a compatible application or select a document from your file manager.
2. Tap **More Options > Print**.
3. Select a printer, and then adjust the settings, if necessary.
4. Tap **Print**.

### PRINTING FROM A MOBILE DEVICE USING AIRPRINT®

The AirPrint software feature is a mobile printing solution that allows you to print directly from Apple devices to an AirPrint-certified printer.




- Make sure that the Apple device and the printer are connected to the same network. If the network has multiple wireless hubs, then make sure that both devices are connected to the same subnet.
  - This application is supported only in some Apple devices.
1. From your mobile device, select a document from your file manager or launch a compatible application.
  2. Tap **Share/Upload > Print**.
  3. Select a printer, and then adjust the settings, if necessary.
  4. Print the document.

### PRINTING FROM A MOBILE DEVICE USING WI-FI DIRECT®

Wi-Fi Direct is a printing service that lets you print to any Wi-Fi Direct-ready printer.




Note: Make sure that the mobile device is connected to the printer wireless network. For more information, see [Connecting a Mobile Device to the Printer](#).

1. From your mobile device, launch a compatible application or select a document from your file manager.
2. Depending on your mobile device, do one of the following:
  - Tap  > **Print**.
  - Tap  > **Print**.
  - Tap  > **Print**.
3. Select a printer, and then adjust the settings, if necessary.
4. Print the document.

## Printing from a flash drive


This feature is available only in some printer models.

1. Insert the flash drive.



- If you insert the flash drive when an error message appears, then the printer ignores the flash drive.
  - If you insert the flash drive while the printer is processing other print jobs, then Busy appears on the display.
2. Select the document that you want to print.  
If necessary, configure other print settings.
  3. Print the document.

To print another document, select **USB Drive**.

 **Warning:** To avoid loss of data or printer malfunction, do not touch the flash drive or the printer in the area shown while actively printing, reading, or writing from the memory device.





## Supported flash drives and file types

### FLASH DRIVES

- Lexar JumpDrive S70 (16GB and 32GB)
- SanDisk Cruzer (16GB and 32GB)
- PNY Attache (16GB and 32GB)
  - The printer supports high-speed flash drives with full-speed standard.
  - Flash drives must support the File Allocation Table (FAT) system.

### FILE TYPES

Documents

PDF (version 1.7 or earlier)

Images

- .dcx
- .gif
- .JPEG or .jpg
- .bmp
- .pcx
- .TIFF or .tif
- .png

## Configuring confidential jobs

### USING THE CONTROL PANEL

1. From the home screen, touch **Settings > Security > Confidential Print Setup**
2. Configure the settings.

### USING THE EMBEDDED WEB SERVER

1. Open a web browser, and then type the printer IP address in the address field.
  - View the printer IP address on the home screen. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123
  - If you are using a proxy server, then temporarily disable it to load the web page correctly.
2. Click **Settings > Security > Confidential Print Setup**.
3. Configure the settings.

## Printing confidential and other held jobs

### FOR WINDOWS USERS

1. With a document open, click **File > Print**.
2. Select a printer, and then click **Properties, Preferences, Options, or Setup**.
3. Click **Print and Hold**.
4. Select **Use Print and Hold**, and then assign a user name.
5. Select the print job type (Confidential, Repeat, Reserve, or Verify).

If you select **Confidential**, then secure the print job with a personal identification number (PIN).

6. Click **OK** or **Print**.
7. From the printer control panel, release the print job.
  - For confidential print jobs, navigate to:  
**Held jobs** > select your user name > **Confidential** > enter the PIN > select the print job > configure the settings > **Print**
  - For other print jobs, navigate to:  
**Held jobs** > select your user name > select the print job > configure the settings > **Print**



Note: For non-touch-screen printer models, press **OK** to navigate through the settings.

### FOR MACINTOSH USERS

#### Using AirPrint

1. With a document open, choose **File > Print**.
2. Select a printer, and then from the drop-down menu following the Orientation menu, choose **PIN Printing**.
3. Enable **Print with PIN**, and then enter a four-digit PIN.
4. Click **Print**.
5. From the printer control panel, release the print job. Navigate to:  
**Held jobs** > select your computer name > **Confidential** > enter the PIN > select the print job > **Print**

For non-touch-screen printer models, press **OK** to navigate through the settings.

#### Using the print driver

1. With a document open, choose **File > Print**.
2. Select a printer, and then from the drop-down menu following the Orientation menu, choose **Print and Hold**.
3. Choose **Confidential Print**, and then enter a four-digit PIN.

Print

4. Click **Print**.
5. From the printer control panel, release the print job. Navigate to:  
**Held jobs** > select your computer name > **Confidential** > select the print job > enter the PIN > **Print**  
For non-touch-screen printer models, press **OK** to navigate through the settings.

## Printing a font sample list

1. From the control panel, navigate to:

**Settings > Reports > Print > Print Fonts**

For non-touch-screen printer models, press  to navigate through the settings.

2. Select **PCL Fonts**.

## Placing separator sheets between copies

1. From the home screen, navigate to:



**Settings > Print > Layout > Separator Sheets > Between Copies**

For non-touch-screen printer models, press  to navigate through the settings.

2. Print the document.

## Canceling a print job

### FROM THE PRINTER CONTROL PANEL

1. Depending on your printer model, do either of the following:
  - Press  twice, and then press .
  - Touch **Cancel Job**.
2. Select a print job to cancel.

### FROM THE COMPUTER

1. Depending on the operating system, do either of the following:
  - Open the printers folder, and then select your printer.
  - From the System Preferences in the Apple menu, navigate to your printer.
2. Select the job to cancel.

## Adjusting toner darkness

1. From the control panel, navigate to:

**Settings > Print > Quality > Toner Darkness**

For non-touch-screen printer models, press  to navigate through the settings.

2. Adjust the setting.
3. Apply the changes.





## Copy

This chapter contains:

Using the automatic document feeder and scanner glass.....	90
Making Copies.....	91
Copying photos .....	92
Copying on letterhead .....	93
Copying on Both Sides of the Paper .....	94
Reducing or enlarging copies.....	95
Copying multiple pages onto a single sheet .....	96
Collating copies .....	97
Copying cards .....	98
Creating a copy shortcut .....	99

## Using the automatic document feeder and scanner glass

AUTOMATIC DOCUMENT FEEDER (ADF)	SCANNER GLASS
 <ul style="list-style-type: none"><li>• Use the ADF for multiple-page or two-sided documents.</li><li>• Load an original document faceup. For multiple-page documents, make sure to align the leading edge before loading.</li><li>• Make sure to adjust the ADF guides to match the width of the paper that you are loading.</li></ul>	 <ul style="list-style-type: none"><li>• Use the scanner glass for single-page documents, book pages, small items (such as postcards or photos), transparencies, photo paper, or thin media (such as magazine clippings).</li><li>• Place the document facedown in the corner with the arrow.</li></ul>

## Making Copies

1. Load an original document into the ADF tray or on the scanner glass.



Note: To avoid a cropped image, make sure that the original document and the output have the same paper size.

2. From the control panel, navigate to:



> **Copy** > specify the number of copies

For non-touch-screen printer models, press **OK** to navigate through the settings.

If necessary, adjust the settings.

3. Copy the document.



Note: To make a quick copy, from the control panel, press **OK**.

## Copying photos

1. Place a photo on the scanner glass.
2. From the control panel, navigate to:



> **Copy** > **Content Type** > **Photo**

For non-touch-screen printer models, press  to navigate through the settings.

3. Copy the document.

## Copying on letterhead

1. Load an original document into the ADF tray or on the scanner glass.
2. From the control panel, navigate to:



> **Copy** > **Copy from** > select the size of the original document

For non-touch-screen printer models, press  to navigate through the settings.

3. Select **Copy To**, and then select the paper source that contains the letterhead.

If you loaded the letterhead into the manual feeder, then navigate to:

**Copy To** > **Manual Feeder** > select a paper size > **Letterhead**

4. Copy the document.

## Copying on Both Sides of the Paper

1. Load an original document into the ADF tray or on the scanner glass.
2. From the control panel, navigate to:


 > **Copy** > **Sides**

For non-touch-screen printer models, press  to navigate through the settings.

3. Adjust the setting.
4. Copy the document.

## Reducing or enlarging copies

1. Load an original document into the ADF tray or on the scanner glass.
2. From the control panel, navigate to:

 > **Copy** > **Scale** > specify a scale value

For non-touch-screen printer models, press  to navigate through the settings.



Note: Changing the size of the original document or output after setting Scale restores the scale value to Auto.

3. Copy the document.

## Copying multiple pages onto a single sheet

1. Load an original document into the ADF tray or on the scanner glass.
2. From the control panel, navigate to:



> **Copy** > **Pages per Side**

For non-touch-screen printer models, press  to navigate through the settings.

3. Adjust the settings.
4. Copy the document.



## Collating copies


1. Load an original document into the ADF tray or on the scanner glass.
2. From the control panel, navigate to:

 > **Copy** > **Collate** > **On [1,2,1,2,1,2]**

For non-touch-screen printer models, press  to navigate through the settings.

3. Copy the document.

## Copying cards

1. Load a card on the scanner glass.
2. Depending on your printer model, do either of the following:
  - From the home screen, touch **Copy > ID Copy**.
  - From the control panel, navigate to:  
**ID Card Copy > **
3. If necessary, adjust the settings.
4. Copy the document.

## Creating a copy shortcut



Note: You may need administrative rights to create a shortcut.

1. Open a web browser, and then type the printer IP address in the address field.
  - View the printer IP address on the home screen. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.
  - If you are using a proxy server, then temporarily disable it to load the web page correctly.
2. Click **Shortcuts > Add Shortcut**.
3. From the Shortcut Type menu, select **Copy**, and then configure the settings.
4. Apply the changes.



Copy

## Email

This chapter contains:

Using the automatic document feeder and scanner glass.....	102
Sending an Email.....	103

## Using the automatic document feeder and scanner glass

AUTOMATIC DOCUMENT FEEDER (ADF)	SCANNER GLASS
 <ul style="list-style-type: none"><li>• Use the ADF for multiple-page or two-sided documents.</li><li>• Load an original document faceup. For multiple-page documents, make sure to align the leading edge before loading.</li><li>• Make sure to adjust the ADF guides to match the width of the paper that you are loading.</li></ul>	 <ul style="list-style-type: none"><li>• Use the scanner glass for single-page documents, book pages, small items (such as postcards or photos), transparencies, photo paper, or thin media (such as magazine clippings).</li><li>• Place the document facedown in the corner with the arrow.</li></ul>

## Sending an Email

Before you begin, make sure that the SMTP settings are configured. For more information, see [Configuring the Email SMTP Settings](#).

### USING THE CONTROL PANEL

1. Load an original document into the ADF tray or on the scanner glass.
2. From the home screen, touch **Email**, and then enter the needed information.

If necessary, configure the output file type settings.

3. Send the email.

### USING A SHORTCUT NUMBER

1. Create an email shortcut.
  - a. Open a web browser, and then type the printer IP address in the address field.
    - View the printer IP address on the home screen. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.
    - If you are using a proxy server, then temporarily disable it to load the web page correctly.
  - b. Click **Shortcuts > Add Shortcut**.
  - c. From the Shortcut Type menu, select **Email**, and then configure the settings.
  - d. Apply the changes.

2. Load an original document into the ADF tray or on the scanner glass.
3. From the control panel, navigate to:

**Shortcuts > Email**

For non-touch-screen printer models, press  to navigate through the settings.

4. Select the shortcut.
5. Send the email.

Email





## Fax

This chapter contains:

Using the automatic document feeder and scanner glass.....	106
Sending a Fax .....	107
Scheduling a fax .....	108
Creating a fax destination shortcut .....	109
Changing the fax resolution .....	110
Adjusting the fax darkness.....	111
Printing a fax log.....	112
Blocking junk faxes.....	113
Holding a fax .....	114
Forwarding a fax.....	115

## Using the automatic document feeder and scanner glass

AUTOMATIC DOCUMENT FEEDER (ADF)	SCANNER GLASS
 <ul style="list-style-type: none"><li>• Use the ADF for multiple-page or two-sided documents.</li><li>• Load an original document faceup. For multiple-page documents, make sure to align the leading edge before loading.</li><li>• Make sure to adjust the ADF guides to match the width of the paper that you are loading.</li></ul>	 <ul style="list-style-type: none"><li>• Use the scanner glass for single-page documents, book pages, small items (such as postcards or photos), transparencies, photo paper, or thin media (such as magazine clippings).</li><li>• Place the document facedown in the corner with the arrow.</li></ul>

## Sending a Fax

### USING THE CONTROL PANEL

1. Load an original document into the automatic document feeder input tray or on the scanner glass.
2. From the home screen, touch **Fax**, then enter the required information.  
Adjust the settings, as needed.
3. Fax the document.

## Scheduling a fax

This feature is available only in some printer models.

1. Load an original document into the ADF tray or on the scanner glass.
2. From the home screen, touch **Fax** > **To** > enter the fax number > **Done**.
3. Touch **Send Time**, configure the date and time, and then touch **OK**.
4. Send the fax.

## Creating a fax destination shortcut



Note: You may need administrative rights to create a shortcut.

1. Open a web browser, and then type the printer IP address in the address field.
  - View the printer IP address on the home screen. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.
  - If you are using a proxy server, then temporarily disable it to load the web page correctly.
2. Click **Shortcuts > Add Shortcut**.
3. From the Shortcut Type menu, select **Fax**, and then configure the settings.
4. Apply the changes.

## Changing the fax resolution

1. Load an original document into the ADF tray or on the scanner glass.
2. From the control panel, touch **Fax > Resolution**.
3. Select a setting.
4. Fax the document.

## Adjusting the fax darkness

1. Load an original document into the Automatic Document Feeder input tray or on the scanner glass.
2. From the control panel, touch **Fax > Darkness**.
3. Select a setting.
4. Fax the document.

## Printing a fax log

1. From the control panel, touch **Settings > Reports > Fax**.
2. Select **Fax Job Log** or **Fax Call Log**.



## Blocking junk faxes


1. From the home screen, navigate to **Settings > Fax > Fax Setup > Fax Receive Settings > Admin Controls**.
2. Set Block No Name Fax to **On**.

## Holding a fax

1. Open a web browser, and then type the printer IP address in the address field.
  - View the printer IP address on the printer home screen. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.
  - If you are using a proxy server, then temporarily disable it to load the web page correctly.
2. Click **Settings > Fax > Fax Setup > Fax Receive Settings > Holding Faxes**.
3. Select a mode.
4. Apply the changes.

## Forwarding a fax

### USING THE CONTROL PANEL

1. Create a fax destination shortcut.
  - a. From the home screen, touch **Fax > To**.
  - b. Enter the recipient number, and then touch **Done**.
  - c. Touch .
  - d. Create a shortcut.
2. From the home screen, touch **Settings > Fax > Fax Setup > Fax Receive Settings > Admin Controls**.
3. In the Fax Forwarding menu, touch **Forward**.
4. In the Forward to menu, configure the destination.

### USING THE EMBEDDED WEB SERVER

1. Create a fax destination shortcut.
  - a. Open a web browser, and then type the printer IP address in the address field.
    - View the printer IP address on the home screen. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.
    - If you are using a proxy server, then temporarily disable it to load the web page correctly.
  - b. Click **Shortcuts > Add Shortcut**.
  - c. From the Shortcut Type menu, select **Fax**, and then configure the settings.
  - d. Apply the changes.
2. Click **Settings > Fax > Fax Setup > Fax Receive Settings > Admin Controls**.
3. In the Fax Forwarding menu, select **Forward**.
4. In the Forward to menu, configure the destination.





## Scan

This chapter contains:

Using the automatic document feeder and scanner glass.....	118
Scanning to a Computer .....	119
Scanning to a flash drive .....	120
Scanning to an FTP server .....	121
Scanning to a network folder.....	122

## Using the automatic document feeder and scanner glass

AUTOMATIC DOCUMENT FEEDER (ADF)	SCANNER GLASS
 <ul style="list-style-type: none"><li>• Use the ADF for multiple-page or two-sided documents.</li><li>• Load an original document faceup. For multiple-page documents, make sure to align the leading edge before loading.</li><li>• Make sure to adjust the ADF guides to match the width of the paper that you are loading.</li></ul>	 <ul style="list-style-type: none"><li>• Use the scanner glass for single-page documents, book pages, small items (such as postcards or photos), transparencies, photo paper, or thin media (such as magazine clippings).</li><li>• Place the document facedown in the corner with the arrow.</li></ul>

## Scanning to a Computer

Before you begin, make sure that:

- The printer firmware is updated. For more information, see [Updating Software](#).
- The computer and the printer are connected to the same network.

### FOR WINDOWS USERS



Note: Make sure that the printer is added to the computer. For more information, refer to [Installing the Software](#).

1. Load an original document into the automatic document feeder or on the scanner glass.
2. From the computer, open **Windows Fax and Scan**.
3. From the Source menu, select a scanner source.
4. If necessary, change the scan settings.
5. Scan the document.

### FOR MACINTOSH USERS




Note: Make sure that the printer is added to the computer. For more information, refer to [Installing the Software](#).

1. Load an original document into the automatic document feeder or on the scanner glass.
2. From the computer, do either of the following:
  - Open **Image Capture**.
  - Open **Printers & Scanners**, and then select a printer. Click **Scan > Open Scanner**.
3. From the Scanner window, do one or more of the following:
  - Select where you want to save the scanned document.
  - Select the size of the original document.
  - To scan from the ADF, select **Document Feeder** from the Scan Menu or enable **Use Document Feeder**.
  - If necessary, configure the scan settings.
4. Click **Scan**.


## Scanning to a flash drive

This feature is available only in some printer models.

1. Load an original document into the ADF tray or on the scanner glass.
2. Insert the flash drive.




3. Touch **Scan to USB** and adjust the settings if necessary.
  - To save the scanned document to a folder, touch **Scan to**, select a folder, and then touch **Scan Here**.
  - If the USB Drive screen does not appear, then touch **USB Drive** on the control panel.
4. Scan the document.

 **Warning:** To avoid loss of data or printer malfunction, do not touch the flash drive or the printer in the area shown while actively printing, reading, or writing from the memory device.






## Scanning to an FTP server

1. Create an FTP shortcut.
  - a. Open a web browser, and then type the printer IP address in the address field.
    - View the printer IP address on the printer home screen. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.
    - If you are using a proxy server, then temporarily disable it to load the web page correctly.
  - b. Click **Shortcuts > Add Shortcut**.
  - c. From the Shortcut Type menu, select **FTP**, and then configure the settings.
  - d. Apply the changes.
2. Load an original document into the ADF tray or on the scanner glass.
3. From the control panel, navigate to:  
**Shortcuts > FTP**  
For non-touch-screen printer models, press  to navigate through the settings.
4. Select the shortcut.
5. Scan the document.

## Scanning to a network folder

1. Create a network folder shortcut.
  - a. Open a web browser, and then type the printer IP address in the address field.
    - View the printer IP address on the printer home screen. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.
    - If you are using a proxy server, then temporarily disable it to load the web page correctly.
  - b. Click **Shortcuts > Add Shortcut**.
  - c. From the Shortcut Type menu, select **Network Folder**, and then configure the settings.
  - d. Apply the changes.
2. Load an original document into the ADF tray or on the scanner glass.
3. From the home screen, navigate to:  
**Shortcuts > Network Folder**  
For non-touch-screen printer models, press  to navigate through the settings.
4. Select the shortcut.

## Use printer menus

This chapter contains:

Menu Map.....	124
Device .....	126
Print .....	137
Paper.....	143
Copy.....	146
Fax.....	148
E-mail.....	155
FTP .....	160
USB Drive .....	164
Network/Ports .....	168
Security.....	187
Reports .....	194
Supplies Plan.....	196
Troubleshooting.....	197



## Menu Map




<b>Device</b>	<ul style="list-style-type: none"> <li>• Preferences</li> <li>• Eco-Mode</li> <li>• Remote Operator Panel<sup>1</sup></li> <li>• Notifications</li> <li>• Power Management</li> </ul>	<ul style="list-style-type: none"> <li>• Restore Factory Defaults</li> <li>• Maintenance</li> <li>• Visible Home Screen Icons<sup>2</sup></li> <li>• About This Printer</li> </ul>
<b>Print</b>	<ul style="list-style-type: none"> <li>• Layout</li> <li>• Setup</li> <li>• Quality</li> <li>• PDF<sup>2</sup></li> </ul>	<ul style="list-style-type: none"> <li>• PostScript<sup>2</sup></li> <li>• PCL</li> <li>• Image</li> </ul>
<b>Paper</b>	<ul style="list-style-type: none"> <li>• Tray Configuration</li> </ul>	<ul style="list-style-type: none"> <li>• Media Configuration</li> </ul>
<b>Copy</b>	Copy Defaults	
<b>Fax</b>	Fax Defaults	
<b>E-mail<sup>1</sup></b>	<ul style="list-style-type: none"> <li>• E-mail Setup</li> </ul>	<ul style="list-style-type: none"> <li>• E-mail Defaults</li> </ul>
<b>FTP<sup>1</sup></b>	FTP Defaults	
<b>USB Drive<sup>2</sup></b>	<ul style="list-style-type: none"> <li>• Flash Drive Scan</li> </ul>	<ul style="list-style-type: none"> <li>• Flash Drive Print</li> </ul>
<b>Network/Ports</b>	<ul style="list-style-type: none"> <li>• Network Overview</li> <li>• Wireless</li> <li>• Wi-Fi Direct</li> <li>• AirPrint</li> <li>• Mobile Services Management</li> <li>• Ethernet</li> <li>• TCP/IP</li> <li>• SNMP</li> </ul>	<ul style="list-style-type: none"> <li>• IPSec</li> <li>• 802.1x</li> <li>• LPD Configuration</li> <li>• HTTP/FTP Settings</li> <li>• USB</li> <li>• Restrict external network access</li> <li>• Universal Print</li> </ul>
<b>Security<sup>1</sup></b>	<ul style="list-style-type: none"> <li>• Login Methods</li> <li>• Certificate Management</li> <li>• Login Restrictions</li> <li>• Confidential Print Setup</li> </ul>	<ul style="list-style-type: none"> <li>• Erase Temporary Data Files</li> <li>• Solutions LDAP Settings</li> <li>• Miscellaneous</li> <li>• Schedule USB Devices<sup>2</sup></li> </ul>
<b>Reports</b>	<ul style="list-style-type: none"> <li>• Menu Settings Page</li> <li>• Device</li> <li>• Print</li> </ul>	<ul style="list-style-type: none"> <li>• Shortcuts</li> <li>• Fax</li> <li>• Network</li> </ul>
<b>Supplies Plan</b>	<ul style="list-style-type: none"> <li>• Plan Activation</li> <li>• Plan Conversion</li> </ul>	<ul style="list-style-type: none"> <li>• Subscription Service</li> </ul>


Troubleshooting	<ul style="list-style-type: none"><li>• Print Quality Test Pages</li></ul>	<ul style="list-style-type: none"><li>• Cleaning the Scanner</li></ul>
<p><sup>1</sup> In some printer models, this menu can be configured from the Embedded Web Server only.</p> <p><sup>2</sup> Available only in some printer models.</p>		

## Device

## PREFERENCES

MENU ITEM	DESCRIPTION
<b>Display Language</b> [List of languages]	Set the language of the text that appears on the display.
<b>Country/Region</b> [List of countries or regions]	Identify the country or region where the printer is configured to operate.
<b>Run initial setup</b> <ul style="list-style-type: none"> <li>No*</li> <li>Yes</li> </ul>	Run the setup wizard.
<b>Keyboard</b> Keyboard Type [List of languages]	Select a language as a keyboard type.   Note: All the Keyboard Type values may not appear or may require special hardware to appear.
<b>Displayed information</b> <ul style="list-style-type: none"> <li>Display Text 1 (IP Address*)</li> <li>Display Text 2</li> <li>Custom Text 1</li> <li>Custom Text 2</li> </ul>	Specify the information to appear on the home screen.
<b>Date and Time</b> <ul style="list-style-type: none"> <li>Configure               <ul style="list-style-type: none"> <li>Current Date and Time</li> <li>Manually Set Date and Time</li> <li>Date Format [MM-DD-YYYY*]</li> <li>Time Format [12 hour A.M./P.M.*]</li> <li>Time Zone</li> </ul> </li> </ul>	Configure the printer date and time.
<b>Date and Time</b> <ul style="list-style-type: none"> <li>Network Time Protocol               <ul style="list-style-type: none"> <li>Enable NTP (On*)</li> <li>NTP Server</li> <li>Enable Authentication (None*)</li> </ul> </li> </ul>	Configure the settings for Network Time Protocol (NTP).   Note: When Enable Authentication is set to MD5 key, Key ID and Password appear.
<b>Paper Sizes</b> <ul style="list-style-type: none"> <li>U.S.*</li> <li>Metric</li> </ul>	Specify the unit of measurement for paper sizes.


MENU ITEM	DESCRIPTION
	 Note: The country or region selected in the initial setup wizard determines the initial paper size setting.
<b>Screen Brightness</b> 20–100 % (100*)	Adjust the brightness of the display.   Note: This feature is available only in some printer models.
<b>Flash Drive Access</b> <ul style="list-style-type: none"> <li>Disabled</li> <li>Enabled*</li> </ul>	Enable access to the flash drive.
<b>One Page Flatbed Scanning</b> <ul style="list-style-type: none"> <li>On</li> <li>Off*</li> </ul>	Set copies from the scanner glass to only one page at a time.
<b>Device Sounds</b>  Note: The Device Sounds icon is available only in some printer models.	
<b>Mute All Sounds</b> On Off*	Disable and ignore all sound settings.
<b>ADF Loaded Beep</b> On* Off	Enable a sound when loading paper into the ADF.
<b>Alarm Control</b> Off Single* Continuous	Set the number of times that the alarm sounds when the printer requires user intervention.
<b>Cartridge Alarm</b> Off* Single Continuous	Disable the cartridge alarm.
<b>Speaker Mode</b> Always Off* Always On On until Connected	Disable the speaker mode.

MENU ITEM	DESCRIPTION
<b>Ringer Volume</b> Off* On	Disable the ringer volume.
<b>Screen Timeout</b> 5–300 (60*)	Set the idle time in seconds before the display shows the home screen, or before the printer logs out a user account automatically.
 Note: An asterisk (*) next to a value indicates the factory default setting.	



**ECO-MODE**

MENU ITEM	DESCRIPTION
<b>Print: Sides</b> <ul style="list-style-type: none"> <li>1-Sided*</li> <li>2-Sided</li> </ul>	Specify whether to print on one side or two sides of the paper.
<b>Print : Pages per Side</b> <ul style="list-style-type: none"> <li>Off*</li> <li>2 pages per side</li> <li>3 pages per side</li> <li>4 pages per side</li> <li>6 pages per side</li> <li>9 pages per side</li> <li>12 pages per side</li> <li>16 pages per side</li> </ul>	Print multiple page images on one side of a sheet of paper.
<b>Print : Toner Darkness</b> <ul style="list-style-type: none"> <li>Light</li> <li>Normal*</li> <li>Dark</li> </ul>	Determine the lightness or darkness of text or images.
<b>Copy :Sides</b> <ul style="list-style-type: none"> <li>1 sided to 1 sided*</li> <li>1 sided to 2 sided</li> </ul>	Specify whether to print on one side or both sides of the paper.
<b>Copy :Pages per Side</b> <ul style="list-style-type: none"> <li>Off*</li> <li>2 Portrait pages</li> <li>4 Portrait pages</li> <li>2 Landscape pages</li> <li>4 Landscape pages</li> </ul>	Specify the number of page images to print on one side of a sheet of paper.




MENU ITEM	DESCRIPTION
<b>Copy</b> <ul style="list-style-type: none"> <li>Darkness</li> <li>1-9 (5*)</li> </ul>	Adjust the darkness of the scanned image.
 Note: An asterisk (*) next to a value indicates the factory default setting.	



## REMOTE OPERATOR PANEL

MENU ITEM	DESCRIPTION
<b>External VNC Connection</b> <ul style="list-style-type: none"> <li>Don't Allow*</li> <li>Allow</li> </ul>	Connect an external Virtual Network Computing (VNC) client to the remote control panel.
<b>Authentication Type</b> <ul style="list-style-type: none"> <li>None*</li> <li>Standard Authentication</li> </ul>	Set the authentication type when accessing the VNC client server.
<b>VNC Password</b>	Specify the password to connect to the VNC client server.   Note: This menu item appears only if Authentication Type is set to Standard Authentication.
 Note: An asterisk (*) next to a value indicates the factory default setting.	

## NOTIFICATIONS


MENU ITEM	DESCRIPTION
<b>ADF Loaded Beep</b> <ul style="list-style-type: none"> <li>Off</li> <li>On*</li> </ul>	Enable a sound when loading paper into the ADF.
<b>Alarm Control</b> <ul style="list-style-type: none"> <li>Off</li> <li>Single*</li> <li>Continuous</li> </ul>	Set the number of times that the alarm sounds when the printer requires user intervention.
<b>Supplies : Show Supply Estimates</b> <ul style="list-style-type: none"> <li>Show estimates*</li> <li>Do not show estimates</li> </ul>	Show the estimated status of the supplies.
<b>Supplies : Cartridge Alarm</b> <ul style="list-style-type: none"> <li>Off*</li> </ul>	Set the number of times that the alarm sounds when the cartridge is low.

MENU ITEM	DESCRIPTION
<ul style="list-style-type: none"> <li>• Single</li> <li>• Continuous</li> </ul>	
<b>Supplies</b> Custom Supply Notifications	Configure notification settings when the printer requires user intervention.   Note: This menu item appears only in the Embedded Web Server.
<b>E-mail Alerts Setup : E-mail Setup</b> <ul style="list-style-type: none"> <li>• Primary SMTP Gateway</li> <li>• Primary SMTP Gateway Port (25*)</li> <li>• Secondary SMTP Gateway</li> <li>• Secondary SMTP Gateway Port (25*)</li> <li>• SMTP Timeout (30 seconds*)</li> <li>• Reply Address</li> <li>• Always use SMTP default Reply Address (Off*)</li> <li>• Use SSL/TLS (Disabled*)</li> <li>• Require Trusted Certificate (On*)</li> <li>• SMTP Server Authentication</li> <li>• (No authentication required*)</li> <li>• Device-Initiated E-mail (None*)</li> <li>• Device Userid</li> <li>• Device Password</li> <li>• NTLM Domain</li> </ul>	Configure the e-mail settings of the printer.
<b>Error Prevention : Jam Assist</b> <ul style="list-style-type: none"> <li>• Off</li> <li>• On*</li> </ul>	Set the printer to check for jammed paper automatically.
<b>Error Prevention : Auto Continue</b> <ul style="list-style-type: none"> <li>• Disabled</li> <li>• Enabled* (5 seconds)</li> <li>• Auto Continue Time</li> </ul>	Let the printer continue processing or printing a job automatically after clearing certain attendance conditions.
<b>Error Prevention : Auto Reboot</b> <ul style="list-style-type: none"> <li>• Auto Reboot (Reboot always*)</li> </ul>	Set the printer to restart when an error occurs.
<b>Error Prevention :Auto Reboot</b> <ul style="list-style-type: none"> <li>• Max Auto Reboots (2*)</li> </ul>	Set the number of automatic reboots that the printer can perform.
<b>Error Prevention : Auto Reboot</b> <ul style="list-style-type: none"> <li>• Auto Reboot Window (720*)</li> </ul>	Set the number of seconds before the printer performs an automatic reboot.
<b>Error Prevention: Auto Reboot</b> <ul style="list-style-type: none"> <li>• Auto Reboot Counter</li> </ul>	Show a read-only information of the reboot counter.
<b>Error Prevention: Display Short Paper Error</b>	Set the printer to show a message when a short paper

MENU ITEM	DESCRIPTION
<ul style="list-style-type: none"> <li>Auto-clear*</li> <li>On</li> </ul>	<p>error occurs.</p> <p> Note: Short paper refers to the size of the paper loaded.</p>
<b>Error Prevention : Page Protect</b> <ul style="list-style-type: none"> <li>Off*</li> <li>On</li> </ul>	Set the printer to process the entire page into the memory before printing it.
<b>Jam Content Recovery : Jam Recovery</b> <ul style="list-style-type: none"> <li>Auto*</li> <li>Off</li> <li>On</li> </ul>	Set the printer to reprint jammed pages.
<b>Jam Content Recovery : Scanner Jam Recovery</b> <ul style="list-style-type: none"> <li>Job level</li> <li>Page level*</li> </ul>	Specify how to restart a scan job after resolving a paper jam.
<p> Note: An asterisk (*) next to a value indicates the factory default setting.</p>	

## POWER MANAGEMENT

MENU ITEM	DESCRIPTION
<b>Sleep Mode Profile : Print from Sleep Mode</b> <ul style="list-style-type: none"> <li>Stay awake after printing</li> <li>Enter Sleep Mode after printing*</li> </ul>	Set the printer to stay in Ready mode or return to Sleep mode after printing.
<b>Timeouts : Sleep Mode</b> <ul style="list-style-type: none"> <li>1–120 minutes (15*)</li> </ul>	Set the idle time before the printer begins operating in Sleep mode.
<b>Timeouts : Hibernate Timeout</b> <ul style="list-style-type: none"> <li>Disabled</li> <li>1 hour</li> <li>2 hours</li> <li>3 hours</li> <li>6 hours</li> <li>1 day</li> <li>2 days</li> <li>3 days*</li> <li>1 week</li> <li>2 weeks</li> <li>1 month</li> </ul>	Set the time before the printer turns off.

MENU ITEM	DESCRIPTION
<b>Timeouts</b> : Hibernate Timeout on Connection <ul style="list-style-type: none"> <li>• Hibernate</li> <li>• Do Not Hibernate*</li> </ul>	Set Hibernate Timeout to turn off the printer while an active Ethernet connection exists.
 Note: An asterisk (*) next to a value indicates the factory default setting.	


## RESTORE FACTORY DEFAULTS





MENU ITEM	DESCRIPTION
<b>Restore Settings</b> <ul style="list-style-type: none"> <li>• Restore all settings</li> <li>• Restore printer settings</li> <li>• Restore network settings</li> <li>• Restore fax settings</li> </ul>	Restore the printer factory default settings.


## MAINTENANCE

### Config Menu


MENU ITEM	DESCRIPTION
<b>USB Configuration</b> : USB PnP <ul style="list-style-type: none"> <li>• 1*</li> <li>• 2</li> </ul>	Change the USB driver mode of the printer to improve its compatibility with a personal computer.
<b>USB Configuration</b> : USB Scan to Local <ul style="list-style-type: none"> <li>• On*</li> <li>• Off</li> </ul>	Set whether the USB device driver enumerates as a USB Simple device (single interface) or as a USB Composite device (multiple interfaces).
<b>USB Configuration</b> : USB Speed <ul style="list-style-type: none"> <li>• Full</li> <li>• Auto*</li> </ul>	Set the USB port to run at full speed and disable its high-speed capabilities.
<b>Tray Configuration</b> : Show Tray Insert Message <ul style="list-style-type: none"> <li>• Off</li> <li>• Only for unknown sizes*</li> <li>• Always</li> </ul>	Show message about the tray status.
<b>Tray Configuration</b> : A5 Loading <ul style="list-style-type: none"> <li>• Short Edge</li> <li>• Long Edge*</li> </ul>	Specify the page orientation when loading A5 paper size.
<b>Tray Configuration</b> : Paper Prompts <ul style="list-style-type: none"> <li>• Auto*</li> </ul>	Set the paper source that the user fills when a prompt to load paper appears.

MENU ITEM	DESCRIPTION
<ul style="list-style-type: none"> <li>Manual Paper</li> </ul>	
<b>Tray Configuration</b> : Envelope Prompts <ul style="list-style-type: none"> <li>Auto*</li> <li>Manual Envelope</li> </ul>	Set the paper source that the user fills when a prompt to load envelope appears.
<b>Tray Configuration</b> : Action for Prompts <ul style="list-style-type: none"> <li>Prompt user*</li> <li>Continue</li> <li>Use current</li> </ul>	Set the printer to resolve paper- or envelope-related change prompts.
<b>Reports</b> : Menu Settings Page <ul style="list-style-type: none"> <li>Event Log</li> <li>Event Log Summary</li> </ul>	Print reports about printer menu settings, status, and event logs.
<b>Supply Usage And Counters</b> Clear Supply Usage History	Reset the supply page counter or view the total printed pages.
<b>Printer Emulations</b> : PS Emulation <ul style="list-style-type: none"> <li>Off*</li> <li>On</li> </ul>	Set the printer to recognize and use the PS data stream.   Note: This menu item appears only in some printer models.
<b>Printer Emulations</b> : Emulator Security <ul style="list-style-type: none"> <li>Page Timeout (60*)</li> </ul>	Set the page timeout during emulation.
<b>Printer Emulations</b> : Emulator Security <ul style="list-style-type: none"> <li>Reset Emulator After Job (Off*)</li> </ul>	Reset the emulator after a print job.
<b>Printer Emulations</b> : Emulator Security <ul style="list-style-type: none"> <li>Disable Printer Message Access (On*)</li> </ul>	Disable access to the printer message during emulation.
<b>Fax Configuration</b> : Fax Low Power Support <ul style="list-style-type: none"> <li>Disable Sleep</li> <li>Permit Sleep</li> <li>Auto*</li> </ul>	Specify the printer power setting when it is in fax mode.
<b>Print Configuration</b> : Font Sharpening <ul style="list-style-type: none"> <li>0–150 (24*)</li> </ul>	Set a text point-size value below which the high-frequency screens are used when printing font data.
<b>Print Configuration</b> <ul style="list-style-type: none"> <li>Print Density               <ul style="list-style-type: none"> <li>Disabled</li> <li>1–5 (3*)</li> </ul> </li> <li>Copy Density</li> </ul>	Adjust the toner density when printing or copying documents.

MENU ITEM	DESCRIPTION
<ul style="list-style-type: none"> <li>– Copy Density</li> <li>– 1–5 (3*)</li> </ul>	
<b>Device Operations</b> : Quiet Mode <ul style="list-style-type: none"> <li>• On</li> <li>• Off*</li> </ul>	Set the printer to reduce the amount of noise that it makes when printing.   Note: Enabling this setting slows down the printer performance.
<b>Device Operations</b> : Panel Menus <ul style="list-style-type: none"> <li>• Enable*</li> <li>• Disable</li> </ul>	Set the printer to enable access to the control panel menus.   Note: This menu item appears only in the Embedded Web Server.
<b>Device Operations</b> Clear Custom Status	Erase all custom messages.
<b>Device Operations</b> Clear all remotely-installed messages	Erase messages that were remotely installed.
<b>Device Operations</b> : Automatically Display Error Screens <ul style="list-style-type: none"> <li>• On*</li> <li>• Off</li> </ul>	Show existing error messages on the display after the printer remains inactive on the home screen for a length of time equal to the Screen Timeout setting.   Note: This menu item appears only in some printer models.
<b>Scanner Configuration</b> : Scanner Manual Registration <ul style="list-style-type: none"> <li>• Print Quick Test</li> </ul>	Print a Quick Test target page.   Note: Make sure that the margin spacing on the target page is uniform all the way around the target. If it is not, then the printer margins may need to be reset.
<b>Scanner Configuration</b> : Scanner Manual Registration <ul style="list-style-type: none"> <li>• Front ADF Registration</li> <li>• Flatbed Registration</li> </ul>	Manually register the flatbed and ADF after replacing the ADF, scanner glass, or controller board.
<b>Scanner Configuration</b> : Edge Erase <ul style="list-style-type: none"> <li>• ADF Edge Erase               <ul style="list-style-type: none"> <li>– 0–6 (3*)</li> </ul> </li> <li>• Flatbed Edge Erase               <ul style="list-style-type: none"> <li>– 0–6 (3*)</li> </ul> </li> </ul>	Set the size, in millimeters, of the no-print area around an ADF or flatbed scan job.
<b>Scanner Configuration</b> : Disable Scanner <ul style="list-style-type: none"> <li>• Enabled*</li> <li>• Disabled</li> <li>• ADF Disabled</li> </ul>	Disable the scanner if it is not working properly.

MENU ITEM	DESCRIPTION
<b>Scanner Configuration : Tiff Byte Order</b> <ul style="list-style-type: none"> <li>• CPU Endianness*</li> <li>• Little Endian</li> <li>• Big Endian</li> </ul>	Set the byte order of a TIFF-formatted scan output.
<b>Scanner Configuration : Exact Tiff Rows Per Strip</b> <ul style="list-style-type: none"> <li>• On*</li> <li>• Off</li> </ul>	Set the RowsPerStrip tag value of a TIFF-formatted scan output.
 Note: An asterisk (*) next to a value indicates the factory default setting.	

### Out of Service Erase

MENU ITEM	DESCRIPTION
<ul style="list-style-type: none"> <li>• Printer Memory Last Sanitized</li> <li>• Sanitize all information on nonvolatile memory</li> <li>• Erase all printer and network settings</li> <li>• Erase all shortcuts and shortcut settings</li> </ul>	Clear all settings and shortcuts that are stored in the printer.   Note: Erase all shortcuts and shortcut settings is available only in some printer models.

### VISIBLE HOME SCREEN ICONS

MENU	DESCRIPTION
<ul style="list-style-type: none"> <li>• Copy</li> <li>• E-mail</li> <li>• Fax</li> <li>• Status/Supplies</li> <li>• Job Queue</li> <li>• Change Language</li> <li>• Held Jobs</li> <li>• USB</li> <li>• Scan to Computer</li> </ul>	Specify which icons to show on the home screen.

### ABOUT THIS PRINTER


MENU ITEM	DESCRIPTION
<b>Xerox Asset Tag</b>	The maximum length is 32 characters.
<b>Customer Asset Tag</b>	Describe the printer. The maximum length is 32 characters.
<b>Printer Location</b>	Identify the printer location. The maximum length is



MENU ITEM	DESCRIPTION
	63 characters.
<b>Contact</b>	Personalize the printer name. The maximum length is 63 characters.
<b>Export Configuration File to USB*</b>	Export configuration files to a flash drive.
<b>Export Compressed Logs to USB*</b>	Export compressed log files to a flash drive.
* This menu item appears only in some printer models.	




## Print


### LAYOUT

MENU ITEM	DESCRIPTION
<b>Sides</b> <ul style="list-style-type: none"> <li>1-sided*</li> <li>2-sided</li> </ul>	Specify whether to print on one side or two sides of the paper.
<b>Flip Style</b> <ul style="list-style-type: none"> <li>Long Edge*</li> <li>Short Edge</li> </ul>	Determine which side of the paper (long edge or short edge) is bound when performing two-sided printing.   Note: Depending on the option selected, the printer automatically offsets each printed information of the page to bind the job correctly.
<b>Blank Pages</b> <ul style="list-style-type: none"> <li>Print</li> <li>Do Not Print*</li> </ul>	Print blank pages that are included in a print job.
<b>Collate</b> <ul style="list-style-type: none"> <li>Off [1,1,1,2,2,2]</li> <li>On [1,2,1,2,1,2]*</li> </ul>	Keep the pages of a print job stacked in sequence, particularly when printing multiple copies of the job.
<b>Separator Sheets</b> <ul style="list-style-type: none"> <li>None*</li> <li>Between Copies</li> <li>Between Jobs</li> <li>Between Pages</li> </ul>	Insert blank separator sheets when printing.
<b>Separator Sheet Source</b> Tray [x] (1*)	Specify the paper source for the separator sheet.
<b>Pages per Side</b> <ul style="list-style-type: none"> <li>Off*</li> <li>2 pages per side</li> <li>3 pages per side</li> <li>4 pages per side</li> <li>6 pages per side</li> <li>9 pages per side</li> <li>12 pages per side</li> <li>16 pages per side</li> </ul>	Print multiple page images on one side of a sheet of paper.
<b>Pages per Side Ordering</b> <ul style="list-style-type: none"> <li>Horizontal*</li> <li>Reverse Horizontal</li> </ul>	Specify the positioning of multiple page images when using Pages per Side.



MENU ITEM	DESCRIPTION
<ul style="list-style-type: none"> <li>• Vertical</li> <li>• Reverse Vertical</li> </ul>	 Note: The positioning depends on the number of page images and their page orientation.
<b>Pages per Side Orientation</b> <ul style="list-style-type: none"> <li>• Auto*</li> <li>• Landscape</li> <li>• Portrait</li> </ul>	Specify the orientation of a multiple-page document when using Pages per Side.
<b>Pages per Side Border</b> <ul style="list-style-type: none"> <li>• None*</li> <li>• Solid</li> </ul>	Print a border around each page image when using Pages per Side.
<b>Copies</b> 1–9999 (1*)	Specify the number of copies for each print job.
<b>Print Area</b> <ul style="list-style-type: none"> <li>• Normal*</li> <li>• Whole Page</li> </ul>	Set the printable area on a sheet of paper.
 Note: An asterisk (*) next to a value indicates the factory default setting.	

## SETUP

MENU ITEM	DESCRIPTION
<b>Printer Language</b> <ul style="list-style-type: none"> <li>• PCL Emulation</li> <li>• PS Emulation</li> </ul>	Set the printer language.   Note: Setting a printer language default does not prevent a software program from sending print jobs that use another printer language.
<b>Resource Save</b> <ul style="list-style-type: none"> <li>• On</li> <li>• Off*</li> </ul>	Determine what the printer does with downloaded resources, such as fonts and macros, when it receives a job that requires more than the available memory. <ul style="list-style-type: none"> <li>• When set to Off, the printer retains downloaded resources only until memory is needed. Resources associated with the inactive printer language are deleted.</li> <li>• When set to On, the printer preserves all the permanent downloaded resources across all language switches. When necessary, the printer shows memory full messages instead of deleting permanent resources.</li> </ul>


MENU ITEM	DESCRIPTION
<b>Print All Order</b> <ul style="list-style-type: none"> <li>• Alphabetical*</li> <li>• Newest First</li> <li>• Oldest First</li> </ul>	Specify the order you choose to print all held and confidential jobs.
 Note: An asterisk (*) next to a value indicates the factory default setting.	

## QUALITY




MENU ITEM	DESCRIPTION
<b>Print Resolution</b> <ul style="list-style-type: none"> <li>• 300 dpi</li> <li>• 600 dpi*</li> <li>• 1200 Image Q</li> <li>• 2400 Image Q</li> </ul>	Set the resolution for the text and images on the printed output.   Note: Resolution is determined in dots per inch or image quality.
<b>Toner Darkness</b> <ul style="list-style-type: none"> <li>• Light</li> <li>• Normal*</li> <li>• Dark</li> </ul>	Determine the lightness or darkness of text images.
<b>Halftone</b> <ul style="list-style-type: none"> <li>• Normal*</li> <li>• Detail</li> </ul>	Enhance the printed output to have smoother lines with sharper edges.
 Note: An asterisk (*) next to a value indicates the factory default setting.	

## PDF

MENU ITEM	DESCRIPTION
<b>Scale To Fit</b> <ul style="list-style-type: none"> <li>• Yes</li> <li>• No*</li> </ul>	Scale the page content to fit the selected paper size.
<b>Annotations</b> <ul style="list-style-type: none"> <li>• Print</li> <li>• Do Not Print*</li> </ul>	Specify whether to print annotations in the PDF.





MENU ITEM	DESCRIPTION
<b>Print PDF Error</b> <ul style="list-style-type: none"> <li>Off</li> <li>On*</li> </ul>	Enable the printing of PDF error.
 Note: An asterisk (*) next to a value indicates the factory default setting.	



## POSTSCRIPT

MENU ITEM	DESCRIPTION
<b>Print PS Error</b> <ul style="list-style-type: none"> <li>Off*</li> <li>On</li> </ul>	Print a page that describes the PostScript® error.   Note: When an error occurs, processing of the job stops, the printer prints an error message, and the rest of the print job is flushed.
<b>Minimum Line Width</b> 1–30 (2*)	Set the minimum stroke width of any job printed in 1200 dpi.
<b>Lock PS Startup Mode</b> <ul style="list-style-type: none"> <li>Off</li> <li>On*</li> </ul>	Disable the SysStart file.
<b>Wait Timeout</b> <ul style="list-style-type: none"> <li>Disabled</li> <li>Enabled*</li> </ul>	Enable the printer to wait for more data before canceling a print job.
<b>Wait Timeout Time</b> 15–65535 (40*)	Set the time in seconds for the printer to wait for more data before canceling a print job.   Note: This menu item appears only when Wait Timeout is enabled.
 Note: An asterisk (*) next to a value indicates the factory default setting.	





## PCL

MENU ITEM	DESCRIPTION
<b>Font Name</b> [List of available fonts] (Courier*)	Select a font from the specified font source.
<b>Symbol Set</b> [List of available symbol set] (10U PC-8*)	Specify the symbol set for each font name.

MENU ITEM	DESCRIPTION
	 Note: A symbol set is a set of alphabetic and numeric characters, punctuation, and special symbols. Symbol sets support the different languages or specific programs such as math symbols for scientific text.
<b>Pitch</b> 0.08–100 (10*)	Specify the pitch for fixed or monospaced fonts.   Note: Pitch refers to the number of fixed-space characters in a horizontal inch of type.
<b>Orientation</b> <ul style="list-style-type: none"> <li>• Portrait*</li> <li>• Landscape</li> <li>• Reverse Portrait</li> <li>• Reverse Landscape</li> </ul>	Specify the orientation of text and graphics on the page.
<b>Lines per Page</b> 1–255	Specify the number of lines of text for each page printed through the PCL data stream. <ul style="list-style-type: none"> <li>• This menu item activates vertical escapement that causes the selected number of requested lines to print between the default margins of the page.</li> <li>• 60 is the U.S. factory default setting. 64 is the international factory default setting.</li> </ul>
<b>PCL5 Minimum Line Width</b> 1–30 (2*)	Set the initial minimum stroke width of any job printed in 1200 dpi.
<b>PCLXL Minimum Line Width</b> 1–30 (2*)	
<b>A4 Width</b> <ul style="list-style-type: none"> <li>• 198mm*</li> <li>• 203mm</li> </ul>	Set the width of the logical page on A4-size paper.   Note: Logical page is the space on the physical page where data is printed.
<b>Auto CR after LF</b> <ul style="list-style-type: none"> <li>• Off*</li> <li>• On</li> </ul>	Set the printer to perform a carriage return after a line feed control command.   Note: Carriage return is a mechanism that commands the printer to move the position of the cursor to the first position on the same line.
<b>Auto LF after CR</b> <ul style="list-style-type: none"> <li>• Off*</li> <li>• On</li> </ul>	Set the printer to perform a line feed after a carriage return control command.
<b>Print Timeout</b> <ul style="list-style-type: none"> <li>• Disabled</li> </ul>	Enable the printer to end a print job after it has been idle for the specified amount of time in seconds.


MENU ITEM	DESCRIPTION
<ul style="list-style-type: none"> <li>Enabled*</li> </ul>	
<b>Print Timeout Time</b> 1–255 (90*)	Set the time in seconds for the printer to end a print job after it has been idle.   Note: This menu item appears only when Print Timeout is enabled.
 Note: An asterisk (*) next to a value indicates the factory default setting.	

## IMAGE

MENU ITEM	DESCRIPTION
<b>Auto Fit</b> <ul style="list-style-type: none"> <li>On</li> <li>Off*</li> </ul>	Select the best available paper size and orientation setting for an image.   Note: When set to On, this menu item overrides the scaling and orientation settings for the image.
<b>Invert</b> <ul style="list-style-type: none"> <li>Off*</li> <li>On</li> </ul>	Invert bitonal monochrome images.   Note: This menu item does not apply to GIF or JPEG image formats.
<b>Scaling</b> <ul style="list-style-type: none"> <li>Anchor Top Left</li> <li>Best Fit*</li> <li>Anchor Center</li> <li>Fit Height/Width</li> <li>Fit Height</li> <li>Fit Width</li> </ul>	Adjust the image to fit the printable area.   Note: When Auto Fit is set to On, Scaling is automatically set to Best Fit.
<b>Orientation</b> <ul style="list-style-type: none"> <li>Portrait*</li> <li>Landscape</li> <li>Reverse Portrait</li> <li>Reverse Landscape</li> </ul>	Specify the orientation of text and graphics on the page.
 Note: An asterisk (*) next to a value indicates the factory default setting.	


## Paper



### TRAY CONFIGURATION

MENU ITEM	DESCRIPTION
<b>Default Source</b> <ul style="list-style-type: none"> <li>Tray [x] (1*)</li> <li>Manual Paper</li> <li>Manual Envelope</li> </ul>	Set the paper source for all print jobs.
<b>Paper Size/Type</b> <ul style="list-style-type: none"> <li>Tray [x] (1*)</li> <li>Manual Paper</li> <li>Manual Envelope</li> </ul>	Specify the paper size or paper type loaded in each paper source.
<b>Substitute Size</b> <ul style="list-style-type: none"> <li>Off</li> <li>Letter/A4</li> <li>All Listed*</li> </ul>	Set the printer to substitute a specified paper size if the requested size is not loaded in any paper source. <ul style="list-style-type: none"> <li>Off prompts the user to load the required paper size.</li> <li>Letter/A4 prints an A4-size document on letter when loading letter, and letter-size jobs on A4 paper size when loading A4.</li> <li>All Listed substitutes Letter/A4.</li> </ul>
 Note: An asterisk (*) next to a value indicates the factory default setting.	


### MEDIA CONFIGURATION

#### Universal Setup

MENU ITEM	DESCRIPTION
<b>Units of Measure</b> <ul style="list-style-type: none"> <li>Inches</li> <li>Millimeters</li> </ul>	Specify the unit of measurement for the universal paper.   Note: Inches is the U.S. factory default setting. Millimeters is the international factory default setting.
<b>Portrait Width</b> <ul style="list-style-type: none"> <li>3.00–14.17inches (8.50*)</li> <li>76–360mm (216*)</li> </ul>	Set the portrait width of the universal paper.
<b>Portrait Height</b> <ul style="list-style-type: none"> <li>3.00–14.17inches (14*)</li> <li>76–360mm (356*)</li> </ul>	Set the portrait height of the universal paper.

MENU ITEM	DESCRIPTION
<b>Feed Direction</b> <ul style="list-style-type: none"> <li>• Short Edge*</li> <li>• Long Edge</li> </ul>	<p>Set the printer to pick paper from the short edge or long edge direction.</p> <p> Note: Long Edge appears only when the longest edge is shorter than the maximum width supported.</p>
<p> Note: An asterisk (*) next to a value indicates the factory default setting.</p>	

### Custom Scan Sizes

MENU ITEM	DESCRIPTION
<b>Custom Scan Size [x]</b> <ul style="list-style-type: none"> <li>• Scan Size Name</li> <li>• Width <ul style="list-style-type: none"> <li>– 1–8.50inches (8.50*)</li> <li>– 25–216mm (216*)</li> </ul> </li> <li>• Height <ul style="list-style-type: none"> <li>– 1–14inches (11*)</li> <li>– 25–356mm (279*)</li> </ul> </li> <li>• Orientation <ul style="list-style-type: none"> <li>– Portrait*</li> <li>– Landscape</li> </ul> </li> <li>• 2 scans per side <ul style="list-style-type: none"> <li>– Off*</li> <li>– On</li> </ul> </li> </ul>	<p>Assign a scan size name and configure the scan settings.</p>
<p> Note: An asterisk (*) next to a value indicates the factory default setting.</p>	




**Media Types**


MENU ITEM	DESCRIPTION
<ul style="list-style-type: none"><li>• Plain Paper</li><li>• Card Stock</li><li>• Recycled</li><li>• Labels</li><li>• Bond</li><li>• Envelope</li><li>• Letterhead</li><li>• Preprinted</li><li>• Colored Paper</li><li>• Light</li><li>• Heavy</li></ul>	Specify the texture, weight, and orientation of the paper loaded.

## Copy

## COPY DEFAULTS

MENU ITEM	DESCRIPTION
<b>Content Type</b> <ul style="list-style-type: none"> <li>Text</li> <li>Text/Photo*</li> <li>Photo</li> <li>Graphics</li> </ul>	Improve the output result based on the content of the original document.
<b>Sides</b> <ul style="list-style-type: none"> <li>1 sided to 1 sided*</li> <li>1 sided to 2 sided</li> </ul>	Specify the scanning behavior based on the original document.
<b>Pages per Side</b> <ul style="list-style-type: none"> <li>Off*</li> <li>2 Portrait pages</li> <li>4 Portrait pages</li> <li>2 Landscape pages</li> <li>4 Landscape pages</li> </ul>	Specify the number of page images to print on one side of a sheet of paper.
<b>Print Page Borders</b> <ul style="list-style-type: none"> <li>Off*</li> <li>On</li> </ul>	Place a border around each image when printing multiple pages on a single page.
<b>Collate</b> <ul style="list-style-type: none"> <li>Off [1,1,1,2,2,2]</li> <li>On [1,2,1,2,1,2]*</li> </ul>	Print multiple copies in sequence.
<b>“Copy from” Size</b> [List of paper sizes]	Set the paper size of the original document.   Note: Letter is the U.S. factory default setting. A4 is the international factory default setting.
<b>“Copy to” Source</b> <ul style="list-style-type: none"> <li>Tray [x] (1*)</li> <li>Manual Feeder</li> <li>Auto Size Match</li> </ul>	Specify the paper source for the copy job.
<b>Darkness</b> 1 to 9 (5*)	Adjust the darkness of the scanned image.
<b>Number of Copies</b> 1–9999 (1*)	Specify the number of copies.


## Advanced Imaging

MENU ITEM	DESCRIPTION
<b>Contrast</b> <ul style="list-style-type: none"> <li>• Best for Content*</li> <li>• -0</li> <li>• -1</li> <li>• -2</li> <li>• -3</li> <li>• -4</li> <li>• -5</li> </ul>	Specify the contrast of the output.
<b>Background Removal</b> <ul style="list-style-type: none"> <li>• Level</li> <li>• -4 to 4 (0*)</li> </ul>	Adjust the amount of background visible on a scanned image.
<b>Scan Edge to Edge</b> <ul style="list-style-type: none"> <li>• Off*</li> <li>• On</li> </ul>	Allow edge-to-edge scanning of the original document.
 Note: An asterisk (*) next to a value indicates the factory default setting.	

## Fax


## FAX DEFAULTS



## Fax Mode

MENU ITEM	DESCRIPTION
<b>Fax Mode</b> <ul style="list-style-type: none"> <li>Fax*</li> <li>Disabled</li> </ul>	Select a fax mode.
 Note: An asterisk (*) next to a value indicates the factory default setting.	




## Fax Setup


## General Fax settings

MENU ITEM	DESCRIPTION
<b>Fax Name</b>	Identify your fax machine.
<b>Fax Number</b>	Identify your fax number.
<b>Fax ID</b> <ul style="list-style-type: none"> <li>Fax Name</li> <li>Fax Number*</li> </ul>	Notify fax recipients of your fax name or fax number.
<b>Memory Use</b> <ul style="list-style-type: none"> <li>All receive</li> <li>Mostly receive</li> <li>Equal*</li> <li>Mostly send</li> <li>All send</li> </ul>	Set the amount of internal printer memory allocated for faxing.  Note: This menu item prevents memory buffer conditions and failed faxes.
<b>Cancel Faxes</b> <ul style="list-style-type: none"> <li>Allow*</li> <li>Don't Allow</li> </ul>	Cancel outgoing faxes before they are transmitted, or cancel incoming faxes before they finish printing.
<b>Fax Number Masking</b> <ul style="list-style-type: none"> <li>Off*</li> <li>From Left</li> <li>From Right</li> </ul>	Specify the format for masking an outgoing fax number.
<b>Digits to Mask</b> 0–58 (0*)	Specify the number of digits to mask in an outgoing fax number.


MENU ITEM	DESCRIPTION
<b>Enable Line Connected Detection</b> <ul style="list-style-type: none"> <li>On*</li> <li>Off</li> </ul>	Determine whether a telephone line is connected to the printer.   Note: Detection takes place when turning on the printer and before each call.
<b>Optimize Fax Compatibility</b>	Configure the printer fax functionality for optimal compatibility with other fax machines.
 Note: An asterisk (*) next to a value indicates the factory default setting.	

### Fax Send Settings


MENU ITEM	DESCRIPTION
<b>Resolution</b> <ul style="list-style-type: none"> <li>Standard*</li> <li>Fine</li> <li>Super Fine</li> <li>Ultra Fine</li> </ul>	Set the resolution of the scanned image.   Note: A higher resolution increases fax transmission time and requires higher memory.
<b>Original Size</b> [List of paper sizes] (Mixed Sizes*)	Specify the size of the original document.
<b>Orientation</b> <ul style="list-style-type: none"> <li>Portrait*</li> <li>Landscape</li> </ul>	Specify the orientation of the original document.   Note: This menu item appears only in some printer models.
<b>Content Type</b> <ul style="list-style-type: none"> <li>Text*</li> <li>Text/Photo</li> <li>Photo</li> <li>Graphics</li> </ul>	Improve the output result based on the content of the original document.
<b>Darkness</b> 1–9 (5*)	Adjust the darkness of the scanned image.
<b>Behind a PABX</b> <ul style="list-style-type: none"> <li>On</li> <li>Off*</li> </ul>	Set the printer to dial a fax number without waiting to recognize the dial tone.   Note: Private Automated Branch Exchange (PABX) is a telephone network that allows a single access number to offer multiple lines to outside callers.


MENU ITEM	DESCRIPTION
<b>Dial Mode</b> <ul style="list-style-type: none"> <li>• Tone*</li> <li>• Pulse</li> </ul>	Specify the dial mode for incoming or outgoing faxes.
 Note: An asterisk (*) next to a value indicates the factory default setting.	

### Advanced Imaging

MENU ITEM	DESCRIPTION
<b>Contrast</b> <ul style="list-style-type: none"> <li>• Best for Content*</li> <li>• 0</li> <li>• 1</li> <li>• 2</li> <li>• 3</li> <li>• 4</li> <li>• 5</li> </ul>	Set the contrast of the output.
<b>Background Removal</b> <ul style="list-style-type: none"> <li>• Level</li> <li>• -4 to 4 (0*)</li> </ul>	Adjust the amount of background visible on a scanned image.
<b>Scan Edge to Edge</b> <ul style="list-style-type: none"> <li>• On</li> <li>• Off*</li> </ul>	Allow edge-to-edge scanning of the original document.
 Note: An asterisk (*) next to a value indicates the factory default setting.	


### Admin Controls

MENU ITEM	DESCRIPTION
<b>Automatic Redial</b> 0–9 (5*)	Adjust the number of redial attempts based on the activity levels of recipient fax machines.
<b>Redial Frequency</b> 1–200 minutes (3*)	Increase the time between redial attempts to increase the chance of sending fax successfully.
<b>Enable ECM</b> <ul style="list-style-type: none"> <li>• On*</li> <li>• Off</li> </ul>	Activate Error Correction Mode (ECM) for fax jobs.   Note: ECM detects and corrects errors in the fax transmission process caused by telephone line noise and poor signal strength.
<b>Enable Fax Scans</b> <ul style="list-style-type: none"> <li>• On*</li> </ul>	Fax documents that are scanned at the printer.

MENU ITEM	DESCRIPTION
<ul style="list-style-type: none"> <li>Off</li> </ul>	
<b>Driver to Fax</b> <ul style="list-style-type: none"> <li>On*</li> <li>Off</li> </ul>	Allow the print driver to send fax.
<b>Allow Save as Shortcut</b> <ul style="list-style-type: none"> <li>On*</li> <li>Off</li> </ul>	Save fax numbers as shortcuts on the printer.
<b>Max Speed</b> <ul style="list-style-type: none"> <li>33600*</li> <li>14400</li> <li>9600</li> <li>4800</li> <li>2400</li> </ul>	Set the maximum speed for sending fax.
<b>Enable Color Fax Scans</b> <ul style="list-style-type: none"> <li>Off by Default*</li> <li>On by Default</li> <li>Never Use</li> <li>Always Use</li> </ul>	Enable color scans for fax.
<b>Auto Convert Color Faxes to Mono Faxes</b> <ul style="list-style-type: none"> <li>On*</li> <li>Off</li> </ul>	Convert all outgoing color faxes to black and white.
<b>Confirm Fax Number</b> <ul style="list-style-type: none"> <li>On*</li> <li>Off</li> </ul>	Ask the user to confirm the fax number.
<b>Dial Prefix</b>	Set a dialing prefix.
 Note: An asterisk (*) next to a value indicates the factory default setting.	

#### Fax Receive Settings



MENU ITEM	DESCRIPTION
<b>Rings to Answer</b> 1–25 (3*)	Set the number of rings for incoming fax.
<b>Auto Reduction</b> <ul style="list-style-type: none"> <li>On*</li> <li>Off</li> </ul>	Scale incoming fax to fit on the page.
<b>Paper Source</b>	Set the paper source for printing incoming fax.

MENU ITEM	DESCRIPTION
<ul style="list-style-type: none"> <li>• Tray [X]</li> <li>• Auto*</li> </ul>	
<b>Separator Sheets</b> <ul style="list-style-type: none"> <li>• None*</li> <li>• Before Job</li> <li>• After Job</li> </ul>	Specify whether to insert blank separator sheets when printing.
<b>Separator Sheet Source</b> Tray [X] (1*)	Specify the paper source for the separator sheet.
<b>Fax Footer</b> <ul style="list-style-type: none"> <li>• On</li> <li>• Off*</li> </ul>	Print the transmission information at the bottom of each page from a received fax.
<b>Fax Footer Time Stamp</b> <ul style="list-style-type: none"> <li>• Receive*</li> <li>• Print</li> </ul>	Print the time stamp at the bottom of each page from a received fax.
 Note: An asterisk (*) next to a value indicates the factory default setting.	

### Admin Controls


MENU ITEM	DESCRIPTION
<b>Enable Fax Receive</b> <ul style="list-style-type: none"> <li>• On*</li> <li>• Off</li> </ul>	Set the printer to receive fax.
<b>Enable Color Fax Receive</b> <ul style="list-style-type: none"> <li>• On*</li> <li>• Off</li> </ul>	Set the printer to receive fax in color.
<b>Enable Caller ID</b> <ul style="list-style-type: none"> <li>• On*</li> <li>• Off</li> </ul>	Show the number that is sending the incoming fax.
<b>Block No Name Fax</b> <ul style="list-style-type: none"> <li>• On*</li> <li>• Off</li> </ul>	Block incoming faxes sent from devices with no station ID or fax ID specified.
<b>Answer On</b> <ul style="list-style-type: none"> <li>• All Rings*</li> <li>• Single Ring Only</li> <li>• Double Ring Only</li> <li>• Triple Ring Only</li> <li>• Single or Double Rings Only</li> </ul>	Set a distinctive ring pattern for incoming fax.




MENU ITEM	DESCRIPTION
<ul style="list-style-type: none"> <li>• Single or Triple Rings Only</li> <li>• Double or Triple Rings Only</li> </ul>	
<b>Auto Answer</b> <ul style="list-style-type: none"> <li>• On*</li> <li>• Off</li> </ul>	Set the printer to receive fax automatically.
<b>Fax Forwarding</b> <ul style="list-style-type: none"> <li>• Print*</li> <li>• Print and Forward</li> <li>• Forward</li> </ul>	Specify whether to forward received fax.
<b>Forward To</b> <ul style="list-style-type: none"> <li>• Destination 1</li> <li>• Destination 2</li> </ul>	Specify where to forward received fax.  Note: This menu item appears only when Fax Forwarding is set to Print and Forward or Forward.
<b>Max Speed</b> <ul style="list-style-type: none"> <li>• 33600*</li> <li>• 14400</li> <li>• 9600</li> <li>• 4800</li> <li>• 2400</li> </ul>	Set the maximum speed for transmitting fax.
 Note: An asterisk (*) next to a value indicates the factory default setting.	

**Fax Log settings**

MENU ITEM	DESCRIPTION
<b>Transmission Log Frequency</b> <ul style="list-style-type: none"> <li>• Always*</li> <li>• Never</li> <li>• Only for Error</li> </ul>	Specify how often the printer creates a transmission log.
<b>Transmission Log Action</b> <ul style="list-style-type: none"> <li>• Print</li> <li>• Off</li> <li>• On*</li> <li>• E-mail</li> <li>• Off*</li> <li>• On</li> </ul>	Print or e-mail a log for successful fax transmission or transmission error.
<b>Receive Error Log</b> <ul style="list-style-type: none"> <li>• Print Never*</li> <li>• Print on Error</li> </ul>	Print a log for fax-receive failures.

MENU ITEM	DESCRIPTION
<b>Auto Print Logs</b> <ul style="list-style-type: none"> <li>On*</li> <li>Off</li> </ul>	Print all fax activity.
<b>Log Paper Source</b> Tray [x] (1*)	Specify the paper source for printing logs.
<b>Logs Display</b> <ul style="list-style-type: none"> <li>Remote Fax Name*</li> <li>Dialed Number</li> </ul>	Identify the sender by remote fax name or fax number.
<b>Enable Job Log</b> <ul style="list-style-type: none"> <li>On*</li> <li>Off</li> </ul>	View a summary of all fax jobs.
<b>Enable Call Log</b> <ul style="list-style-type: none"> <li>On*</li> <li>Off</li> </ul>	View a summary of fax dialing history.
 Note: An asterisk (*) next to a value indicates the factory default setting.	


### Speaker settings

MENU ITEM	DESCRIPTION
<b>Speaker Mode</b> <ul style="list-style-type: none"> <li>Always Off*</li> <li>Always On</li> <li>On until Connected</li> </ul>	Set the fax speaker mode.
<b>Speaker Volume</b> <ul style="list-style-type: none"> <li>Low*</li> <li>High</li> </ul>	Adjust the fax speaker volume.
<b>Ringer Volume</b> <ul style="list-style-type: none"> <li>Off*</li> <li>On</li> </ul>	Enable the ringer volume.
 Note: An asterisk (*) next to a value indicates the factory default setting.	


## E-mail



## E-MAIL SETUP

MENU ITEM	DESCRIPTION
<b>Primary SMTP Gateway</b>	Type the IP address or host name of the primary SMTP server for sending e-mail.
<b>Primary SMTP Gateway Port</b> 1–65535 (25*)	Enter the port number of the primary SMTP server.
<b>Secondary SMTP Gateway</b>	Type the server IP address or host name of your secondary or backup SMTP server.
<b>Secondary SMTP Gateway Port</b> 1–65535 (25*)	Enter the server port number of your secondary or backup SMTP server.
<b>SMTP Timeout</b> 5–30 seconds (30*)	Set the time before the printer times out if the SMTP server does not respond.
<b>Reply Address</b>	Specify a reply address in the e-mail.
<b>Always use SMTP default Reply Address</b> <ul style="list-style-type: none"> <li>Off*</li> <li>On</li> </ul>	Always use the default reply address in the SMTP server.
<b>Use SSL/TLS</b> <ul style="list-style-type: none"> <li>Disabled*</li> <li>Negotiate</li> <li>Required</li> </ul>	Specify whether to send e-mail using an encrypted link.
<b>Require Trusted Certificate</b> <ul style="list-style-type: none"> <li>Off</li> <li>On*</li> </ul>	Require a trusted certificate when accessing the SMTP server.
<b>SMTP Server Authentication</b> <ul style="list-style-type: none"> <li>No authentication required*</li> <li>Login / Plain</li> <li>NTLM</li> <li>CRAM-MD5</li> <li>Digest-MD5</li> </ul>	Set the authentication type for the SMTP server.
<b>Device-Initiated E-mail</b> <ul style="list-style-type: none"> <li>None*</li> <li>Use Device SMTP Credentials</li> </ul>	Specify whether credentials are required for device-initiated e-mail.

MENU ITEM	DESCRIPTION
<b>Device Userid</b>	Specify the user ID and password to connect to the SMTP server.
<b>Device Password</b>	
<b>NTLM Domain</b>	Specify the domain name for the NTLM security protocol.
 Note: An asterisk (*) next to a value indicates the factory default setting.	

## E-MAIL DEFAULTS

MENU ITEM	DESCRIPTION
<b>Subject</b>	Specify the e-mail subject and message.
<b>Message</b>	
<b>File Name</b>	Specify the filename for the scanned image.
<b>Format</b> <ul style="list-style-type: none"> <li>• PDF (.pdf)*</li> <li>• TIFF (.tif)</li> <li>• JPEG (.jpg)</li> </ul>	Specify the file format for the scanned image.
<b>PDF Settings</b> <ul style="list-style-type: none"> <li>• PDF Version               <ul style="list-style-type: none"> <li>– 1.3</li> <li>– 1.4</li> <li>– 1.5*</li> <li>– 1.6</li> <li>– 1.7</li> </ul> </li> <li>• Archival Version               <ul style="list-style-type: none"> <li>– A-1a*</li> <li>– A-1b</li> </ul> </li> <li>• Secure               <ul style="list-style-type: none"> <li>– Off*</li> <li>– On</li> </ul> </li> <li>• Archival (PDF/A)               <ul style="list-style-type: none"> <li>– Off*</li> <li>– On</li> </ul> </li> </ul>	Set the PDF format of the scanned image.   Note: Archival Version and Archival (PDF/A) appear only if PDF Version is set to 1.4.
<b>Content Type</b>	Improve the output result based on the content of the original



MENU ITEM	DESCRIPTION
<ul style="list-style-type: none"> <li>• Text</li> <li>• Text/Photo*</li> <li>• Photo</li> <li>• Graphics</li> </ul>	document.
<b>Color</b> <ul style="list-style-type: none"> <li>• Black and White</li> <li>• Gray</li> <li>• Color*</li> <li>• Auto</li> </ul>	Specify the color when scanning an image.
<b>Resolution</b> <ul style="list-style-type: none"> <li>• 75 dpi</li> <li>• 150 dpi*</li> <li>• 200 dpi</li> <li>• 300 dpi</li> <li>• 400 dpi</li> <li>• 600 dpi</li> </ul>	Set the resolution of the scanned image.
<b>Darkness</b> 1–9 (5*)	Adjust the darkness of the scanned image.
<b>Orientation</b> <ul style="list-style-type: none"> <li>• Portrait*</li> <li>• Landscape</li> </ul>	Specify the orientation of the original document.  Note: This menu item appears only in some printer models.
<b>Original Size</b> [List of paper sizes]	Set the paper size of the original document.  Note: Mixed Sizes is the factory default setting.

## Advanced Imaging

MENU ITEM	DESCRIPTION
<b>Contrast</b> <ul style="list-style-type: none"> <li>Best for content*                             <ul style="list-style-type: none"> <li>0</li> <li>1</li> <li>2</li> <li>3</li> <li>4</li> <li>5</li> </ul> </li> </ul>	Specify the contrast of the output.
<b>Background Removal</b> <ul style="list-style-type: none"> <li>Level</li> <li>-4 to 4 (0*)</li> </ul>	Adjust the amount of background visible on a scanned image.
<b>Scan Edge to Edge</b> <ul style="list-style-type: none"> <li>On</li> <li>Off*</li> </ul>	Allow edge-to-edge scanning of the original document.


## Admin Controls

MENU ITEM	DESCRIPTION
<b>Max E-mail Size</b> 0–65535 (0*)	Set the allowable file size for each e-mail.
<b>Size Error Message</b>	Specify an error message that the printer sends when an e-mail exceeds its allowable file size.  You can type up to 1024 characters.
<b>Send Me a Copy</b> <ul style="list-style-type: none"> <li>Never appears*</li> <li>On by Default</li> <li>Off by Default</li> <li>Always On</li> </ul>	Send a copy of the e-mail to yourself.
<b>Text Default</b> 5–95 (75*)	Set the quality of text on a scanned image.
<b>Text/Photo Default</b> 5–95 (75*)	Set the quality of text or photo on a scanned image.
<b>Photo Default</b> 5–95 (50*)	Set the quality of a photo on a scanned image.



MENU ITEM	DESCRIPTION
<b>Transmission Log</b> <ul style="list-style-type: none"> <li>• Print log*</li> <li>• Do Not Print Log</li> <li>• Print Only For Error</li> </ul>	Print a log for successful e-mail transmission.
<b>Log Paper Source</b> Tray [x] (1*)	Specify the paper source for printing logs.
<b>Allow Save as Shortcut</b> <ul style="list-style-type: none"> <li>• On*</li> <li>• Off</li> </ul>	Save e-mail addresses as shortcuts.  Note: When set to Off, the Save As Shortcut button does not appear on the e-mail Destination screen.
<b>Reset E-mail Information After Sending</b> <ul style="list-style-type: none"> <li>• On*</li> <li>• Off</li> </ul>	Restore the default e-mail information after sending an e-mail.
 Note: An asterisk (*) next to a value indicates the factory default setting.	

## FTP

### FTP DEFAULTS


MENU ITEM	DESCRIPTION
<b>Format</b> <ul style="list-style-type: none"> <li>• PDF (.pdf)*</li> <li>• TIFF (.tif)</li> <li>• JPEG (.jpg)</li> </ul>	Specify the file format for the scanned image.
<b>PDF Settings</b> <ul style="list-style-type: none"> <li>• PDF Version <ul style="list-style-type: none"> <li>– 1.3</li> <li>– 1.4</li> <li>– 1.5*</li> <li>– 1.6</li> <li>– 1.7</li> </ul> </li> <li>• Archival Version <ul style="list-style-type: none"> <li>– A-1a*</li> <li>– A-1b</li> </ul> </li> <li>• Secure <ul style="list-style-type: none"> <li>– Off*</li> <li>– On</li> </ul> </li> <li>• Archival (PDF/A) <ul style="list-style-type: none"> <li>– Off*</li> <li>– On</li> </ul> </li> </ul>	Set the PDF format for the scanned image.   Note: Archival Version and Archival (PDF/A) appear only if PDF Version is set to 1.4.
<b>Content Type</b> <ul style="list-style-type: none"> <li>• Text</li> <li>• Text/Photo*</li> <li>• Photo</li> <li>• Graphics</li> </ul>	Improve the output result based on the content of the original document.
<b>Color</b> <ul style="list-style-type: none"> <li>• Black and White</li> <li>• Gray</li> <li>• Color*</li> <li>• Auto</li> </ul>	Specify the color when scanning an image.
<b>Resolution</b> <ul style="list-style-type: none"> <li>• 75 dpi</li> </ul>	Set the resolution of the scanned image.



MENU ITEM	DESCRIPTION
<ul style="list-style-type: none"> <li>• 150 dpi*</li> <li>• 200 dpi</li> <li>• 300 dpi</li> <li>• 400 dpi</li> <li>• 600 dpi</li> </ul>	
<b>Darkness</b> 1–9 (5*)	Adjust the darkness of the scanned image.
<b>Orientation</b> <ul style="list-style-type: none"> <li>• Portrait*</li> <li>• Landscape</li> </ul>	Specify the orientation of the original document.  Note: This menu item appears only in some printer models.
<b>Original Size</b> [List of paper sizes] (Mixed Sizes*)	Set the paper size of the original document.
<b>File Name</b>	Specify the file name of the scanned image.
 Note: An asterisk (*) next to a value indicates the factory default setting.	


### Advanced Imaging

MENU ITEM	DESCRIPTION
<b>Color Balance</b> <ul style="list-style-type: none"> <li>• Cyan - Red               <ul style="list-style-type: none"> <li>– -4 to 4 (0*)</li> </ul> </li> <li>• Magenta - Green               <ul style="list-style-type: none"> <li>– -4 to 4 (0*)</li> </ul> </li> <li>• Yellow - Blue               <ul style="list-style-type: none"> <li>– -4 to 4 (0*)</li> </ul> </li> </ul>	Adjust the color intensity during scanning.
<b>Auto Color Detect</b> <ul style="list-style-type: none"> <li>• Color Sensitivity               <ul style="list-style-type: none"> <li>– 1–9 (5*)</li> </ul> </li> <li>• Area Sensitivity               <ul style="list-style-type: none"> <li>– 1–9 (5*)</li> </ul> </li> <li>• FTP Bit Depth               <ul style="list-style-type: none"> <li>– 1 bit*</li> <li>– 8 bit</li> </ul> </li> <li>• Minimum Scan Resolution</li> </ul>	Set the amount of color that the printer detects from the original document.

MENU ITEM	DESCRIPTION
<ul style="list-style-type: none"> <li>– 75 dpi</li> <li>– 150 dpi</li> <li>– 200 dpi</li> <li>– 300 dpi*</li> </ul>	
<b>Contrast</b> <ul style="list-style-type: none"> <li>• Best for content* <ul style="list-style-type: none"> <li>– 0</li> <li>– 1</li> <li>– 2</li> <li>– 3</li> <li>– 4</li> <li>– 5</li> </ul> </li> </ul>	Specify the contrast of the output.
<b>Background Removal</b> <ul style="list-style-type: none"> <li>• Level</li> <li>• -4 to 4 (0*)</li> </ul>	Adjust the amount of background visible on a scanned image.
<b>Scan Edge to Edge</b> <ul style="list-style-type: none"> <li>• On</li> <li>• Off*</li> </ul>	Allow edge-to-edge scanning of the original document.
 Note: An asterisk (*) next to a value indicates the factory default setting.	


## Admin Controls



MENU ITEM	DESCRIPTION
<b>Text Default</b> 5–95 (75*)	Set the quality of text on a scanned image.
<b>Text/Photo Default</b> 5–95 (75*)	Set the quality of text or photo image on a scanned image.
<b>Photo Default</b> 5–95(50*)	Set the quality of a photo image on a scanned image.
<b>Transmission Log</b> <ul style="list-style-type: none"> <li>• Print log*</li> <li>• Do Not Print Log</li> <li>• Print Only For Error</li> </ul>	Print a log for successful FTP scan transmission.

MENU ITEM	DESCRIPTION
<b>Log Paper Source</b> Tray [x] (1*)	Specify the paper source for printing FTP logs.
 Note: An asterisk (*) next to a value indicates the factory default setting.	


## USB Drive

### FLASH DRIVE SCAN


MENU ITEM	DESCRIPTION
<b>Format</b> <ul style="list-style-type: none"> <li>• PDF (.pdf)*</li> <li>• TIFF (.tif)</li> <li>• JPEG (.jpg)</li> </ul>	Specify the file format for the scanned image.
<b>PDF Settings</b> <ul style="list-style-type: none"> <li>• PDF Version <ul style="list-style-type: none"> <li>– 1.3</li> <li>– 1.4</li> <li>– 1.5*</li> <li>– 1.6</li> <li>– 1.7</li> </ul> </li> <li>• Archival Version <ul style="list-style-type: none"> <li>– A-1a*</li> <li>– A-1b</li> </ul> </li> <li>• Secure <ul style="list-style-type: none"> <li>– Off*</li> <li>– On</li> </ul> </li> <li>• Archival (PDF/A) <ul style="list-style-type: none"> <li>– Off*</li> <li>– On</li> </ul> </li> </ul>	Set the PDF format for the scanned image.   Note: Archival Version and Archival (PDF/A) appear only if PDF Version is set to 1.4.
<b>Content Type</b> <ul style="list-style-type: none"> <li>• Text</li> <li>• Text/Photo*</li> <li>• Photo</li> <li>• Graphics</li> </ul>	Improve the output result based on the content of the original document.
<b>Color</b> <ul style="list-style-type: none"> <li>• Black and White</li> <li>• Gray</li> <li>• Color*</li> <li>• Auto</li> </ul>	Specify the color when scanning an image.
<b>Resolution</b> <ul style="list-style-type: none"> <li>• 75 dpi</li> </ul>	Set the resolution of the scanned image.

MENU ITEM	DESCRIPTION
<ul style="list-style-type: none"> <li>• 150 dpi*</li> <li>• 200 dpi</li> <li>• 300 dpi</li> <li>• 400 dpi</li> <li>• 600 dpi</li> </ul>	
<b>Darkness</b> 1–9 (5*)	Adjust the darkness of the scanned image.
<b>Orientation</b> <ul style="list-style-type: none"> <li>• Portrait*</li> <li>• Landscape</li> </ul>	Specify the orientation of the original document.  Note: This menu item is available only in some printer models.
<b>Original Size</b> [List of paper sizes] (Mixed Sizes*)	Set the paper size of the original document.
<b>File Name</b>	Specify the file name of the scanned image.
 Note: An asterisk (*) next to a value indicates the factory default setting.	


### Advanced Imaging



MENU ITEM	DESCRIPTION
<b>Contrast</b> <ul style="list-style-type: none"> <li>• Best for content*               <ul style="list-style-type: none"> <li>– 0</li> <li>– 1</li> <li>– 2</li> <li>– 3</li> <li>– 4</li> <li>– 5</li> </ul> </li> </ul>	Specify the contrast of the output.
<b>Background Removal</b> <ul style="list-style-type: none"> <li>• Level</li> <li>• -4 to 4 (0*)</li> </ul>	Adjust the amount of background visible on a scanned image.
<b>Scan Edge to Edge</b> <ul style="list-style-type: none"> <li>• On</li> <li>• Off*</li> </ul>	Allow edge-to-edge scanning of the original document.
 Note: An asterisk (*) next to a value indicates the factory default setting.	

## Admin Controls

MENU ITEM	DESCRIPTION
<b>Text Default</b> 5–95 (75*)	Set the quality of text on a scanned image.
<b>Text/Photo Default</b> 5–95 (75*)	Set the quality of text or photo on a scanned image.
<b>Photo Default</b> 5–95 (50*)	Set the quality of a photo on a scanned image.
 Note: An asterisk (*) next to a value indicates the factory default setting.	



## FLASH DRIVE PRINT

MENU ITEM	DESCRIPTION
<b>Number of Copies</b> 1–9999 (1*)	Set the number of copies.
<b>Paper Source</b> <ul style="list-style-type: none"> <li>• Tray [x] (1*)</li> <li>• Manual Paper</li> <li>• Manual Envelope</li> </ul>	Set the paper source for the print job.
<b>Collate</b> <ul style="list-style-type: none"> <li>• (1,1,1) (2,2,2)</li> <li>• (1,2,3) (1,2,3)*</li> </ul>	Print multiple copies in sequence.
<b>Sides</b> <ul style="list-style-type: none"> <li>• 1-Sided*</li> <li>• 2-Sided</li> </ul>	Specify whether to print on one side or two sides of the paper.
<b>Flip Style</b> <ul style="list-style-type: none"> <li>• Long Edge*</li> <li>• Short Edge</li> </ul>	Determine which side of the paper (long edge or short edge) is bound when performing two-sided printing.   Note: Depending on the option selected, the printer automatically offsets each printed information of the page to bind the job correctly.
<b>Pages per Side</b> <ul style="list-style-type: none"> <li>• Off*</li> <li>• 2 pages per side</li> <li>• 3 pages per side</li> <li>• 4 pages per side</li> </ul>	Print multiple page images on one side of a sheet of paper.


MENU ITEM	DESCRIPTION
<ul style="list-style-type: none"> <li>• 6 pages per side</li> <li>• 9 pages per side</li> <li>• 12 pages per side</li> <li>• 16 pages per side</li> </ul>	
<b>Pages per Side Ordering</b> <ul style="list-style-type: none"> <li>• Horizontal*</li> <li>• Reverse Horizontal</li> <li>• Reverse Vertical</li> <li>• Vertical</li> </ul>	Specify the positioning of multiple page images when using Pages per Side.   Note: The positioning depends on the number of page images and their page orientation.
<b>Pages per Side Orientation</b> <ul style="list-style-type: none"> <li>• Auto*</li> <li>• Landscape</li> <li>• Portrait</li> </ul>	Specify the orientation of a multiple-page document when using Pages per Side.
<b>Pages per Side Border</b> <ul style="list-style-type: none"> <li>• None*</li> <li>• Solid</li> </ul>	Print a border around each page image when using Pages per Side.
<b>Separator Sheets</b> <ul style="list-style-type: none"> <li>• Off*</li> <li>• Between Copies</li> <li>• Between Jobs</li> <li>• Between Pages</li> </ul>	Specify whether to insert blank separator sheets when printing.
<b>Separator Sheet Source</b> Tray 1	Specify the paper source for the separator sheet.
<b>Blank Pages</b> <ul style="list-style-type: none"> <li>• Do Not Print*</li> <li>• Print</li> </ul>	Specify whether to print blank pages in a print job.
 Note: An asterisk (*) next to a value indicates the factory default setting.	

## Network/Ports

## NETWORK OVERVIEW

MENU ITEM	DESCRIPTION
<b>Active Adapter</b> <ul style="list-style-type: none"> <li>• Auto*</li> <li>• Standard Network</li> <li>• Wireless</li> </ul>	Specify the type of the network connection.
<b>Network Status</b>	Show the connectivity status of the printer network.
<b>Display Network Status on Printer</b> <ul style="list-style-type: none"> <li>• On*</li> <li>• Off</li> </ul>	Show the network status on the display.
<b>Speed, Duplex</b>	Show the speed of the currently active network card.
<b>IPv4</b>	Show the IPv4 address.
<b>All IPv6 Addresses</b>	Show all IPv6 addresses.
<b>Reset Print Server</b> Start	Reset all active network connections to the printer.   Note: This setting removes all network configuration settings.
<b>Network Job Timeout</b> <ul style="list-style-type: none"> <li>• Disabled</li> <li>• Enabled*</li> </ul>	Set the time before the printer cancels a network print job.
<b>Network Job Timeout Time</b>	Specify the timeout value (in seconds) when the Network Job Timeout setting is enabled.   Note: This feature is available only in some printer models.
<b>Banner Page</b> <ul style="list-style-type: none"> <li>• Off*</li> <li>• On</li> </ul>	Print a banner page.
<b>Scan to PC Port Range</b>	Specify a valid port range for printers that are behind a port blocking firewall.
<b>Enable Network Connections</b> <ul style="list-style-type: none"> <li>• Enable*</li> <li>• Disable</li> </ul>	Enable or disable all network connections.




MENU ITEM	DESCRIPTION
<b>Enable LLDP</b> <ul style="list-style-type: none"> <li>Off*</li> <li>On</li> </ul>	Enable Link Layer Discovery Protocol (LLDP) in the printer.
 Note: An asterisk (*) next to a value indicates the factory default setting.	


## WIRELESS





Note: This menu is available only in printers connected to a Wi-Fi network or printers that have a wireless network adapter.

MENU ITEM	DESCRIPTION
<b>Setup On Printer Panel</b> <ul style="list-style-type: none"> <li>Choose Network</li> <li>Add Wi-Fi Network               <ul style="list-style-type: none"> <li>Network Name</li> <li>Network Mode                   <ul style="list-style-type: none"> <li>Infrastructure</li> </ul> </li> <li>Wireless Security Mode                   <ul style="list-style-type: none"> <li>Disabled</li> <li>WPA2/WPA - Personal</li> <li>WPA2 - Personal</li> <li>WPA2/WPA3 - Personal</li> <li>WPA3 - Personal</li> <li>802.1x - RADIUS</li> </ul> </li> </ul> </li> </ul>	<p>Determine the wireless network that the printer connects to.</p> <p>Select <b>Choose Network</b> to pick from a list of discovered wireless networks.</p> <p>Select <b>Add Wi-Fi Network</b> to manually add a non-advertised network.</p> <p>When set to 802.1x-RADIUS, make sure to configure the 802.1x authentication settings to avoid network disconnection.</p> <p> Note: This menu item appears as <i>Wireless Connection Setup</i> in the Embedded Web Server.</p>
<b>Wi-Fi Protected Setup</b> <ul style="list-style-type: none"> <li>Start Push Button Method</li> <li>Start PIN Method</li> </ul>	<p>An alternate method to join a wireless network is through Wi-Fi Protected Setup.</p> <ul style="list-style-type: none"> <li>Start Push Button Method connects the printer to a wireless network when buttons on both the printer and the access point (wireless router) are pressed within a given time.</li> <li>Start PIN Method connects the printer to a wireless network when a PIN on the printer is entered into the wireless settings of the access point.</li> </ul>
<b>Compatibility</b> 802.11b/g/n (2.4GHz)*	Specify the wireless standard for the wireless network.
<b>Wireless Security Mode</b> <ul style="list-style-type: none"> <li>Disabled*</li> </ul>	Set the type of security for connecting the printer to wireless devices.

MENU ITEM	DESCRIPTION
<ul style="list-style-type: none"> <li>• WPA2/WPA-Personal               <ul style="list-style-type: none"> <li>– WPA2/WPA-PSK Encryption Mode                   <ul style="list-style-type: none"> <li>– AES</li> </ul> </li> <li>– Set Pre-Shared Key</li> </ul> </li> <li>• WPA2-Personal               <ul style="list-style-type: none"> <li>– WPA2-PSK Encryption Mode                   <ul style="list-style-type: none"> <li>– AES</li> </ul> </li> <li>– Set Pre-Shared Key</li> </ul> </li> <li>• WPA2/WPA3 - Personal               <ul style="list-style-type: none"> <li>– WPA2/WPA3 - PSK Encryption Mode</li> <li>– Set Pre-Shared Key</li> </ul> </li> <li>• WPA3 - Personal               <ul style="list-style-type: none"> <li>– WPA3 - PSK Encryption Mode</li> <li>– Set Pre-Shared Key</li> </ul> </li> <li>• 802.1x - RADIUS               <ul style="list-style-type: none"> <li>– 802.1x Encryption Mode                   <ul style="list-style-type: none"> <li>– WPA +</li> <li>– WPA2*</li> <li>– WPA2 + PMF</li> </ul> </li> </ul> </li> </ul>	<p>Enable wireless security through Wi-Fi Protected Access (WPA) or through 802.1x standard.</p> <p>When set to WPA security mode, for the Pre-Shared Key, enter the password for the secure wireless connection.</p> <p>When set to 802.1x-RADIUS, make sure to configure the 802.1x authentication settings to avoid network disconnection.</p> <p>PMF is Protected Management Frames.</p>
<p><b>IPv4</b></p> <ul style="list-style-type: none"> <li>• Enable DHCP               <ul style="list-style-type: none"> <li>– On*</li> <li>– Off</li> </ul> </li> <li>• Set Static IP Address               <ul style="list-style-type: none"> <li>– IP Address</li> <li>– Netmask</li> <li>– Gateway</li> </ul> </li> </ul>	<p>Enable Dynamic Host Configuration Protocol (DHCP) and configure static IP address.</p> <p>DHCP is a standard protocol that allows a server to distribute IP addressing and configuration information dynamically to clients.</p>
<p><b>IPv6</b></p> <ul style="list-style-type: none"> <li>• Enable IPv6               <ul style="list-style-type: none"> <li>– On*</li> <li>– Off</li> </ul> </li> <li>• Enable DHCPv6</li> </ul>	<p>Enable and configure IPv6 settings in the printer.</p>

MENU ITEM	DESCRIPTION
<ul style="list-style-type: none"> <li>– On</li> <li>– Off*</li> <li>• Stateless Address Auto configuration               <ul style="list-style-type: none"> <li>– On*</li> <li>– Off</li> </ul> </li> <li>• DNS Server Address</li> <li>• Manually Assigned IPv6 Address</li> <li>• Manually Assigned IPv6 Router</li> <li>• Address Prefix 0–128 (64*)</li> <li>• All IPv6 Addresses</li> <li>• All IPv6 Router Addresses</li> </ul>	
<b>Network Address</b> <ul style="list-style-type: none"> <li>• UAA</li> <li>• LAA</li> </ul>	View the network addresses.
<b>PCL SmartSwitch</b> <ul style="list-style-type: none"> <li>• On*</li> <li>• Off</li> </ul>	<p>Set the printer to switch automatically to PCL emulation when a print job requires it, regardless of the default printer language.</p> <p>If PCL SmartSwitch is off, then the printer does not examine incoming data and uses the default printer language specified in the Setup menu.</p>
<b>PS SmartSwitch</b> <ul style="list-style-type: none"> <li>• On*</li> <li>• Off</li> </ul>	<p>Set the printer to switch automatically to PS emulation when a print job requires it, regardless of the default printer language.</p> <p>If PS SmartSwitch is off, then the printer does not examine incoming data and uses the default printer language specified in the Setup menu.</p>
<b>Mac Binary PS</b> <ul style="list-style-type: none"> <li>• Auto*</li> <li>• On</li> <li>• Off</li> </ul>	<p>Set the printer to process Macintosh binary PostScript print jobs.</p> <ul style="list-style-type: none"> <li>• On processes raw binary PostScript print jobs.</li> <li>• Off filters print jobs using the standard protocol.</li> </ul>
 Note: An asterisk (*) next to a value indicates the factory default setting.	

## WI-FI DIRECT



MENU ITEM	DESCRIPTION
<b>Enable Wi-Fi Direct</b> <ul style="list-style-type: none"> <li>On</li> <li>Off*</li> </ul>	Set the printer to connect directly to Wi-Fi devices.
<b>Wi-Fi Direct Name</b>	Specify the name of the Wi-Fi Direct network.
<b>Wi-Fi Direct Password</b>	Set the password to authenticate and validate users on a Wi-Fi connection.
<b>Show Password on Setup Page</b> <ul style="list-style-type: none"> <li>Off</li> <li>On*</li> </ul>	Show the Wi-Fi Direct Password on the Network Setup Page.
<b>Preferred Channel Number</b> <ul style="list-style-type: none"> <li>1–11</li> <li>Auto*</li> </ul>	Set the preferred channel of the Wi-Fi network.
<b>Group Owner IP Address</b>	Specify the IP address of the group owner.
<b>Auto-Accept Push Button Requests</b> <ul style="list-style-type: none"> <li>Off*</li> <li>On</li> </ul>	Accept requests to connect to the network automatically.   Note: Accepting clients automatically is not secured.
 Note: An asterisk (*) next to a value indicates the factory default setting.	

## AIRPRINT




MENU ITEM	DESCRIPTION
<b>AirPrint</b> <ul style="list-style-type: none"> <li>Enabled</li> <li>Disabled</li> </ul>	
<b>Bonjour Name</b>	The name used to identify the printer on Airprint.
<b>Organization Name</b>	
<b>Organizational Unit</b>	
<b>Printer Location</b>	
<b>Printer's Latitude</b>	GPS latitude of the printer. The range is –90 to 90.
<b>Printer's Longitude</b>	GPS longitude of the printer. The range is –180 to 180.
<b>Printer's Altitude</b>	GPS altitude of the printer. The range is –100000 to 100000.



MENU ITEM	DESCRIPTION
<b>More Options</b>	From the Embedded Web Server, navigate to <b>Settings &gt; Network/Ports &gt; AirPrint &gt; More Options</b> for the following options.
<b>Supplies</b> Black Cartridge Imaging Unit	This menu lists the supplies status/notifications.
<b>Printer</b> Device Type Device Speed Firmware Level Tray 1 Standard Bin	This menu lists the printer specifications and input/output tray status/notifications.
<b>Login Methods</b>	For more information, refer to <a href="#">Login Methods</a>
<b>Certificate Management</b>	For more information, refer to <a href="#">Certificate Management</a>
<b>Confidential Print Setup</b>	For more information, refer to <a href="#">Confidential Print Setup</a>

## MOBILE SERVICES MANAGEMENT

MENU ITEM	DESCRIPTION
<b>Enable IPP Print</b> <ul style="list-style-type: none"> <li>On*</li> <li>Off</li> </ul>	Enable IPP Print setting in the printer.
<b>Enable IPP Over USB</b> <ul style="list-style-type: none"> <li>On*</li> <li>Off</li> </ul>	Enable IPP Over USB setting in the Printer.   Note: After changing this setting, user needs to restart the Printer.
<b>Enable Scan</b> <ul style="list-style-type: none"> <li>On*</li> <li>Off</li> </ul>	Enable Mobile Scan setting in the printer.
<b>Enable Mopria Print Discovery</b> <ul style="list-style-type: none"> <li>On*</li> <li>Off</li> </ul>	Enable Mopria Print Discovery setting in the printer.
 Note: An asterisk (*) next to a value indicates the factory default setting.	

## ETHERNET




MENU ITEM	DESCRIPTION
<b>Network Speed</b>	Show the speed of an active network adapter.
<b>IPv4</b> <ul style="list-style-type: none"> <li>• Enable DHCP</li> <li>• On*</li> <li>• Off</li> </ul>	Enable Dynamic Host Configuration Protocol (DHCP).   Note: DHCP is a standard protocol that allows a server to distribute IP addressing and configuration information dynamically to clients.
<b>IPv4</b> <ul style="list-style-type: none"> <li>• Set Static IP Address</li> <li>• IP Address</li> <li>• Netmask</li> <li>• Gateway</li> </ul>	Set the static IP address of your printer.
<b>IPv6</b> <ul style="list-style-type: none"> <li>• Enable IPv6</li> <li>• Off</li> <li>• On*</li> </ul>	Enable IPv6 in the printer.
<b>IPv6</b> <ul style="list-style-type: none"> <li>• Enable DHCPv6</li> <li>• Off</li> <li>• On*</li> </ul>	Enable DHCPv6 in the printer.
<b>IPv6</b> <ul style="list-style-type: none"> <li>• Stateless Address Auto configuration</li> <li>• On*</li> <li>• Off</li> </ul>	Set the network adapter to accept the automatic IPv6 address configuration entries provided by a router.
<b>IPv6</b> DNS Address	Specify the DNS server address.
<b>IPv6</b> Manually Assigned IPv6 Address	Specify IP address for the IPv6 DNS Server   Note: This menu item appears only in some printer models.
<b>IPv6</b> Manually Assigned IPv6 Router	Specify the router for IPv6 network.   Note: This menu item appears only in some printer models.
<b>IPv6</b> Address Prefix 0–128 (64*)	Specify the address prefix.

MENU ITEM	DESCRIPTION
<b>IPv6</b> All IPv6 Addresses	Show all IPv6 addresses.
<b>IPv6</b> All IPv6 Router Addresses	Show all IPv6 router addresses.
<b>Network Address</b> <ul style="list-style-type: none"> <li>• UAA</li> <li>• LAA</li> </ul>	Show the printer Media Access Control (MAC) addresses: Locally Administered Address (LAA) and Universally Administered Address (UAA).   Note: You can change the printer LAA manually.
<b>PCL SmartSwitch</b> <ul style="list-style-type: none"> <li>• On*</li> <li>• Off*</li> </ul>	Set the printer to switch automatically to PCL emulation when a print job requires it, regardless of the default printer language. <ul style="list-style-type: none"> <li>• This menu item is available only in some printer models.</li> <li>• If PCL SmartSwitch is off, then the printer does not examine incoming data and uses the default printer language specified in the Setup menu.</li> </ul>
<b>PS SmartSwitch</b> <ul style="list-style-type: none"> <li>• On*</li> <li>• Off*</li> </ul>	Set the printer to switch automatically to PS emulation when a print job requires it, regardless of the default printer language. <ul style="list-style-type: none"> <li>• This menu item is available only in some printer models.</li> <li>• If PS SmartSwitch is off, then the printer does not examine incoming data and uses the default printer language specified in the Setup menu.</li> </ul>
<b>Mac Binary PS</b> <ul style="list-style-type: none"> <li>• Auto*</li> <li>• On</li> <li>• Off</li> </ul>	Set the printer to process Macintosh binary PostScript print jobs. <ul style="list-style-type: none"> <li>• On processes raw binary PostScript print jobs.</li> <li>• Off filters print jobs using the standard protocol.</li> </ul>
<b>Energy Efficient Ethernet</b> <ul style="list-style-type: none"> <li>• Auto*</li> <li>• On</li> <li>• Off</li> </ul>	Reduce power consumption when the printer does not receive data from the Ethernet network.
 Note: An asterisk (*) next to a value indicates the factory default setting.	




## TCP/IP




Note: This menu appears only in network printers or printers attached to print servers.

MENU ITEM	DESCRIPTION
<b>Set Hostname</b>	Set the current TCP/IP host name.
<b>Domain Name</b>	Set the domain name.  Note: This menu item is available only in some printer models.
<b>Allow DHCP/BOOTP to update NTP server</b> • On* • Off	Allow the DHCP and BOOTP clients to update the NTP settings of the printer.
<b>Zero Configuration Name</b>	Specify a service name for the zero configuration network.  Note: This menu item is available only in some printer models.
<b>Enable Auto IP</b> • On* • Off	Assign an IP address automatically.
<b>DNS Address</b>	Specify the current Domain Name System (DNS) server address.
<b>Backup DNS</b>	Specify the backup DNS server addresses.
<b>Backup DNS 2</b>	
<b>Backup DNS 3</b>	
<b>Domain Search Order</b>	Specify a list of domain names to locate the printer and its resources that reside in different domains on the network.  Note: This menu item is available only in some printer models.
<b>Enable DDNS</b> • Off* • On	Update the Dynamic DNS settings.
<b>DDNS TTL</b>	Specify the current DDNS settings.
<b>Default TTL</b>	
<b>DDNS Refresh Time</b>	
<b>Enable mDNS</b> • On* • Off	Update multicast DNS settings.
<b>WINS Address</b>	Specify a server address for Windows Internet Name Service (WINS).



MENU ITEM	DESCRIPTION
<b>Enable BOOTP</b> <ul style="list-style-type: none"> <li>Off*</li> <li>On</li> </ul>	Allow the BOOTP to assign a printer IP address.
<b>MTU</b>	Specify a maximum transmission unit (MTU) parameter for the TCP connections.  Note: The maximum limit is 1500.
<b>Restricted Server List</b>	Specify an IP address for the TCP connections. <ul style="list-style-type: none"> <li>This menu item appears only in the Embedded Web Server.</li> <li>Use a comma to separate each IP address.</li> <li>You can add up to 50 IP addresses.</li> <li>This menu item is available only in some printer models.</li> </ul>
<b>Restricted Server List Options</b> <ul style="list-style-type: none"> <li>Block All Ports*</li> <li>Block Printing Only</li> <li>Block Printing and HTTP Only</li> </ul>	Specify how the IP addresses in the list can access the printer functionality. <ul style="list-style-type: none"> <li>This menu item appears only in the Embedded Web Server.</li> <li>This menu item is available only in some printer models.</li> </ul>
<b>Raw Print Port</b> 1–65535 (9100*)	Specify a raw port number for printers connected on a network.
<b>Outbound Traffic Maximum Speed</b> <ul style="list-style-type: none"> <li>Disabled*</li> <li>Enabled</li> </ul>	Enable the printer maximum transfer rate.
<b>Kilobits/second</b>	If you select <b>On</b> for <b>Outbound Traffic Maximum Speed</b> , the Kilobits/second field appears. Select a Range between 100–1000000.
<b>TLS Support</b>	From the Embedded Web Server, go to <b>Settings &gt; Network/Ports &gt; TCP/IP</b> . Enhance printer privacy and data integrity.  Note: The TLS settings pertain to the Embedded Web Server only. They do not pertain to clients using TLS. For more information, refer to the <i>Embedded Web Server Administrator Guide</i> .  Note: TLSv1.3 is supported by default, and cannot be disabled. Deselecting the other TLS settings will force the EWS to use TLSv1.3 only.


MENU ITEM	DESCRIPTION
<b>Enable TLSv1.0</b> <ul style="list-style-type: none"> <li>• On*</li> <li>• Off</li> </ul>	Set the Enable TLSv1.0 protocol settings.
<b>Enable TLSv1.1</b> <ul style="list-style-type: none"> <li>• On*</li> <li>• Off</li> </ul>	Set the Enable TLSv1.1 protocol settings.
<b>Enable TLSv1.2</b> <ul style="list-style-type: none"> <li>• On</li> <li>• Off</li> </ul>	Set the Enable TLSv1.2 protocol settings.
<b>SSL Cipher List</b>	Specify the cipher algorithms to use for the SSL or the TLS connections.
<b>TLSv1.3 SSL Cipher List</b>	TLS_AES_256_GCM_SHA384:TLS_AES_128_GCM_SHA256
TCP /IP Port Access [Port Names x] <ul style="list-style-type: none"> <li>• On</li> <li>• Off</li> </ul>	Lists all of the Ports available and their status.
 Note: An asterisk (*) next to a value indicates the factory default setting.	

## SNMP



Note: This menu appears only in network printers or printers that are attached to print servers.







MENU ITEM	DESCRIPTION
<b>SNMP Versions 1 and 2c</b> <ul style="list-style-type: none"> <li>• Enabled <ul style="list-style-type: none"> <li>– Off</li> <li>– On*</li> </ul> </li> <li>• Allow SNMP Set <ul style="list-style-type: none"> <li>– Off</li> <li>– On*</li> </ul> </li> <li>• Enable PPM MIB <ul style="list-style-type: none"> <li>– Off</li> <li>– On*</li> </ul> </li> <li>• SNMP Community</li> </ul>	Configure Simple Network Management Protocol (SNMP) versions 1 and 2c to install print drivers and applications.
<b>SNMP Version 3</b> <ul style="list-style-type: none"> <li>• Enabled <ul style="list-style-type: none"> <li>– Off</li> <li>– On*</li> </ul> </li> <li>• Context Name</li> <li>• Set Read/Write Credentials <ul style="list-style-type: none"> <li>– User Name</li> <li>– Authentication Password</li> <li>– Privacy Password</li> </ul> </li> <li>• Set Read-only Credentials <ul style="list-style-type: none"> <li>– User Name</li> <li>– Authentication Password</li> <li>– Privacy Password</li> </ul> </li> <li>• Authentication Hash <ul style="list-style-type: none"> <li>– MD5</li> <li>– SHA1*</li> </ul> </li> <li>• Minimum Authentication Level <ul style="list-style-type: none"> <li>– No Authentication, No Privacy</li> <li>– Authentication, No Privacy</li> <li>– Authentication, Privacy*</li> </ul> </li> <li>• Privacy Algorithm <ul style="list-style-type: none"> <li>– DES</li> </ul> </li> </ul>	Configure SNMP version 3 to install and update the printer security.




MENU ITEM	DESCRIPTION
– AES-128*	
 Note: An asterisk (*) next to a value indicates the factory default setting.	

## IPSEC



Note: This menu appears only in network printers or printers that are attached to print servers.


MENU ITEM	DESCRIPTION
<b>Enable IPsec</b> <ul style="list-style-type: none"> <li>Off*</li> <li>On</li> </ul>	Enable Internet Protocol Security (IPsec).
<b>Base Configuration</b> <ul style="list-style-type: none"> <li>Default*</li> <li>Compatibility</li> <li>Secure</li> </ul>	Set the IPsec base configuration.  Note: This menu item appears only when Enable IPsec is set to On.
<b>DH (Diffie-Hellman) Group Proposal</b> <ul style="list-style-type: none"> <li>modp2048 (14)*</li> <li>modp3072 (15)</li> <li>modp4096 (16)</li> <li>modp6144 (17)</li> </ul>	Set the IPsec encryption.  Note: This menu item appears only when Base Configuration is set to Compatibility.
<b>Proposed Encryption Method</b> <ul style="list-style-type: none"> <li>AES*</li> <li>3DES</li> </ul>	Specify an encryption method.  Note: This menu item appears only when Base Configuration is set to Compatibility.
<b>Proposed Authentication Method</b> <ul style="list-style-type: none"> <li>SHA256*</li> <li>SHA512</li> <li>SHA1</li> </ul>	Specify an authentication method.  Note: This menu item appears only when Base Configuration is set to Compatibility.
<b>IKE SA Lifetime (Hours)</b> <ul style="list-style-type: none"> <li>-1</li> <li>-2</li> <li>-4</li> <li>-8</li> <li>-24</li> </ul>	Specify the IKE SA expiry period.  Note: This menu item appears only when Base Configuration is set to Secure.
<b>IPsec SA Lifetime (Hours)</b> <ul style="list-style-type: none"> <li>-1</li> <li>-2</li> <li>-4</li> <li>-8</li> </ul>	Specify the IPsec SA expiry period.  Note: This menu item appears only when Base Configuration is set to Secure.

MENU ITEM	DESCRIPTION
<ul style="list-style-type: none"><li>-24</li></ul>	
<b>IPSec Device Certificate</b>  default	Specify an IPSec certificate.   Note: This menu item appears only when Base Configuration is set to Compatibility or Secure.
<b>Pre-Shared Key Authenticated Connections</b> <ul style="list-style-type: none"><li>Host [x]</li><li>Address</li><li>Key</li></ul>	Configure the authenticated connections of the printer.   Note: This menu item appears only when Enable IPSec is set to On.
<b>Certificate Authenticated Connections</b> <ul style="list-style-type: none"><li>Host [x] Address[/subnet]</li><li>Address[/subnet]</li></ul>	
 Note: An asterisk (*) next to a value indicates the factory default setting.	

## 802.1X




Note: This menu appears only in network printers or printers that are attached to print servers.




MENU ITEM	DESCRIPTION
<b>Active</b> <ul style="list-style-type: none"> <li>Off*</li> <li>On</li> </ul>	Let the printer join networks that require authentication before allowing access.
 Note: An asterisk (*) next to a value indicates the factory default setting.	

## LPD CONFIGURATION



Note: This menu appears only in network printers or printers that are attached to print servers.


MENU ITEM	DESCRIPTION
<b>LPD Timeout</b> 0–65535 seconds (90*)	Set the time-out value to stop the Line Printer Daemon (LPD) server from waiting indefinitely for hung or invalid print jobs.
<b>LPD Banner Page</b> <ul style="list-style-type: none"> <li>Off*</li> <li>On</li> </ul>	Print a banner page for all LPD print jobs.   Note: A banner page is the first page of a print job used as a separator of print jobs and to identify the originator of the print job request.
<b>LPD Trailer Page</b>	Print a trailer page for all LPD print jobs.


MENU ITEM	DESCRIPTION
<ul style="list-style-type: none"> <li>Off*</li> <li>On</li> </ul>	 Note: A trailer page is the last page of a print job.
<b>LPD Carriage Return Conversion</b> <ul style="list-style-type: none"> <li>Off*</li> <li>On</li> </ul>	Enable carriage return conversion.   Note: Carriage return is a mechanism that commands the printer to move the position of the cursor to the first position on the same line.
 Note: An asterisk (*) next to a value indicates the factory default setting.	

## HTTP/FTP SETTINGS






Note: This menu appears only in network printers or printers that are attached to print servers.


MENU ITEM	DESCRIPTION
<b>Enable HTTP Server</b> <ul style="list-style-type: none"> <li>Off</li> <li>On*</li> </ul>	Access the Embedded Web Server to monitor and manage the printer.
<b>Enable HTTPS</b> <ul style="list-style-type: none"> <li>Off*</li> <li>On</li> </ul>	Configure the Hypertext Transfer Protocol Secure (HTTPS) settings.
<b>Force HTTPS Connections</b> <ul style="list-style-type: none"> <li>Off</li> <li>On*</li> </ul>	Force the printer to use the HTTPS connections.
<b>Enable FTP/TFTP</b> <ul style="list-style-type: none"> <li>Off</li> <li>On*</li> </ul>	Send files using FTP.
<b>HTTP Proxy IP Address</b>	Configure the HTTP and FTP server settings.   Note: This feature is available only in some printer models.
<b>FTP Proxy IP Address</b>	
<b>HTTP Default IP Port</b> 1–65535 (80*)	
<b>HTTPS Device Certificate</b>	
<b>FTP Default IP Port</b> 1–65535 (21*)	
<b>Timeout for HTTP/FTP Requests</b> 1–299 (30*)	Specify the amount of time before the server connection stops.

MENU ITEM	DESCRIPTION
<b>Retries for HTTP/FTP Requests</b> 1–299 (3*)	Set the number of retries to connect to the HTTP/FTP server.
 Note: An asterisk (*) next to a value indicates the factory default setting.	

## USB

MENU ITEM	DESCRIPTION
<b>PCL SmartSwitch</b> <ul style="list-style-type: none"> <li>Off</li> <li>On*</li> </ul>	Set the printer to switch to PCL emulation when a print job received through a USB port requires it, regardless of the default printer language.   Note: If PCL SmartSwitch is off, then the printer does not examine incoming data and uses the default printer language specified in the Setup menu.
<b>PS SmartSwitch</b> <ul style="list-style-type: none"> <li>Off</li> <li>On*</li> </ul>	Set the printer to switch to PS emulation when a print job received through a USB port requires it, regardless of the default printer language.   Note: If PCL SmartSwitch is off, then the printer does not examine incoming data and uses the default printer language specified in the Setup menu.
<b>Enable USB Port</b> <ul style="list-style-type: none"> <li>Enable*</li> <li>Disable</li> </ul>	Enable the standard USB port.
<b>MAC Binary PS</b> <ul style="list-style-type: none"> <li>Auto</li> <li>On*</li> <li>Off</li> </ul>	Set the printer to process Macintosh binary PostScript print jobs. <ul style="list-style-type: none"> <li>This menu item appears only in some printer models.</li> <li>On processes raw binary PostScript print jobs.</li> <li>Off filters print jobs using the standard protocol.</li> </ul>
 Note: An asterisk (*) next to a value indicates the factory default setting.	

## RESTRICT EXTERNAL NETWORK ACCESS

MENU ITEM	DESCRIPTION
<b>Restrict external network access</b> <ul style="list-style-type: none"><li>• Off*</li><li>• On</li></ul>	Restrict access to network sites.
<b>External network address</b>	Specify the network addresses with restricted access.
<b>E-mail address for notification</b>	Specify an e-mail address to send a notification of logged events.
<b>Ping frequency</b> 1–300 (10*)	Specify the network query interval in seconds.
<b>Subject</b>	Specify the subject and message of the notification e-mail.
<b>Message</b>	
 Note: An asterisk (*) next to a value indicates the factory default setting.	

## UNIVERSAL PRINT

Universal Print is a cloud-based print protocol that provides a simple and secure print solution for Microsoft® 365 users. Universal Print allows administrators to manage printers without the need for on-premises print servers. Universal Print enables users to access cloud printers without the need for print drivers.




You can use the Universal Print page to register your Xerox® device for Universal Print.

### Prerequisites

- Microsoft Azure AD Account
- Windows 10 Client version 1903 or higher

MENU ITEM	DESCRIPTION
<b>Status</b>	Device is not currently registered with Universal Print.
<b>Registration</b>	User can use the Universal print page to register the Xerox® device for Universal Print.
<b>Printer Name</b>	The Default printer name appears. User can also update the Xerox® printer name.



MENU ITEM	DESCRIPTION
<b>Register</b>	<p>To register, do the following steps:</p> <ol style="list-style-type: none"> <li>1 Go to <b>Settings &gt; Network/Ports &gt; Universal Print</b>, then click <b>Register</b>. The Registration process authenticates the device with Microsoft® Azure® Active Directory.</li> <li>2 The Register Device window appears. To copy the registration code, click <b>Copy</b>, then click the link <a href="https://microsoft.com/devicelogin">https://microsoft.com/devicelogin</a>.</li> </ol> <p> Note: The registration code expires after 15 minutes. The registration process needs to be completed before the code expires.</p> <ol style="list-style-type: none"> <li>3 A Microsoft-managed webpage opens. Do the following steps: <ol style="list-style-type: none"> <li>a Paste the registration code into the code field in the Enter code window, then click <b>Next</b>.</li> <li>b Select the appropriate Microsoft® account in the Pick an account window.</li> </ol> </li> </ol> <p> Note: For registration, select an available Microsoft® account. The selected account is used solely to establish a trusted connection for the device with the Universal Print service. After registration, Universal Print does not use the account again.</p> <ol style="list-style-type: none"> <li>4 A Xerox Universal Print window appears. Click <b>Continue</b> and close the window.</li> </ol>
<p> Note: For more information, refer to the <i>Embedded Web Server Administrator Guide</i>.</p>	

MENU ITEM	DESCRIPTION
<b>Status</b>	Device is online and registered with Universal Print.
<b>Registration</b>	User can use the Universal print page to deregister the Xerox® device for Universal Print.
<b>Printer Name</b>	Registered printer name appears.
<b>Deregister</b>	Use this function to deregister the device from the Universal Print Service.

## Additional information for Universal Print

### To add a Printer from Windows Server

1. Go to **Settings > Printer & Scanners**, then click **Add a printer or scanner**.
2. Select the printer from the printer list, then click **Add device**. If the printer does not appear in the list, do the following steps:
  - a. Go to **Search for printers in my organization**.
  - b. Type the registered name on the text field, and click **Search**. Once the printer appears on the list, click **Add Device**.

Use printer menus



Note: Windows 11 supports PIN-protected printing. For example, to protect your print, you can use a 4-digit PIN between 0 and 9.


## Security

### LOGIN METHODS

#### Public



Note: This menu can be configured only from the Embedded Web Server.

MENU ITEM	DESCRIPTION
<b>Manage Permissions</b> <ul style="list-style-type: none"> <li>• Function Access <ul style="list-style-type: none"> <li>– Manage Shortcuts</li> <li>– Create Profiles</li> <li>– Flash Drive Print</li> <li>– Flash Drive Scan</li> <li>– Copy Function</li> <li>– E-mail Function</li> <li>– Fax Function</li> <li>– FTP Function</li> <li>– Release Held Faxes</li> <li>– Held Jobs Access</li> <li>– User Profiles</li> <li>– Cancel Jobs at the Device</li> <li>– Change Language</li> <li>– Internet Printing Protocol (IPP)</li> <li>– Initiate Scans Remotely</li> <li>– B/W Print</li> <li>– Network Folder - Scan</li> </ul> </li> </ul>	Control access to the printer functions.   Note: Flash Drive Print and Flash Drive Scan are available only in some printer models.
<b>Manage Permissions</b> <ul style="list-style-type: none"> <li>• Administrative Menus <ul style="list-style-type: none"> <li>– Security Menu</li> <li>– Network/Ports Menu</li> <li>– Paper Menu</li> <li>– Reports Menu</li> <li>– Function Configuration Menus</li> <li>– Supplies Menu</li> <li>– SE Menu</li> <li>– Device Menu</li> </ul> </li> </ul>	Control access to the printer menus.
<b>Manage Permissions</b> <ul style="list-style-type: none"> <li>• Device Management <ul style="list-style-type: none"> <li>– Remote Management</li> <li>– Firmware Updates</li> </ul> </li> </ul>	Control access to the printer management options.

MENU ITEM	DESCRIPTION
<ul style="list-style-type: none"> <li>– Embedded Web Server Access</li> <li>– Import / Export All Settings</li> <li>– Out of Service Erase</li> </ul>	

### Local Accounts


MENU ITEM	DESCRIPTION
<b>Add User</b> <ul style="list-style-type: none"> <li>• User Name/Password</li> <li>• User Name</li> <li>• Password</li> <li>• PIN</li> </ul>	Create local accounts to manage access to the printer functions.
<b>Manage Groups/Permissions</b> <ul style="list-style-type: none"> <li>• Add Group <ul style="list-style-type: none"> <li>– Import Access Controls <ul style="list-style-type: none"> <li>– Function Access</li> <li>– Administrative Menus</li> <li>– Device Management</li> </ul> </li> </ul> </li> <li>• All Users <ul style="list-style-type: none"> <li>– Import Access Controls <ul style="list-style-type: none"> <li>– Function Access</li> <li>– Administrative Menus</li> <li>– Device Management</li> </ul> </li> </ul> </li> <li>• Admin <ul style="list-style-type: none"> <li>– Function Access</li> <li>– Administrative Menus</li> <li>– Device Management</li> </ul> </li> </ul>	Control group or user access to the printer functions, applications, and security settings.

## CERTIFICATE MANAGEMENT

MENU ITEM	MENU ITEM
<b>Configure Certificate Defaults</b> <ul style="list-style-type: none"> <li>• Common Name</li> <li>• Organization Name</li> <li>• Unit Name</li> <li>• Country/Region</li> <li>• Province Name</li> <li>• City Name</li> <li>• Subject Alternate Name</li> </ul>	Set the default values for generated certificates.
Device Certificates	Generate, delete, or view device certificates.
Manage CA Certificates	Load, delete, or view Certificate Authority (CA) certificates.

## CONFIDENTIAL PRINT SETUP

MENU ITEM	DESCRIPTION
<b>Max Invalid PIN</b> 2–10 (0*)	Set the number of times an invalid PIN can be entered. <ul style="list-style-type: none"> <li>• A value of zero turns off this setting.</li> <li>• When the limit is reached, the print jobs for that user name and PIN are deleted.</li> </ul>
<b>Confidential Job Expiration</b> Off* 1 Hour 4 Hours 24 Hours 1 Week	Set the expiration time for confidential print jobs. <ul style="list-style-type: none"> <li>• If this menu item is changed while confidential print jobs reside in the printer memory, then the expiration time for those print jobs does not change to the new default value.</li> <li>• If the printer is turned off, then all confidential jobs held in the printer memory are deleted.</li> </ul>
<b>Repeat Job Expiration</b> Off* 1 Hour 4 Hours 24 Hours 1 Week	Set the expiration time for a print job that you want to repeat.
<b>Verify Job Expiration</b> Off* 1 Hour	Set the expiration time that the printer prints a copy for the user to examine its quality, before printing the remaining copies.

MENU ITEM	DESCRIPTION
4 Hours 24 Hours 1 Week	
<b>Reserve Job Expiration</b> Off* 1 Hour 4 Hours 24 Hours 1 Week	Set the expiration time that the printer stores print jobs for printing later.
<b>Require All Jobs to be Held</b> Off* On	Set the printer to hold all print jobs.
<b>Keep duplicate documents</b> Off* On	Allow the storage of documents with the same file name.
 Note: An asterisk (*) next to a value indicates the factory default setting.	

## SCHEDULE USB DEVICES


MENU ITEM	DESCRIPTION
<b>Schedules</b> Add New Schedule	Schedule access to the front USB port.

## LOGIN RESTRICTIONS


MENU ITEM	DESCRIPTION
<b>Login failures</b> 1–10 (3*)	Specify the number of failed login attempts before the user gets locked out.
<b>Failure time frame</b> 1–60 minutes (5*)	Specify the time frame between failed login attempts before the user gets locked out.

MENU ITEM	DESCRIPTION
<b>Lockout time</b> 1–60 minutes (5*)	Specify the lockout duration.
<b>Web Login Timeout</b> 1–120 minutes (10*)	Specify the delay for a remote login before the user is logged off automatically.


#### ERASE TEMPORARY DATA FILES

MENU ITEM	DESCRIPTION
<b>Stored in onboard memory</b> <ul style="list-style-type: none"> <li>Off*</li> <li>On</li> </ul>	Delete all files stored on the printer memory.
 Note: An asterisk (*) next to a value indicates the factory default setting.	


#### SOLUTIONS LDAP SETTINGS

USE	TO
<b>Follow LDAP Referrals</b> Off* On	Search the different servers in the domain for the logged-in user account.
<b>LDAP Certificate Verification</b> No* Yes	Enable verification of LDAP certificates.
 Note: An asterisk (*) next to a value indicates the factory default setting.	

#### MISCELLANEOUS

MENU ITEM	DESCRIPTION
<b>Print Permission</b> <ul style="list-style-type: none"> <li>Off*</li> <li>On</li> </ul>	Allow the user to print.
<b>Default Print Permission Login</b>	Shows the default permission used for the user to print.   Note: This setting shows only when one or more Login Methods are created.



MENU ITEM	DESCRIPTION
<b>Security Reset Jumper</b> <ul style="list-style-type: none"> <li>• Enable “Guest” access*</li> <li>• No Effect</li> </ul>	Specify user access to the printer. <ul style="list-style-type: none"> <li>• The jumper is located beside a lock icon on the controller board.</li> <li>• Enable “Guest” access gives anyone access to all aspects of the printer.</li> <li>• No Effect may make access to the printer impossible when the required security information is unavailable.</li> </ul>
<b>Minimum Password Length</b> 0–32	Specify the password length.
 Note: An asterisk (*) next to a value indicates the factory default setting.	

## Reports

### MENU SETTINGS PAGE

MENU ITEM	DESCRIPTION
Menu Settings Page	Print a report that contains the printer menus.

### DEVICE

MENU ITEM	DESCRIPTION
Device Information	Print a report that contains information about the printer.
Device Statistics	Print a report about printer usage and supply status.
Profile List	Print a list of profiles that are stored in the printer.
Asset Report	Print a report that contains the printer serial number and model name.



### PRINT

MENU ITEM	DESCRIPTION
Print Fonts : PCL Fonts	Print samples and information about the fonts that are available in each printer language.



### SHORTCUTS

MENU ITEM	DESCRIPTION
All Shortcuts	Print a report that lists the shortcuts that are stored in the printer.
Fax Shortcuts	
Copy Shortcuts	
E-mail Shortcuts	
FTP Shortcuts	
Network Folder Shortcuts	

## FAX

MENU ITEM	DESCRIPTION
<b>Fax Job Log</b>	<p>Print a report about the last 200 completed fax jobs.</p> <p> Note: This menu item appears only when Enable Job Log is set to On.</p>
<b>Fax Call Log</b>	<p>Print a report about the last 100 attempted, received, and blocked calls.</p> <p> Note: This menu item appears only when Enable Job Log is set to On.</p>

## NETWORK

MENU ITEM	DESCRIPTION
<b>Network Setup Page</b>	<p>Print a page that shows the configured network and wireless settings on the printer.</p> <p> Note: This menu item appears only in network printers or printers connected to print servers.</p>
<b>Wi-Fi Direct Connected Clients</b>	<p>Print a page that shows the list of devices that are connected to the printer using Wi-Fi Direct.</p> <p> Note: This menu item appears only when Enable Wi-Fi Direct is set to On.</p>

## Supplies Plan

### PLAN ACTIVATION

MENU ITEM	DESCRIPTION
<ul style="list-style-type: none"> <li>Sequence Number</li> <li>Device Serial Number</li> <li>Activation Code</li> </ul>	<p>It describes the details of the activation process for the purchased Supplies plan. Contact your Xerox representative to get a Supplies Activation Code.</p> <p>Subscription Service plans are not offered in all geographic locations</p> <p>For more information about Xerox®supplies and service plans, contact your Xerox representative.</p>

### PLAN CONVERSION

MENU ITEM	DESCRIPTION
<ul style="list-style-type: none"> <li>Current Plan</li> <li>Device Serial Number</li> <li>Total Impressions</li> <li>Conversion Code</li> </ul>	<p>It describes the details of the conversion process for the existing Supplies plan. Contact your Xerox representative to get a Supplies Conversion Code.</p> <p>Subscription Service plans are not offered in all geographic locations</p> <p>For more information about Xerox®supplies and service plans, contact your Xerox representative.</p>

### SUBSCRIPTION SERVICE

MENU ITEM	DESCRIPTION
<ul style="list-style-type: none"> <li>Status</li> </ul>	It indicates the subscription status.
<ul style="list-style-type: none"> <li>Check Subscription</li> </ul>	<p>To activate a Subscription Service Plan, do the following:</p> <ol style="list-style-type: none"> <li>1 Go to <b>Settings &gt; Supplies Plan &gt; Subscription Service</b>.</li> <li>2 For Subscription Service, click <b>Check Subscription</b>, then follow the directions provided by your Xerox representative.</li> </ol>

## Troubleshooting

MENU ITEM	DESCRIPTION
<b>Print Quality Test Pages</b>	Print sample pages to identify and correct print quality defects.
<b>Cleaning the Scanner</b>	Print instructions on how to clean the scanner.

Use printer menus

## Maintain the Printer

This chapter contains:

Checking the Status of Supplies.....	200
Configuring Supply Notifications.....	201
Setting up e-mail alerts .....	202
Viewing reports .....	203
Ordering Supplies.....	204
Replacing Supplies .....	205
Cleaning printer parts .....	210
Saving energy and paper.....	213
Moving the Printer to Another Location.....	214

## Checking the Status of Supplies

1. From the control panel, navigate to: **Settings > Reports > Device > Device Statistics**  
For non-touch-screen printer models, press OK to select each menu to navigate through the settings.
2. From the Supply Information section of the pages printed, check the status of supplies.



## Configuring Supply Notifications

1. Open a web browser, and then type the printer IP address in the address field.
  - View the printer IP address on the printer home screen. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.
  - If you are using a proxy server, then temporarily disable it to load the web page correctly.
2. Select an option:
  - If your printer has a control panel, click **Settings > OK > Device > OK > Notifications > OK**
  - If your printer has a touch screen, click **Settings > Device > Notifications**.
3. From the Supplies menu, click **Custom Supply Notifications**.
4. Select a notification for each supply item.
5. Apply the changes.

## Setting up e-mail alerts

Configure the printer to send e-mail alerts when supplies are low, when paper must be changed or added, or when there is a paper jam.

1. Open a web browser, and then type the printer IP address in the address field.
  - View the printer IP address on the printer home screen. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.
  - If you are using a proxy server, then temporarily disable it to load the web page correctly.
2. Click **Settings > Device > Notifications > E-mail Alert Setup**, and then configure the settings.



Note: For more information on SMTP settings, contact your e-mail provider.

3. Click **Setup E-mail Lists and Alerts**, and then configure the settings.
4. Apply the changes.

## Viewing reports

1. From the control panel, navigate to:

**Settings > Reports**

For non-touch-screen printer models, press **OK** to navigate through the settings.

2. Select the report that you want to view.

## Ordering Supplies

To view and order supplies for your printer, go to <https://www.xerox.com/supplies>, then enter your product in the search field.



Note: All life estimates for printer supplies assume printing on letter or A4-size plain paper.



**Warning:** Failure to maintain optimum printer performance or to replace supplies can cause damage to your printer.

### USING GENUINE XEROX SUPPLIES

Your Xerox printer is designed to function best with genuine Xerox supplies. Use of third-party supplies can affect the performance, reliability, or life of the printer and its imaging components. It can also affect warranty coverage. Damage caused by the use of third-party supplies is not covered by the warranty.

All life indicators are designed to function with Xerox supplies and can deliver unpredictable results if third-party supplies are used. Imaging component usage beyond the intended life can damage your Xerox printer or associated components.





**Warning:** Supplies without Return Program agreement terms can be reset and remanufactured. However, the manufacturer's warranty does not cover any damage caused by non-genuine supplies. Resetting counters on the supply without proper remanufacturing can cause damage to your printer. After resetting the supply counter, your printer may display an error indicating the presence of the reset item.

## Replacing Supplies


### REPLACING THE TONER CARTRIDGE

1. Open the front door.


 **Warning:** To prevent damage from electrostatic discharge, touch any exposed metal frame of the printer before accessing or touching interior areas of the printer.




2. Remove the imaging unit.




3. Remove the used toner cartridge from the imaging unit.




4. Unpack the new toner cartridge.
5. Shake the toner cartridge to redistribute the toner.




6. Remove the seal, and then remove the cover.



7. Insert the new toner cartridge into the imaging unit.




8. Insert the imaging unit.




9. Close the door.


## REPLACING THE IMAGING UNIT

1. Open the front door.

 **Warning:** To prevent damage from electrostatic discharge, touch any exposed metal frame of the printer before accessing or touching interior areas of the printer.




2. Remove the used imaging unit.






3. Remove the toner cartridge from the used imaging unit.




4. Unpack the new imaging unit, and then insert the toner cartridge.

**Warning:** Do not expose the imaging unit to direct light for more than 10 minutes. Extended exposure to light may cause print quality problems.

**Warning:** Do not touch the photoconductor drum. Doing so may affect the quality of future print jobs.



5. Insert the new imaging unit.



6. Close the door.

## Cleaning printer parts

### CLEANING THE PRINTER



**CAUTION—SHOCK HAZARD:** To avoid the risk of electrical shock when cleaning the exterior of the printer, unplug the power cord from the electrical outlet and disconnect all cables from the printer before proceeding.

- Perform this task after every few months.
  - Damage to the printer caused by improper handling is not covered by the printer warranty.
1. Turn off the printer, and then unplug the power cord from the electrical outlet.
  2. Remove paper from the standard output tray.
  3. Remove any dust, lint, and pieces of paper around the printer using a soft brush or vacuum.
  4. Wipe the outside of the printer with a damp, soft, lint-free cloth.
    - Do not use household cleaners or detergents, as they may damage the finish of the printer.
    - Make sure that all areas of the printer are dry after cleaning.
  5. Connect the power cord to the electrical outlet, and then turn on the printer.



**CAUTION—POTENTIAL INJURY:** To avoid the risk of fire or electrical shock, connect the power cord to an appropriately rated and properly grounded electrical outlet that is near the product and easily accessible.

### CLEANING THE TOUCH SCREEN



**CAUTION—SHOCK HAZARD:** To avoid the risk of electric shock when cleaning the exterior of the printer, unplug the power cord from the electrical outlet and disconnect all cables from the printer before proceeding.


1. Turn off the printer, and then unplug the power cord from the electrical outlet.
2. Using a damp, soft, lint-free cloth, wipe the touch screen.
  - Do not use household cleaners or detergents, as they may damage the touch screen.
  - Make sure that the touch screen is dry after cleaning.
3. Connect the power cord to the electrical outlet, and then turn on the printer.



**CAUTION—POTENTIAL INJURY:** To avoid the risk of fire or electrical shock, connect the power cord to an appropriately rated and properly grounded electrical outlet that is near the product and easily accessible.


## CLEANING THE SCANNER

1. Open the scanner cover.




2. Using a damp, soft, lint-free cloth, wipe the following areas:


- a. ADF glass pad




- b. Scanner glass pad



c. ADF glass



d. Scanner glass



3. Close the scanner cover.

## Saving energy and paper

### CONFIGURING POWER SAVE MODE SETTINGS

#### Sleep Mode

1. From the control panel, navigate to **Settings > Device > Power Management > Timeouts > Sleep Mode**.  
For printers that use a control panel, press the **OK** button after selecting each menu option.
2. Enter the amount of time that the printer stays idle before it enters Sleep mode.

#### Hibernate Mode

1. From the control panel, navigate to **Settings > Device > Power Management > Timeouts > Hibernate Timeout**.  
For printers that use a control panel, press the **OK** button after selecting each menu option.
2. Select the amount of time before the printer enters Hibernate mode.
  - Make sure to wake the printer from Hibernate mode before sending a print job.
  - To wake the printer from Hibernate mode, press the power button.
  - The Embedded Web Server is disabled when the printer is in Hibernate mode.

### ADJUSTING THE BRIGHTNESS OF THE DISPLAY



Note: This setting is available only in some printer models.

1. From the home screen, touch **Settings > Device > Preferences**.
2. In the Screen Brightness menu, adjust the setting.

### CONSERVING SUPPLIES

- Print on both sides of the paper.



Note: Two-sided printing is the default setting in the print driver.

- Print multiple pages on a single sheet of paper.
- Use the preview feature to see how the document looks like before printing it.
- Print one copy of the document to check its content and format for accuracy.

## Moving the Printer to Another Location



**CAUTION—POTENTIAL INJURY:** If the printer weight is greater than 20kg (44lb), then it may require two or more people to lift it safely.



**CAUTION—POTENTIAL INJURY:** To avoid the risk of fire or electrical shock, use only the power cord provided with this product or the manufacturer's authorized replacement.



**CAUTION—POTENTIAL INJURY:** When moving the printer, follow these guidelines to avoid personal injury or printer damage:

- Make sure that all doors and trays are closed.
- Turn off the printer, and then unplug the power cord from the electrical outlet.
- Disconnect all cords and cables from the printer.
- If the printer has separate floor-standing optional trays or output options attached to it, then disconnect them before moving the printer.
- If the printer has a caster base, then carefully roll it to the new location. Use caution when passing over thresholds and breaks in flooring.
- If the printer does not have a caster base but is configured with optional trays or output options, then remove the output options and lift the printer off the trays. Do not try to lift the printer and any options at the same time.
- Always use the handholds on the printer to lift it.
- Any cart used to move the printer must have a surface able to support the full footprint of the printer.
- Any cart used to move the hardware options must have a surface able to support the dimensions of the options.
- Keep the printer in an upright position.
- Avoid severe jarring movements.
- Make sure that your fingers are not under the printer when you set it down.
- Make sure that there is adequate clearance around the printer.



Note: Damage to the printer caused by improper moving is not covered by the printer warranty.

## Troubleshoot a problem

This chapter contains:

Print quality problems .....	216
Printing problems .....	217
The printer is not responding .....	254
Unable to read flash drive .....	256
Enabling the USB port .....	257
Network connection problems .....	258
Issues with supplies .....	261
Clearing Jams.....	262
Paper feed problems.....	273
E-mailing problems.....	277
Faxing problems .....	278
Scanning problems.....	284
Contacting Customer Support .....	293

## Print quality problems

Find the image that resembles the print quality problem you are having, and then click the link below it to read problem-solving steps.

- [Blank or White Pages](#)
- [Dark Print](#)
- [Fine lines are not printed correctly](#)
- [Folded or wrinkled paper](#)
- [Gray Background](#)
- [Horizontal light bands](#)
- [Incorrect margins](#)
- [Light print](#)
- [Mottled print and dots](#)
- [Paper curl](#)
- [Print crooked or skewed](#)
- [Repeating defects](#)
- [Solid black pages](#)
- [Text or images cut off](#)
- [Toner easily rubs off](#)
- [Vertical dark bands](#)
- [Vertical dark lines or streaks](#)
- [Vertical dark streaks with print missing](#)
- [Vertical white lines](#)
- [Vertical light bands](#)



## Printing problems

### PRINT QUALITY IS POOR

#### Blank or White Pages



Note: Before solving the problem, print the Print Quality Test Pages. From the control panel, navigate to **Settings > Troubleshooting > Print Quality Test Pages**. For non-touch-screen printer models, press **OK** to navigate through the settings.

ACTION	YES	NO
<b>Step 1</b> a. Check if the printer is using a genuine and supported Xerox toner cartridge.  If the cartridge is not supported, then install a supported one.  b. Print the document.  Is the printer printing blank or white pages?	Go to step 2.	The problem is solved.
<b>Step 2</b> a. Remove the imaging unit.  Do not expose the imaging unit to direct light for more than 10 minutes. Extended exposure to light may cause print quality problems.  Do not touch the photoconductor drum under the imaging unit. Doing so may affect the quality of future print jobs.  b. Check the imaging unit for signs of damage.	Go to step 3.	The problem is solved.

ACTION	YES	NO
<p>Make sure that the photoconductor drum contact is not bent or out of place.</p> <p>c. Firmly shake the imaging unit to redistribute the toner.</p> <p>d. Insert the imaging unit.</p> <p>e. Print the document.</p> <p>Is the printer printing blank or white pages?</p>		
<p><b>Step 3</b></p> <p>Replace the toner cartridge.</p> <p>Is the printer printing blank or white pages?</p>	Go to step 4.	The problem is solved.
<p><b>Step 4</b></p> <p>Replace the imaging unit.</p> <p>Is the printer printing blank or white pages?</p>	Refer to <a href="#">Contacting Customer Support</a> .	The problem is solved.

## Dark Print




Note: Before solving the problem, print the Print Quality Test Pages. From the control panel, navigate to **Settings > Troubleshooting > Print Quality Test Pages**. For non-touch-screen printer models, press **OK** to navigate through the settings.

ACTION	YES	NO
<p><b>Step 1</b></p> <p>a. Check if the printer is using a genuine and supported Xerox toner cartridge.</p> <p>If the cartridge is not supported, then install a supported one.</p> <p>b. Print the document.</p> <p>Is the print dark?</p>	Go to step 2.	The problem is solved.
<p><b>Step 2</b></p> <p>a. Turn off the printer, wait for about 10 seconds, and then turn on the printer.</p> <p>b. Reduce toner darkness.</p> <p>From the control panel, navigate to:</p> <p><b>Settings &gt; Print &gt; Quality &gt; Toner Darkness</b></p> <p>c. Print the document.</p> <p>Is the print dark?</p>	Go to step 3.	The problem is solved.
<p><b>Step 3</b></p> <p>a. Depending on your operating system, specify the paper type from the Printing Preferences or Print dialog.</p> <ul style="list-style-type: none"> <li>• Make sure that the setting matches the paper loaded.</li> <li>• You can also change the setting on the printer control panel. Navigate to <b>Settings &gt; Paper &gt; Tray Configuration &gt; Paper Size/Type</b>.</li> </ul> <p>b. Print the document.</p> <p>Is the print dark?</p>	Go to step 4.	The problem is solved.
<p><b>Step 4</b></p> <p>Check if the paper has texture or rough finishes.</p> <p>Are you printing on textured or rough paper?</p>	Go to step 5.	Go to step 6.

ACTION	YES	NO
<p><b>Step 5</b></p> <p>a. Replace textured paper with plain paper.</p> <p>b. Print the document.</p> <p>Is the print dark?</p>	Go to step 6.	The problem is solved.
<p><b>Step 6</b></p> <p>a. Load paper from a fresh package.</p> <p>Paper absorbs moisture due to high humidity. Store paper in its original wrapper until you are ready to use it.</p> <p>b. Print the document.</p> <p>Is the print dark?</p>	Go to step 7.	The problem is solved.
<p><b>Step 7</b></p> <p>a. Remove, and then insert the imaging unit.</p> <p>Do not expose the imaging unit to direct light for more than 10 minutes. Extended exposure to light may cause print quality problems.</p> <p>Do not touch the photoconductor drum under the imaging unit. Doing so may affect the quality of future print jobs.</p> <p>b. Print the document.</p> <p>Is the print dark?</p>	Go to step 8.	The problem is solved.
<p><b>Step 8</b></p> <p>a. Replace the imaging unit.</p> <p>b. Print the document.</p> <p>Is the print dark?</p>	Refer to <a href="#">Contacting Customer Support</a> .	The problem is solved.


## Fine lines are not printed correctly



Note: Before solving the problem, print the Print Quality Test Pages. From the control panel, navigate to **Settings > Troubleshooting > Print Quality Test Pages**. For non-touch-screen printer models, press **OK** to navigate through the settings.

ACTION	YES	NO
<b>Step 1</b> a. Check if the printer is using a genuine and supported Xerox toner cartridge.  If the cartridge is not supported, then install a supported one.  b. Print the document.  Are fine lines not printed correctly?	Go to step 2.	The problem is solved.
<b>Step 2</b> a. Increase toner darkness.  From the control panel, navigate to: <b>Settings &gt; Print &gt; Quality &gt; Toner Darkness</b>  b. Print the document.  Are fine lines not printed correctly?	Refer to <b>Contacting Customer Support</b> .	The problem is solved.


## Folded or wrinkled paper



Note: Before solving the problem, print the Print Quality Test Pages. From the control panel, navigate to **Settings > Troubleshooting > Print Quality Test Pages**. For non-touch-screen printer models, press **OK** to navigate through the settings.

ACTION	YES	NO
<p><b>Step 1</b></p> <p>a. Check if the printer is using a genuine and supported Xerox toner cartridge.</p> <p>If the cartridge is not supported, then install a supported one.</p> <p>b. Print the document.</p> <p>Is the paper folded or wrinkled?</p>	Go to step 2.	The problem is solved.
<p><b>Step 2</b></p> <p>a. Load paper from a fresh package.</p> <p>Paper absorbs moisture due to high humidity. Store paper in its original wrapper until you are ready to use it.</p> <p>b. Print the document.</p> <p>Is the paper folded or wrinkled?</p>	Go to step 3.	The problem is solved.
<p><b>Step 3</b></p> <p>a. Depending on your operating system, specify the paper type from the Printing Preferences or Print dialog.</p> <ul style="list-style-type: none"> <li>• Make sure that the setting matches the paper loaded.</li> <li>• You can also change the setting from the printer control panel. Navigate to <b>Settings &gt; Paper &gt; Tray Configuration &gt; Paper Size/Type</b>.</li> </ul> <p>b. Print the document.</p> <p>Is the paper folded or wrinkled?</p>	Refer to <a href="#">Contacting Customer Support</a> .	The problem is solved.

## Gray Background



Note: Before solving the problem, print the Print Quality Test Pages. From the control panel, navigate to **Settings > Troubleshooting > Print Quality Test Pages**. For non-touch-screen printer models, press **OK** to navigate through the settings.

ACTION	YES	NO
<p><b>Step 1</b></p> <p>a. Turn off the printer, wait for 10 seconds, and then turn on the printer.</p> <p>b. Decrease toner darkness.</p> <p>From the control panel, navigate to: <b>Settings &gt; Print &gt; Quality &gt; Toner Darkness</b></p> <p>c. Print the document.</p> <p>Does gray background appear on prints?</p>	Go to step 2.	The problem is solved.
<p><b>Step 2</b></p> <p>a. Check if the printer is using a genuine and supported Xerox toner cartridge.</p> <p>If the toner cartridge is not supported, then install a supported one.</p> <p>b. Print the document.</p> <p>Does gray background appear on prints?</p>	Go to step 3.	The problem is solved.
<p><b>Step 3</b></p> <p>a. Depending on your operating system, specify the paper type from the Printing Preferences or Print dialog.</p> <ul style="list-style-type: none"> <li>Make sure that the setting matches the paper loaded.</li> </ul>	Go to step 4.	The problem is solved.




ACTION	YES	NO
<ul style="list-style-type: none"> <li>You can also change the setting from the printer control panel. Navigate to <b>Settings &gt; Paper &gt; Tray Configuration &gt; Paper Size/Type</b>.</li> </ul> <p>b. Print the document.</p> <p>Does gray background appear on prints?</p>		
<p><b>Step 4</b></p> <p>a. Remove, and then insert the imaging unit.</p> <p>Do not expose the imaging unit to direct light for more than 10 minutes. Extended exposure to light may cause print quality problems.</p> <p>Do not touch the photoconductor drum under the imaging unit. Doing so may affect the quality of future print jobs.</p> <p>b. Print the document.</p> <p>Does gray background appear on prints?</p>	Go to step 5.	The problem is solved.
<p><b>Step 5</b></p> <p>a. Update the printer firmware. For more information, see <a href="#">Updating Software</a>.</p> <p>b. Print the document.</p> <p>Does gray background appear on prints?</p>	Go to step 6.	The problem is solved.
<p><b>Step 6</b></p> <p>a. Replace the imaging unit.</p> <p>b. Print the document.</p> <p>Does gray background appear on prints?</p>	Refer to <a href="#">Contacting Customer Support</a> .	The problem is solved.

## Incorrect margins



ACTION	YES	NO
<p><b>Step 1</b></p> <p>a. Adjust the paper guides to the correct position for the paper loaded.</p> <p>b. Print the document.</p> <p>Are the margins correct?</p>	<p>The problem is solved.</p>	<p>Go to step 2.</p>
<p><b>Step 2</b></p> <p>a. Set the paper size.</p> <p>From the control panel, navigate to: <b>Settings &gt; Paper &gt; Tray Configuration &gt; Paper Size/Type</b></p> <p>b. Print the document.</p> <p>Are the margins correct?</p>	<p>The problem is solved.</p>	<p>Go to step 3.</p>
<p><b>Step 3</b></p> <p>a. Depending on your operating system, specify the paper size from the Printing Preferences or Print dialog.</p> <p>Make sure that the setting matches the paper loaded.</p> <p>b. Print the document.</p> <p>Are the margins correct?</p>	<p>The problem is solved.</p>	<p>Refer to <b>Contacting Customer Support</b>.</p>

**Light print**

Note: Before solving the problem, print the Print Quality Test Pages. From the control panel, navigate to **Settings > Troubleshooting > Print Quality Test Pages**. For non-touch-screen printer models, press **OK** to navigate through the settings.

ACTION	YES	NO
<b>Step 1</b> a. Check if the printer is using a genuine and supported Xerox toner cartridge.  If the cartridge is not supported, then install a supported one.  b. Print the document.  Is the print light?	Go to step 2.	The problem is solved.
<b>Step 2</b> a. Turn off the printer, wait for about 10 seconds, and then turn on the printer. b. Increase toner darkness.  From the control panel, navigate to: <b>Settings &gt; Print &gt; Quality &gt; Toner Darkness</b>  c. Print the document.  Is the print light?	Go to step 3.	The problem is solved.
<b>Step 3</b> a. Depending on your operating system, specify the paper type from the Printing Preferences or Print dialog. <ul style="list-style-type: none"> <li>Make sure that the setting matches the paper loaded.</li> <li>You can also change the setting on the printer control</li> </ul>	Go to step 4.	The problem is solved.

ACTION	YES	NO
<p>panel. Navigate to <b>Settings</b>  <b>&gt; Paper &gt; Tray</b>  <b>Configuration &gt; Paper</b>  <b>Size/Type.</b></p> <p>b. Print the document.</p> <p>Is the print light?</p>		
<p><b>Step 4</b></p> <p>a. Depending on your operating system, specify the print resolution from the Printing Preferences or Print dialog.</p> <p>b. Set the resolution to <b>600 dpi</b>.</p> <p>c. Print the document.</p> <p>Is the print light?</p>	Go to step 5.	The problem is solved.
<p><b>Step 5</b></p> <p>a. Remove the imaging unit.</p> <p>Do not expose the imaging unit to direct light for more than 10 minutes. Extended exposure to light can cause print quality problems.</p> <p>Do not touch the photoconductor drum under the imaging unit. Doing so may affect the quality of future print jobs.</p> <p>b. Firmly shake the imaging unit to redistribute the toner.</p> <p>c. Insert the imaging unit.</p> <p>d. Turn off the printer, wait for 10 seconds, and then turn on the printer.</p> <p>e. Print the document.</p> <p>Is the print light?</p>	Go to step 6.	The problem is solved.

ACTION	YES	NO
<p><b>Step 6</b></p> <p>a. Check the status of the toner cartridge.</p> <p>From the control panel, navigate to: <b>Settings &gt; Reports &gt; Device &gt; Device Statistics</b></p> <p>b. From the Supply Information section of the pages printed, check the status of the toner cartridge.</p> <p>Is the toner cartridge near end of life?</p>	Go to step 7.	Refer to <b>Contacting Customer Support</b> .
<p><b>Step 7</b></p> <p>a. Replace the toner cartridge.</p> <p>b. Print the document.</p> <p>Is the print light?</p>	Refer to <b>Contacting Customer Support</b> .	The problem is solved.

### Mottled print and dots



Note: Before solving the problem, print the Print Quality Test Pages. From the control panel, navigate to **Settings > Troubleshooting > Print Quality Test Pages**. For non-touch-screen printer models, press **OK** to navigate through the settings.

ACTION	YES	NO
<b>Step 1</b> a. Check if the printer is using a genuine and supported Xerox toner cartridge.  If the cartridge is not supported, then install a supported one.  b. Print the document.  Is the print mottled?	Go to step 2.	The problem is solved.
<b>Step 2</b>  Check the printer for leaked toner contamination.  Is the printer free of leaked toner?	Go to step 3.	Refer to <a href="#">Contacting Customer Support</a> .
<b>Step 3</b> a. Check the status of the imaging unit.  From the control panel, navigate to: <b>Settings &gt; Reports &gt; Device &gt; Device Statistics</b>  b. From the Supply Information section of the pages printed, check the status of the imaging unit.  Is the imaging unit near end of life?	Go to step 4.	Contact <a href="#">Contacting Customer Support</a> .
<b>Step 4</b> a. Replace the imaging unit. b. Print the document.  Is the print mottled?	Contact <a href="#">Contacting Customer Support</a> .	The problem is solved.

## Paper curl



ACTION	YES	NO
<p><b>Step 1</b></p> <p>a. Check if the paper loaded is supported.</p> <p>If paper is not supported, then load a supported paper.</p> <p>b. Print the document.</p> <p>Is the paper curled?</p>	Go to step 2.	The problem is solved.
<p><b>Step 2</b></p> <p>a. Check if the printer is using a genuine and supported Xerox toner cartridge.</p> <p>If the cartridge is not supported, then install a supported one.</p> <p>b. Print the document.</p> <p>Is the paper curled?</p>	Go to step 3.	The problem is solved.
<p><b>Step 3</b></p> <p>a. Adjust the guides in the tray to the correct position for the paper loaded.</p> <p>b. Print the document.</p> <p>Is the paper curled?</p>	Go to step 4.	The problem is solved.
<p><b>Step 4</b></p> <p>a. Depending on your operating system, specify the paper size and paper type from the Printing Preferences or Print dialog.</p> <ul style="list-style-type: none"> <li>Make sure that the settings match the paper loaded.</li> <li>You can also change the setting on the printer control panel. Navigate to <b>Settings &gt; Paper &gt; Tray Configuration &gt; Paper Size/Type</b>. For non-touch-screen printer models, press <b>OK</b> to navigate through the settings.</li> </ul> <p>b. Print the document.</p> <p>Is the paper curled?</p>	Go to step 5.	The problem is solved.

ACTION	YES	NO
<p><b>Step 5</b></p> <p>a. Remove paper, flip it over, and then reload paper.</p> <p>b. Print the document.</p> <p>Is the paper curled?</p>	Go to step 6.	The problem is solved.
<p><b>Step 6</b></p> <p>a. Load paper from a fresh package.</p> <p>Paper absorbs moisture due to high humidity. Store paper in its original wrapper until you are ready to use it.</p> <p>b. Print the document.</p> <p>Is the paper curled?</p>	Refer to <b>Contacting Customer Support</b> .	The problem is solved.

**Print crooked or skewed**



Note: Before solving the problem, print the Print Quality Test Pages. From the control panel, navigate to **Settings > Troubleshooting > Print Quality Test Pages**. For non-touch-screen printer models, press **OK** to navigate through the settings.

ACTION	YES	NO
<b>Step 1</b> a. Adjust the guides in the tray to the correct position for the paper loaded. b. Print the document. Is the print crooked or skewed?	Go to step 2.	The problem is solved.
<b>Step 2</b> a. Load paper from a fresh package.	Go to step 3.	The problem is solved.



ACTION	YES	NO
<p>Paper absorbs moisture due to high humidity. Store paper in its original wrapper until you are ready to use it.</p> <p>b. Print the document.</p> <p>Is the print crooked or skewed?</p>		
<p><b>Step 3</b></p> <p>a. Check if the paper loaded is supported.</p> <p>If paper is not supported, then load a supported paper.</p> <p>b. Print the document.</p> <p>Is the print crooked or skewed?</p>	<p>Refer to <a href="#">Contacting Customer Support</a>.</p>	<p>The problem is solved.</p>
<p><b>Step 4</b></p> <p>a. For two-sided printing, check if the paper size setting in the duplex unit is set correctly.</p> <p>Letter, legal, Oficio, or folio must be set to Letter.</p> <p>b. Print the document.</p> <p>Is the print crooked or skewed?</p>	<p>Refer to <a href="#">Contacting Customer Support</a>.</p>	<p>The problem is solved.</p>

### Solid black pages



Note: Before solving the problem, print the Print Quality Test Pages. From the control panel, navigate to **Settings > Troubleshooting > Print Quality Test Pages**. For non-touch-screen printer models, press **OK** to navigate through the settings.

ACTION	YES	NO
<p><b>Step 1</b></p> <p>a. Check if the printer is using a genuine and supported Xerox toner cartridge.</p> <p>If the toner cartridge is not supported, then install a supported one.</p> <p>b. Print the document.</p> <p>Is the printer printing solid black pages?</p>	<p>Go to step 2.</p>	<p>The problem is solved.</p>
<p><b>Step 2</b></p> <p>a. Remove, and then insert the imaging unit.</p> <p>Do not expose the imaging unit to direct light for more than 10 minutes. Extended exposure to light may cause print quality problems.</p> <p>Do not touch the photoconductor drum under the imaging unit. Doing so may affect the quality of future print jobs.</p> <p>b. Print the document.</p> <p>Is the printer printing solid black pages?</p>	<p>Go to step 3.</p>	<p>The problem is solved.</p>
<p><b>Step 3</b></p> <p>Check the imaging unit for signs of damage.</p> <p>Make sure that the photoconductor drum contact is not bent or out of place.</p> <p>Is the imaging unit free from damage?</p>	<p>Refer to <a href="#">Contacting Customer Support</a>.</p>	<p>Go to step 4.</p>
<p><b>Step 4</b></p> <p>a. Replace the imaging unit.</p> <p>b. Print the document.</p> <p>Is the printer printing solid black pages?</p>	<p>Contact <a href="#">Contacting Customer Support</a>.</p>	<p>The problem is solved.</p>

## Text or images cut off



Note: Before solving the problem, print the Print Quality Test Pages. From the control panel, navigate to **Settings > Troubleshooting > Print Quality Test Pages**. For non-touch-screen printer models, press **OK** to navigate through the settings.

ACTION	YES	NO
<p><b>Step 1</b></p> <p>a. Check if the printer is using a genuine and supported Xerox toner cartridge.</p> <p>If the toner cartridge is not supported, then install a supported one.</p> <p>b. Print the document.</p> <p>Are text or images cut off?</p>	<p>Go to step 2.</p>	<p>The problem is solved.</p>
<p><b>Step 2</b></p> <p>a. Remove, and then insert the imaging unit.</p> <p>Do not expose the imaging unit to direct light for more than 10 minutes. Extended exposure to light may cause print quality problems.</p> <p>Do not touch the photoconductor drum under the imaging unit. Doing so may affect the quality of future print jobs.</p> <p>b. Print the document.</p> <p>Are text or images cut off?</p>	<p>Go to step 3.</p>	<p>The problem is solved.</p>
<p><b>Step 3</b></p> <p>a. Replace the imaging unit.</p> <p>b. Print the document.</p> <p>Are text or images cut off?</p>	<p>Refer to <a href="#">Contacting Customer Support</a>.</p>	<p>The problem is solved.</p>

**Toner easily rubs off**

Note: Before solving the problem, print the Print Quality Test Pages. From the control panel, navigate to **Settings > Troubleshooting > Print Quality Test Pages**. For non-touch-screen printer models, press **OK** to navigate through the settings.

ACTION	YES	NO
<b>Step 1</b> a. Check if the printer is using a genuine and supported Xerox toner cartridge.  If the toner cartridge is not supported, then install a supported one.  b. Print the document.  Does toner easily rub off?	Go to step 2.	The problem is solved.
<b>Step 2</b> a. Depending on your operating system, specify the paper type from the Printing Preferences or Print dialog. <ul style="list-style-type: none"> <li>Make sure that the setting matches the paper loaded.</li> <li>You can also change the setting on the printer control panel. Navigate to <b>Settings &gt; Paper &gt; Tray Configuration &gt; Paper Size/Type</b>.</li> </ul> b. Print the document.  Does toner easily rub off?	Refer to <a href="#">Contacting Customer Support</a> .	The problem is solved.

## Horizontal light bands



Note: Before solving the problem, print the Print Quality Test Pages. From the control panel, navigate to **Settings > Troubleshooting > Print Quality Test Pages**. For non-touch-screen printer models, press **OK** to navigate through the settings.

ACTION	YES	NO
<p><b>Step 1</b></p> <p>a. Check if the printer is using a genuine and supported Xerox toner cartridge.</p> <p>If the cartridge is not supported, then install a supported one.</p> <p>b. Print the document.</p> <p>Do horizontal light bands appear on prints?</p>	Go to step 2.	The problem is solved.
<p><b>Step 2</b></p> <p>a. Remove, and then insert the imaging unit.</p> <p>Do not expose the imaging unit to direct light for more than 10 minutes. Extended exposure to light may cause print quality problems.</p> <p>Do not touch the photoconductor drum under the imaging unit. Doing so may affect the quality of future print jobs.</p> <p>b. Print the document.</p> <p>Do horizontal light bands appear on prints?</p>	Go to step 3.	The problem is solved.
<p><b>Step 3</b></p> <p>a. Replace the imaging unit.</p> <p>b. Print the document.</p> <p>Do horizontal light bands appear on prints?</p>	Refer to <a href="#">Contacting Customer Support</a> .	The problem is solved.

## Vertical light bands



Note: Before solving the problem, print the Print Quality Test Pages. From the control panel, navigate to **Settings > Troubleshooting > Print Quality Test Pages**. For non-touch-screen printer models, press **OK** to navigate through the settings.

ACTION	YES	NO
<b>Step 1</b> a. Check if the printer is using a genuine and supported Xerox toner cartridge.  If the cartridge is not supported, then install a supported one.  b. Print the document.  Do vertical light bands appear on prints?	Go to step 2.	The problem is solved.
<b>Step 2</b> a. Check the status of the toner cartridge.  From the control panel, navigate to: <b>Settings &gt; Reports &gt; Device &gt; Device Statistics</b>  b. From the Supply Information section of the pages printed, check the status of the toner cartridge.  Do vertical light bands appear on prints?	Go to step 3.	The problem is solved.
<b>Step 3</b> a. Replace the toner cartridge. b. Print the document.  Do vertical light bands appear on prints?	Refer to <b>Contacting Customer Support</b> .	The problem is solved.




## Vertical white lines



Note: Before solving the problem, print the Print Quality Test Pages. From the control panel, navigate to **Settings > Troubleshooting > Print Quality Test Pages**. For non-touch-screen printer models, press **OK** to navigate through the settings.

ACTION	YES	NO
<p><b>Step 1</b></p> <p>a. Check if the printer is using a genuine and supported Xerox toner cartridge.</p> <p>If the cartridge is not supported, then install a supported one.</p> <p>b. Print the document.</p> <p>Do vertical white lines appear on prints?</p>	<p>Go to step 2.</p>	<p>The problem is solved.</p>
<p><b>Step 2</b></p> <p>a. Depending on your operating system, specify the paper type from the Printing Preferences or Print dialog.</p> <ul style="list-style-type: none"> <li>Make sure that the setting matches the paper loaded.</li> <li>You can also change the setting on the printer control panel. Navigate to <b>Settings &gt; Paper &gt; Tray Configuration &gt; Paper Size/Type</b>.</li> </ul> <p>b. Print the document.</p> <p>Do vertical white lines appear on prints?</p>	<p>Refer to <a href="#">Contacting Customer Support</a>.</p>	<p>The problem is solved.</p>


## Vertical dark bands



Note: Before solving the problem, print the Print Quality Test Pages. From the control panel, navigate to **Settings > Troubleshooting > Print Quality Test Pages**. For non-touch-screen printer models, press **OK** to navigate through the settings.

ACTION	YES	NO
<p><b>Step 1</b></p> <p>a. Check if the printer is using a genuine and supported Xerox toner cartridge.</p> <p>If the toner cartridge is not supported, then install a supported one.</p> <p>b. Print the document.</p> <p>Do vertical dark bands appear on prints?</p>	Go to step 2.	The problem is solved.
<p><b>Step 2</b></p> <p>a. Remove, and then insert the imaging unit.</p> <p>Do not expose the imaging unit to direct light for more than 10 minutes. Extended exposure to light may cause print quality problems.</p> <p>Do not touch the photoconductor drum under the imaging unit. Doing so may affect the quality of future print jobs.</p> <p>b. Print the document.</p> <p>Do vertical dark bands appear on prints?</p>	Go to step 3.	The problem is solved.
<p><b>Step 3</b></p> <p>a. Check if a bright light enters the right side of the printer, and move the printer if necessary.</p> <p>b. Print the document.</p> <p>Do vertical dark bands appear on prints?</p>	Refer to <a href="#">Contacting Customer Support</a> .	The problem is solved.


### Vertical dark lines or streaks




Note: Before solving the problem, print the Print Quality Test Pages. From the control panel, navigate to **Settings > Troubleshooting > Print Quality Test Pages**. For non-touch-screen printer models, press **OK** to navigate through the settings.

ACTION	YES	NO
<p><b>Step 1</b></p> <p>a. Check if the printer is using a genuine and supported Xerox toner cartridge.</p> <p>If the toner cartridge is not supported, then install a supported one.</p> <p>b. Print the document.</p> <p>Do vertical dark lines or streaks appear on prints?</p>	Go to step 2.	The problem is solved.
<p><b>Step 2</b></p> <p>a. Remove, and then reinstall the imaging unit.</p> <p>Do not expose the imaging unit to direct light for more than 10 minutes. Extended exposure to light can cause print quality problems.</p> <p>Do not touch the photoconductor drum under the imaging unit. Doing so may affect the quality of future print jobs.</p> <p>b. Print the document.</p> <p>Do vertical dark lines or streaks appear on prints?</p>	Go to step 3.	The problem is solved.
<p><b>Step 3</b></p> <p>a. Replace the imaging unit.</p> <p>b. Print the document.</p> <p>Do vertical dark lines or streaks appear on prints?</p>	Refer to <b>Contacting Customer Support</b> .	The problem is solved.


Vertical dark streaks with print missing



 Note: Before solving the problem, print the Print Quality Test Pages. From the control panel, navigate to **Settings > Troubleshooting > Print Quality Test Pages**. For non-touch-screen printer models, press **OK** to navigate through the settings.

ACTION	YES	NO
<p><b>Step 1</b></p> <p>a. Remove, and then insert the imaging unit.</p> <p>Do not expose the imaging unit to direct light for more than 10 minutes. Extended exposure to light may cause print quality problems.</p> <p>Do not touch the photoconductor drum under the imaging unit. Doing so may affect the quality of future print jobs.</p> <p>b. Print the document.</p> <p>Do vertical dark streaks with missing images appear on prints?</p>	<p>Go to step 2.</p>	<p>The problem is solved.</p>
<p><b>Step 2</b></p> <p>a. Check if the printer is using a genuine and supported Xerox toner cartridge.</p> <p>If the toner cartridge is not supported, then install a supported one.</p> <p>b. Print the document.</p> <p>Do vertical dark streaks with missing images appear on prints?</p>	<p>Refer to <b>Contacting Customer Support</b>.</p>	<p>The problem is solved.</p>

## Repeating defects



Note: Before solving the problem, print the Print Quality Test Pages. From the control panel, navigate to **Settings > Troubleshooting > Print Quality Test Pages**. For non-touch-screen printer models, press **OK** to navigate through the settings.

ACTION	YES	NO
<p><b>Step 1</b></p> <p>Using the Print Quality Test Pages, check if the distance between the repeating defects is equal to any of the following:</p> <ul style="list-style-type: none"> <li>• <b>Imaging unit</b> <ul style="list-style-type: none"> <li>– 75.40 mm (2.97 in.)</li> <li>– 34.70 mm (1.37 in.)</li> <li>– 23.9 mm (0.94 in.)</li> </ul> </li> <li>• <b>Toner cartridge</b> <ul style="list-style-type: none"> <li>– 35.70 mm (1.41 in.)</li> <li>– 36.80 mm (1.45 in.)</li> </ul> </li> <li>• <b>Transfer roller</b> <ul style="list-style-type: none"> <li>– 44 mm (1.73 in.)</li> </ul> </li> <li>• <b>Fuser</b> <ul style="list-style-type: none"> <li>– 78.1 mm (3.07 in.)</li> <li>– 75.4 mm (2.97 in.)</li> </ul> </li> </ul> <p>Does the distance between the repeating defects match any of the measurements?</p>	<p>Go to step 2.</p>	<p>Take note of the distance, and then refer to <a href="#">Contacting Customer Support</a>.</p>
<p><b>Step 2</b></p> <p>a. Replace the supply item that matches the repeating defects distance.</p> <p>If the supply item is a transfer roller or fuser, then refer to <a href="#">Contacting Customer Support</a>.</p> <p>b. Print the document.</p> <p>Do the repeating defects appear?</p>	<p>Refer to <a href="#">Contacting Customer Support</a>.</p>	<p>The problem is solved.</p>



**PRINT JOBS DO NOT PRINT**

ACTION	YES	NO
<b>Step 1</b> 1 From the document you are trying to print, open the Print dialog, and then check if you have selected the correct printer. 2 Print the document. Is the document printed?	The problem is solved.	Go to step 2.
<b>Step 2</b> 1 Check if the printer is on. 2 Resolve any error messages that appear on the display. 3 Print the document. Is the document printed?	The problem is solved.	Go to step 3.
<b>Step 3</b> 1 Check if the ports are working and if the cables are securely connected to the computer and the printer.  For more information, see the setup documentation that came with the printer. 2 Print the document. Is the document printed?	The problem is solved.	Go to step 4.
<b>Step 4</b> 1 Turn off the printer, wait for about 10 seconds, and then turn on the printer. 2 Print the document. Is the document printed?	The problem is solved.	Go to step 5.
<b>Step 5</b> 1 Remove, and then reinstall the print driver. 2 Print the document. Is the document printed?	The problem is solved.	Refer to <b>Contacting Customer Support</b> .

## JOB PRINTS FROM THE WRONG TRAY OR ON THE WRONG PAPER

ACTION	YES	NO
<b>Step 1</b> a. Check if you are printing on the correct paper. b. Print the document. Is the document printed on the correct paper?	Go to step 2.	Load the correct paper size and paper type.
<b>Step 2</b> a. Depending on your operating system, specify the paper size and paper type from the Printing Preferences or Print dialog. You can also change the settings on the printer control panel. Navigate to: <b>Settings &gt; Paper &gt; Tray Configuration &gt; Paper Size/Type</b> For non-touch-screen printer models, press <b>OK</b> to navigate through the settings. b. Make sure that the settings match the paper loaded. c. Print the document. Is the document printed on the correct paper?	The problem is solved.	Refer to <a href="#">Contacting Customer Support</a> .

## SLOW PRINTING

ACTION	YES	NO
<b>Step 1</b> Make sure that the printer cable is securely connected to the printer and to the computer, print server, or other network device. Is the printer printing slow?	Go to step 2.	The problem is solved.
<b>Step 2</b>	Go to step 3.	The problem is solved.

ACTION	YES	NO
<p>a. Make sure that the printer is not in Quiet Mode.</p> <p>From the control panel, navigate to: <b>Settings &gt; Device &gt; Maintenance &gt; Config Menu &gt; Device Operations &gt; Quiet Mode</b></p> <p>For non-touch-screen printer models, press <b>OK</b> to navigate through the settings.</p> <p>b. Print the document.</p> <p>Is the printer printing slow?</p>		
<p><b>Step 3</b></p> <p>a. Depending on your operating system, specify the print resolution from the Printing Preferences or Print dialog.</p> <p>b. Set the resolution to <b>600 dpi</b>.</p> <p>c. Print the document.</p> <p>Is the printer printing slow?</p>	Go to step 4.	The problem is solved.
<p><b>Step 4</b></p> <p>a. From the control panel, navigate to: <b>Settings &gt; Print &gt; Quality &gt; Print Resolution</b></p> <p>For non-touch-screen printer models, press <b>OK</b> to navigate through the settings.</p> <p>b. Set the resolution to <b>600 dpi</b>.</p> <p>c. Print the document.</p> <p>Is the printer printing slow?</p>	Go to step 5.	The problem is solved.
<p><b>Step 5</b></p> <p>a. Depending on your operating system, specify the paper type setting from the Printing Preferences or Print dialog.</p> <ul style="list-style-type: none"> <li>• Make sure that the setting matches the paper loaded.</li> <li>• You can also change the setting on the printer control</li> </ul>	Go to step 6.	The problem is solved.

ACTION	YES	NO
<p>panel. Navigate to <b>Settings &gt; Paper &gt; Tray Configuration &gt; Paper Size/Type</b>. For non-touch-screen printer models, press <b>OK</b> to navigate through the settings.</p> <ul style="list-style-type: none"> <li>• Heavier paper prints more slowly.</li> <li>• Paper narrower than letter, A4, and legal may print more slowly.</li> </ul> <p>b. Print the document.</p> <p>Is the printer printing slow?</p>		
<p><b>Step 6</b></p> <p>a. Make sure that the printer settings for texture and weight match the paper being loaded.</p> <p>From the control panel, navigate to: <b>Settings &gt; Paper &gt; Media Configuration &gt; Media Types</b></p> <p>For non-touch-screen printer models, press <b>OK</b> to navigate through the settings.</p> <p>Rough paper textures and heavy paper weights may print more slowly.</p> <p>b. Print the document.</p> <p>Is the printer printing slow?</p>	<p>Go to step 7.</p>	<p>The problem is solved.</p>

ACTION	YES	NO
<b>Step 7</b> Remove held jobs. Is the printer printing slow?	Go to step 8.	The problem is solved.
<b>Step 8</b> a. Make sure that the printer is not overheating. <ul style="list-style-type: none"> <li>• Allow the printer to cool down after a long print job.</li> <li>• Observe the recommended ambient temperature for the printer. For more information, see <a href="#">Selecting a location for the printer</a>.</li> </ul> b. Print the document. Is the printer printing slow?	Refer to <a href="#">Contacting Customer Support</a> .	The problem is solved.

## The printer is not responding

ACTION	YES	NO
<b>Step 1</b> Check if the power cord is connected to the electrical outlet.  To avoid the risk of fire or electrical shock, connect the power cord to an appropriately rated and properly grounded electrical outlet that is near the product and easily accessible.  Is the printer responding?	The problem is solved.	Go to step 2.
<b>Step 2</b> Check if the electrical outlet is turned off by a switch or breaker.  Is the electrical outlet turned off by a switch or breaker?	Turn on the switch or reset the breaker.	Go to step 3.
<b>Step 3</b> Check if the printer is on.  Is the printer on?	Go to step 4.	Turn on the printer.
<b>Step 4</b> Check if the printer is in Sleep or Hibernate mode.  Is the printer in Sleep or Hibernate mode?	Press the power button to wake the printer.	Go to step 5.
<b>Step 5</b> Check if the cables connecting the printer and the computer are inserted to the correct ports.  Are the cables inserted to the correct ports?	Go to step 6.	Insert the cables to the correct ports.

ACTION	YES	NO
<b>Step 6</b> Install the correct print driver. Is the printer responding?	The problem is solved.	Go to step 7.
<b>Step 7</b> Turn off the printer, wait for about 10 seconds, and then turn on the printer. Is the printer responding?	The problem is solved.	Refer to <a href="#">Contacting Customer Support</a> .

## Unable to read flash drive

ACTION	YES	NO
<p><b>Step 1</b></p> <p>Check if the printer is not busy processing another print, copy, scan, or fax job.</p> <p>Is the printer ready?</p>	<p>Go to step 2.</p>	<p>Wait for the printer to finish processing the other job.</p>
<p><b>Step 2</b></p> <p>Check if the flash drive is supported. For more information, see <a href="#">Supported flash drives and file types</a>.</p> <p>Is the flash drive supported?</p>	<p>Go to step 3.</p>	<p>Insert a supported flash drive.</p>
<p><b>Step 3</b></p> <p>Remove, and then insert the flash drive.</p> <p>Does the printer recognize the flash drive?</p>	<p>The problem is solved.</p>	<p>Refer to <a href="#">Contacting Customer Support</a>.</p>



## Enabling the USB port

From the control panel, navigate to **Settings > Network/Ports > USB > Enable USB Port**

For non-touch-screen printer models, press  to navigate through the settings.

## Network connection problems

### CANNOT OPEN EMBEDDED WEB SERVER

ACTION	YES	NO
<b>Step 1</b> Check if the printer is on. Is the printer on?	Go to step 2.	Turn on the printer.
<b>Step 2</b> Make sure that the printer IP address is correct. <ul style="list-style-type: none"> <li>View the IP address on the home screen.</li> <li>An IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.</li> </ul> Is the printer IP address correct?	Go to step 3.	Type the correct printer IP address in the address field.
<b>Step 3</b> Check if you are using a supported browser: <ul style="list-style-type: none"> <li>Internet Explorer version 11 or later</li> <li>Microsoft Edge</li> <li>Safari version 6 or later</li> <li>Google Chrome™ version 32 or later</li> <li>Mozilla Firefox version 24 or later</li> </ul> Is your browser supported?	Go to step 4.	Install a supported browser.
<b>Step 4</b> Check if the network connection is working. Is the network connection working?	Go to step 5.	Contact your administrator.
<b>Step 5</b> Make sure that the cable connections to the printer and print server are secure. For more information, see the documentation	Go to step 6.	Secure the cable connections.

ACTION	YES	NO
that came with the printer. Are the cable connections secure?		
<b>Step 6</b> Check if the web proxy servers are disabled. Are the web proxy servers disabled?	Go to step 7.	Contact your administrator.
<b>Step 7</b> Access the Embedded Web Server. Did the Embedded Web Server open?	The problem is solved.	Refer to <a href="#">Contacting Customer Support</a> .

#### CANNOT CONNECT THE PRINTER TO THE WI-FI NETWORK

ACTION	YES	NO
<b>Step 1</b> Make sure that Active Adapter is set to Auto.  From the control panel, navigate to <b>Settings &gt; Network/Ports &gt; Network Overview &gt; Active Adapter &gt; Auto</b>  For non-touch-screen printer models, press <b>OK</b> to navigate through the settings.  Can the printer connect to the Wi-Fi network?	The problem is solved.	Go to step 2.
<b>Step 2</b> Check if the correct Wi-Fi network is selected.  Some routers may share the default SSID.  Are you connecting to the correct Wi-Fi network?	Go to step 4.	Go to step 3.
<b>Step 3</b> Connect to the correct Wi-Fi network. For more information, see <a href="#">Connecting the Printer to a Wi-Fi</a>	The problem is solved.	Go to step 4.

ACTION	YES	NO
<p><b>Network.</b></p> <p>Can the printer connect to the Wi-Fi network?</p>		
<p><b>Step 4</b></p> <p>Check the wireless security mode.</p> <p>From the control panel, navigate to <b>Settings &gt; Network/Ports &gt; Wireless &gt; Wireless Security Mode</b></p> <p>For non-touch-screen printer models, press <b>OK</b> to navigate through the settings.</p> <p>Is the correct wireless security mode selected?</p>	Go to step 6.	Go to step 5.
<p><b>Step 5</b></p> <p>Select the correct wireless security mode.</p> <p>Can the printer connect to the Wi-Fi network?</p>	The problem is solved.	Go to step 6.
<p><b>Step 6</b></p> <p>Make sure that you entered the correct network password.</p> <p>Take note of the spaces, numbers, and capitalization in the password.</p> <p>Can the printer connect to the Wi-Fi network?</p>	The problem is solved.	Refer to <b>Contacting Customer Support.</b>

## Issues with supplies

### REPLACE CARTRIDGE, PRINTER REGION MISMATCH — USE 708699

To correct this problem, purchase a cartridge with the correct region that matches the printer region, or purchase a worldwide cartridge.

- The first number in the message after 42 indicates the region of the printer.
- The second number in the message after 42 indicates the region of the cartridge.

**Table 12.1 Printer and toner cartridge regions**

REGION	NUMERIC CODE
Worldwide or Undefined region	0
North America (United States, Canada)	1
European Economic Area, Western Europe, Nordic countries, Switzerland	2
Asia Pacific	3
Latin America	4
Rest of Europe, Middle East, Africa	5
Australia, New Zealand	6
Invalid region	9



Note: To find the region settings of the printer and toner cartridge, print the print quality test pages. From the control panel, navigate to: **Settings > Troubleshooting > Print Quality Test Pages**.

### NON-XEROX SUPPLIES

The printer has detected a non-Xerox supply installed in the printer.

Your Xerox printer is designed to function best with genuine Xerox supplies. Use of third-party supplies can affect the performance, reliability, or life of the printer and its imaging components.

All life indicators are designed to function with Xerox supplies and can deliver unpredictable results if third-party supplies are used. Imaging component usage beyond the intended life may damage your Xerox printer or associated components.



**Warning:** Use of third-party supplies or parts can affect warranty coverage. Damage caused by the use of third-party supplies or parts may not be covered by the warranty.

To accept any and all of these risks and to proceed with the use of non-genuine supplies in your printer, press and hold X and OK simultaneously for 15 seconds.


If you do not want to accept these risks, then remove the third-party supply or part from your printer and install a genuine Xerox supply or part. For more information, refer to [Using Genuine Xerox Supplies](#).

## Clearing Jams


### AVOIDING JAMS

#### Load Paper Properly

- Make sure that the paper lies flat in the tray.




- Do not load or remove a tray while the printer is printing.
- Do not load too much paper. Make sure that the stack height is below the maximum paper fill indicator.
- Do not slide paper into the tray. Load paper as shown in the illustration.



- Make sure that the paper guides are positioned correctly and are not pressing tightly against the paper or envelopes.
- For two-sided printing on A4-size paper, make sure that the paper size setting in the duplex unit is set to A4.
- For two-sided printing on letter-, legal-, Oficio-, or folio-size paper, make sure that the paper size setting in the duplex unit is set to Letter.
- Push the tray firmly into the printer after loading paper.

### Use Recommended Paper


- Use only recommended paper or specialty media.
- Do not load paper that is wrinkled, creased, damp, bent, or curled.
- Flex, fan, and align the paper edges before loading.



- Do not use paper that has been cut or trimmed by hand.
- Do not mix paper sizes, weights, or types in the same tray.
- Make sure that the paper size and type are set correctly on the computer or printer control panel.
- Store paper according to manufacturer recommendations.

### IDENTIFYING JAM LOCATIONS

- When Jam Assist is set to On, the printer flushes blank pages or pages with partial prints after a jammed page has been cleared. Check your printed output for blank pages.
- When Jam Recovery is set to On or Auto, the printer reprints jammed pages.




1. Automatic document feeder (ADF)
2. Standard output tray
3. Front door
4. Manual feeder
5. Tray

Troubleshoot a problem


6. Rear door
7. Duplex unit


### PAPER JAM IN THE TRAY

1. Remove the tray.



2. Remove the jammed paper.

 Note: Make sure that all paper fragments are removed.





3. Insert the tray.




## PAPER JAM IN THE FRONT DOOR


1. Open the front door.


 **Warning:** To prevent damage from electrostatic discharge, touch any exposed metal frame of the printer before accessing or touching interior areas of the printer.




2. Remove the imaging unit.



 **Warning:** Do not expose the imaging unit to direct light for more than 10 minutes. Extended exposure to light may cause print quality problems.

 **Warning:** Do not touch the photoconductor drum. Doing so may affect the quality of future print jobs.




3. Remove the jammed paper.




**CAUTION—HOT SURFACE:** The inside of the printer might be hot. To reduce the risk of injury from a hot component, allow the surface to cool before touching it.



Note: Make sure that all paper fragments are removed.



4. Insert the imaging unit.




5. Close the door.

## PAPER JAM IN THE REAR DOOR


1. Open the rear door.




**CAUTION—HOT SURFACE:** The inside of the printer might be hot. To reduce the risk of injury from a hot component, allow the surface to cool before touching it.




2. Open the fuser access door.



3. Remove the jammed paper.


 Note: Make sure that all paper fragments are removed.





4. Close the fuser access door.
5. Close the rear door.

#### PAPER JAM IN THE DUPLEX UNIT

1. Pull out the duplex unit, and then remove the jammed paper.

 **Warning:** To prevent damage from electrostatic discharge, touch any exposed metal frame of the printer before accessing or touching interior areas of the printer.





 Note: Make sure that all paper fragments are removed.

2. Insert the duplex unit.

### PAPER JAM IN THE STANDARD OUTPUT TRAY

1. Raise the scanner, and then remove the jammed paper.


 Note: Make sure that all paper fragments are removed.




2. Lower the scanner.

### PAPER JAM IN THE MANUAL FEEDER

Remove the jammed paper.

 Note: Make sure that all paper fragments are removed.




### PAPER JAM IN THE AUTOMATIC DOCUMENT FEEDER

1. Remove all original documents from the ADF tray.

2. Open the ADF cover.




**Warning:** To prevent damage from electrostatic discharge, touch any exposed metal frame of the printer before accessing or touching interior areas of the printer.




3. Remove the jammed paper.



Note: Ensure that all paper fragments are removed.





4. Close the ADF cover.
5. Open the scanner cover.



## Troubleshoot a problem

6. Remove the jammed paper.

 Note: Make sure that all paper fragments are removed.




7. Close the scanner cover.



## Paper feed problems


## ENVELOPE SEALS WHEN PRINTING

ACTION	YES	NO
<p><b>Step 1</b></p> <p>a. Use an envelope that has been stored in a dry environment.</p> <p>Printing on envelopes with high moisture content can seal the flaps.</p> <p>b. Send the print job.</p> <p>Does the envelope seal when printing?</p>	Go to step 2.	The problem is solved.
<p><b>Step 2</b></p> <p>a. Make sure that paper type is set to Envelope.</p> <p>From the control panel, navigate to <b>Settings &gt; Paper &gt; Tray Configuration &gt; Paper Size/Type</b></p> <p>For non-touch-screen printer models, press  to navigate through the settings.</p> <p>b. Send the print job.</p> <p>Does the envelope seal when printing?</p>	Refer to <a href="#">Contacting Customer Support</a> .	The problem is solved.

## COLLATED PRINTING DOES NOT WORK

ACTION	YES	NO
<p><b>Step 1</b></p> <p>a. From the control panel, navigate to <b>Settings &gt; Print &gt; Layout &gt; Collate</b></p> <p>For non-touch-screen printer models, press <b>OK</b> to navigate through the settings.</p> <p>b. Select <b>On [1,2,1,2,1,2]</b>.</p> <p>c. Print the document.</p> <p>Is the document collated correctly?</p>	The problem is solved.	Go to step 2.
<p><b>Step 2</b></p> <p>a. From the document that you are trying to print, open the Print dialog, and then select <b>Collate</b>.</p> <p>b. Print the document.</p> <p>Is the document collated correctly?</p>	The problem is solved.	Go to step 3.
<p><b>Step 3</b></p> <p>a. Reduce the number of pages to print.</p> <p>b. Print the document.</p> <p>Are the pages collated correctly?</p>	The problem is solved.	Refer to <b>Contacting Customer Support</b> .

## PAPER FREQUENTLY JAMS

ACTION	YES	NO
<p><b>Step 1</b></p> <ol style="list-style-type: none"> <li>Remove the tray.</li> <li>Check if paper is loaded correctly.               <ul style="list-style-type: none"> <li>Make sure that the paper guides are positioned correctly.</li> <li>Make sure that the stack height is below the maximum paper fill indicator.</li> <li>Make sure to print on recommended paper size and type.</li> </ul> </li> <li>Insert the tray.</li> <li>Print the document.</li> </ol> <p>Do paper jams occur frequently?</p>	Go to step 2.	The problem is solved.
<p><b>Step 2</b></p> <ol style="list-style-type: none"> <li>From the control panel, navigate to <b>Settings &gt; Paper &gt; Tray Configuration &gt; Paper Size/Type</b>  For non-touch-screen printer models, press  to navigate through the settings.</li> <li>Set the correct paper size and type.</li> <li>Print the document.</li> </ol> <p>Do paper jams occur frequently?</p>	Go to step 3.	The problem is solved.
<p><b>Step 3</b></p> <ol style="list-style-type: none"> <li>Load paper from a fresh package.  Paper absorbs moisture due to high humidity. Store paper in its original wrapper until you are ready to use it.</li> <li>Print the document.</li> </ol> <p>Do paper jams occur frequently?</p>	Refer to <a href="#">Contacting Customer Support</a> .	The problem is solved.

## JAMMED PAGES ARE NOT REPRINTED

ACTION	YES	NO
<p>a. From the control panel, navigate to <b>Settings &gt; Device &gt; Notifications &gt; Jam Content Recovery</b></p> <p>For non-touch-screen printer models, press <b>OK</b> to navigate through the settings.</p> <p>b. In the Jam Recovery menu, select <b>On</b> or <b>Auto</b>.</p> <p>c. Print the document.</p> <p>Are the jammed pages reprinted?</p>	<p>The problem is solved.</p>	<p>Contact <a href="#">Contacting Customer Support</a>.</p>

## E-mailing problems

### DISABLING THE SMTP SERVER NOT SET UP ERROR MESSAGE

Depending on your printer model, from the control panel, select an option:

- Touch **Home** > **Settings** > **E-mail** > **E-mail Setup** > **Disable “SMTP Server not set up” error** > **On**.
- Navigate to **Settings** > **E-mail** > **OK** > **E-mail Setup** > **OK** > **Disable “SMTP Server not set up” error** > **OK** > **On** > **OK**.

To prevent the error from happening again, do one of the following:

- Update the firmware. For more information, see
- Configure the e-mail SMTP settings. For more information, see [Updating Software.Configuring the Email SMTP Settings](#).

### CANNOT SEND E-MAILS

ACTION	YES	NO
<b>Step 1</b>  Make sure that the e-mail SMTP settings are configured correctly. For more information, see <a href="#">Configuring the Email SMTP Settings</a> .  Can you send an e-mail?	The problem is solved.	Go to step 2.
<b>Step 2</b>  Make sure that you are using the correct password. Depending on your e-mail service provider, use your account password, app password, or authentication password. For more information, see <a href="#">Configuring the Email SMTP Settings</a> .  Can you send an e-mail?	The problem is solved.	Go to step 3.
<b>Step 3</b>  Make sure that the printer is connected to a network and that the network is connected to the Internet.  Can you send an e-mail?	The problem is solved.	Refer to <a href="#">Contacting Customer Support</a> .

## Faxing problems

### CANNOT SEND OR RECEIVE FAXES

ACTION	YES	NO
<b>Step 1</b> Resolve any error messages that appear on the display. Can you send or receive a fax?	The problem is solved.	Go to step 2.
<b>Step 2</b> Make sure that the cable connections for the following equipment are secure: <ul style="list-style-type: none"> <li>• Telephone</li> <li>• Handset</li> <li>• Answering machine</li> </ul> Can you send or receive a fax?	The problem is solved.	Go to step 3.
<b>Step 3</b> Check for a dial tone. <ul style="list-style-type: none"> <li>• Call the fax number to check if it is working properly.</li> <li>• If you are using the On Hook Dial feature, then turn up the volume to check if you hear a dial tone.</li> </ul> Can you hear a dial tone?	Go to step 5.	Go to step 4.
<b>Step 4</b> Check the telephone wall jack. <ol style="list-style-type: none"> <li>Connect the analog telephone directly to the wall jack.</li> <li>Listen for a dial tone.</li> <li>If you do not hear a dial tone, then use a different telephone cable.</li> <li>If you still do not hear a dial tone, then connect the analog telephone to a different wall jack.</li> </ol>	The problem is solved.	Go to step 5.

ACTION	YES	NO
<p>e. If you hear a dial tone, then connect the printer to that wall jack.</p> <p>Can you send or receive a fax?</p>		
<p><b>Step 5</b></p> <p>Check if the printer is connected to an analog phone service or to the correct digital connector.</p> <ul style="list-style-type: none"> <li>• If you are using an Integrated Services for Digital Network (ISDN) telephone service, then connect to an analog telephone port of an ISDN terminal adapter. For more information, contact your ISDN provider.</li> <li>• If you are using DSL, then connect to a DSL filter or router that supports analog use. For more information, contact your DSL provider.</li> <li>• If you are using a private branch exchange (PBX) telephone service, then make sure that you are connecting to an analog connection on the PBX. If none exists, then consider installing an analog telephone line for the fax machine.</li> </ul> <p>Can you send or receive a fax?</p>	The problem is solved.	Go to step 6.

ACTION	YES	NO
<p><b>Step 6</b></p> <p>Temporarily disconnect other equipment and disable other telephone services.</p> <ol style="list-style-type: none"> <li>Disconnect other equipment (such as answering machines, computers, modems, or telephone line splitters) between the printer and the telephone line.</li> <li>Disable call waiting and voice mail. For more information, contact your telephone company.</li> </ol> <p>Can you send or receive a fax?</p>	<p>The problem is solved.</p>	<p>Go to step 7.</p>
<p><b>Step 7</b></p> <p>Scan the original document one page at a time.</p> <ol style="list-style-type: none"> <li>Dial the fax number.</li> <li>Scan the document.</li> </ol> <p>Can you send or receive a fax?</p>	<p>The problem is solved.</p>	<p>Refer to <b>Contacting Customer Support</b>.</p>



## CAN RECEIVE BUT NOT SEND FAXES

ACTION	YES	NO
<p><b>Step 1</b></p> <p>Load the original document properly into the ADF tray or on the scanner glass.</p> <p>Can you send faxes?</p>	<p>The problem is solved.</p>	<p>Go to step 2.</p>
<p><b>Step 2</b></p> <p>Set up the shortcut number properly.</p> <ul style="list-style-type: none"> <li>• Check if the shortcut number is set for the telephone number that you want to dial.</li> <li>• Dial the telephone number manually.</li> </ul> <p>Can you send faxes?</p>	<p>The problem is solved.</p>	<p>Refer to <b>Contacting Customer Support</b>.</p>

## CAN SEND BUT NOT RECEIVE FAXES

ACTION	YES	NO
<b>Step 1</b> Make sure that the paper source is not empty. Can you receive faxes?	The problem is solved.	Go to step 2.
<b>Step 2</b> Check the ring count delay settings. From the control panel, navigate to <b>Settings &gt; Fax &gt; Fax Setup &gt; Fax Receive Settings &gt; Rings to Answer</b> For non-touch-screen printer models, press <b>OK</b> to navigate through the settings. Can you receive faxes?	The problem is solved.	Go to step 3.
<b>Step 3</b> If the printer is printing blank pages, then see <b>Blank or White Pages</b> . Can you receive faxes?	The problem is solved.	Refer to <b>Contacting Customer Support</b> .

## POOR FAX PRINT QUALITY


ACTION	YES	NO
<p><b>Step 1</b></p> <p>Make sure that there are no print quality defects.</p> <p>a. From the control panel, navigate to <b>Settings &gt; Troubleshooting &gt; Print Quality Test Pages</b></p> <p>For non-touch-screen printer models, press <b>OK</b> to navigate through the settings.</p> <p>b. Correct any print quality defects. For more information, see <a href="#">Print quality is poor</a>.</p> <p>Is the fax print quality satisfactory?</p>	<p>The problem is solved.</p>	<p>Go to step 2.</p>
<p><b>Step 2</b></p> <p>Decrease the incoming fax transmission speed.</p> <p>a. From the control panel, navigate to <b>Settings &gt; Fax &gt; Fax Setup &gt; Fax Receive Settings &gt; Admin Controls &gt; Max Speed</b></p> <p>For non-touch-screen printer models, press <b>OK</b> to navigate through the settings.</p> <p>b. Select a lower transmission speed.</p> <p>Is the fax print quality satisfactory?</p>	<p>The problem is solved.</p>	<p>Refer to <a href="#">Contacting Customer Support</a>.</p>

## Scanning problems

### CANNOT SCAN TO A COMPUTER

ACTION	YES	NO
<b>Step 1</b> Perform a copy job. Is the copy job successful?	Go to step 3.	Go to step 2.
<b>Step 2</b> a. Turn off the printer, wait for about 10 seconds, and then turn it back on. b. Scan the document. Can you scan the document to a computer?	The problem is solved.	Go to step 3.
<b>Step 3</b> Check the printer connectivity. a. Print the Network Setup Page. From the control panel, navigate to <b>Settings &gt; Reports &gt; Network &gt; Network Setup Page</b> b. Check the network status. Is the printer connected to the network?	Go to step 5.	Go to step 4.
<b>Step 4</b> a. Connect the printer to the network. b. Scan the document. Can you scan the document to a computer?	The problem is solved.	Go to step 5.
<b>Step 5</b> a. Make sure that the printer and the computer are connected to the same network. b. Scan the document. Can you scan the document to a computer?	The problem is solved.	Refer to <a href="#">Contacting Customer Support</a> .

**CANNOT SCAN TO A NETWORK FOLDER**

ACTION	YES	NO
<p><b>Step 1</b></p> <ol style="list-style-type: none"> <li>Create a network folder shortcut.</li> <li>Scan a document using the shortcut. For more information, see <a href="#">Scanning to a network folder</a>.</li> </ol> <p>Can you scan a document and save it to a network folder?</p>	The problem is solved.	Go to step 2.
<p><b>Step 2</b></p> <p> Note: Make sure that the network folder path and format are correct. For example, //server_hostname/foldername/path, where server_hostname is a fully qualified domain (FQDN) or IP address.</p> <p>Is the network folder path and format correct?</p>	Go to step 3.	Go to step 4.
<p><b>Step 3</b></p> <p>Make sure that you have a write access permission to the network folder.</p> <p>Can you scan a document and save it to a network folder?</p>	The problem is solved.	Go to step 4.

ACTION	YES	NO
<p><b>Step 4</b></p> <p>Update the network folder shortcut.</p> <ol style="list-style-type: none"> <li>Open a web browser, and then type the printer IP address in the address field. <ul style="list-style-type: none"> <li>View the printer IP address on the home screen. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.</li> <li>If you are using a proxy server, then temporarily disable it to load the web page correctly.</li> </ul> </li> <li>Click <b>Shortcuts</b>, and then select a shortcut. <p>If you have multiple shortcut types, then select Network Folder.</p> </li> <li>In the Share Path field, type the network folder path. <ul style="list-style-type: none"> <li>If your share path is \server_hostname\foldername\path, then type //server_hostname/foldername/path.</li> <li>Make sure that you use forward slashes when typing the share path.</li> </ul> </li> <li>From the Authentication menu, select your authentication method. <p>If Authentication is set to “Use assigned username and password,” then in the User Name and Password fields, type your credentials.</p> </li> <li>Click <b>Save</b>.</li> </ol> <p>Can you scan a document and save it to a network folder?</p>	<p>The problem is solved.</p>	<p>Go to step 5.</p>
<p><b>Step 5</b></p>	<p>The problem is solved.</p>	<p>Refer to <a href="#">Contacting Customer</a></p>

ACTION	YES	NO
<p>Make sure that the printer and the network folder are connected to the same network.</p> <p>Can you scan a document and save it to a network folder?</p>		Support.

#### PARTIAL COPIES OF DOCUMENT OR PHOTO

ACTION	YES	NO
<p><b>Step 1</b></p> <p>a. Make sure that the document or photo is loaded facedown on the upper left corner of the scanner glass.</p> <p>b. Copy the document or photo.</p> <p>Is the document or photo copied correctly?</p>	The problem is solved.	Go to step 2.
<p><b>Step 2</b></p> <p>a. Match the paper size setting and the paper loaded in the tray.</p> <p>b. Copy the document or photo.</p> <p>Is the document or photo copied correctly?</p>	The problem is solved.	Refer to <a href="#">Contacting Customer Support</a> .

## SCAN JOB WAS NOT SUCCESSFUL


ACTION	YES	NO
<p><b>Step 1</b></p> <p>Check the cable connections.</p> <ol style="list-style-type: none"> <li>Make sure that the Ethernet or USB cable is securely connected to the computer and the printer.</li> <li>Resend the scan job.</li> </ol> <p>Is the scan job successful?</p>	The problem is solved.	Go to step 2.
<p><b>Step 2</b></p> <p>Check the file you want to scan.</p> <ol style="list-style-type: none"> <li>Make sure that the file name is not already used in the destination folder.</li> <li>Make sure that the document or photo you want to scan is not open in another application.</li> <li>Resend the scan job.</li> </ol> <p>Is the scan job successful?</p>	The problem is solved.	Go to step 3.
<p><b>Step 3</b></p> <ol style="list-style-type: none"> <li>Make sure that the <b>Append time stamp</b> or the <b>Overwrite existing file</b> check box is selected in the destination configuration settings.</li> <li>Resend the scan job.</li> </ol> <p>Is the scan job successful?</p>	The problem is solved.	Refer to <b>Contacting Customer Support</b> .



## POOR COPY QUALITY

ACTION	YES	NO
<b>Step 1</b> a. Clean the scanner glass and the ADF glass with a damp, soft, lint-free cloth. If your printer has a second ADF glass inside the ADF, then also clean that glass.  For more information, see <a href="#">Cleaning the Scanner</a> .  b. Make sure that the document or photo is loaded facedown on the upper left corner of the scanner glass.  c. Copy the document or photo.  Is the copy quality satisfactory?	The problem is solved.	Go to step 2.
<b>Step 2</b> a. Check the quality of the original document or photo. b. Adjust the scan quality settings. c. Copy the document or photo.  Is the copy quality satisfactory?	The problem is solved.	Refer to <a href="#">Contacting Customer Support</a> .

## VERTICAL DARK STREAKS ON OUTPUT WHEN SCANNING FROM THE ADF



ACTION	YES	NO
a. Open the scanner cover. b. Using a damp, soft, lint-free cloth, wipe the ADF glass and the ADF glass pad. c. Close the scanner cover. d. Scan the document.  Do vertical streaks appear on scanned documents?	Refer to <a href="#">Contacting Customer Support</a> .	The problem is solved.

#### SCANNER DOES NOT CLOSE

ACTION	YES	NO
<p>Remove obstructions that keep the scanner cover open.</p> <p>Did the scanner cover close correctly?</p>	The problem is solved.	Refer to <a href="#">Contacting Customer Support</a> .

#### SCANNING TAKES TOO LONG OR FREEZES THE COMPUTER

ACTION	YES	NO
<p>Close all applications that are interfering with the scan.</p> <p>Does scanning take too long or freeze the computer?</p>	Refer to <a href="#">Contacting Customer Support</a> .	The problem is solved.

## SCANNER DOES NOT RESPOND

ACTION	YES	NO
<b>Step 1</b> a. Check if the power cord is connected properly to the printer and the electrical outlet.  To avoid the risk of fire or electrical shock, connect the power cord to an appropriately rated and properly grounded electrical outlet that is near the product and easily accessible.  b. Copy or scan the document.  Is the scanner responding?	The problem is solved.	Go to step 2.
<b>Step 2</b> a. Check if the printer is turned on. b. Resolve any error messages that appear on the display. c. Copy or scan the document.  Is the scanner responding?	The problem is solved.	Go to step 3.
<b>Step 3</b> a. Turn off the printer, wait for about 10 seconds, and then turn the printer on. b. Copy or scan the document.  Is the scanner responding?	The problem is solved.	Refer to <a href="#">Contacting Customer Support</a> .

## ADJUSTING SCANNER REGISTRATION

1. From the control panel, navigate to **Settings > Device > Maintenance > Config Menu > Scanner Configuration > Scanner Manual Registration > Print Quick Test**.

For non-touch-screen printer models, press  to navigate through the settings.

2. Place the Print Quick Test page on the scanner glass, and then select **Flatbed Registration**.
3. Select **Copy Quick Test**.
4. Compare the Copy Quick Test page with the original document.



Note: If the margins of the test page are different from the original document, then adjust Left Margin and Top Margin.

5. Repeat [Step 3](#) and [Step 4](#) and until the margins of the Copy Quick Test page closely match the original document.

## ADJUSTING ADF REGISTRATION

1. From the control panel, navigate to **Settings > Device > Maintenance > Config Menu > Scanner Configuration > Scanner Manual Registration > Print Quick Test**.

For non-touch-screen printer models, press  to navigate through the settings.

2. Place the Print Quick Test page on the ADF tray, and then select **Front ADF Registration**.



Note: To align the front ADF registration, place the test page faceup, short edge first into the ADF.

3. Select **Copy Quick Test**.
4. Compare the Copy Quick Test page with the original document.



Note: If the margins of the test page are different from the original document, then adjust Horizontal Adjust and Top Margin.

5. Repeat **Step 3** and **Step 4** and until the margins of the Copy Quick Test page closely match the original document.

## Contacting Customer Support

Before contacting customer support, make sure to have the following information:

- Printer problem
- Error message
- Printer model type and serial number

To receive email, chat support, or to browse the supported documentation, drivers, and other downloads, go to [www.xerox.com](http://www.xerox.com), click on the **Customer Support** link, and search for your product.

Technical support via telephone is also available. In the U.S. or Canada, go to [www.xerox.com/supplies](http://www.xerox.com/supplies). For other countries or regions, go to or contact the place where you purchased the printer.



# Regulatory Information

This appendix contains:

Basic Regulations ..... 296


Copy Regulations ..... 305

Material Safety Data Sheets ..... 308

Basic Regulations

NOISE EMISSION LEVELS

The following measurements were made in accordance with ISO 7779 and reported in conformance with ISO 9296.

 Note: Some modes may not apply to your product.

1-METER AVERAGE SOUND PRESSURE, DBA	
Printing	One-sided: 52 Two-sided: 50
Scanning	52
Copying	55
Ready	14

EUROPEAN UNION LOT 19 ECODESIGN DIRECTIVE

Per European Commission Ecodesign Directive, the light source contained within this product or its components is intended to be used for Image Capture or Image Projection only, and is not intended for use in other applications.

STATIC SENSITIVITY NOTICE



This symbol identifies static-sensitive parts. Do not touch the areas near these symbols without first touching a metal surface in an area away from the symbol.

To prevent damage from electrostatic discharge when performing maintenance tasks, such as clearing paper jams or replacing supplies, touch any exposed metal frame of the printer before accessing or touching interior areas of the printer, even if the symbol is not present.

ENERGY STAR



Any Xerox product bearing the ENERGY STAR emblem on the product or on a start-up screen is certified to comply with Environmental Protection Agency (EPA) ENERGY STAR requirements as of the date of manufacture.



**TEMPERATURE INFORMATION**

Ambient operating temperature	10 to 32.2°C (50 to 90°F)
Shipping temperature	-40 to 43.3°C (-40 to 110°F)
Storage temperature and relative humidity	-40 to 43.3°C (-40 to 110°F), 8 to 80 % RH

**INFORMACIÓN DE LA ENERGÍA DE MÉXICO**

- Consumo de energía en operación: 550 Wh
- Consumo de energía en modo de espera: 0.1 Wh
- Cantidad de producto por unidad de energía consumida: 4.15 páginas/Wh

**LASER NOTICE**

The printer is certified in the U.S. to conform to the requirements of DHHS 21 CFR, Chapter I, Subchapter J for Class I (1) laser products, and elsewhere is certified as a Class I laser product conforming to the requirements of IEC 60825-1: 2014.

Class I laser products are not considered to be hazardous. The laser system and printer are designed so there is never any human access to laser radiation above a Class I level during normal operation, user maintenance, or prescribed service conditions. The printer has a non-serviceable printhead assembly that contains a laser with the following specifications:

- Class: IIIb (3b) AlGaAs
- Nominal output power (milliwatts): 15
- Wavelength (nanometers): 775–800

**POWER****Product Power Consumption**

The following table documents the power consumption characteristics of the product.



Note: Some modes may not apply to your product.

MODE	DESCRIPTION	POWER CONSUMPTION (WATTS)
Printing	The product is generating hard-copy output from electronic inputs.	One-sided: 460 Two-sided: 325
Copy	The product is generating hard-copy output from hard-copy original documents.	460
Scan	The product is scanning hard-copy documents.	N/A (B225); 9.5 (B235, flash drive)

MODE	DESCRIPTION	POWER CONSUMPTION (WATTS)
Ready	The product is waiting for a print job.	5.5 (B225); 6.0 (B235)
Sleep Mode	The product is in a high-level energy-saving mode.	1.2 (B225) or 1.1 (B235)
Hibernate	The product is in a low-level energy-saving mode.	N/A
Off	The product is plugged into an electrical outlet, but the power switch is turned off.	0.1 (B225); 0.2 (B235)

The power consumption levels listed in the previous table represent time-averaged measurements. Instantaneous power draws may be substantially higher than the average.

### Sleep Mode

This product is designed with an energy-saving mode called Sleep Mode. The Sleep Mode saves energy by lowering power consumption during extended periods of inactivity. The Sleep Mode is automatically engaged after this product is not used for a specified period of time, called the Sleep Mode Timeout.



Note: Factory default Sleep Mode Timeout for this product is 15 minutes.

By using the configuration menus, the Sleep Mode Timeout can be modified between 1 minute and 120 minutes. If the print speed is less than or equal to 30 pages per minute, then you can set the timeout only up to 60 minutes. Setting the Sleep Mode Timeout to a low value reduces energy consumption, but may increase the response time of the product. Setting the Sleep Mode Timeout to a high value maintains a fast response, but uses more energy.

### Hibernate Mode

This product is designed with an ultra-low power operating mode called Hibernate mode. When operating in Hibernate Mode, all other systems and devices are powered down safely.

The Hibernate mode can be entered in any of the following methods:

- Using the Hibernate Timeout
- Using the Schedule Power modes



Note: Factory default Hibernate Timeout for this product in all countries or regions is 3 days.

The amount of time the printer waits after a job is printed before it enters Hibernate mode can be modified between one hour and one month.

### Off Mode

If this product has an off mode which still consumes a small amount of power, then to completely stop product power consumption, disconnect the power supply cord from the electrical outlet.

## Total Energy Usage

It is sometimes helpful to estimate the total product energy usage. Since power consumption claims are provided in power units of Watts, the power consumption should be multiplied by the time the product spends in each mode in order to calculate energy usage. The total product energy usage is the sum of each mode's energy usage.

## TELECOMMUNICATION REGULATORY NOTICES

### Regulatory Notices for Telecommunication Terminal Equipment

This section contains regulatory information pertaining to products that contain the analog facsimile card.

#### FCC Requirements Notice to Users of the US Telephone Network

This equipment complies with Part 68 of the FCC rules and the requirements adopted by the Administrative Council for Terminal Attachments (ACTA). On the back of this equipment is a label that contains, among other information, a product identifier in the format US:AAAEQ##TXXXX. If requested, this number must be provided to your telephone company.

This equipment uses the RJ-11C Universal Service Order Code (USOC) jack.

A plug and jack used to connect this equipment to the premises' wiring and telephone network must comply with the applicable FCC Part 68 rules and requirements adopted by the ACTA. Use a compliant telephone cord (RJ-11) that is 26 AWG or larger when connecting this product to the public switched telephone network. See your setup documentation for more information.

The Ringer Equivalence Number (REN) is used to determine the number of devices that may be connected to a telephone line. Excessive RENs on a telephone line may result in the devices not ringing in response to an incoming call. In most but not all areas, the sum of RENs should not exceed five (5.0). To be certain of the number of devices that may be connected to a line, as determined by the total RENs, contact your local telephone company. For products approved after July 23, 2001, the REN for this product is part of the product identifier that has the format US:AAAEQ##TXXXX. The digits represented by ## are the REN without a decimal point (for example, 03 is a REN of 0.3). For earlier products, the REN is shown separately on the label.

If this equipment causes harm to the telephone network, the telephone company will notify you in advance that temporary discontinuance of service may be required. If advance notice is not practical, the telephone company will notify the customer as soon as possible. You will also be advised of your right to file a complaint with the FCC.

The telephone company may make changes in its facilities, equipment, operations or procedures that could affect the operation of this equipment. If this happens, the telephone company will provide advance notice in order for you to make necessary modifications to maintain uninterrupted service.

If you experience trouble with this equipment, for repair or warranty information, contact your point of purchase. If the equipment is causing harm to the telephone network, the telephone company may request that you disconnect the equipment until the problem is resolved.

This equipment contains no user serviceable parts. For repair and warranty information, contact your point of purchase.

Connection to party line service is subject to state tariffs. Contact the state public utility commission, public service commission, or corporation commission for information.

If your home has specially wired alarm equipment connected to the telephone line, ensure the installation of this equipment does not disable your alarm equipment. If you have questions about what will disable alarm equipment, consult your telephone company or a qualified installer.

The Telephone Consumer Protection Act of 1991 makes it unlawful for any person to use a computer or other electronic device, including fax machines, to send any message unless said message clearly contains in a margin at the top or bottom of each transmitted page or on the first page of the transmission, the date and time it is sent and an identification of the business or other entity, or other individual sending the message, and the telephone number of the sending machine or such business, other entity, or individual. (The telephone number provided may not be a 900 number or any other number for which charges exceed local or long-distance transmission charges.)

Refer to your user documentation in order to program this information into your fax machine.

### **Notice to Users of the Canadian Telephone Network**

This product meets the applicable Innovation, Science and Economic Development Canada technical specifications.

The Ringer Equivalence Number (REN) indicates the maximum number of devices allowed to be connected to a telephone interface. The termination of an interface may consist of any combination of devices subject only to the requirement that the sum of the RENs of all the devices not exceed five. The REN is located on the product label.

This equipment uses CA11A telephone jacks.

### **Avis Réservé aux Utilisateurs du Réseau Téléphonique du Canada**

Ce produit est conforme aux spécifications techniques d'Innovation, Sciences et Développement économique Canada.

Le numéro REN (ringer equivalence number: numéro d'équivalence de sonnerie) indique le nombre maximum d'appareils pouvant être connectés à l'interface téléphonique. En bout de ligne, le nombre d'appareils qui peuvent être connectés n'est pas directement limité, mais la somme des REN de ces appareils ne doit pas dépasser cinq. Le numéro REN est indiqué sur l'étiquette produit.

Cet équipement utilise des prises de téléphone CA11A.

### **Notice to Users of the New Zealand Telephone Network**

The following are special conditions for the Facsimile User Instructions. The grant of a telepermit for any item of terminal equipment indicates only that Telecom has accepted that the item complies with minimum conditions for connection to its network. It indicates no endorsement of the product by Telecom, nor does it provide any sort of warranty. Above all, it provides no assurance that any item will work correctly in all respects with another item of telepermitted equipment of a different make or model, nor does it imply that any product is compatible with all of Telecom's network services.

This equipment shall not be set up to make automatic calls to the Telecom "111" Emergency Service.

This equipment may not provide for the effective hand-over of a call to another device connected to the same line.

This equipment should not be used under any circumstances that may constitute a nuisance to other Telecom customers.

This equipment is not capable, under all operating conditions, of correct operation at the higher speeds for which it is designed. Telecom will accept no responsibility should difficulties arise in such circumstances.

The decadic (or pulse) dialing on this device is unsuitable for use on the Telecom network in New Zealand.

For correct operation, the total of all the Ringer Equivalence Numbers (RENs) of all parallel devices connected to the same telephone line may not exceed 5. The REN of this device is located on the label.

This device uses an RJ-11C modular connector. Contact your point of purchase if a BT adapter is required.

Some parameters required for compliance with Telecom's telepermit requirements are dependent on the equipment associated with this device. The associated equipment shall be set to operate within the following limits for compliance to Telecom's specifications:

- There shall be no more than 10 call attempts to the same number within any 30 minute period for any single manual call initiation, and
- The equipment shall go on-hook for a period of not less than 30 seconds between the end of one attempt and the beginning of the next call attempt.
- The equipment shall be set to ensure that automatic calls to different numbers are spaced such that there is not less than 5 seconds between the end of one call attempt and the beginning of another.

### **Verwendung dieses Produkts in Deutschland**

Für dieses Produkt muss ein deutscher Billing Tone Filter zur Zählzeichenübertragung für jede Leitung installiert werden, über die in Deutschland Zeitsteuertakte übertragen werden. Zeitsteuertakte sind in analogen Leitungen in Deutschland möglicherweise nicht vorhanden. Der Teilnehmer kann die Bereitstellung von Zeitsteuertakten veranlassen oder beim deutschen Netzanbieter telefonisch deren Deaktivierung beantragen. Im Regelfall werden Zeitsteuertakte nur dann bereitgestellt, wenn dies vom Teilnehmer bei der Installation ausdrücklich erwünscht wird.

### **Using this Product in Switzerland**

This product requires a Swiss billing tone filter to be installed on any line which receives metering pulses in Switzerland.

### **Utilisation de ce produit en Suisse**

Cet appareil nécessite l'utilisation d'un filtre de tonalité de facturation suisse devant être installé sur toute ligne recevant des impulsions de comptage en Suisse.

### **Verwendung dieses Produkts in der Schweiz**

Für dieses Produkt muss ein schweizerischer Billing Tone Filter zur Zählzeichenübertragung für jede Leitung installiert werden, über die in der Schweiz Zeitsteuertakte übertragen werden.

### **Uso del prodotto in Svizzera**

Questo prodotto richiede un filtro toni Billing svizzero, da installare su tutte le linee che ricevono impulsi remoti in Svizzera.

## **REGULATORY NOTICES FOR WIRELESS PRODUCTS**

This section contains regulatory information that applies only to wireless models.

If in doubt as to whether your model is a wireless model, go to <http://support.xerox.com>.

### Modular Component Notice

Wireless models contain modular components. To determine which modular components are installed in your particular product, refer to the labeling on your actual product.

### Exposure to Radio Frequency Radiation

The radiated output power of this device is far below the radio frequency exposure limits of the FCC and other regulatory agencies. A minimum separation of 20 cm (8 inches) must be maintained between the antenna and any persons for this device to satisfy the RF exposure requirements of the FCC and other regulatory agencies.

### Innovation, Science and Economic Development Canada

This device complies with Innovation, Science and Economic Development Canada license-exempt RSS standards. Operation is subject to the following two conditions:

1. This device may not cause interference, and
2. This device must accept any interference, including interference that may cause undesired operation of the device.

### Innovation, Sciences et Développement économique Canada

Cet appareil est conforme aux normes RSS exemptes de licence d'Innovation, Sciences et Développement économique Canada. Son fonctionnement est soumis aux deux conditions suivantes:

1. Cet appareil ne doit pas causer d'interférences et
2. Il doit accepter toutes les interférences, y compris les celles qui peuvent entraîner un fonctionnement indésirable.

### European Union and European Economic Area Compliance



The CE mark applied to this product indicates compliance to applicable EU Directives. The full text of the EU Declaration of Conformity is located at <https://www.xerox.com/en-us/about/ehs>.

### Restrictions

This radio equipment is restricted to indoor use only. Outdoor use is prohibited. This restriction applies to all the countries listed in the table below:

AT	BE	BG	CH	CY	CZ
DE	DK	EE	EL	ES	FI
FR	HR	HU	IE	IS	IT

LI	LT	LU	LV	MT	
NL	NO	PL	PT	RO	
SE	SI	SK	TR	UK	

### EU and Other Countries Statement of Radio Transmitter Operational Frequency Bands and Maximum RF Power

This radio product transmits in either the 2.4GHz (2.412–2.472 GHz in the EU) or 5GHz (5.15–5.35, 5.47–5.725 in the EU) bands. The maximum transmitter EIRP power output, including antenna gain, is  $\leq 20$ dBm for both bands.

### FEDERAL COMMUNICATIONS COMMISSION (FCC) COMPLIANCE INFORMATION STATEMENT

This product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

The FCC Class B limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult your point of purchase or service representative for additional suggestions.

The manufacturer is not responsible for radio or television interference caused by using other than recommended cables or by unauthorized changes or modifications to this equipment. Unauthorized changes or modifications could void the user's authority to operate this equipment.



Note: To assure compliance with FCC regulations on electromagnetic interference for a Class B computing device, use a properly shielded and grounded cable. Use of a substitute cable not properly shielded and grounded may result in a violation of FCC regulations.

For more information on Environment, Health, and Safety in relation to this Xerox product and supplies, contact the following:

**Web address:** <https://www.xerox.com/en-us/about/ehs>

**Call (US and Canada only):** 1-800-ASK-XEROX (1-800-275-9376)

**Email:** EHS-Europe@xerox.com

## INNOVATION, SCIENCE AND ECONOMIC DEVELOPMENT CANADA COMPLIANCE STATEMENT

This Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Standard ICES-003.

### Avis de conformité aux normes de l'Innovation, Sciences et Développement économique Canada

Cet appareil numérique de classe B est conforme aux exigences de la norme canadienne relative aux équipements pouvant causer des interférences NMB-003.

## GERMANY

### Blendschutz

Das Gerät ist nicht für die Benutzung im unmittelbaren Gesichtsfeld am Bildschirmarbeitsplatz vorgesehen. Um störende Reflexionen am Bildschirmarbeitsplatz zu vermeiden, darf dieses Produkt nicht im unmittelbaren Gesichtsfeld platziert werden.

### Importeur

Xerox GmbH

Hellersbergstraße 2-4

41460 Neuss

Deutschland

## TURKEY ROHS REGULATION

In compliance with Article 7 (d), we hereby certify "it is in compliance with the EEE regulation."

"EEE yönetmeliğine uygundur."

## UKRAINE ROHS COMPLIANCE

Обладнання відповідає вимогам Технічного регламенту щодо обмеження використання деяких небезпечних речовин в електричному та електронному обладнанні, затвердженого постановою Кабінету Міністрів України від 3 грудня 2008 № 1057.

(The equipment complies with requirements of the Technical Regulation, approved by the Resolution of Cabinet of Ministry of Ukraine as of December 3, 2008, in terms of restrictions for the use of certain dangerous substances in electrical and electronic equipment.)



## Copy Regulations

### UNITED STATES

Congress, by statute, has forbidden the reproduction of the following subjects under certain circumstances. Penalties of fine or imprisonment may be imposed on those guilty of making such reproductions.

1. Obligations or Securities of the United States Government, such as:
  - Certificates of Indebtedness.
  - National Bank Currency.
  - Coupons from Bonds.
  - Federal Reserve Bank Notes.
  - Silver Certificates.
  - Gold Certificates.
  - United States Bonds.
  - Treasury Notes.
  - Federal Reserve Notes.
  - Fractional Notes.
  - Certificates of Deposit.
  - Paper Money.
  - Bonds and Obligations of certain agencies of the government, such as FHA and so on.
  - Bonds. United States Savings Bonds may be photographed only for publicity purposes in connection with the campaign for the sale of such bonds.
  - Internal Revenue Stamps. If it is necessary to reproduce a legal document on which there is a canceled revenue stamp, this may be done provided the reproduction of the document is performed for lawful purposes.
  - Postage Stamps, canceled or uncanceled. For philatelic purposes, Postage Stamps may be photographed, provided the reproduction is in black and white and is less than 75 % or more than 150 % of the linear dimensions of the original.
  - Postal Money Orders.
  - Bills, Checks, or Drafts of money drawn by or upon authorized officers of the United States.
  - Stamps and other representatives of value, of whatever denomination, which have been or may be issued under any Act of Congress.
  - Adjusted Compensation Certificates for Veterans of the World Wars.
2. Obligations or Securities of any Foreign Government, Bank, or Corporation.
3. Copyrighted materials, unless permission of the copyright owner has been obtained or the reproduction falls within the "fair use" or library reproduction rights provisions of the copyright law. Further information of these provisions may be obtained from the Copyright Office, Library of Congress, Washington, D.C. 20559. Ask for Circular R21.

4. Certificate of Citizenship or Naturalization. Foreign Naturalization Certificates may be photographed.
5. Passports. Foreign Passports may be photographed.
6. Immigration papers.
7. Draft Registration Cards.
8. Selective Service Induction papers that bear any of the following Registrant's information:
  - Earnings or Income.
  - Court Record.
  - Physical or mental condition.
  - Dependency Status.
  - Previous military service.
  - Exception: United States military discharge certificates may be photographed.
9. Badges, Identification Cards, Passes, or Insignia carried by military personnel, or by members of the various Federal Departments, such as FBI, Treasury, and so on (unless photograph is ordered by the head of such department or bureau).

Reproducing the following is also prohibited in certain states:

- Automobile Licenses.
- Drivers' Licenses.
- Automobile Certificates of Title.

The preceding list is not all inclusive, and no liability is assumed for its completeness or accuracy. In case of doubt, consult your attorney.

For more information about these provisions contact the Copyright Office, Library of Congress, Washington, D.C. 20559. Ask for Circular R21.

## CANADA

Parliament, by statute, has forbidden the reproduction of the following subjects under certain circumstances. Penalties of fine or imprisonment may be imposed on those guilty of making such reproductions.

- Current bank notes or current paper money
- Obligations or securities of a government or bank
- Exchequer bill paper or revenue paper
- The public seal of Canada or of a province, or the seal of a public body or authority in Canada, or of a court of law
- Proclamations, orders, regulations, or appointments, or notices thereof (with intent to falsely cause same to purport to have been printed by the Queens Printer for Canada, or the equivalent printer for a province)
- Marks, brands, seals, wrappers, or designs used by or on behalf of the Government of Canada or of a province, the government of a state other than Canada or a department, board, Commission, or agency established by the Government of Canada or of a province or of a government of a state other than Canada

- Impressed or adhesive stamps used for the purpose of revenue by the Government of Canada or of a province or by the government of a state other than Canada
- Documents, registers, or records kept by public officials charged with the duty of making or issuing certified copies thereof, where the copy falsely purports to be a certified copy thereof
- Copyrighted material or trademarks of any manner or kind without the consent of the copyright or trademark owner

This list is provided for your convenience and assistance, but it is not all-inclusive, and no liability is assumed for its completeness or accuracy. In case of doubt, consult your solicitor.

## OTHER COUNTRIES

Copying certain documents may be illegal in your country. Penalties of fine or imprisonment may be imposed on those found guilty of making such reproductions.

- Currency notes
- Bank notes and checks
- Bank and government bonds and securities
- Passports and identification cards
- Copyright material or trademarks without the consent of the owner
- Postage stamps and other negotiable instruments

This list is not inclusive and no liability is assumed for either its completeness or accuracy. In case of doubt, contact your legal counsel.

## Material Safety Data Sheets

For Material Safety Data information regarding your printer, go to:

- Web Address: <https://safetysheets.business.xerox.com/en-us/>
- United States and Canada: 1-800-ASK-XEROX (1-800-275-9376)
- Other markets, send an email request to [EHS-Europe@xerox.com](mailto:EHS-Europe@xerox.com)

# Recycling and Disposal

This appendix contains:

- Product Disposal and Recycling..... 310
- North America..... 311
- Xerox Green World Alliance ..... 312
- Waste from Electrical and Electronic Equipment (WEEE) Directive ..... 313

## Product Disposal and Recycling

Do not dispose of the printer or supplies in the same manner as normal household waste. Consult your local authorities for disposal and recycling options.

## North America

Xerox operates an equipment take-back and reuse and recycle program. Contact your Xerox representative (1-800-ASK-XEROX) to determine if this Xerox product is part of the program. For more information about Xerox environmental programs, go to <https://www.xerox.com/en-us/about/ehs>.

## Xerox Green World Alliance

The Xerox Green World Alliance Program allows you to return qualified supplies to Xerox for reuse or recycling. One hundred percent of the empty cartridges returned to Xerox are either reused or de-manufactured for recycling. The boxes used to return the cartridges are also recycled.

To return Xerox cartridges for reuse or recycling, do the following:

1. Go to <https://www.xerox.com/office/recycle>.
2. Click **Recycling**.
3. Select an option for return.



## Waste from Electrical and Electronic Equipment (WEEE) Directive



The WEEE logo signifies specific recycling programs and procedures for electronic products in countries of the European Union. We encourage the recycling of our products.

If you have further questions about recycling options, contact your local sales office.

### INDIA E-WASTE NOTICE



This product including components, consumables, parts and spares complies with the “India E-Waste Rules” and prohibits use of lead, mercury, hexavalent chromium, polybrominated biphenyls or polybrominated diphenyl ethers in concentrations exceeding 0.1 % by weight and 0.01 % by weight for cadmium, except for the exemption set in the Rule.





