

FP *FLASHPOINT*

**Barndoor Filter & Grid Set
for 6.5"-8.5" Reflectors**

FPLFBD

To Mount the Barndoors on Your Reflector

1. Remove the reflector from the strobe
2. Lay the barndoors on a flat surface, loosen the two screws enough to slide in the reflector, so the lip is trapped under the quick release bar
3. Tighten the two screws simultaneously until reflector is held snugly in place, without placing extreme tension on the quick release bar
4. Test the tension by sliding the quick release bar out of its lock, then re-locking it
5. Gently shake the reflector to check that you have securely fastened the barndoors on
6. You can now mount the reflector on the strobe. (For future use, the barndoors can be mounted to the reflector without removing it from the strobe.)
7. Extend or retract the barndoors to increase and decrease the light spread, or slide in a filter or grid for various lighting effects.
8. To remove the barndoors, open the quick release bar. There is no need to adjust the screws.