



# Kipon Electronic Adapter From Micro 4/3 Mount to Canon EF Lenses (Eos Mount)

[KAELAM43EOS2] Compatibility list

Lens Camera Body	Auto Focus Function					Aperture Function		Remark
	Fast	Normal	Slow	unstable	inactive			
CANON EF 8-15mm F4L USM	●			X		●	X	
OLYMPUS OM-D E-M1 (Ver3.0)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
CANON EF 16-35mm F2.8L II USM	●			X		●	X	
OLYMPUS OM-D E-M1 (Ver3.0)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
CANON EF 16-35mm F4L IS USM	●			X		●	X	
OLYMPUS OM-D E-M1 (Ver3.0)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
CANON EF 17-40mm F4L USM	●			X		●	X	
OLYMPUS OM-D E-M1 (Ver3.0)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
CANON EF-S 17-55mm F2.8 IS USM	●			X		●	X	
OLYMPUS OM-D E-M1 (Ver3.0)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
CANON EF-S 18-135mm F3.5-5.6 IS	●			X			X	
OLYMPUS OM-D E-M1 (Ver3.0)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
CANON EF-S 18-200mm F3.5-5.6 IS	●			X		●	X	
OLYMPUS OM-D E-M1 (Ver3.0)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
CANON EF 24-70mm F2.8L II USM	●			X		●	X	
OLYMPUS OM-D E-M1 (Ver3.0)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
CANON EF 24-70mm F4L IS USM	●			X		●	X	
OLYMPUS OM-D E-M1 (Ver3.0)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
CANON EF 24-105mm F4L IS USM	●			X		●	X	
OLYMPUS OM-D E-M1 (Ver3.0)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
CANON EF 28-300mm F3.5-5.6L IS USM	●			X		●	X	
OLYMPUS OM-D E-M1 (Ver3.0)	Fast	Normal	Slow	unstable	inactive		aperture unstable	

Lens Camera Body	Auto Focus Function					Aperture Function		Remark
CANON EF 70-200mm F2.8L IS II USM	●			X		●	X	
OLYMPUS OM-D E-M1 (Ver3.0)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
CANON EF 70-300mm F4-5.6 IS USM	●			X		●	X	
OLYMPUS OM-D E-M1 (Ver3.0)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
CANON EF 70-300mm F4-5.6L IS USM	●			X		●	X	
OLYMPUS OM-D E-M1 (Ver3.0)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
CANON EF 24mm F1.4L II USM	●			X		●	X	
OLYMPUS OM-D E-M1 (Ver3.0)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
CANON EF 24mm F2.8 IS USM	●			X		●	X	
OLYMPUS OM-D E-M1 (Ver3.0)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
CANON EF 28mm F1.8 USM	●			X		●	X	Max. Aperture F3.5
OLYMPUS OM-D E-M1 (Ver3.0)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
CANON EF 28mm F2.8 IS USM	●			X		●	X	
OLYMPUS OM-D E-M1 (Ver3.0)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
CANON EF 50mm F1.2L USM	●			X		●	X	Max. Aperture F3.5
OLYMPUS OM-D E-M1 (Ver3.0)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
CANON EF 85mm F1.2L II USM	●			X		●	X	
OLYMPUS OM-D E-M1 (Ver3.0)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
CANON EF 85mm F1.8 USM	●			X		●	X	Max. Aperture F3.5
OLYMPUS OM-D E-M1 (Ver3.0)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
CANON EF 100mm 2.8L Macro IS USM	●			X		●	X	
OLYMPUS OM-D E-M1 (Ver3.0)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
SIGMA 8-16mm F4.5-5.6 DC HSM	●			X		●	X	
OLYMPUS OM-D E-M1 (Ver3.0)	Fast	Normal	Slow	unstable	inactive		aperture unstable	

Lens Camera Body	Auto Focus Function					Aperture Function		Remark
SIGMA 18-300mm F3.5-6.3 DC MACRO OS HSM	●			X		●	X	Max. Aperture F3.5
OLYMPUS OM-D E-M1 (Ver3.0)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
SIGMA 24-105mm F4 DG OS HSM	●			X		●	X	
OLYMPUS OM-D E-M1 (Ver3.0)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
SIGMA APO 50-500mm F4.5-6.3 DG OS HSM	●			X		●	X	
OLYMPUS OM-D E-M1 (Ver3.0)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
SIGMA 150-600mm F5-6.3 DG OS HSM	●			X		●	X	
OLYMPUS OM-D E-M1 (Ver3.0)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
SIGMA MACRO 105mm F2.8 EX DG OS HSM	●			X		●	X	
OLYMPUS OM-D E-M1 (Ver3.0)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
SIGMA APO MACRO 180mm F2.8 EX DG OS HSM	●			X		●	X	
OLYMPUS OM-D E-M1 (Ver3.0)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
TAMRON SP AF 10-24mm F/3.5-4.5 Di II LD Aspherical	●			X		●	X	
OLYMPUS OM-D E-M1 (Ver3.0)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
TAMRON 16-300mm F/3.5-6.3 Di II VC PZD MACRO	●			X		●	X	
OLYMPUS OM-D E-M1 (Ver3.0)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
TAMRON SP 150-600mm F/5-6.3 Di VC USD	●			X		●	X	
OLYMPUS OM-D E-M1 (Ver3.0)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
TAMRON SP 90mm F2.8 Di MACRO 1:1 VC USD	●			X		●	X	
OLYMPUS OM-D E-M1 (Ver3.0)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
TOKINA AT-X 12-28 PRO DX 12-28mm F4	●			X		●	X	
OLYMPUS OM-D E-M1 (Ver3.0)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
CANON EF 24-105mm F3.5-5.6 IS STM	●			X		●	X	
OLYMPUS OM-D E-M1 (Ver3.0)	Fast	Normal	Slow	unstable	inactive		aperture unstable	

Lens Camera Body	Auto Focus Function					Aperture Function		Remark
CANON EF 50mm F1.8 STM	●			X		●	X	At certain zoom settings Max. Aperture F3.5
OLYMPUS OM-D E-M1 (Ver3.0)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
CANON EF 40mm F2.8 STM	●			X		●	X	
OLYMPUS OM-D E-M1 (Ver3.0)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
CANON EF 70-200mm F4L IS USM	●			X		●	X	
OLYMPUS OM-D E-M1 (Ver3.0)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
CANON EF 8-15mm F4L USM	●			X		●	X	
PANASONIC LUMIX DMC-GX7 (Ver1.3)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
CANON EF 16-35mm F2.8L II USM	●			X		●	X	
PANASONIC LUMIX DMC-GX7 (Ver1.3)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
CANON EF 16-35mm F4L IS USM	●			X		●	X	
PANASONIC LUMIX DMC-GX7 (Ver1.3)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
CANON EF 17-40mm F4L USM	●			X		●	X	
PANASONIC LUMIX DMC-GX7 (Ver1.3)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
CANON EF-S 17-55mm F2.8 IS USM	●			X		●	X	
PANASONIC LUMIX DMC-GX7 (Ver1.3)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
CANON EF-S 18-135mm F3.5-5.6 IS	●			X			X	
PANASONIC LUMIX DMC-GX7 (Ver1.3)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
CANON EF-S 18-200mm F3.5-5.6 IS	●			X		●	X	
PANASONIC LUMIX DMC-GX7 (Ver1.3)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
CANON EF 24-70mm F2.8L II USM	●			X		●	X	
PANASONIC LUMIX DMC-GX7 (Ver1.3)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
CANON EF 24-70mm F4L IS USM	●			X		●	X	
PANASONIC LUMIX DMC-GX7 (Ver1.3)	Fast	Normal	Slow	unstable	inactive		aperture unstable	

Lens Camera Body	Auto Focus Function					Aperture Function		Remark
CANON EF 24-105mm F4L IS USM	●			X		●	X	
PANASONIC LUMIX DMC-GX7 (Ver1.3)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
CANON EF 28-300mm F3.5-5.6L IS USM	●			X		●	X	
PANASONIC LUMIX DMC-GX7 (Ver1.3)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
CANON EF 70-200mm F2.8L IS II USM	●			X		●	X	
PANASONIC LUMIX DMC-GX7 (Ver1.3)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
CANON EF 70-300mm F4-5.6 IS USM	●			X		●	X	
PANASONIC LUMIX DMC-GX7 (Ver1.3)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
CANON EF 70-300mm F4-5.6L IS USM	●			X		●	X	
PANASONIC LUMIX DMC-GX7 (Ver1.3)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
CANON EF 24mm F1.4L II USM	●			X		●	X	
PANASONIC LUMIX DMC-GX7 (Ver1.3)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
CANON EF 24mm F2.8 IS USM	●			X		●	X	
PANASONIC LUMIX DMC-GX7 (Ver1.3)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
CANON EF 28mm F1.8 USM	●			X		●	X	
PANASONIC LUMIX DMC-GX7 (Ver1.3)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
CANON EF 28mm F2.8 IS USM	●			X		●	X	
PANASONIC LUMIX DMC-GX7 (Ver1.3)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
CANON EF 50mm F1.2L USM	●			X		●	X	Max. Aperture F3.5
PANASONIC LUMIX DMC-GX7 (Ver1.3)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
CANON EF 85mm F1.2L II USM	●			X		●	X	
PANASONIC LUMIX DMC-GX7 (Ver1.3)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
CANON EF 85mm F1.8 USM	●			X		●	X	
PANASONIC LUMIX DMC-GX7 (Ver1.3)	Fast	Normal	Slow	unstable	inactive		aperture unstable	

Lens Camera Body	Auto Focus Function					Aperture Function		Remark
CANON EF 100mm 2.8L Macro IS USM	●			X		●	X	
PANASONIC LUMIX DMC-GX7 (Ver1.3)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
SIGMA 8-16mm F4.5-5.6 DC HSM	●			X		●	X	
PANASONIC LUMIX DMC-GX7 (Ver1.3)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
SIGMA 18-300mm F3.5-6.3 DC MACRO OS HSM	●			X		●	X	
PANASONIC LUMIX DMC-GX7 (Ver1.3)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
SIGMA 24-105mm F4 DG OS HSM	●			X		●	X	
PANASONIC LUMIX DMC-GX7 (Ver1.3)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
SIGMA APO 50-500mm F4.5-6.3 DG OS HSM	●			X		●	X	
PANASONIC LUMIX DMC-GX7 (Ver1.3)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
SIGMA 150-600mm F5-6.3 DG OS HSM	●			X		●	X	
PANASONIC LUMIX DMC-GX7 (Ver1.3)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
SIGMA MACRO 105mm F2.8 EX DG OS HSM	●			X		●	X	
PANASONIC LUMIX DMC-GX7 (Ver1.3)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
SIGMA APO MACRO 180mm F2.8 EX DG OS HSM	●			X		●	X	Max. Aperture F3.5
PANASONIC LUMIX DMC-GX7 (Ver1.3)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
TAMRON SP AF 10-24mm F/3.5-4.5 Di II LD Aspherical	●			X		●	X	
PANASONIC LUMIX DMC-GX7 (Ver1.3)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
TAMRON 16-300mm F/3.5-6.3 Di II VC PZD MACRO	●			X		●	X	
PANASONIC LUMIX DMC-GX7 (Ver1.3)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
TAMRON SP 150-600mm F/5-6.3 Di VC USD	●			X		●	X	
PANASONIC LUMIX DMC-GX7 (Ver1.3)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
TAMRON SP 90mm F2.8 Di MACRO 1 : 1 VC USD	●			X		●	X	
PANASONIC LUMIX DMC-GX7 (Ver1.3)	Fast	Normal	Slow	unstable	inactive		aperture unstable	

Lens Camera Body	Auto Focus Function					Aperture Function		Remark
TOKINA AT-X 12-28 PRO DX 12-28mm F4	●			X		●	X	
PANASONIC LUMIX DMC-GX7 (Ver1.3)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
CANON EF 24-105mm F3.5-5.6 IS STM	●			X		●	X	
PANASONIC LUMIX DMC-GX7 (Ver1.3)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
CANON EF 50mm F1.8 STM	●			X		●	X	
PANASONIC LUMIX DMC-GX7 (Ver1.3)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
CANON EF 40mm F2.8 STM	●			X		●	X	
PANASONIC LUMIX DMC-GX7 (Ver1.3)	Fast	Normal	Slow	unstable	inactive		aperture unstable	
CANON EF 70-200mm F4L IS USM	●			X		●	X	
PANASONIC LUMIX DMC-GX7 (Ver1.3)	Fast	Normal	Slow	unstable	inactive		aperture unstable	