

Firmware Instructions

- 1. Please update the firmware with FP firmware update software F3. F3 can be downloaded on the official website.**
- 2. Firmware Version Checking:** Press the “Mode” button and switch the flash on. The firmware update version (e.g. Ver X.X) will be displayed on the LCD panel.
- 3. Version Instructions:**

Version	What's New	Date
V1.21	Fixed a high-speed anomaly issue when using Mask function.	2026-04-28
V1.20	Upgraded the Mask function (cycle count increased to 8 — supports multiple flash firings).	2025-11-26

Note: For more details, please download the newest instruction manual on the official website http://www.adorama.com/g/flashpoint_firmware_download