

## Firmware Instructions

**1. Please update the firmware with FP firmware update software F3. F3 can be downloaded on the official website.**

**2. Firmware Version Checking:** Press the “Mode” button and switch the flash on. The firmware update version (e.g. Ver X.X) will be displayed on the LCD panel.

### **3. Version Instructions:**

Version	Updated Contents	Date
V1.2	1. Initial adjustment.	6/05/2019

**Note: For more details, please download the newest instruction manual on the official website [http://www.adorama.com/g/flashpoint\\_firmware\\_download](http://www.adorama.com/g/flashpoint_firmware_download)**

1.