

Firmware Instructions

1. Please update the firmware with FP firmware update software F1. F1 can be downloaded on the Flashpoint official website.
2. Firmware Version Checking: Turn the speedlight on, then long press the button corresponding to the “C.Fn” (Custom Function) button to have the menu displayed. The firmware update version (e.g. Ver 2.8) will be displayed on the upper right hand corner of the LCD panel.
3. Version Update History:

Version	Updated Contents	Date
V3.2	this firmware solve the compatibility issue with Nikon D780.	12/01/2020
V3.1	1.To add the option of wireless ID (C.Fn-ID) 2.To add the ON/OFF option of SLAVE mode indicator (C.Fn-Sv LED) 3.To add the function that the flash can be triggered by pressing the TEST button when being attached to camera.	12/01/2017
V3.0	compatible with Olympus,Panasonic, Fuji systems.	6/28/2017
V2.9	1. Nikon Camera + FPRRR2TN, FPLFSMZCA or FPLFSMZSO can achieve TTL and HSS functions when used off camera	4/19/2017
V2.8	1. Solves the out-of-sync triggering problem when using FEL in the Master mode in 2.4G radio transmission.	6/17/2016
V2.7	1. Solves the problem that some cameras will display a luminance edge when using radio transmission to trigger with high speed.	12/21/2015
V2.6	1. In order to improve anti-interference ability, the frequency of CH9, CH 12, CH15, CH18, CH21, CH24, CH27 and CH30 has been adjusted. As these 8 channels are not compatible with the old version, please update the relevant product.	11/25/2015

Remark: Long press Zm/C.Fn button after turn on the power to display the firmware version.
(FPLFSMZCA/NK/SO)