

Firmware Instructions

1. Please update the firmware with FP firmware update software F1. F1 can be downloaded on the Flashpoint official website.
2. Firmware Version Checking: Turn the speedlight on, then long press the button corresponding to the “C.Fn” (Custom Function) button to have the menu displayed. The firmware update version (e.g. Ver 1.4) will be displayed on the upper right hand corner of the LCD panel.
3. Version Update History:

Version	Updated Contents	Date
V1.9	To solve the compatible problem of new camera D780.	6/09/2020
V1.8	Compatible with R2 wireless PENTAX system.	10/23/2018
V1.7	To solve the problem that the focus lamp will be photographed in slow shutter shooting.	5/26/2018
V1.6	1.To add the option of wireless ID (C.Fn-ID) 2.To add the ON/OFF option of SLAVE mode indicator (C.Fn-Sv LED) 3.To add the function that the flash can be triggered by pressing the TEST button when being attached to camera.	12/01/2017
V1.5	Compatible with Olympus,Panasonic, Fuji systems.	6/28/2017
V1.4	1.Compatible with R2T-C (for Canon) and R2T-S (for Sony) flash trigger. 2.To repair the Auto-off function in the wireless SLAVE mode.	12/8/2016
V1.3	1. Solves the out-of-sync triggering problem when using FEL in the Master mode in 2.4G radio transmission.	6/17/2016