

## Firmware Instructions

### 1. Please update the firmware with FP firmware update software F3.

F3 can be downloaded on the official website.

1. Firmware Version Checking: Turn the speedlight on, then long press the button corresponding to the "C.Fn" (Custom Function) button to have the menu displayed. The firmware update version (e.g. Ver 1.4) will be displayed on the upper right hand corner of the LCD panel.

### 2. Version Update History:

Version	Updated Contents	Date
V1.3	<ol style="list-style-type: none"><li>1. To improve the heat protection system.</li><li>2. To adjust the control methods of LED.</li><li>3. To optimize the hotshoe communication protocol.</li></ol>	7/22/2019