



THE TRAVEL TRIPOD
OF YOUR DREAMS

3POD WANDER

COMPACT ALUMINUM TRAVEL TRIPOD



3PACTT

3POD

SUPPORT THE ART OF PHOTOIMAGING

3POD Wander. The best balance of stability, weight, dexterity, and compact travel in a tripod, optimized for easy transport and quick setup.

For the Wander Lust in you.

The Wander from 3POD may be the most travel-friendly camera support ever created.

The telescopic legs feature a unique design; cluster close-fitting about the center column for an amazingly compact traveling height of less than 15", and with the entire unit weighing in at an ultralight 4lb/1.8kg, there's nothing to stop you from carrying it with you anywhere you go. The center column can be extended to give the system a total height of 68.5in/174cm without sacrificing stability. Each 4-sectioned telescoping leg features three-position auto-settings and can lock in place individually at preset angles for perfect stance on uneven terrain. The positive clamp flip locks are fortified with a cutting-edge, wear-resistant internal structure, making them immune to dust, moisture, changes in temperature, and the gradual loosening over time that can occur in inferior locking mechanisms. And the feet... self-leveling flexible feet to meet surfaces and stand firm.

A convenient retractable weight hook provides an additional counterbalance to hang accessories. Wander with this rugged yet lightweight aluminum construction and anodized fashionable red accents have a stunning appearance and a superior wear-resistant finish.

Smart and sure, ever ready for action, the Wander lusts for the chance to capture the image of your dreams.


Contents

FEATURES	3
OVERVIEW OF THE 3POD WANDER	4
TRIPOD HEIGHT	5
LEG ANGLE	6
CENTER COLUMN HEIGHT	7
CENTER COLUMN REVERSE	8
TRAVEL PREP	9
NOTES	10
SPECIFICATIONS	11
IN THE BOX	11
WARRANTY	12
CUSTOMER SUPPORT	13

FEATURES:


- Grasp the Travel-Friendly Tripod with one hand.
- Adventure with ultimate interlocking zero space waste.
- Unique telescoping legs with flip-clamp wear-resistant sure-locks.
- A tuck no larger than a 1-liter water bottle.
- Abrasion-resistant aluminum appointed construction.
- Anodized red fashion accents stand apart.
- Reversible center column for macro and low angle shots.
- Travels at Minimum 15in / 38cm and reaches max height 68.5in / 274cm.
- Retractable weight/accessory hook.
- Handles the load with a capacity of up to 33lbs / 15kg.

OVERVIEW




TRIPOD HEIGHT

The height of the Wander is user adjustable by extending each leg. Flip open the leg extension locks [a] to reach to set the telescopic leg extensions [b] to your desired length. Once you are satisfied with the setup, close the flip-locks [c] to lock the leg in position.




LEG ANGLE

Each leg can be set independently at any of the 3 angles of spread. To change the angle on a leg, close the leg slightly towards the center column and press down the leg angle adjustment button at the top of the leg. While pressing the button down, select the new leg angle and release button to lock it automatically in position. Lift the leg slightly to meet the preset notch.




CENTER COLUMN HEIGHT

The height of the Center Column is, unlock knob [a] and adjust the height of the column as required. Tighten the Center Column lock knob [a] to secure the column in position.





CENTER COLUMN REVERSE

The center column reverse process for switching to low angle point of view is straightforward. Unlock the Center Column Lock [a]. Press down the small silver button on the lower portion of the column [b] and simultaneously remove the column [c] by pulling it upward out of the shoulder of the tripod. Invert the column and insert it into the shoulder from below (in the direction of [d]). Tighten the Center Column Lock [C].



TRAVEL PREP

Retract all legs and lock tightly. Close the leg towards the center column in the direction of "a". The legs all fit together with the least wasted space - perfect for travel!



NOTES

1. Do not exceed the maximum payload.
2. When using the tripod, always lock the central column. Lock or tighten every place that has been loosened during setup.
3. Always use the tripod in a safe manner. It's not a baseball bat!
4. Do not use at temperatures below -104°F/-40°C or more than 212°F/100°C.
5. Do not expose to wet, sandy, or dusty environments, especially seawater.
6. Protect the tripod from direct or indirect sun exposure and avoid high temperature environments, such as vehicle interiors
7. Do not set the tripod as a trip magnet for unaware people in private or public areas.
8. Use a mild detergent and a soft towel to clean the tripod. Pay particular attention to the lock system and the sliding leg extensions.
9. Do not expose the tripod to electrical currents. The results could be shocking!



SPECIFICATIONS:

Materials	Hardened Aluminum, Alloy Polycarbonate
Total Max Height	68.5 inches / 174 cm
Compact Height	15 inches / 38 cm
Weight	4.0 lbs / 1.8 kg
Leg Sections	4
Center Column Sections	1
Load Capacity	33 lbs / 15 kg

IN THE BOX:

- 3POD Wander Aluminum Travel Tripod
- Smartphone Mount
- Mini Toolkit
- Carry Case
- Manual
- Five Year 3POD Warranty

FIVE YEAR 3POD LIMITED WARRANTY

3POD warrants to the original purchaser that your 3POD product shall be free from defects in material and workmanship for the period of five (5) years from the date of purchase (or delivery as may be required in certain jurisdictions), or thirty (30) days after replacement, whichever comes later.

3POD's entire liability and your exclusive remedy for any breach of warranty shall be, at 3POD's option, to repair or replace the hardware, provided that the hardware is returned to the point of purchase or such other place as 3POD may direct with a copy of the sales receipt or dated itemized receipt. 3POD may, at its option, replace your product, offer to provide a functionally equivalent product, or repair any product with new, refurbished or used parts as long as such parts are in compliance with the product's technical specifications. Any replacement hardware product will be warranted for the remainder of the original warranty period or thirty (30) days, whichever is longer, or for any additional period of time that may be applicable in your jurisdiction. If the product has been discontinued, the warranty provider reserves the right to replace it with a model of equivalent quality and function.

This warranty does not cover problems or damage resulting from accident, abuse, misapplication, or any unauthorized repair, modification or disassembly, improper operation or maintenance, normal wear and tear, or usage not in accordance with product instructions or connection to improper voltage supply, use of consumables, such as replacement batteries, not supplied by 3POD, except where such restriction is prohibited by applicable law.

Except where prohibited by applicable law, this warranty is nontransferable and is limited to the original purchaser and the country in which the product was purchased. This warranty gives you specific legal rights, and you may also have other rights, including a longer warranty duration that may vary under local laws.

To start a warranty claim, contact the 3POD Customer Service Department to obtain a return merchandise authorization ("RMA") number, and return the defective product to 3POD, along with the RMA number and proof of purchase.

Question about our product line? Need Product Support?

We are proud of our products and celebrate our customers.
We are with you, from product selection to everyday use.
Be secure with your purchase and reach us as you need.



212-647-9300



brands@adorama.com



Adorama Brands,
42 West 18th Street,
New York, NY 10011

You can always contact us at **BRANDS@ADORAMA.COM** for
personal technical support.

Our website contains a wide range of Support and FAQ
pages with valuable technical assistance.

3POD is a registered trademark of ADORAMA CAMERA.

© 2022 Adorama Camera, Corp.

All Rights Reserved.

