

Disassembly and Storage

Disassemble and repack the POP bank for SkyPanel S360 by following the assembly instructions in reverse. Note” when folding the POP bank, fold the two short sides in first, then fold the bank in half. This will ensure the Lightbank will fit in its storage sack.

Tips for Care and Use

Cleaning - Your Chimera Lightbank can be cleaned by hand washing with cold water, a sponge and mild soap. Do not machine wash. To dry, assemble the Lightbank onto a Speed Ring and completely air dry.

Repair - Chimera has an expert in-house repair department. Lightbanks need to be clean, with any added tape removed before sending in for repair. If the Lightbank is received in dirty or in taped condition, the repair may be refused and returned to the sender. Please call in advance to get a Return Authorization Number and repair estimate at +1.888.444.1812 or +1.303.444.8000.

Warranty Information

At Chimera, we stand behind our Lightbanks, speed rings, and light control accessories with a limited 5-year warranty against manufacturing defects in materials, workmanship, and color stability. If our products are not fully operational out of the box or if they fail to perform within five years from the date of purchase, return it for repair or replacement at no charge. Of course, Chimera’s warranty cannot cover damage caused by accidents, improper care or use, or the natural deterioration of materials over an extended period of time. **This warranty does not apply to expendables, such as light bulbs, and certain OEM products.**



POP bank for ARRI SkyPanel S360

Instructions for Care and Use



Assembly



1. Begin by unfolding your S360 POP bank, aligning the side marked "This Way Up" with the top of the fixture. Unfold until you hear a resounding POP from all 4 sides of the Lightbank.

2. Place the elastic corner straps over the top two corners of the fixtures looping them over the foot eyelets. Repeat this process on the bottom two corners of the fixture. Ensure that the side marked "This Way Up" is pointing up.



3. Using the supplied straps, secure the Lightbank to the fixture. One set of straps will run vertically across the back of the fixture. The other set will run horizontally. Secure the straps using the attached D Rings. Again, ensure that the side marked "This Way Up" is pointing up.



4. Install the front screen by attaching to the Velcro on the front of the Lightbank.



5. Your S360 POP bank is now set up!



****NOTE: Four attachment points for a safety bond are located on the outside of the Lightbank body, as highlighted in this picture.