
# FLASHPOINT



EPLESU100

**SU100** ADDITIONAL FLASH FOR ZOOM LION X PRO

#### Name of Parts




- 1. Flash Tube
- 2. Detaching Pusher

## Installing/Detaching SU-1


### Installing:

Align the detachable sub flash SU-1 with the external flash interface of V1 Pro and insert it parallelly, then press it down, a "click" sound means it's properly installed.



#### Detaching

Push the detaching pusher on SU-1 and pull it up at the same time to detach it.



Please turn off the V1 Pro series flashes before Installing and detaching SU-1. Do not insert in or pull out SU-1 when the V1 Pro series flashes are in power on status or working, otherwise malfunctions may occur.

### Using the Detachable Sub Flash SU-1

Align the SU-1 with the external flash interface of V1 Pro series camera flash and insert it parallelly, then press it down, a "click" sound means it's properly installed. Then press the function button 1 < MODEL > to set the flash to M (manual) flash/TTL auto flash

mode, then press function button 4 < SUB > to enter sub flash settings interface, and press function button 3 < ON/OFF > to turn on/off it.

When the sub flash is turned on, turn the select dial can adjust flash output of the sub flash from 1/128 to 1/1 in 22 flash steps, with +1/3 increment each step.



- SU-1 is not useable in wireless transmission shooting.
- SU-1 is not useable in high-speed sync.
- The flash head need to be uplifted in order to use SU-1 properly.
- The above using instructions are for detachable sub flash SU-1 only, V1 Pro series camera flashes are sold separately.

#### **FCC Statement**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved

by the party responsible for compliance could void the user's authority to operate the equipment. Note: This equipment has been tested and found to

comply with the limits for a Class B digital device. pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the

- interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and
- receiver Connect the equipment into an outlet on a circuit
- different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## One Year Flashpoint Limited Warranty

Flashpoint warrants to the original purchaser that your Flashpoint product shall be free from defects in material and workmanship for the period of one (1) years from the date of purchase (or delivery as may be required in certain jurisdictions), or thirty (30) days after replacement, whichever comes later. Flashpoint's entire liability and your exclusive remedy for any breach of warranty shall be, at Flashpoint's option, to repair or replace the hardware, provided that the hardware is returned to the point of purchase or such other place as Flashpoint may direct with a copy of the sales receipt or dated itemized receipt. Flashpoint may, at its option, replace your product. offer to provide a functionally equivalent product. or repair any product with new, refurbished or used parts as long as such parts are in compliance with the product's technical specifications. Any replacement hardware product will be warranted for the remainder of the original warranty period or thirty (30) days, whichever is longer, or for any additional period of time that may be applicable in your jurisdiction. If the product has been discontinued, the warranty provider reserves the right to replace it with a model of equivalent quality and function.

This warranty does not cover problems or damage resulting from accident, abuse, misapplication, or any unauthorized repair, modification or disassembly, improper operation or maintenance, normal wear and tear, or usage not in accordance with product instructions or connection to improper voltage supply, use of consumables, such as replacement batteries, not supplied by Flashpoint, except where

such restriction is prohibited by applicable law. Except where prohibited by applicable law, this warranty is nontransferable and is limited to the original purchaser and the country in which the product was purchased. This warranty gives you specific legal rights, and you may also have other rights, including a longer warranty duration that may vary under local laws. To start a warranty claim contact the Flashpoint Customer Service Department to obtain a return merchandise authorization ("RMA") number, and return the defective product to Flashpoint, along with the RMA number and proof of purchase.

#### Question about our product line? Need Product Support?

We are proud of our products and celebrate our customers. We are with you, from product selection to everyday use. Be secure with your purchase and reach us as you need.

**1** 212-647-9300

Flashpoint, 42 West 18th

42 West 18th Street, New York, NY 10011

You can always contact us at BRANDS@ADORAMA.COM for personal technical support. Our website contains a wide range of Support and FAQ pages with valuable technical assistance.

Flashpoint is a registered trademark of ADORAMA CAMERA.
© 2024 Adorama Camera, Corp.

All Rights Reserved.