

FLASHPOINT



FPLSLTL


LAPTOP TRAY

Thank You for choosing **FLASHPOINT**.

The Flashpoint Laptop Tray adds a sturdy 18 × 16-inch platform to any photo or video setup. It's ideal for adding a laptop to your rig, and it keeps your computer nearby for convenient tethering and playback.

Sturdy aluminum construction provides you with a solid and flat surface that won't bend or buckle. Four mounting options are integrated into the design, so this platform is compatible with tripods, light stands, arca-type ball heads, and accessory bars.

Product Overview



Arca Base

Use the arca base to mount the platform onto a ballhead or tripod head with an arca-type clamp.

3/8-16 Socket

Use this socket to attach the platform to a light stand with a 3/8-16 top stud, or a tripod head.

5/8 in. Receiver

Use this socket to mount the platform on any lighting accessory with a 5/8-inch baby pin, such as a light stand or C-stand.

1/4-20 Socket

Use this socket to mount the platform onto a tripod or a leveling base with a 1/4-20 stud.

One Year Flashpoint Limited Warranty

Flashpoint warrants to the original purchaser that your Flashpoint product shall be free from defects in material and workmanship for the period of one (1) year from the date of purchase (or delivery as may be required in certain jurisdictions), or thirty (30) days after replacement, whichever comes later.

Flashpoint's entire liability and your exclusive remedy for any breach of warranty shall be, at Flashpoint's option, to repair or replace the hardware, provided that the hardware is returned to the point of purchase or such other place as Flashpoint may direct with a copy of the sales receipt or dated itemized receipt. Flashpoint may, at its option, replace your product, offer to provide a functionally equivalent product, or repair any product with new, refurbished or used parts as long as such parts are in compliance with the product's technical specifications. Any replacement hardware product will be warranted for the remainder of the original warranty period or thirty (30) days, whichever is longer, or for any additional period of time that may be applicable in your jurisdiction. If the product has been discontinued, the warranty provider reserves the right to replace it with a model of equivalent quality and function.

This warranty does not cover problems or damage resulting from accident, abuse, misapplication, or any unauthorized repair, modification or disassembly, improper operation or maintenance, normal wear and tear, or usage not in accordance with product instructions or connection to improper voltage supply, use of consumables, such as replacement batteries, not supplied by Flashpoint, except where such restriction is prohibited by applicable law.

Except where prohibited by applicable law, this warranty is nontransferable and is limited to the original purchaser and the country in which the product was purchased.

This warranty gives you specific legal rights, and you may also have other rights, including a longer warranty duration that may vary under local laws.

To start a warranty claim contact the Flashpoint Customer Service Department to obtain a return merchandise authorization (“RMA”) number, and return the defective product to Flashpoint, along with the RMA number and proof of purchase.



Scan to follow our official instagram

Question about our product line? Need Product Support?

We are proud of our products and celebrate our customers. We are with you, from product selection to everyday use. Be secure with your purchase and reach us as you need.

📞 212-647-9300

✉ support@flashpointlighting.com

📍 Flashpoint,
42 West 18th Street,
New York, NY 10011

You can always contact us at BRANDS@ADORAMA.COM for personal technical support. Our website contains a wide range of Support and FAQ pages with valuable technical assistance.

Flashpoint is a registered trademark of ADORAMA CAMERA.

© 2023 Adorama Camera, Corp.

All Rights Reserved.