

FP FLASHPOINT

Steel Wheeled
Pistol Stand

FPLSRBPG

Thank you for choosing this Flashpoint Steel Wheeled Pistol Stand!

Before proceeding to assemble this stand, please check that all components are present. This kit should include one chrome-plated steel shaft, one sliding pistol arm, one base with folding legs, three caster wheels, one carry bag, and one Allen key.

This stand is designed for holding photo lights or other equipment with up to 22 lb (9.9 kg) of weight and offers a fast height adjustment using a pistol arm. If your stand arrives fully disassembled, assemble the base first by inserting the caster wheels into the sockets of the legs of the base. They should stay securely in place. Release the legs and extend them until they lock in extended position. Insert the grip onto the shaft and insert the shaft into the base. Make sure the shaft is stable in a vertical position. In an assembled configuration, this stand should enable you to lift your payload up to 6.5' (1.98 m) high. Before attaching anything to the arm, it is advisable to lock the wheel brakes to prevent unwanted rolling of the stand on the floor.

The sliding pistol support arm allows you to change the height quickly by simply squeezing the spring-loaded trigger lever and moving the arm up or down on the vertical shaft. As soon as you release this trigger lever, the arm firmly clamps to the shaft at a given height. It can also rotate around the shaft (in the unlocked state) for pointing your device in different directions. For adapter compatibility with your lights or other accessories, the arm has a removable pin with a 5/8" stud on one end a 1/4"-20 stud on another end. If needed, the up-down orientation of this pin can be reversed and clamped down with a twist lock. Once your equipment is securely attached to the pistol arm, you can release the breaks on the wheels and cart the entire assembly offering horizontally.

When you need to store or transport the stand, the base's legs can be folded up and secured, while the central column can be pulled out and removed from the base.

Specifications

Max Load	22.0 lb / 10.0 kg
Max Height	6.5' / 2.0 m
Shaft Diameter	1.4' / 3.5 cm
Weight	18.0 lb / 8.2 kg

Warnings

- Do not disassemble components
- Do not attempt to repair broken parts
- Use caution and care
- Keep the children away from the stand
- It is advisable to use parts and accessories recommended by manufacturer
- Do not exceed maximum load capacity
- Only use as directed

One Year Flashpoint Limited Warranty

Flashpoint warrants to the original purchaser that your Flashpoint product shall be free from defects in material and workmanship for the period of one (1) year from the date of purchase (or delivery as may be required in certain jurisdictions), or thirty (30) days after replacement, whichever comes later.

Flashpoint's entire liability and your exclusive remedy for any breach of warranty shall be, at Flashpoint's option, to repair or replace the hardware, provided that the hardware is returned to the point of purchase or such other place as Flashpoint may direct with a copy of the sales receipt or dated itemized receipt. Flashpoint may, at its option, replace your product, offer to provide a functionally equivalent product, or repair any product with new, refurbished or used parts as long as such parts are in compliance with the product's technical specifications. Any replacement hardware product will be warranted for the remainder of the original warranty period or thirty (30) days, whichever is longer, or for any additional period of time that may be applicable in your jurisdiction. If the product has been discontinued, the warranty provider reserves the right to replace it with a model of equivalent quality and function.

This warranty does not cover problems or damage resulting from accident, abuse, misapplication, or any unauthorized repair, modification or disassembly, improper operation or maintenance, normal wear and tear, or usage not in accordance with product instructions or connection to improper voltage supply, use of consumables, such as replacement batteries, not supplied by Flashpoint, except where such restriction is prohibited by applicable law.

Except where prohibited by applicable law, this warranty is nontransferable and is limited to the original purchaser and the country in which the product was purchased. This warranty gives you specific legal rights, and you may also have other rights, including a longer warranty duration that may vary under local laws.

To start a warranty claim contact the Flashpoint Customer Service Department to obtain a return merchandise authorization ("RMA") number, and return the defective product to Flashpoint, along with the RMA number and proof of purchase.

Question About Our Product Line? Need Product Support?

We are proud of our products and celebrate our customers. We are with you, from product selection to everyday use. Be secure with your purchase and reach us as you need.

Email us: brands@adorama.com

Call: 212-647-9300

Address: Adorama Brands, 42 West 18th Street, New York, NY 10011

You can always contact us at BRANDS@ADORAMA.COM for personal technical support. Our web site contains a wide range of Support and FAQ pages with valuable technical assistance.

Flashpoint is a registered trademark of ADORAMA CAMERA.

© 2019 Adorama Camera, Corp. All Rights Reserved.