

FLASHPOINT



FPLTSAT

LAPTOP STAND

AND ACCESSORY TRAY

Foreword

Amazing!

You now have the low-tech solution for high-tech excellence with the **Flashpoint Laptop Stand and Accessory Tray**; the digital studio bane stay! Keep the essential mobile laptop and mouse near the imaging device for tethering, monitoring, wireless capture, or just for show (watch that latest episode of *As The Stomach Turns*). Combining a laptop stand with a mouse/accessory plate makes camera support proximity a smooth union.

The low gravity support is reliable, versatile, and stable for a portable computer or related imaging gear weighing up to 45 pounds.

Not only is the Laptop Stand at home in the imaging department, but cozy. With live audio or studio music production, video production, grave lectures, lively classrooms, and virtually any venue where a laptop or portable device needs to be secure and close at hand.

The stand's exceptionally sturdy construction and wide-diameter tubing provide strength and stability. The telescoping column shaft can be adjusted between 29 and 47 inches. Carefully designed ergonomic locking knobs secure the stand for use in the studio or near a set. The accessory tray is designed with lipped edges for additional security from unintentional drops.

The tri-stand base spread can be adjusted to fit your space requirements. And easily folds up for positioning wherever you need to use the mobile laptop or associated device.

Features

- Designed Laptop and Mouse Platform with a protective edge.
- Free positioning column mounting bracket.
- Shaft support bracket assembly.
- Variable height telescoping shaft to accommodate set situations.
- Platform angle adjustment locking knob for customization.
- Height adjustment locking knob.
- Tripod base spread adjustment locking knob.
- Thick tripod legs and column elements for strong stance.
- Rubber feet protect the floor.

Notes

There is not a whole lot of “Heads Up” we can give you for using this product.

You already probably know not to club others with the closed stand or sail the sharp-edged trays at unsuspecting individuals. Not lovely, OddJobs.

But, we would be amiss if we did not forewarn you to keep heavy objects off the computer laptop support. [Commonly called Maximum Load Capacity]

Also, watch those fingers! Don’t get them pinched or clipped by nasty telescoping tubes or sliding joints! Good business for ERs and Band-Aids, but not so cool for our customers.

Gravity is still king. Secure your valuables to the stand’s post, edge, or column, just in case. Take heed of the connecting cords to avoid dragging the delicate attached gear earthward.

Guide



1. Platform
2. Platform Mounting Bracket
4. Shaft Support Bracket
5. Telescoping Shaft
6. Height Adjustment Locking Knob
7. Tripod Base Adjustment Locking Knob

8. Tripod Legs
9. Rubber Feet
10. Carriage Bolt
11. Washer
12. Platform Angle Adjustment Locking Knob

Build it! Assembling the Laptop Stand



1. Set up the Laptop Stand by loosening the tripod base adjustment locking knob counterclockwise.

Fully extend the legs and securely tighten the locking knob, as the lightstands are open to supporting gear. Place the open stand with spread legs on a flat surface, preferably on the floor.



2. Slide the mounting bracket of the Laptop Platform into the slot of the support bracket on the top of the shaft.

Slide it all the way to the end of the slot until the bolt holes are visible.



3. Slide the carriage bolt into the square-shaped hole until the cap of the bolt is flush with the mounting bracket.



4. Place the washer on the end of the bolt and screw on the locking knob.





The height of the Laptop Stand is user adjustable. Twist counterclockwise to loosen and clockwise to tighten.
[Lefty loosie. Righty tighty]



When you hit the right spot, fix the platform adjustment knob and slip in the cotter lock pin.

The Laptop computer is an excellent tool while tethering with cables or wirelessly to an imaging device. In any case, take heed of the connecting cords to avoid dragging the delicate attached gear earthward. Use our helpful securing tools for a safe experience.

The Mouse Platform Level



The exact sequence is used for the mouse platform.



Embellish the area to your liking for comfortable and accurate mousing.

Specifications

Model	FPLTSAT
Height	29 to 47 in / 74 to 119 cm
Weight	11 lb / 5 kg
Platform size	12.25 X 17 in / 31 X 43 cm
Base spread	26 in / 66 cm
Weight capacity	45 lb / 20.4 kg
Mouse Tray	
Dimension	11.8 x 7.8 in / 30 x 20 cm
Clamp Spacing Width	1.3 in / 3.2 cm
Weight	2.3 lb / 1 kg

One Year Flashpoint Limited Warranty

Flashpoint warrants to the original purchaser that your Flashpoint product shall be free from defects in material and workmanship for the period of one (1) year from the date of purchase (or delivery as may be required in certain jurisdictions), or thirty (30) days after replacement, whichever comes later.

Flashpoint’s entire liability and your exclusive remedy for any breach of warranty shall be, at Flashpoint’s option, to repair or replace the hardware, provided that the hardware is returned to the point of purchase or such other place as Flashpoint may direct with a copy of the sales receipt or dated itemized receipt. Flashpoint may, at its option, replace your product, offer to provide a functionally equivalent product, or repair any product with new, refurbished or used parts as long as such parts are in compliance with the product’s technical specifications.

Any replacement hardware product will be warranted for the remainder of the original warranty period or thirty (30) days, whichever is longer, or for any additional period of time that may be applicable in your jurisdiction. If the product has been discontinued, the warranty provider reserves the right to replace it with a model of equivalent quality and function.

This warranty does not cover problems or damage resulting from accident, abuse, misapplication, or any unauthorized repair, modification or disassembly, improper operation or maintenance, normal wear and tear, or usage not in accordance with product instructions or connection to improper voltage supply, use of consumables, such as replacement batteries, not supplied by Flashpoint, except where such restriction is prohibited by applicable law.

Except where prohibited by applicable law, this warranty is nontransferable and is limited to the original purchaser and the country in which the product was purchased. This warranty gives you specific legal rights, and you may also have other rights, including a longer warranty duration that may vary under local laws.


To start a warranty claim contact the Flashpoint Customer Service Department to obtain a return merchandise authorization (“RMA”) number, and return the defective product to Flashpoint, along with the RMA number and proof of purchase.

Question about our product line? Need Product Support?

We are proud of our products and celebrate our customers.
We are with you, from product selection to everyday use.
Be secure with your purchase and reach us as you need.

 212-647-9300

 support@flashpointlighting.com



 Flashpoint,
42 West 18th Street,
New York, NY 10011

You can always contact us at SUPPORT@FLASHPOINTLIGHTING.COM
for personal technical support. Our website contains a wide range of
Support and FAQ pages with valuable technical assistance.

Flashpoint is a registered trademark of ADORAMA CAMERA.

© 2022 Adorama Camera, Corp.

All Rights Reserved.



FLASHPOINTLIGHTING

Scan to follow our
official instagram

WWW.FLASHPOINTLIGHTING.COM