PFLASHPOINT

eVOLV 200 Multi Battery Charger

FPPPEV200MBC

Thank You for Choosing Flashpoint!

Before using this product please read this user manual carefully in order to ensure your safety and the proper operation of this product. Keep for future reference.

By choosing The EV200-MB-6 multiple battery charger. It supports to charge multiple batteries at the same time.

Please observe all warnings and cautions stated below:

Do not use in rain or in humid conditions.

Do not disassemble. Should repairs become necessary, this product must be sent to an authorized maintenance center.

Keep out of reach of children.

Disconnect the power supply when not in use

- When EV200-MB-6 connected, the red power indicator light will be light up. When battery mounted in the charger, the green charging indicator light will continue blink until it is fully charged.
- 2) When battery is charging, press the maintenance button, the charger will automatically power off when battery level reach 60%.
- 3) Battery level indication



Charge battery to 0-25%, the first green indicator light continue to blink.



Charge battery to 26%-50%, the first green indicator light being on and the second light continue to blink.



Charge battery to 51%-80%, the first two green indicator light being on and the third light continue to blink.



Charge battery to 81%-99%, the first three green indicator light being on and the fourth light continue to blink.



Charge full to 100%, all lights being on.

Technical Data

Model	EV200-MB-6
Applications	eVOLV200 Series
Rated Input Voltage	AC110V/220V
Input Voltage	AC100-240V
Rated Output Voltage	DC16.8
Output Voltage	DC10-1 6.8V
Applicable Batteries	14.8V Li-ion Battery
Working Temperature/Humidity	-10 ~ +40°C/<+90%
Charging Current	1.1A± 0.11A
Dimension	340×120×34mm
Net Weight	750g

One Year Flashpoint Limited Warranty

Flashpoint warrants to the original purchaser that your Flashpoint Multi Battery Charger shall be free from defects in material and workmanship for the period of one (2) year from the date of purchase (or delivery as may be required in certain jurisdictions), or thirty (30) days after replacement, whichever comes later. Flashpoint's entire liability and your exclusive remedy for any breach of warranty shall be, at Flashpoint's option, to repair or replace the hardware, provided that the hardware is returned to the point of purchase or such other place as Flashpoint may direct with a copy of the sales receipt or dated itemized receipt. Flashpoint may, at its option. replace your product, offer to provide a functionally equivalent product, or repair any product with new, refurbished or used parts as long as such parts are in compliance with the product's technical specifications. Any replacement hardware product will be warranted for the remainder of the original warranty period or thirty (30) days, whichever is longer, or for any additional period of time that may be applicable in your jurisdiction. If the product has been discontinued, the warranty provider reserves the right to replace it with a model of equivalent quality and function. This warranty does not cover problems or damage resulting from accident, abuse. misapplication, or any unauthorized repair, modification or disassembly, improper operation or maintenance, normal wear and tear, or usage not in accordance with product instructions or connection to improper voltage supply, use of consumables, such as replacement batteries, not supplied by Flashpoint, except where such restriction is prohibited by applicable law. Except where prohibited by applicable law, this warranty is nontransferable and is limited to the original purchaser and the country in which the product was purchased. This warranty gives you specific legal rights, and you may also have other rights, including a longer warranty duration that may vary under local laws. To start a warranty claim contact the Flashpoint Customer Service Department to obtain a return merchandise authorization ("RMA") number, and return the defective product to Flashpoint, along with the RMA number and proof of purchase.

Question about our product line? Need Product Support?

We are proud of our products and celebrate our customers. We are with you, from product selection to everyday use. Be secure with your purchase and reach us as you need.

Email us: brands@adorama.com

Call: 212-647-9300

Address: Adorama Brands, 42 West 18th Street, New York, NY 10011

You can always contact us at BRANDS@ADORAMA.COM for personal technical support. Our web site contains a wide range of Support and FAQ pages with valuable technical assistance.

Flashpoint is a registered trademark of ADORAMA CAMERA. © 2019 Adorama Camera, Corp. All Rights Reserved.