



# Quick Start Guide



## Z1200VC CTD-Soft

Vari-Color LED Panel Light

**1** Getting Started

**2** Functions

## What's in the box?



Z1200VC CTD-Soft



Controller



Offset Mounting Plate



\*AC Adapter with Cable  
(for Studio Pack or Rental Kit)




\*Battery Plate  
(for Location Pack or Rental Kit)

## 1 Getting Started

### 1 Mount

Offset mounting plate w/ baby receiver (16mm)




### 2 Power

Two power options

- ① AC adapter (for Studio Pack or Rental Kit)
- ② V-mount Li-ion battery (for Location Pack or Rental Kit)

### 3 Let's do this!

Turn the light ON



## 2 Functions

### 1 Mode Selection | <MENU> & <↑> <↓>

Start in the main menu interface.

From other interface pages press <MENU> to return to the main menu.

Select Mode: Press <↑> <↓> to move the cursor to select the mode or setting menu.

Enter Mode: Press <MENU> to enter the selected mode or setting interface.

### 2 Adjusting Parameters | <Adjustment Knob> & <↑> <↓>

Enter a lighting mode or setting interface first:

Select: Press <↑> <↓> to move the cursor to the parameter of choice.

Adjust: Turn top <Adjustment Knob> to quickly or bottom <Adjustment Knob> to slowly adjust the selected parameter.



### 3 Presets | <MODE> + <1~4> & <1~4>

Four scene presets can be saved independently in each mode. Please enter one of the lighting mode operation interfaces first:

Save: To save the light parameters in the current mode to a preset, press and hold <SAVE> and press one of the preset number buttons <1> <2> <3> <4>.

Recall: To recall a saved preset in the current mode, press one of the saved preset number buttons <1> <2> <3> <4>.

