



HIGLOW ILLUMINATED  
WHITE BACKGROUND

6' x 7'

# Foreword

## Thank you for choosing **Glow!**

Angler's HiKey illuminated background is ideal for shooting high-key lighting images like portraits, fashion, and products. It features a flexible frame that springs open, and easy-to-install frame supports which hold the background upright and free standing. The background offers four zippered openings so you can insert your lights for maximum coverage on either side. Use the background like a large softbox with evenly spread light across the surface.

## Precautions

- Please read and follow these instructions, and keep this manual in a safe place.
- Keep this product away from water and any flammable gases and liquids.
- Handle this product with care.
- Use only parts provided by the manufacturer.
- Make sure this item is intact and that no parts are missing.
- All images are for illustrative purposes only.

## Contents


- HiKey illuminated background
- Frame supports (x4) / Spare (x1)
- Carry bag

# Assembling the HiKey

1. Lay the background flat on the ground. Pull back the frame support's clip and hook it under the frame, and repeat for the other side. Attach a frame support to each of the four corners.



2. Position the background in landscape or portrait orientation.



3. For extra stability, move the bottom two frame supports so they come in contact with the ground.



4. Position lights inside both sides of the HiKey.

**Warning:** Make sure to use reflectors with your lights to avoid damaging the fabric.



## Folding the Background

1. Remove all four frame supports.
2. Grip the frame on either side of one corner, and point the corner down into the opposite corner on the ground.
3. Twist your hand outward while the corner folds inwards towards your feet. Lean forward and drop both sides onto the section that's on the floor.
4. Reshape to fit in the carry bag.



## Adding Color Backgrounds

You can add colored backgrounds for different lighting hues and effects by attaching them to the touch fastener strips located around the frame.



### Specifications

Dimensions (H x W x D)	84.5 x 70 x 18 in. (2.1 x 1.8 x 0.4 m)
------------------------	--

Weight	10.6 lb. (4.8 kg)
--------	-------------------



Scan to join our Instagram community for product tips, inspirations, and more.

# One Year Glow Limited Warranty

Glow warrants to the original purchaser that your Glow product shall be free from defects in material and workmanship for the period of one (1) year from the date of purchase (or delivery as may be required in certain jurisdictions), or thirty (30) days after replacement, whichever comes later.

Glow's entire liability, and your exclusive remedy for any breach of warranty shall be, at Glow's option, to repair or replace the hardware, provided that the hardware is returned to the point of purchase or such other place as Glow may direct with a copy of the sales receipt or dated itemized receipt. Glow may, at its option, replace your product, offer to provide a functionally equivalent product, or repair any product with new, refurbished or used parts as long as such parts comply with the product's technical specifications. Any replacement hardware product will be warranted for the remainder of the original warranty period or thirty (30) days, whichever is longer, or for any additional period that may be applicable in your jurisdiction. If the product has been discontinued, the warranty provider reserves the right to replace it with a model of equivalent quality and function.

This warranty does not cover problems or damage resulting from accident, abuse, misapplication, or any unauthorized repair, modification or disassembly, improper operation or maintenance, normal wear and tear, or usage not in accordance with product instructions or connection to improper voltage supply, use of consumables, such as replacement batteries, not supplied by Glow, except where such restriction is prohibited by applicable law.

Except where prohibited by applicable law, this warranty is nontransferable and is limited to the original purchaser and the country in which the product was purchased. This warranty gives you specific legal rights, and you may also have other rights, including a longer warranty duration that may vary under local laws.

To start a warranty claim contact the Glow Customer Service Department to obtain a return merchandise authorization ("RMA") number, and return the defective product to Glow, along with the RMA number and proof of purchase.

## Question about our product line? Need Product Support?

We are proud of our products and celebrate our customers. We are with you, from product selection to everyday use. Be secure with your purchase and reach us as you need.

☎ 212-647-9300

✉ [brands@adorama.com](mailto:brands@adorama.com)

📍 Adorama Brands,  
42 West 18th Street,  
New York, NY 10011

You can always contact us at [BRANDS@ADORAMA.COM](mailto:BRANDS@ADORAMA.COM) for personal technical support. Our website contains a wide range of Support and FAQ pages with valuable technical assistance.

GLOW is a registered trademark of ADORAMA CAMERA.

© 2024 Adorama Camera, Corp.

All Rights Reserved.