



EZ LOCK QUICK SOFTBOX

GLSBEZ1024/GLSBEZ1256/GLSBEZ1648/
GLSBEZ2436/GLSBEZ2839/GLSBEZ3147/
GLSBEZ1236



The Glow EZ Lock QUICK SOFTBOX takes the EZ Lock feature concept to the traditional lightbank design and scores! The rectangular shape features flattering, soft and rich color lighting with all the great advantages of plume softbox quality with an unbeatable safe and sure EZ positive and lock system. No more clumsy construction, fumbling with flex resistant rods or struggling in frustration for careful alignment of speedring holes. The 4-ribbed softbox opens up and closes down, 'umbrella style.' The self-catch EZ Lock surrounds a thick center shaft, providing a comfortable place for your fingers to push-lock the mechanism open, and a generous release to close the softbox painlessly. The quick-to-setup umbrella-like assembly has all the advantages of a metallic magnum style reflector without the delicate nature. This collapsible unit was borne for the road or studio, with sturdy aluminum support rods for structural stability and extraordinary fabric strength.

The various editions of the Quick Softbox are suitable for everything from fashion to portraiture, illuminating an entire person and small groups with smooth, nonetheless, exciting light. The softbox rectangular shape streams all the light in one controllable direction. With much attention to minutia in its tough build, from resilient form-fitting fabric to flexible aluminum frame ribs, this GLOW EZ LOCK QUICK SOFTBOX sets the standard for portable light control for people and subjects.

Glow EZ Lock.

The FastPath To Light. For Studio, Location, or Home.

Included Items

- Glow EZ Lock Quick Softbox
- External Diffuser
- Internal Diffuser
- Eggcrate Grid
- Bowens Mount Speedring Adapter
- Reversible Deflection Cap Disk
- Storage Bag

Precautions


- Please study this guide and store for future reference.
- The materials used in this product are not waterproof or flame resistant. Care must be taken to avoid damage.
- Attach strobes with modeling lamps following the recommended bulb wattage limits.
- Store in a cool and dry environment.
- The EZ Lock Quick Softbox and diffusers can be hand cleaned with cold water and mild detergent. Air dry.
- Handle this Quick Softbox with care when opening and closing. Be especially diligent when closing, to hold onto the Parabolic Softbox. The EZ Lock mechanism releases with force.
- Make sure the unit is intact, and there are no missing parts.
- All photos used in the manual represent all EZ Lock Quick Softbox varieties and are for illustrative purposes only.

EZ Lock Setup Instructions

1. Remove the EZ Lock Quick Softbox from the carrying case.
2. Rest the back of the Quick Softbox, the Bowens speedring, on a flat surface and gently spread out the aluminum rods that support the silvered fabric material.
3. Grasp the aluminum EZ Lock mechanism that is suspended, above the center cage hub.



4. Press down on the EZ Lock ring to slide it down to mate with the hub of the rod spokes, until it is firmly seated. The EZ Lock automatically latches in, pressed against the center post of the hub.



5. The EZ Lock Quick Softbox is now fully opened and correctly constructed. You can now attach the assembled softbox directly on a Bowens mount flash like any other modifier or replace the adapter to match the strobe of choice from the wide variety of Glow speedrings. Always follow the strobe's instructions for installing a modifier.




Optional Steps

6. **Attach the deflector plate cap.** This step must be accomplished after the Quick Softbox is assembled and EZ Locked. The softest effect is reached with the plate in position. The plate is reversible to achieve a variety of properties.
 - A. Hold the disk concave profile up to control the center hotspot and spread the light about the softbox. By reversing the deflector disk and changing the position of placement on the shaft, the light spread is customizable.




- B. Screw in the hub extension rod onto the center hub.



- C. Place the deflector Plate on the extension and screw in the retaining bolt on the center shaft.



- D. The light bounces off the inner curved deflector plate and flood the walls of the outer bowl of the Quick Softbox, resulting in a broad spread of softer indirect light. You can flip the deflector plate convex side out, creating an alternate light distribution.



- E. For ease of access to the Deflector Plate after the Quick Softbox is complete or in use, a zippered slit opens to reveal the assembly. Now, you can change the orientation or remove it completely. Close the zipper to keep the light in the softbox.



7. **Attach the inner diffuser.** The inner layer can be used with or without the deflector cap. The more diffusion, the less dramatic the Quick Softbox wrap. The fabric snaps onto the interior elastic tabs that are on each rod spoke.



8. **Attach the outer diffuser.** Join the outer diffusion fabric to the Velcro strips that line the inner perimeter of the softbox. Again, the deflector cap, as well as the inner diffuser, can be used together to maximize the softness of the flash.

- A. Unfold the diffusion material and align the diffuser's corners with the outside junctions of the opened Quick Softbox.



- B. Press the strips firmly to seal off light leaks.

9. **Attach the Eggcrate Grid.** The grid attaches using the Velcro touch sensitive strips running along the inside edge of the bowl.

- A. Align the shape carefully to match the perimeter shape for the strongest feathering.



- B. Press the surfaces firmly to seal the grid for spill control and drama.

10. Closer 'er up!

- A. Remove any diffusers that are attached.
- B. Reach into the center of the hub and hold onto the EZ Lock knob on the center hub.



- C. Lift the center EZ Lock hub while holding the softbox firmly. The EZ Lock mechanism is released, and the structure relaxes.
- D. Complete the closure by bringing the spokes and sections together, as if closing an umbrella. Bind the closed softbox with the Velcro strap, slip the bundle into the zippered case and call it a day.

Specifications

Materials	Reinforced Fabric, Aluminum Rods, Aluminum Ring		
Finish	Silver interior, black matte exterior, custom trim		
Mount	Glow / Bowens		
Sections	4		

Specifications	Dimensions	Weight	Dimensions Closed
10 x 24"	10 x 24 x 13.25 in / 25.4 x 61 x 33.6 cm	1lb 1.5oz / 496g	17 x 6.25 in / 43.2 x 15.9 cm
24 x 36"	24 x 36 x 19 in / 61 x 91.4 x 48.3 cm	1lb 11.9oz / 792g	26.5 x 6.25 in / 67.3 x 15.9 cm
28 x 39"	28 x 39 x 21 in / 71.1 x 99 x 53.3 cm	2lb 4.8oz / 1.44kg	31 x 6.25 in / 78.7 x 15.9 cm
31 x 47"	31 x 47 x 23 in / 71.1 x 99 x 53.3 cm	2lb 15.6 oz / 1.35kg	37 x 6.25 in / 78.7 x 15.9 cm
16 x 48"	16 x 48 x 25 in / 40.5 x 122 x 63.5 cm	2lb 8.2 oz / 1.14 kg	36 x 6.25 in / 91.5 x 15.9 cm
12 x 56"	12 x 56 x 26 in / 30.5 x 142 x 66 cm	2lb 10.1 oz / 1.19kg	38 x 6.25 in / 96.5 x 15.9 cm

No accessories are included in the weights or measurements.

Two Year Glow Limited Warranty

Glow warrants to the original purchaser that your Glow product shall be free from defects in material and workmanship for the period of two (2) years from the date of purchase (or delivery as may be required in certain jurisdictions), or thirty (30) days after replacement, whichever comes later.

Glow's entire liability and your exclusive remedy for any breach of warranty shall be, at Glow's option, to repair or replace the hardware, provided that the hardware be returned to the point of purchase or such other place as Glow may direct with a copy of the sales receipt or dated itemized receipt. Glow may, at its option, replace your product, offer to provide a functionally equivalent product, or repair any product with new, refurbished or used parts as long as such parts comply with the product's technical specifications. Any replacement hardware product will be warranted for the remainder of the original warranty period or thirty (30) days, whichever is longer, or for any additional period that may be applicable in your jurisdiction. If the product has been discontinued, the warranty provider reserves the right to replace it with a model of equivalent quality and function.

This warranty does not cover problems or damage resulting from accident, abuse, misapplication, or any unauthorized repair, modification or disassembly, improper operation or maintenance, normal wear and tear, or usage not in accordance with product instructions or connection to improper voltage supply, use of consumables, such as replacement batteries, not supplied by Glow, except where such restriction is prohibited by applicable law.

Except where prohibited by applicable law, this warranty is nontransferable and is limited to the original purchaser and the country in which the product was purchased. This warranty gives you specific legal rights, and you may also have other rights, including a longer warranty duration that may vary under local laws.

To start a warranty claim contact the Glow Customer Service Department to obtain a return merchandise authorization ("RMA") number, and return the defective product to Glow, along with the RMA number and proof of purchase.

Question about our product line? Need Product Support?

We are proud of our products and celebrate our customers. We are with you, from product selection to everyday use. Be secure with your purchase and reach us as you need.

Email us: brands@adorama.com

Call: 212-647-9300

Address: Adorama Brands, 42 West 18th Street, New York, NY 10011

You can always contact us at BRANDS@ADORAMA.COM for personal technical support. Our web site contains a wide range of Support and FAQ pages with valuable technical assistance.

GLOW is a registered trademark of ADORAMA CAMERA.
© 2020 Adorama Camera, Corp. All Rights Reserved.