

GLOW ONE YEAR LIMITED USA WARRANTY

Glow warrants to the original purchaser that your Glow product shall be free from defects in material and workmanship for the period of two (2) years from the date of purchase (or delivery as may be required in certain jurisdictions), or thirty (30) days after replacement, whichever comes later.

Glow's entire liability and your exclusive remedy for any breach of warranty shall be, at Glow's option, to repair or replace the hardware, provided that the hardware be returned to the point of purchase or such other place as Glow may direct with a copy of the sales receipt or dated itemized receipt. Glow may, at its option, replace your product, offer to provide a functionally equivalent product, or repair any product with new, refurbished or used parts as long as such parts comply with the product's technical specifications. Any replacement hardware product will be warranted for the remainder of the original warranty period or thirty (30) days, whichever is longer, or for any additional period that may be applicable in your jurisdiction. If the product has been discontinued, the warranty provider reserves the right to replace it with a model of equivalent quality and function.

This warranty does not cover problems or damage resulting from accident, abuse, misapplication, or any unauthorized repair, modification or disassembly, improper operation or maintenance, normal wear and tear, or usage not in accordance with product instructions or connection to improper voltage supply, use of consumables, such as replacement batteries, not supplied by Glow, except where such restriction is prohibited by applicable law. Except where prohibited by applicable law, this warranty is nontransferable and is limited to the original purchaser and the country in which the product was purchased. This warranty gives you specific legal rights, and you may also have other rights, including a longer warranty duration that may vary under local laws.

To start a warranty claim contact the Glow Customer Service Department to obtain a return merchandise authorization ("RMA") number, and return the defective product to Glow, along with the RMA number and proof of purchase.

Question about our product line? Need Product Support?

We are proud of our products and celebrate our customers. We are with you, from product selection to everyday use. Be secure with your purchase and reach us as you need.

Email us: brands@adorama.com

Call: 212-647-9300

Address: Adorama Brands, 42 West 18th Street, New York, NY 10011

You can always contact us at BRANDS@ADORAMA.COM for personal technical support. Our website contains a wide range of Support and FAQ pages with valuable technical assistance.

GLOW is a registered trademark of ADORAMA CAMERA.

© 2019 Adorama Camera, Corp. All Rights Reserved.



EZ Lock Octa Quick Softbox Guide



Introduction

Glow EZ Lock Octa Quick Softbox sports a dynamic eight-sided deep parabolic shape featuring flattering, soft and rich color lighting with all the great advantages of the softbox/umbrella quality with an unbeatable safe and sure EZ positive and lock system. No more clumsy construction, fumbling with flex resistant rods or struggling in frustration for careful alignment of speedring holes. The 8-ribbed softbox opens up and closes down, 'umbrella style.' The self-catch EZ Lock surrounds a thick center shaft, providing a comfortable place for your fingers to push-lock the mechanism open, and a generously sized release to close the softbox painlessly. The quick-to-setup umbrella-like assembly has all the advantages of a metallic magnum style reflector without the delicate nature. This collapsible unit was borne for the road or studio, with sturdy aluminum support rods for structural stability and extraordinary fabric strength.

The Glow EZ Lock Octa Quick Softbox sets the standard for portable light control for people and subjects.

Precautions

- Please study this guide and store for future reference.
- The materials used in this product are not waterproof or flame resistant. Care must be taken to avoid damage.
- Attach strobes with modeling lamps following the recommended bulb wattage limits.
- Store in a cool and dry environment.
- The EZ Lock Octa Quick Softbox and diffusers can be hand cleaned with cold water and mild detergent. Air dry.
- Handle this Octa Quick Softbox with care when opening and closing. Be especially diligent when closing, to hold onto the Softbox. The EZ Lock mechanism releases with force.
- Make sure the unit is intact, and there are no missing parts.
- All photos in the manual cover all EZ Lock Octa Quick Softbox varieties and are for illustrative purposes only.

INCLUDES:


- Glow EZ Lock Octa Quick Softbox
- Internal Diffuser
- Reversible Deflector Disk
- Bowens Mount Speedring Adapter (insert Size **130mm**)
- External Diffuser
- Eggcrate Grid
- Storage Bag

Setup Instructions

1. Remove the EZ Lock Octa Quick Softbox from the carrying case.
2. Rest the back of the Octa Quick Softbox, the Bowens speedring, on a flat surface and gently spread out the aluminum rods that support the silvered fabric material.
3. Grasp the aluminum EZ Lock mechanism that is suspended above the center cage hub.
4. Press down on the EZ Lock ring to slide it down to mate with the hub of the rod spokes, until it seats firmly. The EZ Lock automatically latches in, pressed against the center post of the hub.
5. The Octa Quick Softbox is now fully opened and correctly constructed. Unzip the slit on the side of the softbox, reach inside, and grasp the speedring insert and the softbox firmly. Align the mount to mate with your flash and lock into place according to the flash manufacturer's instructions, or replace the adapter to match the strobe of choice from the wide variety of Glow 130mm speedring inserts.

Optional Steps

6. Attach the deflector disc. This step must be accomplished after the Octa Quick Softbox is assembled and EZ Locked. The softest effect is reached with the disk in position. The disk is reversible to achieve a variety of properties.
 - A. Hold the disk concave profile up to control the center hotspot and spread the light about the softbox. By reversing the deflector disk and changing the position of placement on the shaft, the light spread is customizable.
 - B. Screw in the hub extension rod onto the center hub.
 - C. Place the deflector disk on the extension and screw in the retaining bolt on the center shaft.
 - D. The light bounces off the inner curved deflector disk and flood the walls of the outer bowl of the Octa Quick Softbox, resulting in a broad spread of softer indirect light.



Optional Steps

You can flip the deflector disk convex side out, creating an alternate light distribution.



- E. For ease of access to the Deflector Disk after the Octa Quick Softbox is complete or in use, a zippered slit opens to reveal the assembly. Now, you can change the orientation or remove it completely. Close the zipper to keep the light in the softbox.



7. **Attach the inner diffuser.** The inner layer can be used with or without the deflector disk. The more diffusion, the less dramatic the Octa Quick Softbox wrap. The fabric snaps onto the interior elastic tabs that are on each rod spoke.



8. **Attach the outer diffuser.** Join the outer diffusion fabric to the Velcro strips that line the inner perimeter of the softbox. Again, the deflector disk, as well as the inner diffuser, can be used together to maximize the softness of the flash.




- A. Unfold the diffusion material and align the diffuser's corners with the outside junctions of the opened Octa Quick Softbox.
- B. Press the strips firmly to seal off light leaks.



Optional Steps

9. **Attach the Eggcrate Grid.** The grid attaches using the Velcro touch sensitive strips running along the inside edge of the bowl.

- Align the shape carefully to match the perimeter shape for the strongest feathering.
- Press the surfaces firmly to seal the grid for spill control and drama.



10. **Close'r up!**

- Remove any diffusers that are attached.
- Reach into the center of the hub and hold onto the EZ Lock knob.
- Press the wide side button into the center while holding the softbox firmly. The EZ Lock mechanism is released, and the structure relaxes.
- Complete the closure by bringing the spokes and sections together, as if closing an umbrella. Bind the closed softbox with the Velcro strap, slip the bundle into the zippered case and call it a day.




Optional Beauty Dish Adapter Insert Ring

Speedring Mount Adapter Insert

The EZ Lock octa quick softbox includes an installed 130mm Bowens mount insert for use on Bowens mount strobes.

To change the insert ring to fit onto a different flash mount:

- Stretch the fabric in the rear of the softbox to reveal one of the tab screws.
- Unscrew that one entirely and set it aside. You only need to loosen the two adjoining screws enough for the insert to slip out of the tabs.
- Remove it and replace the insert with your mount version.
- Put to removed screw back into place and tighten all the screws.



SPECIFICATIONS

Materials	Reinforced Fabric, Aluminum Rods, Aluminum Ring			
Finish	Silver interior, black matte exterior, custom trim			
Mount	Interchangeable Bowens speedring supplied (Insert Size 130mm)			
Sections	8			
Removable Front Diffuser	Yes			
Removable Interior Baffle	Yes			
Accepts Grids	Yes (included)			
Speedring	130mm insert			

Specifications	GLSBEZ25OCTA	GLSBEZ36OCTA	GLSBEZ48OCTA	GLSBEZ60OCTA
Diameter open	25" / 63.5cm	36" / 91.5cm	48" / 120cm	60" / 152cm
Depth open	11.75" / 30cm	19.25" / 49cm	24" / 61cm	26" / 66cm
Weight	1lb 3.5oz / 552kg	2lb 1.5oz / 952kg	3lb 8oz / 1.736kg	3lb 14.2oz / 1.75kg
Dimensions closed	15x6" / 38x15.3cm	25x6" / 63.5x15.3cm	31x5" / 80x15.3cm	36x6" / 91.4x15.3cm

No accessories are included in the weights or measurements