



KHRONOS

KHRONOS iPhone 17 Pro / 17 Pro Max
Mobile Imaging Accessory-User Guide

KHRONOS 适用于iPhone 17 Pro / 17 Pro Max
手机影像配件-使用指南

Disclaimer

Thank you for purchasing TILTA products.

Before using this product, please carefully read this document to ensure that the product has been set up correctly. The final interpretation of this document and all related documents for this product belongs to TILTA. For updates, please visit the official website at www.tilta.com for the latest product information.

TILTA reserves the right to modify any information in this manual at any time without prior notice and without assuming any responsibility.

By using this product, you are deemed to have carefully read the disclaimer and warnings, understood, agreed, and accepted all the terms and content of this statement. You promise to take full responsibility for the use of this product and any consequences that may arise.

You commit to using this product only for legitimate purposes and agree to these terms as well as any related regulations, policies, and guidelines set by TILTA.

TILTA is not responsible for any damages, injuries, or legal liabilities caused directly or indirectly by the use of this product. Users should follow all safety guidelines mentioned in this document, including but not limited to those mentioned.


Despite the above provisions, consumer rights are still protected by local laws and regulations and are not affected by this disclaimer.

Precautions

Prior to using this product, please carefully follow the instructions provided. TILTA shall not be held liable for any consequences arising from improper operation, misuse, or failure to comply with these instructions.

- Keep away from sharp objects to prevent surface scratches and marks.
- Minimize contact with water and chemicals (such as perfume or cleaners), and wipe dry immediately after exposure.
- Store the device in a dry environment, with an ideal storage humidity not exceeding 40%.
- In high-temperature environments, monitor the device temperature to avoid prolonged heavy load operation.
- Do not subject the device or its accessories to strong impacts or vibrations to prevent damage and device malfunction.
- Do not charge the device near flammable or combustible materials (such as carpets or wooden products). Always monitor the charging process to prevent accidents.

Phone Case Packing List



Khronos iPhone 17 Pro Case ×1




Khronos Multi-Functional Magnetic Backplate for iPhone 17 Pro ×1



Screen Protector for iPhone 17 Pro ×1




Screen Cleaning Kit ×1



Khronos Universal Phone Lanyard ×1

User Guide ×1



Khronos iPhone 17 Pro Max Case ×1




Khronos Multi-Functional Magnetic Backplate for iPhone 17 Pro Max ×1



Screen Protector for iPhone 17 Pro Max ×1



Screen Cleaning Kit ×1



Khronos Universal Phone Lanyard ×1


User Guide ×1

Product Specifications

Khronos iPhone 17 Pro Case	Materials	Aluminum + Plastic + Silicone
	Dimensions	158.8×79.6×16mm (6.25×3.13×0.63in)
	Weights	56.5g (1.99oz) (Case) 119.5g (4.22oz) (Case+ Multi-Functional Magnetic Backplate)
	Colors	Space Gray/Black/Orange/Beige
Khronos iPhone 17 Pro Max Case	Materials	Aluminum + Plastic + Silicone
	Dimensions	172.2×85.7×16.2mm (6.78×3.37×0.64in)
	Weights	62.5g (2.20oz) (Case) 130.9g (4.62oz) (Case+ Multi-Functional Magnetic Backplate)
	Colors	Space Gray/Black/Orange/Beige
Khronos Multi-Functional Magnetic Backplate for iPhone 17 Pro	Materials	Aluminum + PC + Stainless Steel
	Dimensions	92×61.8×5.4mm (3.62×2.43×0.21in)
	Weight	63g (2.22oz)
	Colors	Space Gray/Black/Orange/Beige
Khronos Multi-Functional Magnetic Backplate for iPhone 17 Pro Max	Materials	Aluminum + PC + Stainless Steel
	Dimensions	101.7×61.8×5.4mm (4×2.43×0.21in)
	Weight	68.4g (2.41oz)
	Colors	Space Gray/Black/Orange/Beige

Khronos iPhone 17 Pro Case


Overview



Front and Side View

01 Top Cover
02 Backplate Safety Slot
03 Case Unlock Button
04 Electronic Contact Points

05 Phone Power Button
06 Camera Control Bar
07 Quick-Release Mounting Points
08 Lanyard / Strap Port



Back and Side View


09 Filter / Lens Frame

11 Phone Button Access

10 Cooling System
Locating Points

Khronos iPhone 17 Pro Max Case


Overview



Front and Side View

01 Top Cover
02 Backplate Safety Slot
03 Case Unlock Button
04 Electronic Contact Points

05 Phone Power Button
06 Camera Control Bar
07 Quick-Release Mounting Points
08 Lanyard / Strap Port



Back and Side View


09 Filter / Lens Frame

11 Phone Button Access


10 Cooling System
Locating Points

Unlocking the Phone Case


(1) Slide the unlock button to unlock the phone case.



(2) Push the top cover at both ends in the unlocking direction, applying force to the pressure zones (as shown in the figure below). Continue until you hear a “click”, indicating the phone case is unlocked.




(3) Detach the top and bottom covers.




Assembly

- (1) Align the phone with the lens frame inside the inner case, and place it into the case.
- (2) Align the mounting points and securely snap the top cover into place.




(3) Check and gently press down the top cover to ensure it fits closely with the bottom case, making it easier to lock securely.

(4) At the same time, push the top cover at both ends in the locking direction, applying force to the pressure zones (as shown in the figure below, with the phone horizontal). Continue until you hear a “click”, indicating the phone case is securely locked.




(5) Slide the unlock button to secure the phone case.



Khronos Multi-Functional Magnetic Backplate


Parts Overview



- | | |
|--------------------------|-------------------------------|
| 01 Flat Head Screwdriver | 04 Double Sided Magnetic Ring |
| 02 Collapsible Kickstand | 05 Ring Support |
| 03 Lanyard / Strap Port | 06 Box Cutter Release Button |

Functions


1. Using the collapsible phone kickstand.




2. Using the box cutter.

Slide and hold the release button to extend the box cutter.

Release the button to retract it.




3. Using the magnetic ring stand.




Assembly



(1) Using the backplate for iPhone 17 Pro as an example: first, attach the backplate magnetically to the back of the phone ①, then push the backplate upward ② to lock it into the safety slot of the phone case.






(2) The assembly is complete.



The backplate and ring stand can be attached directly to phones with MagSafe or a magnetic ring.



Installing the Screen Protector



NOTE:

The Khronos iPhone 17 Pro / 17 Pro Max cases only support tempered glass screen protectors with a thickness of up to 0.7mm, or the included tempered glass.

免责声明

感谢您购买TILTA的产品。

使用本产品前,请仔细阅读本文以确保已对产品进行正确的设置。本文档及本产品所有相关的文档最终解释权归TILTA所有。如有更新,请访问www.tilta.com官方网站获取最新的产品信息。

TILTA保留随时修改本手册中任何信息的权利,无需提前通知且不承担任何责任。

一旦使用本产品,即视为您已经仔细阅读免责声明、注意事项与警告,理解、认可和接受本声明全部条款和内容。您承诺对使用本产品以及可能带来的后果负全部责任。您承诺仅出于正当目的使用本产品,并且同意本条款以及TILTA制定的任何相关条例、政策和指引。

TILTA对于直接或间接使用本产品而造成的损坏、伤害以及任何法律责任不予负责。用户应遵循包括但不限于本文提及的所有安全指引。


即使存在上述规定,消费者权益依然受当地法律法规所保障,并不受本免责声明影响。

注意事项

使用本产品前,请严格遵守以下说明,如因失误操作或者不正当使用等造成的相关后果,TILTA不负任何责任。

- 远离尖锐物品,防止表面划伤留痕。
- 减少接触水、化学制剂(如香水、清洁剂),接触后及时擦干。
- 高温环境下注意设备温度,避免长时间高负荷运行。
- 请勿将充电设备放置在易燃、可燃物(如地毯和木制品)附近充电。请时刻留意充电过程,谨防发生意外。
- 请在干燥的环境下存储设备,理想的设备存储环境湿度不高于40%RH。
- 请勿使设备及其配件受到强烈的冲击或震动,以免损坏设备及其配件,导致设备故障。

手机壳配置清单




适用于iPhone 17 Pro 专用手机壳 ×1



适用于iPhone 17 Pro 磁吸多功能背板 ×1



适用于iPhone 17 Pro 钢化膜 ×1
屏幕清洁工具包 ×1



专用手机壳通用挂绳 ×1
用户使用手册 ×1




适用于iPhone 17 Pro Max 专用手机壳 ×1



适用于iPhone 17 Pro Max 磁吸多功能背板 ×1



适用于iPhone 17 Pro Max 钢化膜 ×1
屏幕清洁工具包 ×1




专用手机壳通用挂绳 ×1
用户使用手册 ×1

产品参数

KHRONOS 适用于 iPhone 17 Pro 专用手机壳	材质 尺寸 重量 颜色	铝合金+塑胶+硅胶 158.8×79.6×16mm 56.5g(单手机壳) 119.5g(手机壳+背板) 深空灰/黑色/ 星壤橙/落陨灰
KHRONOS 适用于 iPhone 17 Pro Max 专用手机壳	材质 尺寸 重量 颜色	铝合金+塑胶+硅胶 172.2×85.7×16.2mm 62.5g(单手机壳) 130.9g(手机壳+背板) 深空灰/黑色/ 星壤橙/落陨灰
KHRONOS 适用于 iPhone 17 Pro 磁吸多功能背板	材质 尺寸 重量 颜色	铝合金+PC+不锈钢 92×61.8×5.4mm 63g 深空灰/黑色/ 星壤橙/落陨灰
KHRONOS 适用于 iPhone 17 Pro Max 磁吸多功能背板	材质 尺寸 重量 颜色	铝合金+PC+不锈钢 101.7×61.8×5.4mm 68.4g 深空灰/黑色/ 星壤橙/落陨灰


适用于 iPhone 17 Pro 专用手机壳

部件介绍



正侧图

- | | |
|------------|------------|
| 01 上盖 | 05 手机电源按键 |
| 02 背板安全槽 | 06 相机触控按键 |
| 03 手机壳防脱按键 | 07 配件快拆接口 |
| 04 电子触点 | 08 挂绳孔/肩带孔 |



背侧图


09 滤镜/镜头卡口限位槽

11 手机按键

10 散热器定位孔


适用于 iPhone 17 Pro Max 专用手机壳

部件介绍



正侧图

- | | |
|------------|------------|
| 01 上盖 | 05 手机电源按键 |
| 02 背板安全槽 | 06 相机触控按键 |
| 03 手机壳防脱按键 | 07 配件快拆接口 |
| 04 电子触点 | 08 挂绳孔/肩带孔 |



背侧图


09 滤镜/镜头卡口限位槽

11 手机按键


10 散热器定位孔

解锁手机壳


(1) 解锁手机壳防脱按键。



(2) 往解锁方向推动上盖上下两端的受力区解锁(如下图,灰色填充区域为受力区),直至听到“咔哒”声,解锁手机壳。




(3) 解锁后拆分手机壳上盖与下壳。



安装手机到手机壳中

- (1) 将手机对准手机壳内壳的镜头框，放置到内壳中。
- (2) 上盖卡扣对准下壳安装孔，合上上盖。




(3) 检查并轻轻按压上盖,使上盖更贴合下壳,便于锁紧。

(4) 同时,往锁紧方向推动上盖上下两端的受力区锁紧(如下图,以手机横屏方向展示,灰色填充区域为受力区),直至听到“咔哒”声,即锁紧手机壳。




(5) 锁紧防脱按键加固锁紧手机壳。




磁吸多功能背板

部件介绍



适用于iPhone 17 Pro



适用于iPhone 17 Pro Max

01 一字螺丝刀

02 折叠支架

03 挂绳孔


04 双面磁吸圈

05 指环支架

06 拆箱刀解锁键

功能介绍


1. 切换为手机折叠支架




2.切换为拆箱刀

推动解锁键不放： 使用小刀。

松开按键： 自动收回小刀。




3.切换为磁吸解压指环支架




安装介绍



(1) 以适用于iPhone 17 Pro 手机壳的背板为例，将背板磁吸到手机背面①后，向上推动背板②嵌入手机壳的背板安全槽中。




(2) 完成。




背板和指环可直接磁吸到带MagSafe或磁圈的手机上。




安装钢化膜




使用清洁工具包清洁手机屏幕。



撕下保护膜,将钢化膜对准屏幕边缘慢慢放下。



手指轻按中间位置,使钢化膜吸附于屏幕上。



用手指或刮片轻松挤掉剩余微小气泡,再撕下钢化膜背膜完成。



注意：

适用于iPhone 17 Pro/iPhone 17 Pro Max 手机壳仅支持使用0.7mm厚度内的钢化膜或配备的钢化膜。

Warranty / 保修说明

Dear Valued Customer: Thank you for choosing TILTA products. Please keep your warranty card safe for future repairs or service requests.

敬爱的用户：感谢您选择TILTA的产品，请保存好您的保修卡，以便维修或需时提供。

Product SKU / 产品型号：

Product Name / 产品名称：

Warranty Terms / 保修条款：

- The warranty covers electronic accessories for 1 year and mechanical parts for 2 years (excluding damage caused by human error).
- 本产品机械部件及电子附件保修期为一年(人为损坏除外)。
- Damage caused by human error, self-disassembly, removal of seals, improper use, any external damage, or repairs and modifications conducted at unauthorized service centers are not covered under warranty.
- 一切人为损坏、自行拆机、拆封标、使用不当等一切外表的损坏及在非TILTA官方授权维修认定点进行维修，改造等造成的损坏，不在保修范围内。



Scan the code to enter WeChat
mini programs

扫码进入微信小程序



Scan the QR code to enter
Tilta website

扫码进入官网

For more operational instructions, please scan the QR code in the image and enter the relevant product model to access the electronic version of the user manual.

更多操作说明请扫描图中二维码，输入相关产品型号，获取产品电子版说明书。

Manufacturer : Shenzhen Tilta Technology Co. Ltd.

Address (China) : 1st and 2nd Floor, Building B,
Qiaode High Technology Park, No.7 Road,
Guangming New Dist, Shenzhen, 518125

Address (United States) : 1901 W Magnolia Blvd,
Burbank, CA 91506

Address (Germany) : Lise-Meitner-Allee 13.
Bochum, North Rhine-Westphalia 44801

Address (United kingdom) : Room 3, Unit 11,
Woodland Business Park, Ystradgynlais, Swansea
SA9 1JW

Official website : <https://tilta.com/>
<https://eu.tilta.com/>
<https://tilta.uk/>

制 造 商：深圳市铁头科技有限公司

地 址：深圳市光明区玉塘街道田寮社区光明高新
园西区七号侨德科技园厂房B栋一层、二层

服务热线：4006 1998 67