
Assembly Manual



All rights reserved.

No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photo-copying, recording, or otherwise, except as may be expressly permitted by the applicable copyright statutes or in writing by the Publisher.

What's In The Box

Please inspect the contents of your shipped package to ensure you have received everything that is listed below.



Doorway Platform Dolly



Handle

Steering Handle



2 x Wheel Tracks



4 x Pneumatic Wheels



4 x T-Type Allen Key
(Size: 10mm,6mm,5mm,4mm)



Adapter with
4 x Button Heads



17mm & 13mm
Spanners



1 x L-Type Allen Key
(Size: 4mm)

Spin Lightweight Doorway Platform Dolly Setup

Pneumatic Wheels Assembly

- Use a 5mm Allen key to loosen and remove the CSK bolt from the wheel axle.



- Attach the pneumatic wheel to the axle and reinsert the CSK bolt.



- Next, Tighten the bolt securely using the 5mm Allen key.
- The wheel is now properly attached.



- Repeat the same process to attach the remaining wheels.

Feature: The pneumatic 11" wheels absorb shocks, ensuring a smooth ride across various surfaces.



Steering Handle Assembly

- Loosen and remove the knob from the rear wheel steering.



- Insert the steering handle into place.
- Align the holes of the steering handle and knob.



- Insert the knob and tighten it securely to lock the handle in place.
- The steering handle is now properly attached.

Feature: The steering bar tilts down 270° for added convenience for the dolly grip.



Steering Bar Tilts down 270°



4-Wheel & 2-Wheel Steering Modes



ROUND:

Front and rear wheels rotate independently with mechanical compensation to allow variable radius turns.



REAR (CONVENTIONAL):

Front wheels are locked, rear wheels can rotate 360°.

Handle Assembly

- Start by loosening the knobs on located on each side of the dolly.
- Then, Insert the handle into the dolly's handle slot.



- After inserting the handle, re-tighten the knobs to secure the handle in place firmly.



NOTE: Handles can be installed on either side of the dolly as needed.



Switchable Steering & Push-Pull Bars



Adapter Mounting

NOTE: Use the adapter when not using the steering handle

- Use a 4mm Allen key to loosen and remove the Button Head from the adapter.



- Secure the adapter to the handle, then reinsert the button head.



- Tighten it using the 4mm Allen key.
- The adapter is now securely attached.



- Now, insert the steering handle into the adapter.



- Loosen and remove the knob of the rear wheel steering.



- Now, Insert the steering handle into the place.
- Align the holes of the knob and handle, and re-insert the knob



- Tighten the knob to secure the steering handle in place.
- The steering handle is now properly attached.



Track Wheel Assembly

- Loosen & remove the knob located at the bottom center of the dolly.



- Use a 4mm Allen key to loosen the bolts on the plate at the bottom, as shown in the image.



- Slide the track wheel into place and secure it by reinserting the knob and tightening it.



- Next, Re-tighten all plate bolts with the 4mm Allen key.



- Repeat the same process to attach the second track wheel.
- After both wheels are securely attached, mount the dolly onto the track **(Not included)**.



Bazooka Mounting

- Use a 6mm Allen key to loosen & remove all the Allen bolts for the Euro mounting on the dolly, then remove them.



- Mount the Euro Plate (**Not Included**) onto the dolly.
- Re-insert the Allen bolts, aligning them with the holes on the Euro Plate.



- Now tighten all bolts using a 6mm Allen key.
- The Euro plate is now securely mounted.

Feature: The Euro/Elemac mounts onto the platform, allowing you to attach a variety of Elemac accessories.



25mm Holes for Seat Post & Euro Mount



- Mount the Bazooka (**Not included**) onto the Euro Plate (**Not included**) and tighten the knob on top of the lever inside the Bazooka.



- Lock the Bazooka in place using the lever.
- The Bazooka is now securely mounted on the dolly.



Height Riser Mounting

- Mount the Height Riser (**Not Included**) onto the bazooka.
- Secure the riser by tightening the ratchet knob firmly.



Fluid Head Mounting

- Mount the fluid head (Not Included) onto the height riser and insert the locking knob from the bottom to secure it.



- Once the fluid head is securely mounted, slide the camera into position, as shown in the image.



Shortening the length of Dolly

- Use a 5mm Allen key to loosen the bolt-on wheel axle and remove the wheel as shown in the image.



- Use a 10mm Allen key to loosen the Allen bolt on one side of the dolly's front section and remove it.
- Repeat the same process to remove the Allen bolt on the opposite side.



- Use a 6mm Allen key and a 17mm spanner to loosen the bolt and hex nut from the bottom side, then remove the steering rod.

NOTE: When the steering rod is removed, the handle will be mounted on only one side.



- Now, carefully de-attach the front section of the dolly.



- Now insert the wheel Axel on both side of dolly.



- Now attach the wheel to both sides of the dolly.
- Then insert the CSK bolt and tighten it using a 5mm Allen key.



- Your dolly's length is now properly shortened.



**YOUR PROAIM SPIN LIGHTWEIGHT DOORWAY PLATFORM DOLLY
ALL DRESSED UP AND READY TO GO!**



(SHOWN WITH OPTIONAL ACCESSORIES)

Warranty: We offer one year warranty for our products from date of purchase. Within this period of time, we will repair it without charge for labor or parts. Warranty doesn't cover transportation costs nor does it cover a product subjected to misuse or accidental damage. Warranty repairs are subjected to inspection and evaluation by us.

Liability: We are not liable for damage caused by products that we do not supply or from mishandling in transit, accident, misuse, neglect, lack of care of the product, or service by anyone other than our company.

Contact Us: In case of any kind of dissatisfaction, please Contact us immediately and we promise our utmost support and care until you use our product.