


Please note:

- Do not shine the LED directly at people's eyes at short distances. This can cause short-term vision issues. Use at distances of at least 1m from subject – or use a reflector/diffuser to soften the light.
- Do not place the LED close to alcohol or flammable objects.
- Do not place liquids on or near the LED. The product is not water, splash or dust resistant.
- Use a soft cloth and neutral cleaner to clean the LED light. Do not use strong cleaning agents or solvents such as thinners, gasoline or alcohol to clean the LED light.
- Do not store the LED at temperatures of +40C as high temperatures may damage the product components.
- Do not use the LED in outdoors in direct sunlight for an extended period of time to prevent the product from overheating and possible damage.



Features


The Phottix Nuada R3II LED is a powerful light source for still and video photography. It uses the latest in flicker-free LED technology, making it efficient and durable.

The Nuada R3 II features:

- Softlight design for 50W of flattering light
- Excellent color - CRI rating of 96+
- 2.4G remote control with 3 groups and 40 channels
- Digital Brightness and Temperature Control
- Battery and AC Power Modes
- Compact size – 12mm thick


Parts

- Battery Ports
- LCD Display
- Brightness Button
- Color Temperature Button
- Channel / Group Button (CH/Grp)
- Adjustment Dial
- AC Adapter Port
- Power / Battery / AC modes Switch
- Battery Release Button






Wireless Remote

- LCD
- Channel / Group button (CH/Grp)
- ON/OFF button
- + / - Adjustment Buttons
- Set Button



Mounting and Adjusting the Nuada R3II

- Use the Mounting Bracket to mount the Nuada R3II to a Light Stand or other mount. The Nuada R3II can be mounted horizontally or vertically.
- Ensure the Mounting Bracket Locking Nut is securely fastened.
- Loosen and tighten the Locking Nuts on the Mounting Bracket to adjust the Nuada R3II angle.



To use NP-style Batteries

- Align the battery with the Battery Port.
- Push the battery until locked into position.
- Move the Power / Battery / AC Modes Switch to the Battery position.

Please Note:

The Nuada R3II will operate with 2 pcs NP-F750 or NP-F960 batteries being used only.

Removing Batteries

Push the battery release button and remove battery from the battery chamber.

Using AC Power

- Connect the AC Adapter to the AC Adapter Port on the Nuada R3II.
- Plug the other end of the AC Adapter into mains power.
- Move the Power / Battery / AC Modes Switch to the AC position.

Power OFF Nuada R3II

Move the Power / Battery / AC Modes Switch to the Center position.

The LCD Display On the Nuada R3II LCD Display

- Brightness displayed from 01-100%.
- Color Temperature is displayed from 3200K-5600K.
- Channel (CH) from 01-40
- Group A/B/C
- The estimated remaining battery power is indicated by the battery icon.

Adjusting Brightness and Temperature

- Press the Brightness button and turn the Adjustment Dial to adjust output from 01–100%.
- Press the Color temperature button and turn the Adjustment Dial to adjust color temperature from 3200K-5600K.

Setting the Group on the Nuada R3II

- Press the Channel Button (CH/Grp) on Nuada R3II.
- Use the Adjustment Dial to set the group between A/B/C.

Setting the Wireless Channel on the Nuada R3II

- Press the Channel Button (CH/Grp) twice on Nuada R3II.
- Use the Adjustment Dial to set the Channel from 01-40.

Please note:

The Channel and Group on the Remote and Nuada R3II needs to be the same for the remote to control the Nuada R3II.

Using the Remote Control

The Phottix Nuada R3II comes with wireless remote control. Using this remote, Nuada R3II can be controlled from up to 50m away.

Install Batteries on Remote control

- Slide out back side cover.
- Insert 2pcs AAA batteries.

Power ON/OFF the Remote control

Hold 1sec ON/OFF button on Remote Control to power ON/OFF the Remote Control.

Adjusting Brightness on Remote control

Press the + / - buttons to direct adjust output from 01–100%.

Adjusting Color Temperature on Remote control

- Press the Set button
- Press the + / - buttons to adjust color temperature from 3200K-5600K.
- Press the ON/OFF button to confirm and exit.

Remote ON/OFF Nuada R3II on Remote control

- Press ON/OFF button on Remote Control to remote ON/OFF the Nuada R3II.
- LCD will display OFF on both Nuada R3II and remote control when remote Nuada R3II to OFF.

Setting the Group on the Remote Control

- Press the CH/Grp Button to enter group setting.
- Using the + / - buttons to select the group between A/B/C.
- Press the ON/OFF button to confirm and exit.

Setting the Wireless Channel on the Remote Control

- Press the CH/Grp Button twice to enter channel setting.
- Set the Channel from 01-40 using the + / - buttons
- Press the ON/OFF button to confirm and exit.

Technical Specs

Nuada R3II LED

Color temperature	3200K - 5600K
Brightness range	01% - 100%
Max. brightness / illuminance	1400Lux @ 1m
Max.Power	50W @ full power
Color rendering index	CRI 96+ / TLCI 98+
AC/DC adaptor operation voltage:	100-240VAC
Battery operation	NP-F750 or NP-F960 battery x2
LED numbers	136 PCS Cool color 136 PCS Warm color
Dimension	430mm x 433mm x 32mm
Weight	2140g (not include battery)

Remote Control

Remote Control	40 channels 2.4G wireless remote control
Remote Control Range	<50m
Battery operation	AAA x 2

What's included

- Nuada R3II LED Panel • Remote control • AC Adapter
- UK plug • US plug • EU plug • SAA plug • Carrying Bag

Phottix®

Warranty Card


Phottix Warranty Card

Phottix offers warranty service and/or replacement that comply with local regulations. For full information see: phottix.com/warranty

Keep this card – do not lose.

安全須知

- 避免用本產品於近距離對人眼直接照射以避免短暫性影響視力。建議近距離使用時加上柔光罩
- 請勿將本產品存放在酒精或易燃物品附近，以免發生危險
- 請勿將本產品放置於液體附近，本產品沒有防水，防濺及防塵功能。
- 不要使用稀釋劑，酒精等有機溶劑來清潔產品表面，以免損壞外殼。
- 請勿將本產品存放在攝氏40度以上的地方，避免對內部元件造成損壞。
- 在戶外使用本產品時，請勿長時間在被陽光直射的環境下使用本產品，以免因過熱而造成損壞。




產品功能

Phottix Nuada R3II LED補光燈功率強大，優良光質，適用於攝影及攝錄。備有電池或電源適配器供電模式，LCD顯示，遙控功能，功率及色溫調校


部件

1. 電池倉
2. LCD 顯示屏
3. 亮度按鍵
4. 色溫按鍵
5. 頻道 /組別按鍵 (CH/Grp)
6. 調整轉輪
7. DC插座
8. 電源開關選擇
9. 電池固定鎖



無線遙控


1. LCD顯示屏
2. 頻道 /組別按鍵 (CH/Grp)
3. ON/OFF按鍵
4. +/- 調整鍵
5. 設定鍵 (SET)



產品安裝及使用

a. 產品安裝

1. 取出柔光燈，將固定座旋逆時針擰出 (圖 1)。
2. 將三腳架的固定杆插入到固定座的孔位內 (圖 2)。
3. 順時針擰緊固定座旋鈕，將柔光燈固定於三腳架上 (圖 3)。



b. 角度調節

1. 將柔光燈左右兩側的角度調節旋鈕逆時針擰鬆至燈面可以前後轉動
2. 將燈面調節至所需角度
3. 將左右兩側的角度調節旋鈕順時針擰緊

使用NP電池供電

1. 將兩顆索尼NP-F系列的電池卡入到電池倉內
 2. 將電池推進電池倉
 3. 將電源開關撥動到電池端，即可使用電池供電及開啟LED
- 註：本產品需安裝兩顆NP-F750或NP-F960電池才可以使用

移除電池

按下電池固定鎖並將電池推出

使用外接電源

1. 將外置電源轉接器插入電源插孔
2. 將電源轉接器另一端連接電源插頭
3. 將電源開關撥動到AC端，即可使用適配器供電及開啟LED

開機

在開機狀態下，將電源開關撥動到中間端開機

LCD顯示屏

Nuada R3II 顯示屏顯示

- 亮度顯示由01-100%
- 色溫顯示由3200K-5600K
- 頻道CH01-40
- 組別A/B/C
- 電池電量估計資訊

調整亮度及色溫

1. 按下亮度按鍵後轉動調整轉輪，調節亮度由01-100%
2. 按下色溫按鍵後轉動調整轉輪，調節色溫由3200K-5600K

在Nuada R3II上設置組別

1. 在Nuada R3II按下 頻道 /組別按鍵 (CH/Grp)
2. 轉動調整轉輪選擇組別A/B/C

在Nuada R3II上設置頻道

1. 在Nuada R3II按下 頻道 /組別按鍵 (CH/Grp) 兩次
2. 轉動調整轉輪選擇組別頻道01-40

註：Nuada R3II主機跟遙控器的頻道和組別必須一樣才可遙控

使用遙控器

本產品附有遙控器，可在50米以內遙控Nuada R3II

安裝遙控器電池

1. 拉出遙控器背部後蓋
2. 安裝兩個AAA電池

開關遙控器電源

長按遙控器上ON/OFF 按鍵1秒開啟或關閉遙控器電源

使用遙控器調節亮度

使用遙控器上的 +/-調整鍵 可直接遙控Nuada R3II亮度01-100%

使用遙控器調節色溫

1. 按下遙控器的 設定鍵 (SET)
2. 使用 +/-調整鍵直接可遙控Nuada R3II色溫3200K-5600K
3. 按下ON/OFF 按鍵 確認及退出

使用遙控器開關Nuada R3 II主機

1. 使用ON/OFF 按鍵可直接遙控Nuada R3II主機開關
2. Nuada R3II主機以及遙控器上的LCD 顯示屏會顯示OFF狀態

在遙控器上設置組別

1. 在遙控器按下 頻道 /組別按鍵 (CH/Grp)
2. 使用遙控器上的 +/-調整鍵 選擇設置組別A/B/C
3. 按下ON/OFF 按鍵確認及退出

在遙控器上設置頻道

1. 在遙控器按下 頻道 /組別按鍵 (CH/Grp) 兩次。
2. 使用遙控器上的 +/-調整鍵 選擇設置頻道01-40
3. 按下ON/OFF 按鍵 確認及退出

技術規格

Nuada R3II主機

色溫範圍	3200K - 5600K
調光範圍	01% - 100%
最大照度	1400Lux @ 1m
最大功率	50W
顯色指數 (CRI)	CRI 96+ / TLCI 98+
外置電源轉接器電源輸入	100-240VAC
電池種類	NP-F750 or NP-F960 x 2
LED 數量	136顆冷色 136顆暖色
產品尺寸	430mm x 433mm x 32mm
產品淨重	2140g

遙控器

頻道 /遙控	40頻道 2.4G 無線遙控
遙控距離	<50m
電池	AAA x 2

附件

- Nuada R3II 補光燈本體 • 遙控器 • 電源適配器 • 便攜袋
- 插頭(英規) • 插頭(美規) • 插頭(歐規) • 插頭(澳規)

Phottix®

保 修 卡

Phottix 保修卡

Phottix 將會按當地法規提供保修 / 更換服務。
詳情請查閱 Phottix 網站 phottix.com/warranty

請小心保存此卡，不要遺失