

Client	Adorama
Project No.	F230922AR01
Description	Slinger Manual-SLEDC55LC-V2

FormatManual

Print Colors	C 100%
	M 100%
	Y 100%
	K 100%

Non-Print Colors	Dieline
	Transparent
	Label


Note to Printer刀模线 标示线 勿印!

PDF仅供预览用, 实际印刷请使用AI档案  
PDF is for preview only, please use AI file for printing.

Us Office	St. Paul MN 55118 United States +1 651 278 1920
Canada Office	Toronto, ON, M2N 7G9, Canada +1 416 877 5157
Taiwan Studio	Tainan, Taiwan 700 +886 6 3556600

**Important:** Every effort has been made to ensure accuracy in our artwork, however, errors may still occur. Please review this file carefully. Client and his/her supplier(s) are responsible for reviewing all label contents: wordmarks, text, nutritional information, etc., and all technical aspects prior to production. Should any error be found subsequent to client and/or supplier approval, Fin Studio Co. Ltd. shall be responsible only for replacement of the artwork containing the error, and in addition shall not be held responsible for any consequent changes or losses incurred as a result of any error.

Size: 56×20 cm刀模线 标示线 勿印!



Specifications

Product Number	SLEDC35	SLEDC55	SLEDC90	SLEDC125	SLEDC195	SLEDC300	SLEDC600
Chamber Configuration							
Capacity (Liters)	35 Liters	55 Liters	90 Liters	125 Liters	195 Liters	300 Liters	600 Liters
Number of Zones	1	1	1	1	2	1	2
Number of Shelves	1	3	3	4	5	3	4
Shelf Material	Plastic	Plastic	Plastic	Plastic	Plastic	Metal	Metal
Power	<8 W	<8 W	<8 W	<15 W	<15 W	<15 W	<30 W
Lock Type	Combination Lock	Combination Lock	Combination Lock	Combination Lock	Combination Lock	Combination Lock	Combination Lock
External Power Requirement	110-240 V, 50/60 Hz	110-240 V, 50/60 Hz	110-240 V, 50/60 Hz	110-240 V, 50/60 Hz	110-240 V, 50/60 Hz	110-240 V, 50/60 Hz	110-240 V, 50/60 Hz
Input Voltage	5 VDC, 2A	5 VDC, 2A	5 VDC, 2A	5 VDC, 3A	5 VDC, 3A	5 VDC, 3A	5 VDC, 6A
Display Type	Digital LED	Digital LED	Digital LED	Digital LED	Digital LED	Digital LED	Digital LED
Number of Controllers	1	1	1	2	2	2	4
Relative Humidity (RH)	30-60 % (±3%)	30-60 % (±3%)	30-60 % (±3%)	30-60 % (±3%)	30-60 % (±3%)	30-60 % (±3%)	30-60 % (±3%)
Operation Mode	Automatic	Automatic	Automatic	Automatic	Automatic	Automatic	Automatic
Support	4 round feet, 2 have adjustable height	4 round feet, 2 have adjustable height	4 round feet, 2 have adjustable height	4 round feet, 2 have adjustable height	4 round feet, 2 have adjustable height	4 locking caster wheels	4 locking caster wheels
Dimensions	17.1 x 12.6 x 12.4" (43.5 x 32.0 x 31.5 cm)	24.4 x 12.6 x 12.4" (62.0 x 32.0 x 31.5 cm)	24.0 x 16.0 x 15.3" (60.9 x 40.6 x 38.9 cm)	35.2 x 16.1 x 15.4" (89.5 x 41.0 x 39.0 cm)	46.7 x 16.1 x 15.3" (118.5 x 41.0 x 39.0 cm)	37.8 x 33.5 x 17.2" (96.0 x 85.1 x 43.2 cm)	33.5 x 16.9 x 22.0" (85.1 x 43.0 x 183.0 cm)
Weight	15.6 lb 7.1 kg	22.3 lb 10.1 kg	34.2 lb 15.5 kg	43.0 lb 19.5 kg	55.1 lb 25.0 kg	84.9 lb 38.5 kg	158.7 lb 72.0 kg

We are excited to have you as a customer and hope that our product serves you well for years to come!

Slinger Limited 1-Year USA Warranty

Slinger warrants to the original purchaser that your Slinger product shall be free from defects in material and workmanship for the period of one (1) year from the date of purchase (or delivery as may be required in certain jurisdictions), or thirty (30) days after replacement, whichever comes later. Slinger's entire liability and your exclusive remedy for any breach of warranty shall be, at Slinger's option, to repair or replace the hardware, provided that the hardware is returned to the point of purchase or such other place as Slinger may direct with a copy of the sales receipt or dated itemized receipt. Slinger may, at its option, replace your product, offer to provide a functionally equivalent product, or repair any product with new, refurbished or used parts as long as such parts are in compliance with the product's technical specifications. Any replacement hardware product will be warranted for the remainder of the original warranty period or thirty (30) days, whichever is longer, or for any additional period of time that may be applicable in your jurisdiction. If the product has been discontinued, the warranty provider reserves the right to replace it with a model of equivalent quality and function. This warranty does not cover problems or damage resulting from accident, abuse, misapplication, or any unauthorized repair, modification or disassembly, improper operation or maintenance, normal wear and tear, or usage not in accordance with product instructions or connection to improper voltage supply, use of consumables, such as replacement batteries, not supplied by Slinger, except where such restriction is prohibited by applicable law. Except where prohibited by applicable law, this warranty is nontransferable and is limited to the original purchaser and the country in which the product was purchased. This warranty gives you specific legal rights, and you may also have other rights, including a longer warranty duration that may vary under local laws. To start a warranty claim contact the Slinger Customer Service Department to obtain a return merchandise authorization ("RMA") number, and return the defective product to Slinger, along with the RMA number and proof of purchase.

Question about our product line? Need Product Support?

We are proud of our products and celebrate our customers. We are with you, from product selection to everyday use. Be secure with your purchase and reach us as you need.

Email us: brands@adorama.com Call: 212-647-9300

Address: Adorama Brands, 42 West 18th Street, New York, NY 10011

You can always contact us at BRANDS@ADORAMA.COM for personal technical support. Our web site contains a wide range of support and FAQ pages with valuable technical assistance.

Slinger is a registered trademark of ADORAMA CAMERA.

© 2023 Adorama Camera, Corp. All Rights Reserved.

ELECTRONIC  
DRY CABINET



Front

Introduction

Thank you for choosing Slinger product! Our goal is to make your professional life easier and to maximize your effectiveness.


(!) The handle(s) may be attached to the interior surface of the door by default for safety during shipping. Unscrew it (them) using an appropriate screwdriver and reattach to the exterior surface of the door.

Features

- Energy-efficient, quiet, LED illuminated dry cabinet
- Thermoelectric (TE) dehumidification method
- For photo, video, audio, and other moisture-sensitive items
- Prevents damage due to humidity and extends the lifetime
- Protects from corrosion, deterioration, and growth of fungi
- Regulates internal relative humidity from 30 % to 60 %
- Height-adjustable shelves with foam padding
- Digital LED display(s) shows climate conditions: RH, T
- Easy-to-use three-button function control panel(s)
- Rubber-sealed, lockable glass door(s) with a handle(s)

Models SL-EDC-35LC - 195LC have height adjustment front feet  
Models SL-EDC-300LC - 600LC have casters

Schematic Diagram for Sliding Shelf Models



1. DC input port
2. Moisture sync(s)
3. Digital LED display
4. Removable shelf brackets
5. Removable shelf
6. Handle
7. Contoured foam padding for lenses
8. Flat foam padding
9. Three-button control pad


Operating Instructions

Using the Combination Lock

The cabinet comes with the default combination set to 000.

1. With the door closed, select the default combination, and turn the lock counterclockwise to unlock it.
2. To change the combination, insert the pin and lightly press it into the hole with one hand. Set the combination to the numbers of your choice with the other hand, and then remove the pin.
3. Turn the lock clockwise and scramble the numbers to lock the door.

**Important:** Keep a record of your combination, and keep it in a safe and accessible place.



Turning On

1. Plug the power supply into the wall outlet and connect it to the cabinet.
2. The digital (red-green) display should light up.
3. Short-press top [▲, F/C Set] button to turn **On** or **Off** internal illumination.

Changing Temperature Units between Fahrenheit (F°) and Centigrade (C°)

1. Long-press the top [▲, F/C Set] button to switch between Fahrenheit (F°) and Centigrade (C°).

Setting Inside Relative Humidity (RH) Level

1. Short-press twice the bottom [Set] button to start humidity setting mode.
2. Short-press the top [▲, F/C Set] or middle [▼, %RH] buttons repeatedly to reach the desired humidity level.
3. Press the bottom [Set] button again to set the desired humidity.
4. The cabinet will now start dehumidifying the chamber.

Back