Smith-Victor - WARRANTY -

Smith-Victor warrants to the first commercial owner to be free from defects in the material and workmanship for a period of one (1) year from the date of purchase and will repair or replace product found to be defective under normal use. Warranty does not cover damage caused by shipment, by product abuse, accident, modification, disassembly or use beyond intended use specified by Smith-Victor. The Umbrella Kits used with nonstandard Smith-Victor electrical accessories will render this warranty immediately void.

This warranty is the only warranty made to any person by Smith-Victor and is in lieu of all other expressed or implied warranties. The remedies set forth in this warranty shall be the exclusive remedies available to any person for breach of this warranty. Under no circumstances shall Smith-Victor be liable to any person for incidental or consequential damages, whether arising out of breach of warranty or other contract, negligence, strict liability or other tort or otherwise.

Smith-Victor • Photogenic • Dot Line Quantum • Radiopopper • Photoflex • Cool-Lux Speedotron • Norman • Logan

Smith-Victor is a division of PromarkBRANDS 1268 Humbracht Circle, Bartlett, IL 60103 U.S.A. 800-348-9862 or 630-830-9200

sales@smithvictor.com | www.smithvictor.com www.promarkbrands.com



KT750LED & KT1500LED Umbrella Kits

User Manual

Two LED Light Umbrella Kit

Model: KT750LED

Item: 401608

Four LED Light Dual Socket Umbrella Kit Model: KT1500LED

Item: 401609





Featuring

LED Bulb Model: 45LED

Item: 401900

Optional Accessory

Bluetooth LED Bulb Model: SmartLED50

Item: 401625



What's in the Box:



Model: KT750LED Item: 401608

Two LED Light Umbrella Kit



Kit includes: one Case; two Light Stands; two Umbrellas; two 45 watt LED bulbs and two Sockets.



Model: KT1500LED Item: 401609

Four LED Light Dual Socket Umbrella Kit



Kit includes: one Case; two Light Stands; two Umbrellas; four 45 watt LED bulbs and two Dual Sockets.

Set Up of the Kit Components

- Set up the light stands.
- Loosen the thumb screw of the stand mount on the back of the LED Socket Mount.
- Place the LED Bulb Socket onto the top of the stand upright and secure by tightening the thumb screw.
- Insert umbrella into the umbrella holder below the socket and open until it locks in place.
- Screw in the LED bulb(s), being careful to not cross thread the lamp with the socket.
- · Plug into outlet after all parts are assembled.
- To disassemble the unit, reverse the process described above.

WARNING:

- Do NOT plug the unit into an electric socket until the kit is fully assembled and LED bulbs are in place. Failure to observe this warning could result in electric shock, injury and even death.
- Appliance must only be used with rated voltage and frequency.
- Avoid unplugging the power by pulling the power cord.
- Do not touch the power cord with wet hands.
- Never attempt to insert any metal objects into the cooling holes of the lamp.
- Avoid moving the umbrella/stand by pulling the power cable.
- Discontinue use if the unit is damaged, especially the power cord and socket.
- Avoid exposure to moisture.
- Indoor use only.
- In the event service is needed, contact Smith-Victor.