











Access Reader Lite




1























B











2




Internet




UniFi Gateway Console



Switch



3





If you need further assistance, visit our [Help Center](#) or contact [Ubiquiti Support](#).

©2019-2021 Ubiquiti Inc. All rights reserved. Ubiquiti, Ubiquiti Networks, the Ubiquiti U logo, UniFi Access, and UniFi are trademarks or registered trademarks of Ubiquiti Inc. in the United States and in other countries. All other trademarks are the property of their respective owners.