



Apple Watch Ultra 2 Instructions

[Home](#) » [Apple](#) » Apple Watch Ultra 2 Instructions 

Contents

- [1 Apple Watch Ultra 2](#)
- [2 Product Usage Instructions](#)
- [3 Get Started](#)
- [4 Safety and Handling](#)
- [5 Battery and Charging](#)
- [6 FCC and ISED Canada Compliance for Apple Watch and Apple Watch Magnetic Charging Cable](#)
- [7 Apple One-Year Limited Warranty Summary](#)
- [8 Documents / Resources](#)
 - [8.1 References](#)
- [9 Related Posts](#)



Apple Watch Ultra 2



Apple Watch

Specifications

- **Operating System:** Apple Watch OS
- **Battery Type:** Lithium-ion
- **Wireless Connectivity:** Bluetooth, Wi-Fi
- Magnetic Charger Included

Product Usage Instructions

1. Getting Started

To turn on Apple Watch, press and hold the power button.

2. Charging

To charge Apple Watch, use the provided magnetic charger. Simply attach the charger to the back of the watch, and ensure it is properly aligned. Connect the charger to a power source.

3. Safety and Handling

Please refer to the Safety and Handling section in the Apple Watch User Guide for detailed information on how to handle and use Apple Watch safely. Note that Apple Watch, its operating systems, and the health sensors are not medical devices.

4. Exposure to Radio Frequency

To obtain radio frequency exposure information for Apple Watch, open the Apple Watch app on your iPhone. Tap “My Watch,” then go to “General,” “About,” “Legal,” and finally “RF Exposure.” Alternatively, you can visit apple.com/legal/rfexposure for more information.

5. Battery and Charging

The lithium-ion battery in Apple Watch should only be serviced or recycled by Apple or an authorized service provider. If you need battery service, you may receive a replacement Apple Watch. Remember to recycle or dispose of batteries separately from household waste. For more information about battery service and recycling, visit apple.com/batteries/service-and-recycling. Additionally, refer to the Important Safety Information section in the Apple Watch User Guide for information about charging.

6. Medical Device Interference

Apple Watch, certain bands, and Apple Watch magnetic charging accessories contain magnets that may interfere with medical devices. It is important to review the Important Safety Information section in the Apple Watch User Guide for further details.

7. Avoid Hearing Damage

To prevent possible hearing damage, avoid listening to Apple Watch at high volume levels for extended periods. For more information about sound and hearing, visit apple.com/sound. Detailed guidelines can also be found in the Important Safety Information section of the Apple Watch User Guide.

8. Regulatory

Regulatory certification information can be found on the device itself. Go to “Settings,” “General,” and “Regulatory” to access this information. Additional regulatory details are available in the Safety and Handling section of the Apple Watch User Guide.

9. FCC and ISCED Canada Compliance

Apple Watch and Apple Watch Magnetic Charging Cable comply with part 15 of the FCC Rules and ISCED Canada licence-exempt RSS standard(s). The operation is subject to two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

10. EU / UK Compliance

Apple Inc. declares that this wireless device is in compliance with Directive 2014/53/EU and Radio Equipment Regulations 2017. The Declaration of Conformity can be accessed at apple.com/euro/compliance. Apple’s representatives for the EU and UK are Apple Distribution International Ltd. and Apple UK Ltd., respectively

11. Disposal and Recycling Information

The symbol above indicates that according to local laws and regulations, the product and/or its battery should be disposed of separately from household waste. When the product reaches its end of life, take it to a designated collection point as specified by local authorities. Proper collection and recycling of the product and/or its battery will help conserve natural resources and protect human health and the environment. For more information about Apple’s recycling program, collection points, restricted substances, and environmental initiatives, visit apple.com/environment.

Frequently Asked Questions (FAQ)

• Q: Is Apple Watch a medical device?

A: No, Apple Watch is not a medical device. Please refer to the Safety and Handling section in the Apple Watch User Guide for more information.

• Q: How can I check the radio frequency exposure information for Apple Watch?

A: Open the Apple Watch app on your iPhone, tap “My Watch,” then go to “General,” “About,” “Legal,” and finally “RF Exposure.” Alternatively, you can visit apple.com/legal/rfexposure for more details.

- **Q: Can the magnets in Apple Watch interfere with medical devices?**



A: Yes, Apple Watch, certain bands, and Apple Watch magnetic charging accessories contain magnets that may interfere with medical devices. Review the Important Safety Information section in the Apple Watch User Guide for more details.

- **Q: How should I dispose of my Apple Watch and its battery?**

A: According to local laws and regulations, your Apple Watch and its battery should be disposed of separately from household waste. Take it to a designated collection point as specified by local authorities. For more information about Apple's recycling program and environmental initiatives, visit apple.com/environment.

Before using Apple Watch, review the Apple Watch User Guide at support.apple.com/guide/watch. Retain documentation for future reference.

Get Started

-  Press and hold to turn on Apple Watch.
-  Charge with magnetic charger.

Safety and Handling

See "Safety and handling" in the Apple Watch User Guide. Apple Watch, its operating systems, and the health sensors are not medical devices.

Exposure to Radio Frequency

For radio frequency exposure information for Apple Watch, open the Apple Watch app on iPhone and tap My Watch, then go to General > About > Legal > RF Exposure. Or go to apple.com/legal/rfexposure.

Battery and Charging

- The lithium-ion battery in Apple Watch should be serviced or recycled by Apple or an authorized service provider. You may receive a replacement Apple Watch when ordering battery service. Batteries must be recycled or disposed of separately from household waste. For information about battery service and recycling, go to apple.com/batteries/service-and-recycling. For information about charging, see
- "Important safety information" in the Apple Watch User Guide.

Medical Device Interference

Apple Watch, some of the bands, and Apple Watch magnetic charging accessories contain magnets that may interfere with medical devices. See "Important safety information" in the Apple Watch User Guide.

Avoid Hearing Damage

To prevent possible hearing damage, do not listen at high volume levels for long periods. More information about sound and hearing is available online at apple.com/sound and in "Important safety information" in the Apple Watch User Guide.

Regulatory

Regulatory certification information is available on-device. Go to Settings > General > Regulatory. Additional regulatory information is in “Safety and handling” in the Apple Watch User Guide.

FCC and ISED Canada Compliance for Apple Watch and Apple Watch Magnetic Charging Cable

This device complies with part 15 of the FCC Rules and ISED Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

EU / UK Compliance

Apple Inc. hereby declares that this wireless device is in compliance with Directive 2014/53/EU and Radio Equipment Regulations 2017. A copy of the Declaration of Conformity is available at apple.com/euro/compliance. Apple's EU representative is Apple Distribution International Ltd., Hollyhill Industrial Estate, Cork, Ireland. Apple's UK representative is Apple UK Ltd., 2 Furzeground Way, Stockley Park, Middlesex, UB11 1BB.

Disposal and Recycling Information



The symbol above means that according to local laws and regulations your product and/or its battery shall be disposed of separately from household waste. When this product reaches its end of life, take it to a collection point designated by local authorities. The separate collection and recycling of your product and/or its battery at the time of disposal will help conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For information about Apple's recycling program, recycling collection points, restricted substances, and other environmental initiatives, visit apple.com/environment.


Apple One-Year Limited Warranty Summary

- Apple warrants the included hardware product and accessories against defects in materials and workmanship for one year from the date of original retail purchase. Apple does not warrant against normal wear and tear, nor damage caused by accident or abuse. To obtain service, call Apple or visit an Apple Store or an Apple Authorized Service Provider—available service options are dependent on the country in which service is requested and may be restricted to the original country of sale. Call charges and international shipping charges may apply, depending on the location. Subject to the full terms and detailed information on obtaining service available at apple.com/legal/warranty and support.apple.com, if you submit a valid claim under this warranty, Apple will either repair, replace, or refund your hardware device at its own discretion. Warranty benefits are in addition to rights provided under local consumer laws. You may be required to furnish proof of purchase details when making a claim under this warranty.
- For Australian Consumers: Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. Apple Pty Ltd, PO Box A2629, Sydney South, NSW 1235. Tel: 133-622.
- For EU consumers: Apple means Apple Distribution International Ltd., Hollyhill Industrial Estate, Cork, Ireland. Consumers might have remedies free of charge against the seller in the event of a lack of conformity, which are not affected by this warranty.

• © 2023 Apple Inc. All rights reserved. Apple, the Apple logo, Apple Watch, and iPhone are trademarks of Apple Inc., registered in the U.S. and other countries and regions. Apple Store is a service mark of Apple Inc., registered in the U.S. and other countries and regions. Printed in XXXX. 034-05899-A



Documents / Resources

	Apple Apple Watch Ultra 2 [pdf] Instructions Apple Watch Ultra 2, Apple, Watch Ultra 2, Ultra 2
---	--

References

-  [Apple](#)
-  [Batteries - Service and Recycling - Apple](#)
-  [Environment - Apple](#)
-  [apple.com/euro/](#)
-  [Apple - Declarations of Conformity](#)
-  [Apple Regulatory Information](#)
-  [Legal - Hardware Warranties - Apple](#)
-  [Sound and Hearing - Apple](#)
-  [Official Apple Support](#)
-  [Apple Watch User Guide - Apple Support](#)
- [User Manual](#)