


GARMIN®



INREACH® MINI

Owner's Manual

© 2018 Garmin Ltd. or its subsidiaries

All rights reserved. Under the copyright laws, this manual may not be copied, in whole or in part, without the written consent of Garmin. Garmin reserves the right to change or improve its products and to make changes in the content of this manual without obligation to notify any person or organization of such changes or improvements. Go to www.garmin.com for current updates and supplemental information concerning the use of this product.

Garmin®, the Garmin logo, ANT+®, Earthmate®, fēnix®, inReach®, and TracBack® are trademarks of Garmin Ltd. or its subsidiaries, registered in the USA and other countries. Garmin Explore™ and Garmin ResponseSM are trademarks of Garmin Ltd. or its subsidiaries. These trademarks may not be used without the express permission of Garmin.

The BLUETOOTH® word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Garmin is under license. Facebook™ and the Facebook logo are trademarks of Facebook and its affiliate companies. Iridium® is a registered trademark of Iridium Satellite LLC. TWITTER™ and the Twitter logo are trademarks of Twitter, Inc. or its affiliates. Other trademarks and trade names are those of their respective owners.

Table of Contents

Getting Started.....	1
Device Overview	1
Keys	1
Turning On the Device	2
Status Icons	2
Viewing the Main Menu	2
Power Menu	2
Main Pages	2
Bluetooth Connected Features	3
Pairing Your Mobile Device	3
Activating the Device	3
Iridium Satellite Network	3
Testing the Device	3
Syncing inReach Data	4
Messages	4
Sending a Preset Message	4
Sending a Text Message	4
Replying to a Message	4
Checking for Messages	5
Viewing Message Details	5
Navigating to a Message Location	5
Deleting Messages	5
Contacts	5
Viewing a Contact	5
Deleting a Contact	5
SOS	6
Initiating an SOS Rescue	6
Sending a Custom SOS Message	6
Canceling an SOS Request	7
Tracking	7
Clearing the Track Log	7
Starting Tracking	7
Stopping Tracking	7
Sharing Your Tracking Page	7
Navigation	8

Acquiring GPS Satellite Signals	8
Routes	8
Navigating a Saved Route	8
Reversing a Route	8
Viewing Route Details	8
Deleting a Route	8
Waypoints	8
Creating a Waypoint	8
Navigating to a Waypoint	9
Editing a Waypoint	9
Deleting a Waypoint	9
Navigating Using TracBack®	9
Stopping Navigation	9
Location	9
Viewing and Sharing Your Current Location	9
Compass	9
Weather	9
Adding a Weather Location	9
Setting the Weather Location	10
Requesting a Weather Forecast	10
Deleting a Weather Location	10
Remote Control	10
Data Use and History	10
Viewing Data Use	10
Resetting the Data Use Counter	10
Customizing the Device	10
Display Settings	10
Tracking Settings	11
Bluetooth Settings	11
ANT+ Settings	11
Messages Settings	11
Sounds Settings	12
Time Settings	12
Units Settings	12
Automatically Turning Off the Device ..	12
Changing the Device Language	12
Adding Owner Information	12
Device Information	13
Support and Updates	13
Attaching the Spine Mount Adapter	13
Attaching a Lanyard	14

Locking and Unlocking the Keys	14
Device Care	14
Cleaning the Device	14
Getting More Information	14
Troubleshooting	15
Maximizing Battery Life	15
Resetting the Device	15
Restoring All Default Settings	15
Viewing Device Information	15
My device is in the wrong language	15
Charging the Device	16
Saving Energy While Charging the Device	16
Specifications	16
Battery Information	17


Getting Started

⚠ WARNING




See the *Important Safety and Product Information* guide in the product box for product warnings and other important information.

Device Overview



①	Internal Iridium® antenna
②	Keys
③	Micro-USB port (under weather cap)
④	SOS button (under protective cap)
⑤	Power key 
⑥	Mounting screw









Keys

	Select to scroll through menus, pages, and settings.
	Select to cancel or return to the previous page.
OK	Select to choose an option or to acknowledge a message. From the home page, select to open the main menu.
	Select to turn the device on. Select to open the Power menu.

Turning On the Device

Hold .


Status Icons

	Sending and receiving data
	Unable to send and receive data
	Tracking enabled
	Bluetooth® technology connection status
	ANT+® technology enabled
	Extended tracking mode enabled
	Charging battery
	Charging complete

Viewing the Main Menu

From the home page, select **OK** to open the main menu.

Power Menu

The Power menu displays the device battery life. It also allows you to adjust settings and turn off the device. From any page, select .

Battery: Displays the current battery level.



Lock Screen: Locks the touchscreen to prevent inadvertent key presses.

Turn Off: Turns off the device.

Brightness: Adjusts the brightness of the screen.

Mute Sounds: Mutes all device tones.

Main Pages

The main pages contain all the information you need to operate your device. You can select  or  to scroll through the pages.

Home page: Displays the date, time, and status icons ([Status Icons, page 2](#)). It also displays tracking and weather information when those features are in use. You can select OK to open the main menu.

Messages page: Enables you to send and receive text messages ([Messages, page 4](#)).

Mail Check page: Enables you to check for new messages ([Checking for Messages, page 5](#)).

Tracking page: Allows you to start and stop tracking. While tracking, this page shows your distance traveled and average speed ([Tracking, page 7](#)).

Location page: Displays your current GPS location and elevation ([Location, page 9](#)).

Compass page: Displays your heading and speed when you are moving ([Compass, page 9](#)).

Bluetooth page: Enables you to pair the inReach device with a compatible mobile device ([Pairing Your Mobile Device, page 3](#)).

Weather page: Enables you to request weather forecasts ([Weather, page 9](#)).

Bluetooth Connected Features

Your device has several Bluetooth connected features for your compatible smartphone or mobile device using the Earthmate® app. The Earthmate app allows you to use inReach features such as maps, tracking, messaging, and SOS on your mobile device.

Downloadable Features: View downloaded maps, aerial imagery, USGS quadrangle maps, and NOAA nautical charts on your mobile device. You should download maps and charts before going on your trip.

Sync: Earthmate syncs your device with your explore.garmin.com account, updating presets, waypoints, and routes.

Messages: Allows you to read and write messages, and access the contacts list on your mobile device. Messages appear on both devices.

NOTE: You can have only one mobile device paired with your inReach device at a time.

Pairing Your Mobile Device

You must pair your inReach device with your mobile device to use Bluetooth features.

- 1 From the app store on your mobile device, install and open the Earthmate app.
- 2 Place the inReach device and your mobile device within 3 m (10 ft.) of each other.
- 3 From the main menu, select **Setup > Bluetooth > Pair Device**.
- 4 Follow the instructions in the Earthmate app to complete the pairing and setup process.

After the devices are paired, they connect automatically when they are turned on and within range.

Activating the Device

Before you can use your inReach Mini device, you must activate it.

- 1 Create an account, and select a satellite subscription at explore.garmin.com.
- 2 Turn on the device.
- 3 Follow the on-screen instructions.
- 4 When prompted, go outdoors to an open area with a clear view of the sky.
- 5 Wait while the device communicates with the Iridium satellite network.

NOTE: It may take up to 20 minutes to activate your device. The device must send and receive several messages, which takes longer than sending a single message during regular use.

Iridium Satellite Network

Your device requires a clear view of the sky to transmit messages and track points over the Iridium satellite network. Without a clear view of the sky, your device attempts to send the information until it acquires satellite signals.

TIP: For the best connection with satellites, attach the device to a backpack or to your upper body.

Testing the Device

You should test the device outdoors before using it on a trip to ensure your satellite subscription is active.

From the main menu, select **Utilities > Test Service > OK**.

Wait while the device sends a test message. When you receive a confirmation message, your device is ready to use.

Syncing inReach Data

You can sync data from your explore.garmin.com account. After you make edits to your data, such as contacts, preset messages, or quick text messages, you must sync them to your device from explore.garmin.com.

- 1 Go to explore.garmin.com.
- 2 Select **Plans & Devices**.
- 3 Next to your device, select **Sync & Update**.
- 4 Follow the on-screen instructions.

Messages

Your inReach Mini device sends and receives text messages using the Iridium satellite network. You can send messages to an SMS phone number, an email address, or another device with inReach technology. Each message you send includes your location details.

NOTE: A preset message includes predefined text with predetermined recipients, and you must set it up on the Garmin Explore™ website.

Sending a Preset Message

Preset messages are messages that you created at explore.garmin.com. Preset messages have predefined text and recipients.

- 1 From the main menu, select **Send Preset**.
- 2 Choose a preset message, and select **Send**.

TIP: You can select View Details to view the content and recipient of the preset message.

Sending a Text Message

- 1 From the **Messages** page, select **OK**.
- 2 Select **New Message > Select Contacts**.
- 3 Choose recipients from your contacts list, and select **Done**.
- 4 Select an option:

- To start with a pre-written message, select **Pick Quick Text**.

NOTE: You can add and edit quick text messages on the Garmin Explore website.

- To write a custom message, select **Write Message**.

NOTE: To select from the autocomplete options, begin typing a word, hold **OK**, and use ▲ and ▼ to scroll through the options.

- 5 When you have finished your message, select ✓ > **Send**.

Replying to a Message

- 1 From the **Messages** page, select **OK**.
- 2 Select a conversation, and select **Reply**.
- 3 Select an option:
 - To start with a pre-written message, select **Pick Quick Text**.
 - To write a custom message, select **Write Message**.
- 4 When you have finished your message, select ✓ > **Send**.

Checking for Messages

Your device listens for new messages at regular listen intervals. Satellites announce recently sent messages, and your device receives the message at the next listen interval. The device will listen for 10 minutes after you send a message, and then again every hour.

NOTE: Your device must be in view of a satellite at the time of the listen to receive messages.

You can force a check for messages by manually checking for messages, sending a message, or sending a track point. During a check, your device connects to satellites and receives messages waiting to be sent to your device.

From the **Mail Check** page, select **OK**.

Viewing Message Details

- 1 From the **Messages** page, select **OK**.
- 2 Select a conversation.
- 3 Select a message, and select **OK**.

Navigating to a Message Location

When you receive a message from another device with inReach technology, the message may include location information. For these messages, you can navigate to the location from which the message was sent.

- 1 From the **Messages** page, select **OK**.
- 2 Select a conversation with location information.
- 3 Select a message.
- 4 Select **OK > Navigate**.

Deleting Messages

- 1 From the **Messages** page, select **OK**.
- 2 Select a message.
- 3 Select **Delete Thread**.

Contacts

You can add contacts to the Garmin Explore website and sync them to your device. Go to explore.garmin.com.

Viewing a Contact

- 1 From the main menu, select **Utilities > Contacts**.
- 2 Select a contact, and select **View Details**.

Deleting a Contact

- 1 From the main menu, select **Utilities > Contacts**.
- 2 Select a contact, and select **Delete**.

SOS

⚠ WARNING

Before you can use the SOS function, you must have an active satellite subscription. Always test your device before you use it outdoors.

Ensure you have a clear view of the sky when using the SOS function, because this feature requires satellite access to operate properly.

NOTICE

Some jurisdictions regulate or prohibit the use of satellite communications devices. It is the responsibility of the user to know and follow all applicable laws in the jurisdictions where the device is intended to be used.

During an emergency, you can use your inReach Mini device to contact the Garmin ResponseSM center to request help. Pressing the SOS button sends a message to the Garmin Response team, and they notify the appropriate emergency responders of your situation. You can communicate with the Garmin Response team during your emergency while you wait for help to arrive. You should only use the SOS function in a real emergency situation.

Initiating an SOS Rescue

You can initiate an SOS rescue with the device turned on or off if the device has battery power.

- 1 Lift the protective cap ① from the **SOS** button ②.



- 2 Press and hold the **SOS** button.
- 3 Wait for the SOS countdown.
The device sends a default message to the emergency response service with details about your location.
- 4 Reply to the confirmation message from the emergency response service.
Your reply lets the emergency response service know that you are capable of interacting with them during the rescue. If you do not reply, the emergency response service will still initiate a rescue.

For the first 10 minutes of your rescue, an updated location is sent to the emergency response service every minute. To conserve battery power after the first 10 minutes, an updated location is sent every 10 minutes.

Sending a Custom SOS Message

After pressing the SOS button to initiate an SOS rescue, you can reply with a custom message using the SOS page.

- 1 Select **Reply** to compose a custom SOS message.
- 2 When you have finished your message, select ✓ > **Send**.

Your reply lets the emergency response service know that you are capable of interacting with them during the rescue.

Canceling an SOS Request

If you no longer need assistance, you can cancel an SOS request after it is sent to the emergency response service.

- 1 Lift the protective cap, and hold the **SOS** button.
- 2 Select **Cancel SOS**.
- 3 When prompted to confirm your cancellation request, select **Cancel SOS**.
Your device transmits the cancellation request. When you receive a confirmation message from the emergency response service, the device returns to normal operation.

Tracking

Tracking records your path. When you start tracking, your device logs your location and updates the track line at the specified log interval. Your device records track points and transmits them over the satellite network at the specified send interval. You can view the total number of track points sent.

TIP: You can adjust the tracking log interval and the tracking send interval to maximize battery life ([Tracking Settings, page 11](#)).

NOTE: When the tracking log storage is full, your device overwrites older track points, but retains a lower-detail tracking line.

Clearing the Track Log

Before you can clear the track log, you must begin tracking.

- 1 From the **Tracking** page, select **OK**.
- 2 Select **Clear Log**.
The recorded track log is deleted.

Starting Tracking

From the **Tracking** page, select **OK**.

Your track appears on a tracking webpage for friends and family to follow your trip.

Stopping Tracking

- 1 From the **Tracking** page, select **OK**.
- 2 Select **Stop Tracking**.

Sharing Your Tracking Page

You can share a link to a tracking webpage with other people. The system automatically adds text, including link information, to the end of your message.

- 1 From the **Tracking** page, select **OK**.
- 2 Select **Share With > Select Contacts**.
- 3 Choose recipients from your contacts list, or enter a recipient's contact information.
- 4 Select **Send**.

Navigation

Acquiring GPS Satellite Signals

Before you can use GPS navigation features, you must acquire satellite signals.

When you turn on your navigation device, the GPS receiver must collect satellite data and establish the current location. The time required to acquire satellite signals varies based on several factors, including how far you are from the location where you last used your navigation device, whether you have a clear view of the sky, and how long it has been since you last used your navigation device. The first time you turn on your navigation device, it may take several minutes to acquire satellite signals.

- 1 Turn on the device.
- 2 Wait while the device locates satellites.
It may take up to 60 seconds to acquire satellite signals.
- 3 If necessary, go to an open area, away from tall buildings and trees.

Routes

A route is a sequence of locations that leads you to your final destination. You can create and save routes at explore.garmin.com.

Navigating a Saved Route

Starting navigation updates your tracking page, and your friends and family can view the route you are navigating.

- 1 From the main menu, select **Navigate > Routes**.
- 2 Select a route, and select **Navigate**.

Reversing a Route

You can switch the start and end points of your route to navigate the route in reverse.

- 1 From the main menu, select **Navigate > Routes**.
- 2 Select a route, and select **Reverse Route**.

Viewing Route Details

- 1 From the main menu, select **Navigate > Routes**.
- 2 Select a route.
The route details appear, including the number of legs, route length, and date created.

Deleting a Route

- 1 From the main menu, select **Navigate > Routes**.
- 2 Select a route, and select **Delete**.

Waypoints

Waypoints are locations you record and store in the device. Waypoints can mark where you are, where you are going, or where you have been.

Creating a Waypoint

You can save your current location as a waypoint or create custom waypoints.

- 1 Choose an option:
 - To mark your current location as a waypoint, select **Mark Waypoint** from the main menu.
 - To create a custom waypoint, select **Navigate > Waypoints > New Waypoint** from the main menu.
- 2 If necessary, edit the waypoint information.

Navigating to a Waypoint

- 1 From the main menu, select **Navigate > Waypoints**.
- 2 Select a waypoint, and select **Navigate**.

Editing a Waypoint

- 1 From the main menu, select **Navigate > Waypoints**.
- 2 Select a waypoint, and select an option:
 - To change the name of the waypoint, select **Edit Name**.
 - To change the symbol representing the waypoint, select **Edit Symbol**.
 - To change the GPS coordinates of the waypoint, select **Edit Coordinates**.
- 3 Enter the new information, and select **✓** if necessary.

Deleting a Waypoint

- 1 From the main menu, select **Navigate > Waypoints**.
- 2 Select a waypoint, and select **Delete**.

Navigating Using TracBack

While recording, you can navigate back to the beginning of your activity. This can be helpful when finding your way back to camp or the trail head.

From the main menu, select **Navigate > TracBack**.

Stopping Navigation

- 1 From the navigation page, select **OK**.
- 2 Select **Stop Navigating**.

Location

You can view your current GPS location and elevation from the Location page. Each message you send includes a link to your current location. You can also send your location details as text within a message.

Viewing and Sharing Your Current Location

- 1 From the **Location** page, select **OK**.
- 2 Select **Share Location** to send your location details as text within a message.

Compass

The compass page shows your heading and speed when you are moving.

Weather

Your inReach device can send a message to request basic, premium, or marine weather forecasts. You can receive weather forecasts for your current location, a waypoint, or GPS coordinates. Weather forecasts incur data usage charges. For more information, go to [explore.garmin.com](https://www.garmin.com/explore).

Adding a Weather Location

You can add waypoints as weather locations.

- 1 From the **Weather** page, select **OK**.
- 2 Select **Change Location > New Location**.
- 3 Select an option:
 - To add an existing waypoint as a weather location, select a waypoint.
 - To create a new waypoint to add as a weather location, select **New Waypoint**.

Setting the Weather Location

- 1 From the **Weather** page, select **OK**.
- 2 Select **Change Location**.
- 3 Select a location.

Requesting a Weather Forecast

For best results, you should ensure your device has a clear view of the sky when you request a weather forecast.

- 1 From the **Weather** page, select **OK**.
- 2 Select **Update**.
- 3 If necessary, select a forecast type.

NOTE: For best results, you should request a marine forecast for a location away from shore and over a large body of water.

The device sends a request for the forecast. It may take several minutes to receive the weather forecast data. After the device finishes downloading the data, you can view the forecast at any time until all the information in the forecast has expired. You can also update the forecast at any time.

NOTE: Updating a forecast incurs data charges or additional usage charges.

Deleting a Weather Location

You must set the weather location before you can delete it ([Setting the Weather Location, page 10](#)).

- 1 From the **Weather** page, select **OK**.
- 2 Select **Remove**.

Remote Control

You can access some inReach Mini features using another compatible device with ANT+ wireless technology, such as the fēnix® watch. You can use remote control to view incoming messages, send preset messages, start and stop tracking, and initiate or cancel an SOS.

NOTE: You must enable ANT+ before pairing your device ([ANT+ Settings, page 11](#)).

Data Use and History

Viewing Data Use

You can view the number of messages, preset messages, and track points sent during the current billing cycle. You can also view the details of your current data plan and check for data plan updates. The data use counter resets automatically at the beginning of each billing cycle.

From the main menu, select **Utilities > Data Use**.

Resetting the Data Use Counter

If you are a professional customer, you can reset the data use counter to monitor your usage.

From the main menu, select **Utilities > Data Use > Reset Counter**.

Customizing the Device

Display Settings

From the main menu, select **Setup > Display**.

Brightness: Sets the backlight brightness.

Timeout: Sets the length of time before the backlight turns off.

Tracking Settings

From the main menu, select **Setup > Tracking**.

Send Interval: Sets the frequency at which the device records a track point and transmits it over the satellite network when you are moving.

Log Interval: Sets the frequency at which the device logs your location and updates the track line in memory.

Auto Track: Sets the device to start tracking when you turn on the device.

Ext. Tracking: Sets the device to enter sleep mode between track points to maximize battery life. Sleep mode disables Bluetooth wireless technology, detailed track lines, and message checking.

Stationary Interval: Sets the frequency at which the device records a track point and transmits it over the satellite network when you are not moving. This setting is only available for professional customers with a byte-based subscription plan.

Burst Tracking: When tracking, sets the device to create and send a detailed track line to provide the best approximation of your location. You can select the amount of data to use, and the device will create as many track points as possible. This setting is only available for professional customers with a byte-based subscription plan.

Bluetooth Settings

From the main menu, select **Setup > Bluetooth**.

Status: Enables Bluetooth wireless technology.

Pair Device: Connects your device with a compatible Bluetooth enabled mobile device. This setting allows you to use Bluetooth connected features using the Earthmate app.

Forget Device: Removes the connected device from the list of mobile devices to connect to. This option is available only after the device has paired.

Pair Again: Restarts the pairing process. This option is available only after the device has paired.

ANT+ Settings

When enabled, ANT+ technology allows you to access some inReach Mini features using another compatible device ([Remote Control](#), page 10).

From the main menu, select **Setup > ANT+**.

Status: Turns ANT+ technology on or off.

Verification: Enables user verification to communicate with a wireless device.

Device Number: The device number for the ANT+ channel.

Verified Devices: Displays a list of verified devices that this device can wirelessly connect to.

Messages Settings

From the main menu, select **Setup > Messages**.

Ring Until Read: Sets the device to ring until you read a new message. This feature is helpful if you are in a noisy environment.

Adaptive Mail Check: When this setting is enabled, the device listens more frequently for a reply to a sent message for ten minutes. If the recipient replies quickly, you can receive the reply before the next scheduled listen interval. This setting is always enabled on consumer and professional flex accounts. On byte-based plans, it can be disabled to reduce battery consumption.

Sounds Settings

From the main menu, select **Setup > Sounds**.

Mute All: Mutes all device tones.

Volume: Sets the device volume level.

Message Rec.: Sets the tone that sounds when you receive a message.

Message Sent: Sets the tone that sounds when the you send a message.

Critical Alert: Sets the tone that sounds when the device announces a critical alert.

Power Off: Sets the tone that sounds when you turn off the device.

Time Settings

From the main menu, select **Setup > Time**.

Time Format: Sets the device to show time in a 12-hour or 24-hour format.

Time Zone: Sets the time zone for the device.

Daylight Saving: Sets the device to use daylight saving time. This option is not available when Time Zone is set to Automatic.

Units Settings

NOTE: You should not change the position-coordinate format or the map datum coordinate system unless you are using a map or chart that specifies a different position format.

From the main menu, select **Setup > Units**.

Coordinates: Sets the format used for geographical position coordinates.

Datum: Sets the coordinate system used by the map.

Speed/Distance: Sets the unit of measure for distance.

Wind Speed: Sets the unit of measure for wind speed.

Temperature: Sets the temperature units to Fahrenheit (°F) or Celsius (°C).

Pressure: Sets the pressure units.

Bearing: Sets the north reference used on the compass to true or magnetic north.

Automatically Turning Off the Device


The Auto Off setting automatically turns the device off 30 seconds after you disconnect it from external power.

- 1 From the main menu, select **Setup > External Power**.
- 2 Select **Auto Off > On**.

Changing the Device Language

- 1 From the main menu, select **Setup > Language**.
- 2 Select a language.

Adding Owner Information

- 1 From the main menu, select **Setup > Owner Info**.
- 2 Select **OK**, enter your information, and select .

Device Information

Support and Updates

Go to explore.garmin.com for easy access to these services for inReach devices.

- Product registration
- Firmware updates
- Data uploads and syncing your device with your account

Attaching the Spine Mount Adapter

- 1 Remove the short screw ① from the carabiner strap ②.



- 2 Secure the spine mount adapter ① over the back of the device using the long screw ② included with the device.

TIP: The spine mount adapter fits over the carabiner strap. You can attach the adapter over the strap or remove the strap.



Attaching a Lanyard

- 1 Insert the loop of the lanyard through the slot in the device.



- 2 Thread the other end of the lanyard through the loop, and pull it tight.
- 3 If necessary, attach the lanyard to your clothing or backpack to tether it during an activity.

Locking and Unlocking the Keys

You can lock the keys to prevent inadvertent key presses.

- 1 Select > **Lock Screen**.
- 2 Select > **Unlock** to unlock the keys.

Device Care

NOTICE

Avoid chemical cleaners, solvents, and insect repellents that can damage plastic components and finishes.

Do not store the device where prolonged exposure to extreme temperatures can occur, because it can cause permanent damage.

The device is water resistant to IEC Standard 60529 IPX7. It can withstand accidental immersion in 1 meter of water for 30 minutes. Prolonged submersion can cause damage to the device. After submersion, be certain to wipe dry and air dry the device before using or charging.

Thoroughly rinse the device with fresh water after exposure to chlorinated or salt water environments.

Cleaning the Device

- 1 Wipe the device using a cloth dampened with a mild detergent solution.
- 2 Wipe it dry.

After cleaning, allow the device to dry completely.

Getting More Information

You can find more information about this product on the Garmin® website.

- Go to support.garmin.com for additional manuals, articles, and software updates.
- Go to buy.garmin.com, or contact your Garmin dealer for information about optional accessories and replacement parts.




Troubleshooting

Maximizing Battery Life

- Turn on the **Ext. Tracking** setting ([Tracking Settings, page 11](#)).
- Reduce the backlight timeout ([Display Settings, page 10](#)).
- Reduce the value of the tracking **Log Interval** and **Send Interval** settings ([Tracking Settings, page 11](#)).
- Turn off Bluetooth wireless technology ([Bluetooth Settings, page 11](#)).
- Turn off ANT+ wireless technology ([ANT+ Settings, page 11](#)).

Resetting the Device

If the device stops responding, you may need to reset it. This does not erase any of your data or settings.

- 1 Hold  and  until the device turns off.
- 2 Hold  to turn on the device.

Restoring All Default Settings

You can restore all device settings to the factory default values.

NOTE: This deletes all user-entered information.

From the main menu, select **Setup > Recovery Options > Restore Defaults**.

Viewing Device Information

You can view the IMEI number, firmware version, regulatory information, license agreement, and other device information.

- 1 From the main menu, select **Setup**.
- 2 Select **About This Device**.

Viewing E-Label Regulatory and Compliance Information

The label for this device is provided electronically. The e-label may provide regulatory information, such as identification numbers provided by the FCC or regional compliance markings, the IMEI number, as well as applicable product and licensing information.

- 1 From the main menu, select **Setup**.
- 2 Select **About This Device**.
- 3 Select **Regulatory**.

My device is in the wrong language

You can change the device language selection if you have accidentally selected the wrong language on the device.

- 1 From the home page, select **OK**.
- 2 Scroll down to the last item in the list, and select it.
- 3 Scroll down to the tenth item in the list, and select it.
- 4 Select your language.

Charging the Device

NOTICE

To prevent corrosion, thoroughly dry the USB port, the weather cap, and the surrounding area before charging or connecting to a computer.

NOTE: The device does not charge when it is outside the approved temperature range (*Specifications, page 16*).

- 1 Lift the weather cap ①.



- 2 Plug the small end of the power cable into the USB port ② on the device.
- 3 Plug the other end of the power cable into an appropriate power source.
- 4 Charge the device completely.

Saving Energy While Charging the Device

You can turn off device features while charging.

- 1 Connect your device to an external power source.
- 2 Hold the power button until the screen turns off.
The device goes into a low power, battery charging mode, and the battery gauge appears.
- 3 Charge the device completely.

Specifications

Battery type	Rechargeable, built-in lithium-ion battery
Battery capacity	1,250 mAh
Water rating	IEC 60529 IPX7 ¹
Operating temperature range	From -20° to 60°C (from -4° to 140°F)
Charging temperature range	From 0° to 45°C (from 32° to 113°F)
Wireless frequency/protocol	1.6 GHz @ 31.7 dBm nominal 2.4 GHz @ 5 dBm nominal

¹ The device withstands incidental exposure to water of up to 1 m for up to 30 min. For more information, go to www.garmin.com/waterrating.

Battery Information

The actual battery life depends on your device settings, such as the tracking and message checking intervals.

Battery Life	Mode
Up to 35 hr.	10-minute tracking send interval and 1-second log interval
Up to 90 hr.	Default mode with 10-minute tracking send interval
Up to 24 days	Extended tracking mode with 30-minute tracking send interval
Up to 1 yr.	Turned off

