

**SONY®**

CAMERA CONTROL NETWORK ADAPTOR

**CNA-1**

TECHNICAL MANUAL  
1st Edition (Revised 1)

English

---

# Table of Contents

<b>Overview .....</b>	<b>3</b>
Abstract .....	3
How does the CNA-1 work? .....	3
Terminology .....	3
Application example .....	3
Sony camera control application .....	3
Your system participates in CNS as “Sony Camera” ...	3
<b>CNA-1 Configuration .....</b>	<b>4</b>
Examples of system configurations.....	4
One camera control by your system .....	4
Multiple camera control application with your system .....	5
Your system controlled by Sony RCP peer-to-peer .....	6
Your system participates in CNS as one of Sony camera .....	7
System/Command log configuration .....	8
<b>Sony Simple Camera Protocol .....</b>	<b>9</b>
Introduction .....	9
Overview .....	9
Overall operation .....	9
Specification.....	9
Network .....	9
Data structure .....	9
Command .....	9
Connection .....	9
Examples of using commands .....	10
Details of Command .....	10
Types of the command .....	11
Rules .....	12
Appendix .....	13
Example of State Machine diagram for your system .....	13
Example of Startup Sequence (your system works as Controller) .....	14
Example of Startup Sequence (your system works as Camera) .....	15
<b>Extended commands of Optional Software .....</b>	<b>16</b>
Multi camera control (HZC-MSCN1) .....	16
Using commands for multiple camera control .....	16
RCP Assignment control (HZC-RACN1) .....	18
RCP Assignment control commands .....	19
Commands to get Camera status information .....	20
Commands to get RCP status information .....	21
Commands to change RCP assignment status .....	22
<b>List of available commands.....</b>	<b>24</b>

# Overview

## Abstract

CNA-1 is a network point that works as a “Protocol converter”. It acts as an entrance to the Sony Camera Network System (CNS).

Your system can control a Sony Camera, and can be controlled from Sony Control Panels via CNA-1 with its communication protocol.

## How does the CNA-1 work?

CNA-1 participates in CNS as another “Sony protocol capable” device.

It can talk to your system with a simple command protocol (Sony Simple Camera Protocol: SSCP), providing a simple communication mechanism for your system. It mutually translates the protocol for a Sony Camera to SSCP.

## Terminology

### CNS: Sony Camera Network System

A network system consisting of Sony Cameras (Sony CCUs) and Sony Control Panels, connected to each other via TCP/IP.

### SPP: Sony Proprietary Protocol

A communication protocol used by CNS devices.

### SSCP: Sony Simple Camera Protocol

A communication protocol between CNA-1 and your system.

### RCP-mode, CAM-mode:

An emulation mode of CNA-1.

CNA-1 acts as a Sony Control Panel in RCP-mode.

CNA-1 acts as a Sony Camera in CAM-mode.


This configuration can be selected using the Web configurator of CNA-1.

## Application example

### Sony camera control application

In this application, your system behaves as a controller for a Sony Camera.


Your system can control a Sony Camera via CNA-1 (RCP-mode configured) with SSCP.



### Your system participates in CNS as “Sony Camera”

In this application, your system may behave as a Camera or other device similar to a camera.


Your system can be controlled from Sony Control Panels via CNA-1 (CAM-mode configured) with SSCP.



## CNA-1 Configuration

## Examples of system configurations

## One camera control by your system




### CNA-1 setup

For details of the following setting items, see “Operation Manual (page 17).”

CNS Configuration	CNS Mode	Bridge
	Master Mode	Disable
	Master IP Address	Variable
	Target IP Address	CCU's IP Address
	Device No.	Variable
Gateway Configuration	Gateway Mode	Enable
	Emulation Mode	RCP

## Multiple camera control application with your system



### CNA-1 setup

For details of the following setting items, see “Operation Manual (page 17).”

CNS Configuration	CNS Mode	MCS
	Master Mode	Disable
	Master IP Address	Master MSU's IP address
	Target IP Address	Variable
	Device No.	Depends on RCPs connected to the network.
Gateway Configuration	Gateway Mode	Enable
	Emulation Mode	RCP

### Device No. Configuration for CNA-1

In this case, Device number of CNA-1 must be set to different number from RCPs connected to the network. CNA-1 will be recognized as one of RCP and CNA-1's Device number is handled as RCP number in CNS.

In default setting of RCP assignment, RCP can control CCU (and camera) which has same number from RCP number.


Ex. RCP No. (1) can control CCU No. (1)

CNA-1 (1)-(3) has Device number (4)-(6). In this setting, CNA-1 cannot control any CCU (and camera) (4)-(6) because CCU (4)-(6) is not connected in this network.

For control (1)-(3) camera by CNA-1 (1)-(3), CNA-1 must be assigned to CCU (and camera) (1)-(3) by RCP assignment function provided from MSU. MSU will find CNA-1 as RCP (4)-(6).

For detail of RCP assignment function, see MSU's Operation Manual.

Your system controlled by Sony RCP peer-to-peer



CNA-1 setup

For details of the following setting items, see “Operation Manual (page 17).


CNS Configuration	CNS Mode	Bridge
	Master Mode	Disable
	Master IP Address	Variable
	Target IP Address	Variable
	Device No.	Variable
Gateway Configuration	Gateway Mode	Enable
	Emulation Mode	CAM

RCP setup

For details of the following setting items, see RCP’s Operation Manual.

CNS Configuration	CNS Mode	Bridge
	Bridge Mode: Connection mode	Semi-Auto
	Bridge Mode: Target	CNA-1’s IP address

# Your system participates in CNS as one of Sony camera



## CNA-1 setup

For details of the following setting items, see “Operation Manual (page 17).

CNS Configuration	CNS Mode	MCS
	Master Mode	Disable
	Master IP Address	Master MSU's IP address
	Target IP Address	Variable
	Device No.	Depends on CCUs connected to the network.
Gateway Configuration	Gateway Mode	Enable
	Emulation Mode	CAM

## Device No. Configuration for CNA-1

In this case, Device number of CNA-1 must be set to different number from CCUs connected to the network. CNA-1 will be recognized as one of camera and CNA-1's Device number is handled as CCU number in CNS.

CNA-1's Device number is set to (3). Therefore, MSU can find CNA-1 as Camera (3) and also RCP (3) can control CNA-1 as Camera (3).

---

## System/Command log configuration

CNA-1 can record system event log and SSCP command log. This utility function assists you to develop and validate software for your system.

### Log format

CNA-1 records log using Syslog format.

### To display the Log menu

Access to the following URL by a PC with its web browser.  
"http://(CNA-1's IP address)/admin/log.html"

For details of how to access the menu, see "Operation Manual (page 16)"

### Log menu

- 1 Log Configuration  
System Log:  
Set the log function to on/off  
Command Log:  
Set the SSCP command log function to on/off  
Log Level:  
Select the minimum message severity level to record in CNA-1  
\* If you plan to record command log, do not set the level to "Notice" or higher.  
Show All System Log button:  
Click to show all system log and command log stored in CNA-1's RAM.  
Show All Command Log button:  
Click to show only command log stored in CNA-1's RAM.  
\* If there is a large amount of log stored in RAM, displaying log list operation may take long time depending on the network and performance of the PC.
- 2 Log Storage Configuration  
Storage:  
Select storage for log.  
Next File every \*\* KB, Ring buffer with \*\* Files:  
Select log rotation number and size of file.  
Eject button:  
Eject the inserted USB flash drive.
- 3 Sever Log  
Server Log:  
Set the Server log function to on/off  
Server IP Address:  
Set the IP address of a server which can receive log from CNA-1.  
Server UDP Port:  
Set the UDP port of a server.

### Notes on using USB flash drive

- Do not operate CNA-1 with USB flash drive.  
USB flash drive is development use only.  
Log processing with USB flash drive may interfere with CNA-1's SSCP connection if an inserted USB flash drive has some malfunction or does not have enough capability of data writing speed.
- Sony USB flash drive USM\*GLX series are recommended.  
USB drives other than those recommended may not be recognized when connected to the USB connector.  
USB drives must be formatted with the FAT16 or FAT32 file system. Recommended Sony USB drives are preformatted, and can be used without any prior setup.



# Sony Simple Camera Protocol

## Introduction

### Overview

Sony Simple Camera Protocol (SSCP) is a communication protocol between your system and CNA-1. It is an ASCII character based protocol via TCP/IP. The port number of TCP is configurable.

It has no complex mechanism such as Application-level session control, Keep-alive, Device identification or Authentication. Therefore, your system can control Sony Cameras, or can be controlled from Sony Control Panels, using just send/receive command(s) without any complex procedure.

### Overall operation

Basically, CNA-1 listens to a specified TCP port and awaits a connection from your system. When a connection is established, CNA-1 is ready to send and receive control commands immediately.

The connection behavior varies based on its emulation mode. (See connection section.)

## Specification

### Network

Link layer:

Ethernet, 100BASE-TX

Network layer:

IPv4

Transport Layer:

TCP

Port number is configurable other than 7700 (CNA-1 reserved) or well known ports (1-1023)

### Data structure

Packet:

Variable length depends on MTU configuration.  
MTU value of CNA-1 is 1500 bytes. It is preferred that MTU of your system is configured less than 1500.

Data:

ASCII character codes:

- Available ASCII printable characters:
  - Lower alpha: "a" .. "z"
  - Higher alpha: "A" .. "Z"
  - Digit: "0" .. "9"
  - Others: ",", (comma)
- Available ASCII control characters:
  - New line: "\n", "\r"

#### Note

If a packet includes unavailable characters or bytes, it is handled as an invalid packet and discarded.

### Command

A command is described by Hexadecimal data assembled by ASCII characters above.

Lower and upper case alphabetical/numeric:

2 characters requires 1 byte

Comma:

Delimiter of each byte

New line:

Termination of a command, "\n", "\r" and "\n\r" are available.

Example: (Set Master Black to 0):

"23,a9,00,00\n"

Constructing a command by multi-packet is possible.

Example:

"23," Packet1

"a9" Packet2

",00,00" Packet3

"\n" Packet4

CNA-1 will concatenate packets (1-4) and recognize that as "23,a9,00,00\n".

Multiple commands in a packet is possible.

Example (Set White Balance R-ch, G-ch, B-ch to 0 at the same time):

"23,01,00,00\n23,02,00,00\n23,03,00,00\n"

### Important limitation

Maximum command length: 168 byte (characters) / packet

If CNA-1 cannot find the terminator (New line) after it receives 168 bytes, it will discard the received data.

Minimum inter-packet (including complete command(s)) interval: 50 msec

This limitation is important to avoid Camera malfunctions. An overly short inter-packet gap can impose a heavy load on a Camera's processor, and interfere with its processing. It is possible that unexpected Camera errors might occur.

If your system needs to send a number of commands, the commands must be concatenated and put in a packet. In an application including periodic scan for Camera status, it is recommended that the inter-packet-interval is set to as long as possible, for effective Camera operation.

Terminator:

CNA-1 only sends "\n" as terminator even if it receives "\r" and "\n\r".

## Connection

### CNA-1 configured for RCP mode

- 1 CNA-1 searches for a Sony Camera or Sony CCU by CNS configuration.
- 2 When CNA-1 connects to that, CNA-1 listens to specified TCP port and awaits a connection from your system.
- 3 Your system ready to connect to CNA-1

#### Note

If CNA-1 loses its CNS connection (to Camera or CCU), it terminates the connection with your system, and returns to (1).

## CNA-1 configured for CAM mode

- 1 After booting CNA-1, it listens to the specified TCP port, and awaits connection from your system immediately.
- 2 Your system connects to CNA-1.
- 3 When connection is established, CNA-1 searches a CNS by its configuration and participate in CNS as one of a Sony Camera.

### Note

If CNA-1 loses connection with your system, it closes the session to CNS, and returns to (1).

## Examples of using commands

For details of commands, see “Details of Command” and “List of available commands”.

### Master Gain control (Inc/Dec command)

Get current Gain value

Send: “20,01,00\n” => Receive: “21,01,02\n” (Reply current status from Camera)

Increase Gain

Send: “21,01,80\n” => Receive: “21,01,03\n” (in case of current parameter being 02)

Reduce Gain

Send: “21,01,40\n” => Receive: “21,01,01\n” (in case of current parameter being 02)

Set Gain value directory

Send: “21,01,01\n” => Receive: “21,01,01\n”

### Control several Camera functions (Bit command)

Get current function states (ON or OFF) at

CHU\_FUNCTION01

Send: “20,81,00\n” => Receive: “21,81,31\n” “31” is handled as bits-array: “00110001” means:

- Knee Saturation (Bit7) = OFF
- Auto Knee (Bit6) = OFF
- Knee (Bit5) = ON
- Gamma (Bit4) = ON
- Flare (Bit3) = OFF
- S-EVS (Bit2) = OFF
- ECS (Bit1) = OFF
- Shutter (Bit0) = ON

Invert function states

Send: “20,81,33\n” (00110011) => Receive: “21,81,02\n” (in above condition)

- Knee Saturation (Bit7) = OFF (0 no operation)
- Auto Knee (Bit6) = OFF (0 no operation)
- Knee (Bit5) = OFF (1 ON to OFF)
- Gamma (Bit4) = OFF (1 ON to OFF)
- Flare (Bit3) = OFF (0 no operation)
- S-EVS (Bit2) = OFF (0 no operation)
- ECS (Bit1) = ON (1 OFF to ON)
- Shutter (Bit0) = OFF (1 ON to OFF)

Set function states

Send: “21,81,31\n” (00110001) => Receive: “21,81,31\n” (in above condition)

- Knee Saturation (Bit7) = OFF
- Auto Knee (Bit6) = OFF

- Knee (Bit5) = ON
- Gamma (Bit4) = ON
- Flare (Bit3) = OFF
- S-EVS (Bit2) = OFF
- ECS (Bit1) = OFF
- Shutter (Bit0) = ON

Set function status with bit-mask

Send: “29,81,03,11\n” (00000011 & 00010001) =>

Receive: “21,81,21\n” (in above condition)

- Knee Saturation (Bit7) = OFF (0-0 no operation)
- Auto Knee (Bit6) = OFF (0-0 no operation)
- Knee (Bit5) = ON (0-0 no operation)
- Gamma (Bit4) = OFF (0-1 Effective OFF)
- Flare (Bit3) = OFF (0-0 no operation)
- S-EVS (Bit2) = OFF (0-0 no operation)
- ECS (Bit1) = OFF (1-0 no operation)
- Shutter (Bit0) = ON (1-1 Effective ON)

### Control White Balance R-Channel of Camera (Word command)

Get current value

Send: “22,01,00,00\n” => Receive: “23,01,01,40\n”

Current value is “01,40” = 0x0140 (16bits Hex)

Add/Subtraction control

Send: “22,01,00,01\n” => Receive: “23,01,01,41\n” (Add +0001)

Send: “22,01,ff,ff\n” => Receive: “23,01,01,3f\n” (Subtraction -0001)

Set value directory

Send: “23,01,00,01\n” => Receive: “23,01,00,01\n”

### Details of Command

Command has 2 parts, “Command group: CMD-GP” and “Parameter: PARAM”.

CMD-GP is a byte at the head of a command. PARAM is one or a number of bytes describing the contents of a command. The length of PARAM is dependent on CMD-GP.

“[CMD-GP],[PARAM0],[PARAM1],[PARAM2],...,[PARAM N]\n”

**Example: “23,a9,00,00\n”**

CMD-GP: “23”

Adjust the word-size parameter of Camera

PARAM: “a9,00,00”

PARAM0:

“a9” Parameter address of Master Black of Camera

PARAM1-2:

“00,00” 2 bytes parameter value of Master Black (PARAM0)

## Types of the command

There are several types of commands and formats, depending on CMD-GP or combination of CMD-GP and PARAM0.

[CMD-GP]:

Categorizes a command into “Byte type”, “Word type”, “Other type”, and appends a control method “Relative” or “Absolute”

[CMD-GP] + [PARAM0]:

Categorizes “Byte type command” into “Byte command”, “Bit command”, “Inc/Dec command”

Almost all commands have two different control types: “Relative” and “Absolute” assigned to a different CMD-GP (see the List of available commands)

Example: Master Black control

- Relative control: “22,a9,00,01\n” This command “adds” 0x0001 to the current parameter
- Absolute control: “23,a9,00,01\n” This command “sets” 0x0001 to the parameter (overwrite)

## Byte command

Controls or Queries a byte-size parameter of a Camera.

**Format:**

- “[CMD-GP],[PARAM0],[PARAM1]\n”
- PARAM0: Parameter address
- PARAM1: Value

**Relative control:**

It means a status query.

PARAM1 is ignored and does not affect the status of the Camera.

**Absolute control:**

Set the parameter of Camera specified by the PARAM0 address to PARAM1, or a response of the value of the parameter from the Camera.

## Bit command

Controls or Queries the ON or OFF state of a function of a Camera using bit (0 or 1).

**Format:**

- “[CMD-GP],[PARAM0],[PARAM1]\n”
- PARAM0: Parameter address
- PARAM1: Value affects each bit

**Relative control:**

Inverts the function state specified by the PARAM0 address ON to OFF, or OFF to ON when bit is set to 1. If PARAM1 bits are all set to 0, it means a status query.

**Absolute control:**

Set the state at the PARAM0 address to PARAM1 or a response of the value of the parameter from the Camera.

## Inc/Dec command

Increments or decrements a Camera parameter and also adjusts a value directory.

**Format:**

- “[CMD-GP],[PARAM0],[PARAM1]\n”
- PARAM0: Parameter address
- PARAM1: Value

PARAM1

bit7-6: Inc/Dec control

[00] Set a value directory or status query

[01] Increment the parameter specified by the PARAM0 address

[10] Decrement the parameter specified by the PARAM0 address

[11] N/A

bit5-0: Value of the parameter

**Relative control:**

bit5-0 is ignored.

bit7-6 [00] or [10] or [01]: Parameter (bit5-0) query.

bit7-6 [11]: Maximum value query for the parameter (bit5-0).

**Absolute control:**

bit7-6:

[00]: Set the parameter specified by the PARAM0 address to bit5-0.

[01]: Decrement the parameter. bit5-0 is ignored.

[10]: Increment the parameter. bit5-0 is ignored.

[11]: Maximum value reply from a Camera. Do not use this bit pattern to control.

bit5-0: Value of the parameter.

## Word command

Adjust a word-size parameter of a Camera, or status response of it.

**Format:**

“[CMD-GP],[PARAM0],[PARAM1],[PARAM2]\n”

PARAM0: Parameter address

PARAM1-2: Value 16bit

PARAM1: Higher byte

PARAM2: Lower byte

**Relative control:**

PARAM1-2 [0x0000]:Parameter query.

[Others]: Add PARAM1-2 to the current parameter.

**Absolute control:**

Set the parameter to PARAM1-2.

## Other command

Depends on CMD-GP, details are described in the list of commands.

## Rules

### Request and Response

Requests and response correspond loosely.

There is no one to one mapping between requests and responses: “No reply” means “I can’t process such a command”.

Do not send anything if an error has occurred. Errors must be handled the same as “No command”.

Responses from a Camera can be sent to your system anytime without a request from your system. The status of Camera can be changed by itself (Auto iris function, etc.), changed by a camera operator’s hand manually or changed by another control panel connected to the Camera. The Camera sends status changes to all connected controllers.

Your system can ignore any responses not needed by your system.

### When to send

In the case of your system working as a controller for a Camera, your system should send a parameter query that it want to get.

Almost Sony Camera only send status when its status is changed by receiving commands or its function (ex. automatic iris control or etc.).

The status of your system can be updated by receiving status responses from a connected Sony Camera by sending status queries to that Camera (via CNA-1).

In another case, your system works as a Camera among CNS, your system should send commands when its status is changed (must behave like a Sony Camera). The commands must be absolute commands in this case.

If Sony control panels receive no absolute command responses from your system, they cannot update their status and also cannot update the displays.

Therefore, the absolute command responses from your system are necessarily for the control system.

### Permission control (Panel Active control)

CNS supports operating multiple cameras by multiple control panels. In case of using the Panel Assign Function, control panels are assigned to Cameras by a CNS Master device, such as MSU.

The assignment function allows duplicate assignment, meaning one camera can be controlled by two or more control panels. Control conflicts can occur in this case. Therefore, permission control for the Camera is determined by the CNS Master device, using Panel Active command.

If a network system with your system requires permission control, your system should use Panel Active command and your system’s Panel Active state should be controlled by the CNS Master device because CNA-1 behaves in the same way as the Sony Control Panel in RCP-mode.

In a single connection (CNA-1 configured Bridge mode of CNS setting), the permission control is managed by CNA-1 itself.

Permission allows your system to send all available commands. Without permission, your system can send only Status Query commands (Control commands are rejected). Permission control does not regulate receiving commands.

When your system receives permission using Panel Active command, another control panel assigned to the same Camera loses permission.

If your system does not want to affect the permission of another control panel, your system can use Para command instead of Panel Active command. Usage of Para command is the same as Panel Active command. However, permission by Para command does not allow controlling of Iris, Master Black and sending Absolute Word command.

A configuration of CNA-1 “Panel Active Function Enable/Disable” enables this permission control function. If Panel Active Function is enabled, CNA-1 manages Panel Active state and your system can use Panel Active/ Iris Active/ Para commands. If the function is disabled, CNA-1 rejects these commands.

Permission control is not necessarily in the network system. Your system can ignore that and can send command if CNA-1 configured “Panel Active Disable (default)”. However, if a duplicate assignment is set to CNA-1 and another control panel, conflict can occur between other control panels in the no permission control state. Especially, Absolute type commands will certainly conflict, and erratic Camera behavior can occur. For this reason, pay close attention to Absolute type commands

### Panel active command examples:

Get current permission state

Send: “0b,90,01,00\n” => Receive: “0b,XX,01,81\n”

XX is ID of Master device. Value “81” means sender (your system) has No permission

Send: “0b,90,01,00\n” => Receive: “0b,XX,01,82\n”

XX is ID of Master device. Value “82” means sender (your system) has permission to control

Require the permission


Send: “0b,90,01,02\n” => Receive: “0b,XX,01,81\n” or “0b,XX,01,82\n”

Release the permission


Send: “0b,90,01,01\n” => Receive: “0b,XX,01,81” or “0b,XX,01,82\n”

## Appendix


### Example of State Machine diagram for your system



Example of Startup Sequence (your system works as Controller)



## Example of Startup Sequence (your system works as Camera)



# Extended commands of Optional Software

By installing optional software on CNA-1, you can use extensional commands in addition to the standard commands described in the list of commands. To purchase an optional software, consult with qualified Sony personnel.

This chapter describes the extended functions and the specifications of the commands of the optional software HZC-MSCN1 and HZC-RACN1.

## Multi camera control (HZC-MSCN1)

### Abstract

CNA-1 supports Multiple Camera Control by an optional software HZC-MSCN1 that enables “MSU-mode” of Emulation mode. In MSU-mode, CNA-1 works as a Sony MSU in Camera Network System to handle multiple control sessions between CNA-1 and cameras.

A control session is provided by CNA-1 as single TCP/IP session for your system. It is the same session control procedure as RCP-mode.

Multiple camera control methods are provided as “Camera Selection” and “Command Destination Control” by CNA-1 in MSU-mode. Details are described in the next section.




Figure.1 Session abstract of multiple control

### MSU-mode

To enable multiple camera control by CNA-1, CNA-1 has to be configured to MSU-mode that configurable by web configuration menu “CNS” -> “Gateway Configuration” -> “Emulation Mode”.

Device number of CNA-1 is handled as MSU number in the network. The device number has to be set to different number from all MSUs in the network.

### Camera selection

CNA-1 selects a control target camera from connected cameras by receiving a “Camera Select” command from your system.

“Camera Select” command switches the session between CNA-1 and Camera/CCU.




Figure.2 Camera selection

### Command destination control

In principle, CNA-1 controls an only one camera selected by “Camera Select” command. If your system needs to control two or more cameras simultaneously, “Address Selector” command has to be added to a head of control command to control the destination of the command.

A command with “Address Selector” is able to send to unselected Camera/CCU, however, your system cannot receive any responses from unselected Camera/CCU.




Figure.3 Command destination control (Address selection)

## Using commands for multiple camera control

### Camera Select command

Format:

Byte command

“[CMD-GP],[PARAM0],[PARAM1]n”

CMD-GP: 0x60/0x61 (relative/absolute)

PARAM0: 0x02

PARAM1: Camera number 0x00 to 0x60 (decimal 0 to 96)

Relative control:

It means a status query.

A camera number which is currently selected is received by this query.

PARAM1 is ignored and does not affect.

Absolute control:

Select a camera that has PARAM1 camera number.



#### Usage:

Get a current selected camera number  
Send: "60,02,00\n" -> Receive: "61,02,02\n"  
(Your system is selecting a camera 2)  
Select a camera number 12  
"61,02,0c\n" -> Receive: "61,02,0c\n" (Selection success. Your system is selecting a camera 12)

#### Timing and delay specification:

Sending commands after camera selection  
Your system can send camera select command and control commands simultaneously (into a same TCP packet). The control commands will send to selected Camera/CCU immediately.

Receiving commands after camera selection  
Your system has to wait 50msec or more if your system requires responses from Camera/CCU.  
Session switching by "Camera Select" command takes several tens of milliseconds to ready to setup session between CNA-1 and Camera/CCU.

### Address Selector command

#### Format:

Add an attribute to control a command destination.  
"[CMD-GP],[PARAM0],[PARAM1],[COMMAND]\n"  
CMD-GP: 0x6c  
PARAM0: Destination device type  
0x02 Camera (CHU + CCU)  
PARAM1: Destination device number 0x00 to 0x60  
(0 to 96 decimal)  
COMMAND: Control command that your system needs to send.

#### Usage:

Send: "6c,02,02,23,a9,00,00\n" (Clear Master black of Camera 2)  
-> Receive: No response  
"6c,02,02" is an address selector command. This means "Send command to Camera 2"  
"23,a9,00,00" is normal control command  
Send: "6c,02,02,23,a9,00,00\n6c,02,03,23,a9,00,00\n"  
(Clear Master black of Camera 2 and Camera 3 at same time)  
-> Receive: No response


#### Processing commands with address selector arrived from other device in the network

Your system can be received command with "Address Selector" from other devices. If your system receives the commands, your system should decompose that into destination header (Address Selector command) and control command.  
Your system can process the received control commands and also can discard the commands if your system does not need to process.

#### Inter-packet interval limitation

This limitation described on SSCP document is applied each session individually at multiple camera control.  
The packet interval limitation can be ignored if you send commands to different Camera/CCU.

#### Example:



# RCP Assignment control (HZC-RACN1)

## Overview

RCP assignment function is for managing the assignment between RCP and Camera on Sony Camera Network System (CNS). You can get their assignment status and change them. This chapter explains how the SSCP commands work with RCP assignment by showing some concrete examples.




Figure.1

Figure 1 shows the standard configuration of CNS. In this case, there are one MSU as a Master device, two Cameras/CCUs and two RCPs on the CNS. By default, RCP is assigned to the same number of the Camera/CCU which is connected to the CNS. Actually, Camera No. is depended on the CCU No. Following table shows the relationship between RCP and Camera.

RCP Assignment	
RCP No.1	Camera No.1
RCP No.2	Camera No.2

In this assignment, RCP No.1 controls Camera No.1 and receives the status from it. On the other hand, RCP No.2 and Camera No.2 have same relationship.

### Confirm assignment status

You can get the current assignment status by using following SSCP command.

“6d,4e,02,fe,12\n”

- “6d”: Command Group of RCP Assignment
- “4e”: This means 'Request Available RCP status list'
- “02,fe,12”: Fixed value of this command

This command is to get the status list of available RCP which is turned on and is connected to the CNS. Send this command to CNA-1 and you will receive following command as a reply.

“6d,8e,0d,fe,12,02,00,01,fe,01,01,00,02,fe,02,01\n”

- “6d”: Command Group of RCP Assignment
- “8e”: This means reply of 'Request Available RCP status list'
- “0d”: Data length after this parameter
- “fe,12”: Fixed value
- “02”: Number of RCP status info. There are two status info on this command
- “00,01,fe,01,01”: Status info of RCP No.1
- “00,02,fe,02,01”: Status info of RCP No.2

The RCP-01 status of “00,01,fe,01,01” can be interpret as follows.

- “00”: Fixed value
- “01”: RCP No.
- “fe”: Fixed value
- “01”: Camera No. which is assigned to this RCP

“01”: RCP Status which is represented by bit info.  
bit 1: 0 = Assignment is default, 1 = Assignment has been changed  
bit 0: 0 = not Available, 1 = Available

According to this info, you can see that RCP No.1 is assigned to Camera No.1, it's assignment is default value and it is available on the CNS. The status of RCP No.2 can be parsed as well.

### Change RCP assignment

Now, we change the assignment of RCP No.2 to Camera No.1. The result should be as follows.

RCP Assignment	
RCP-01	Camera-01
RCP-02	Camera -01

The SSCP commands to do this is follows.

**“6d,6d,09,fe,12,01,00,02,fe,01,00,00\n”**

“6d”: Command Group of RCP Assignment  
“6d” This means 'Request RCP assignment change'  
“09” Data length after this parameter  
“fe,12”: Fixed value  
“01”: Number of RCP info which you want to change  
“00”: Fixed value  
“02”: RCP No.  
“fe”: Fixed value  
“01”: Camera No. to which you want assign  
“00,00”: Fixed value

Send this command and you will receive RCP-02 status info which was changed as a reply.

**“6d,8d,08,fe,12,01,00,02,fe,01,03\n”**

“6d”: Command Group of RCP Assignment  
“8d”: Reply of 'Request RCP assignment change'  
“08”: Data length after this parameter  
“fe,12”: Fixed value  
“01”: Number of RCP status info. There are one status info on this command  
“00,02,fe,01,03”: Status info of RCP No.2

We already saw how to interpret the status of RCP on the command in previous section.

In this case, RCP No.2 status of “00,02,fe,01,03” is showing that it is assigned to Camera No.1, its assignment has been changed and it is available on the CNS.

So far, we have seen how the SSCP commands work with RCP assignment in some cases. For more information about command's specification, refer the explanation from next chapter.

### RCP Assignment control commands

To control RCP assignment, we provide command group (CMD-GP) of 0x6d. Since RCP assignment is managed in

CNS Master device, you need one Master device in you CNS, and the task of CMD-GP 0x6d is communication with Master device.

Each command in this group is distinguished by PARAM0. Following list shows all commands in CMD-GP 0x6d:

PARAM0	Task of Command
0x48	Request Camera number range info to CNS Master device
0x88	Reply of Camera number range info from CNS Master device
0x49	Request Camera status to CNS Master device
0x89	Reply of Camera status from CNS Master device
0x4a	Request Available Camera status list to CNS Master device
0x8a	Reply of Available Camera status list from CNS Master device
0x4b	Request All Camera status list to CNS Master device
0x8b	Reply of All Camera status list from CNS Master device
0x4c	Request RCP number range info to CNS Master device
0x8c	Reply of RCP number range info from CNS Master device
0x4d	Request RCP status to CNS Master device
0x8d	Reply of RCP status from CNS Master device
0x6d	Request RCP assignment status change to CNS Master device
0x4e	Request Available RCP status list to CNS Master device
0x8e	Reply of Available RCP status list from CNS Master device
0x4f	Request All RCP status list to CNS Master device
0x8f	Reply of All RCP status list from CNS Master device
0xad	Request RCP assignment reset to CNS Master device
0xae	Request All RCP assignment reset to CNS Master device

Commands in CMD-GP 0x6d can be classified in three types.

Type	PARAM0		Task
	Request	Reply	
Commands to get Camera status information	0x48	0x88	Get Camera number range info
	0x49	0x89	Get Camera status info
	0x4a	0x8a	Get Available Camera status info list
	0x4b	0x8b	Get All Camera status info list
Commands to get RCP status information	0x4c	0x8c	Get RCP number range info
	0x4d	0x8d	Get RCP status info
	0x4e	0x8e	Get Available RCP status info list
	0x4f	0x8f	Get All RCP status info list
Commands to change RCP assignment status	0x6d	—	Change RCP assignment status
	0xad	—	Reset RCP assignment status
	0xae	—	Reset all RCP assignment status

## Commands to get Camera status information

There are four kinds of commands to get Camera status information from CNS Master device. Each kind has request command and reply command.

## Commands to get RCP status information

There are four kinds of commands to get RCP status information from CNS Master device. Each kind has request command and reply command.

## Commands to change RCP assignment status

There are three kinds of commands to change RCP assignment status. All kinds only have request command. Reply for these commands is PARAM0: 0x8d which is same as the reply of command "Get RCP status info"

## Commands to get Camera status information

### Get Camera number range info

Type	Format
Request	6d,48,01,fe\n
Reply	6d,88,03,fe,[CAM No. Min],[CAM No. Max]\n

#### Parameters:

CAM No. Min: Minimal value of Camera number, "01"-"60" (1-96 in Decimal)  
CAM No. Max: Maximal value of Camera number, "01"-"60" (1-96 in Decimal)

#### Example:

Send: "6d,48,01,fe\n"  
Receive: "6d,88,03,fe,01,0c\n"

Reply from Master is:

Available Cameras on the CNS has the number in range from 1 to 12.

### Get Camera status info

Type	Format
Request	6d,49,[DLEN],fe,[NUM],[CAM No.]...\n
Reply	6d,89,[DLEN],fe,[NUM],[CAM No.],00,[CAM Status])...\n

#### Parameters:

DLEN: Data length after "[DLEN]"  
"fe": Fixed value. No other value is permitted.  
NUM: Number of parameters on this command.  
when Request, this means number of "[CAM No.]", range is "01"-"33"(1-51 in Decimal)  
when Reply, this means number of "[CAM No.],00,[CAM Status]"  
CAM No.: "01"-"60" (1-96 in Decimal)  
"00": Fixed value. No other value is permitted.  
CAM status: "00" = not Available, "01" = Available  
Camera is recognized as available when it is turned on and is connected to the CNS.

#### Example:

1. Request status of Camera No.1.  
Send: "6d,49,03,fe,01,01\n"

Receive: "6d,89,05,fe,01,01,00,01\n"

Reply from Master is: Camera No.1 is available.

2. Request status of Camera No.1, Camera No.2 and Camera No.4.

Send: "6d,49,05,fe,03,01,02,04\n"

Receive: "6d,89,0b,fe,03,01,00,01,02,00,00,04,00,01\n"

Reply from Master is:

Camera No.1 is available  
Camera No.2 is not available  
Camera No.4 is available

### Get Available Camera status info list

Type	Format
Request	6d,4a,01,fe\n
Reply	6d,8a,[DLEN],fe,[NUM],[CAM No.],00,[CAM Status])...\n

#### Parameters:

DLEN: Data length after "[DLEN]"  
"fe": Fixed value. No other value is permitted.  
NUM: Number of parameters on this command.  
when Reply, this means number of "[CAM No.],00,[CAM Status]"  
CAM No.: "01"-"60" (1-96 in Decimal)  
"00": Fixed value. No other value is permitted.  
CAM status: "00" = not Available, "01" = Available  
Camera is recognized as available when it is turned on and is connected to the CNS.

#### Example:

Send: "6d,4a,01,fe\n"  
Receive: "6d,8a,08,fe,02,01,00,01,04,00,01\n"

Reply from Master is:

There are two cameras available on the CNS, the number of which is 1 and 4.

### Get All Camera status info list

Type	Format
Request	6d,4b,01,fe\n
Reply	6d,8b,[DLEN],fe,[NUM],[CAM No.],00,[CAM Status])...\n

#### Parameters:

DLEN: Data length after "[DLEN]"  
"fe": Fixed value. No other value is permitted.  
NUM: Number of parameters on this command.  
when Reply, this means number of "[CAM No.],00,[CAM Status]"  
CAM No.: "01"-"60" (1-96 in Decimal)  
"00": Fixed value. No other value is permitted.  
CAM status: "00" = not Available, "01" = Available  
Camera is recognized as available when it is turned on and is connected to the CNS.

#### Example:

Send: "6d,4b,01,fe\n"

Receive:

"6d,8b,26,fe,0c,01,00,01,02,00,00,03,00,00,04,00,01,05,00,00,06,00,00,07,00,00,08,00,00,09,00,00,0a,00,00,0b,00,00,0c,00,00\n"

Reply from Master is:

There are 12 Cameras.

Camera No.1 and No.4 are available, and others are not available.

## Commands to get RCP status information

### Get RCP number range info

Type	Format
Request	6d,4c,02,fe,12\n
Reply	6d,8c,06,fe,12,00,[RCP No. Min],00,[RCP No. Max]\n

#### Parameters:

RCP No. Min: Minimal value of RCP number, "01"-"60" (1-96 in Decimal)  
RCP No. Max: Maximal value of RCP number, "01"-"60" (1-96 in Decimal)

#### Example:

Send: "6d,4c,02,fe,12\n"

Receive: "6d,8c,06,fe,12,00,01,00,0c\n"

Reply from Master is:

Available RCP on the CNS has the number in range from 1 to 12.

### Get RCP status info

Type	Format
Request	6d,4d,[DLEN],fe,12,[NUM],(00,[RCP No.])...\n
Reply	6d,8d,[DLEN],fe,12,[NUM],(00,[RCP No.],fe,[CAM No.],[RCP Status])...\n

#### Parameters:

DLEN: Data length after "[DLEN]"  
"fe,12": Fixed value. No other value is permitted.  
NUM: Number of parameters on this command.

when Request, this means number of "00, [RCP No.]", range is "01"-"19" (1-25 in Decimal)

when Reply, this means number of "00,[RCP No.],fe,[CAM No.],[RCP Status]"

"00": Fixed value. No other value is permitted.

RCP No.: "01"-"60" (1-96 in Decimal)

"fe": Fixed value. No other value is permitted.

CAM No.: Camera to which RCP is assigned, "01"-"60" (1-96 in Decimal), "00"=None

RCP status: Status is presented by bit info.  
bit 1: 0 = Assignment is default, 1 = Assignment has been changed  
bit 0: 0 = not Available, 1 = Available  
RCP is recognized as available when it is turned on and is connected to the CNS.

#### Example:

1. Request status of RCP No.1.

Send: "6d,4d,05,fe,12,01,00,01\n"

Receive: "6d,8d,08,fe,12,01,00,01,fe,01,01\n"

Reply from Master is:

RCP No.1 is assigned to Camera No.1, its assignment is default and it is available.

2. Request status of RCP No.1 and RCP No.4.

Send: "6d,4d,07,fe,12,02,00,01,00,04\n"

Receive:

"6d,8d,0d,fe,12,02,00,01,fe,01,01,00,04,fe,01,03\n"

Reply from Master is:

RCP No.1 is assigned to Camera No.1, its assignment is default and it is available.

RCP No.4 is assigned to Camera No.1, its assignment has been changed and it is available.

### Get Available RCP status info list

Type	Format
Request	6d,4e,02,fe,12\n
Reply	6d,8e,[DLEN],fe,12,[NUM],(00,[RCP No.],fe,[CAM No.],[RCP Status])...\n

#### Parameters:

DLEN: Data length after "[DLEN]"  
"fe,12": Fixed value. No other value is permitted.  
NUM: Number of parameters on this command.

when Reply, this means number of "00, [RCP No.],fe,[CAM No.],[RCP Status]"

"00": Fixed value. No other value is permitted.

RCP No.: "01"-"60" (1-96 in Decimal)

"fe": Fixed value. No other value is permitted.

CAM No.: Camera to which RCP is assigned, "01"-"60"

(1-96 in Decimal), "00"=None

RCP status: Status is presented by bit info.

bit 1: 0 = Assignment is default,

1 = Assignment has been changed

bit 0: 0 = not Available, 1 = Available

RCP is recognized as available when it is turned on and is connected to the CNS.

#### Example:

Send: "6d,4e,02,fe,12\n"

Receive:

"6d,8e,0d,fe,12,02,00,01,fe,01,01,00,04,fe,01,03\n"

Reply from Master is:

There are two RCP available in the CNS, the number of which is 1 and 4.

RCP No.1 is assigned to Camera No.1, its assignment is default and it is available.

RCP No.4 is assigned to Camera No.1, its assignment has been changed and it is available.

### Get All RCP status info list

Type	Format
Request	6d,4f,02,fe,12\n
Reply	6d,8f,[DLEN],fe,12,[NUM],(00,[RCP No.],fe,[CAM No.],[RCP Status])...\n

### Parameters:

DLEN:	Data length after "[DLEN]"
"fe,12":	Fixed value. No other value is permitted.
NUM:	Number of parameters on this command.
	when Reply, this means number of "00, [RCP No.],fe,[CAM No.],[RCP Status]"
"00":	Fixed value
RCP No.:	"01"-"60" (1-96 in Decimal)
"fe":	Fixed value. No other value is permitted.
CAM No.:	Camera to which RCP is assigned, "01"-"60"
	(1-96 in Decimal), "00"=None
RCP status:	Status is presented by bit info.
	bit 1: 0 = Assignment is default, 1 = Assignment has been changed
	bit 0: 0 = not Available, 1 = Available
	RCP is recognized as available when it is turned on and is connected to the CNS.

**Example:**

```
Send: "6d,4f,02,fe,12\n"
Receive:
    "6d,8f,30,fe,12,09,00,01,fe,01,01,00,02,fe,00,00,00,
    03,fe,00,00,00,04,fe,04,01,00,05,fe,00,00,00,06,fe,0
    0,00,00,07,fe,00,00,00,08,fe,00,00,00,09,fe,00,00\n"
    "6d,8f,12,fe,12,03,00,0a,fe,00,00,00,0b,fe,00,00,00,
    0c,fe,00,00\n"
```

Two commands are sent from Master device because total length of the reply info is over the limitation of command length, 168 characters.

Reply from Master is:  
 There are 12 RCPs.  
 RCP No.1 is assigned to Camera No.1, its assignment is default and it is available.  
 RCP No.4 is assigned to Camera No.1, its assignment has been changed and it is available.  
 Other RCPs, their number are other than 1 and 4, are assigned to none of Camera and are not available.

## Commands to change RCP assignment status

## Change RCP assignment status

Type	Format
Request	6d,6d,[DLEN],fe,12,[NUM],(00,[RCP No.],fe,[CAM No.],00,00)... n
Reply	same as reply of “Get RCP status info”

### Parameters:

DLEN:	Data length after “[DLEN]”
“fe,12”:	Fixed value. No other value is permitted.
NUM:	Number of parameters on this command.
	“01”-“08” (1-8 in Decimal)
	when Request, this means number of
	“00,
	[RCP No.],fe,[CAM No.],00,00”
“00”:	Fixed value. No other value is permitted.
RCP No.:	“01”-“60” (1-96 in Decimal)

"fe":	Fixed value. No other value is permitted.
CAM No.:	Camera to which you want to assign, "01"-"60" (1-96 in Decimal), "00"=None
"00.00":	Fixed value. No other value is permitted.

**Example:**

1. change assign of RCP No.1 to Camera No.4  
Send: "6d,6d,09,fe,12,01,00,01,fe,04,00,00\n"  
Receive: "6d,8d,08,fe,12,01,00,01,fe,04,03\n"  
Reply from Master is:  
RCP No.1 is assigned to Camera No.4, its assignment has been changed and it is available.
2. change assignment of RCP No.1 to Camera No.4, and assignment of RCP No.4 to Camera No.1  
Send:  
"6d,6d,0f,fe,12,02,00,01,fe,04,00,00,00,04,fe,01,00,00\n"  
Receive:  
"6d,8d,0d,fe,12,02,00,01,fe,04,03,00,04,fe,01,03\n"  
Reply from Master is:  
RCP No.1 is assigned to Camera No.4, its assignment has been changed and it is available.  
RCP No.4 is assigned to Camera No.1, its assignment has been changed, and it is available.

## Reset RCP assignment status

Type	Format
Request	6d,ad,[DLEN],fe,12,[NUM],[00,[RCP No.]]...\n
Reply	same as reply of "Get RCP status info" (Reply contains RCP status info of which assignment has been changed)

### Parameters:

DLEN:	Data length after “[DLEN]”
“fe,12”:	Fixed value. No other value is permitted.
NUM:	Number of parameters on this command. “01”-“19” (1-25 in Decimal) when Request, this means number of “00, [RCP No.]”
“00”:	Fixed value. No other value is permitted.
RCP No.:	“01”-“60” (1-96 in Decimal)

**Example:**

1. reset assignment of RCP No.1  
Send: "6d,ad,05,fe,12,01,00,01\n"  
Receive: "6d,8d,08,fe,12,01,00,01,fe,01,01\n"  
Reply from Master is:  
RCP No.1 is assigned to Camera No.1, its assignment is default and it is available.
2. reset assignment of RCP No.1 and RCP No.4  
Send: "6d,ad,07,fe,12,02,00,01,00,04\n"  
Receive:  
"6d,8d,0d,fe,12,02,00,01,fe,01,01,00,04,fe,04,01\n"  
Reply from Master is:  
RCP No.1 is assigned to Camera No.1, its assignment is default and it is available.  
RCP No.4 is assigned to Camera No.4, its assignment is default and it is available.

## Reset All RCP assignment status

Type	Format
Request	6d,ae,02,fe,12\n
Reply	same as reply of "Get RCP status info" (Reply contains RCP status info of which assignment has been changed)

### Parameters:

None

### Example:

When RCP No.1 is assigned to Camera No.1, and RCP No.4 is assigned to Camera No.1.

Send: "6d,ae,02,fe,12\n"

Receive: "6d,8d,08,fe,12,01,00,04,fe,04,01\n"

Reply from Master is:

RCP No.4 is assigned to Camera No.4, its assignment is default and it is available.

The status of RCP No.1 isn't included in the reply command because its assignment is already default and hasn't been changed.

# List of available commands

Command							Usage
Command Category	Command Type	Command Name	CMD_GP (Relative/Absolute)	PARAM0	PARAM1	PARAM2	
System Control	Bit command	tally	0x08	0x20	TALLY_DATA	–	* Receive only When Sony CCU inputs a Tally signal via External I/O, The CCU sends the tally command to CNA-1 TALLY_DATA= bit0 Red bit1 Green bit2 Yellow
	Other command	call	0x0b	SENDER_SRCID	0x00	CALL VALUE	SENDER_SRCID= 0x90 when your system works as Controller 0x20 when your system works as Camera CALL VALUE= 0x80 current status query 0x81 Call off 0x82 Call on (two seconds)
		panel_active	0x0b	SENDER_SRCID	0x01	CONTROL VALUE	SENDER_SRCID= 0x90 CONTROL VALUE= 0x00 Current active status query 0x01 Active-off (release own control to Camera) 0x02 Active-on (get control to Camera) 0x81 Active-off status reply 0x82 Active-on status reply *This command is available in condition of Panel Active Function of CNA-1 is enabled (default is disable).
		iris_active	0x0b	SENDER_SRCID	0x02	CONTROL VALUE	Same as panel_active command but this command affects only Iris and MasterBlack control.
		para	0x0b	SENDER_SRCID	0x03	CONTROL VALUE	Same as panel_active command but this command does not affect permission of another control panel (parallel control can be used). * Iris, Master Black, all absolute word commands are not allowed in the permission received by this command.



Command							Usage
Command Category	Command Type	Command Name	CMD_GP (Relative/Absolute)	PARAM0	PARAM1	PARAM2	
CHU Function Control	Inc/Dec command	shutter_speed	0x20/0x21	0x00	INC/DEC value	–	Bit5-0 00: 1/60 01: 1/100 02: 1/125 03: 1/250 04: 1/500 05: 1/1000 06: 1/2000 07: 1/3000 08: 1/4000 09: 1/5000 0A: 1/10000 0B: 1/32 0C: 1/33 0D: 1/40 0E: 1/48 0F: 1/50 10: 1/96 11: 1/120
		master_gain		0x01	INC/DEC value	–	Bit5-0 00: -6dB 01: -3dB 02: 0dB 03: 3dB 04: 6dB 05: 9dB 06: 12dB 07: 15dB 08: 18dB 09: 21dB 0A: 24dB 0B: 27dB 0C: 30dB 0D: 33dB 0E: 36dB 0F: 39dB 10: 42dB 11: 45dB 12: 48dB 13: 51dB 14: 54dB 15: 57dB 16: 60dB
		nd_filter		0x03	INC/DEC value	–	Bit5-0 00: Filter 1-1 (ND 1) 01: Filter 1-2 (ND 2) 02: Filter 1-3 (ND 3) 03: Filter 1-4 (ND 4) 04: Filter 1-5 (ND 5)
		cc_filter		0x04	INC/DEC value	–	Bit5-0 00: Filter 2-1 (CC A) 01: Filter 2-2 (CC B) 02: Filter 2-3 (CC C) 03: Filter 2-4 (CC D) 04: Filter 2-5 (CC E)

Command							Usage
Command Category	Command Type	Command Name	CMD_GP (Relative/Absolute)	PARAM0	PARAM1	PARAM2	
CHU Function Control	Inc/Dec command	master_gamma_select	0x20/0x21	0x06	INC/DEC value	–	Bit5-0 00: 1 01: 0.95 02: 0.90 03: 0.85 04: 0.80 05: 0.75 06: 0.70 07: 0.65 08: 0.60 09: 0.55 0A: 0.50 0B: 0.45 0C: 0.40 0D: 0.35 0E: 0.30 0F: 0.25 10: 0.20 11: 0.15 12: 0.10
		mic1_gain_select		0x08	INC/DEC value	–	Bit5-0 1C: -60dB 1D: -50dB 1E: -40dB 1F: -30dB 20: -20dB
		mic2_gain_select		0x09	INC/DEC value	–	Bit5-0 1C: -60dB 1D: -50dB 1E: -40dB 1F: -30dB 20: -20dB
		auto_iris_window_select		0x0a	INC/DEC value	–	Bit5-0 00: Cutting the top end 01: Cutting the top, bottom, left and right ends 02: Cutting the left and right ends 03: Cutting uniformly 04: Cutting the top, left and right ends 05: Cutting the bottom end 06: Variable-Window
		preset_mtx_select		0x0d	INC/DEC value	–	Bit5-0 00: Default 01: SMPTE-240M 02: REC-709 03: SMPTE-WIDE 04: NTSC 05: EBU
		standard_gamma_table_mode		0x13	INC/DEC value	–	Bit5-0 00: Standard 01: Special 1 02: Special 2 03: User
		standard_gamma_select		0x14	INC/DEC value	–	
		special_gamma_select		0x15	INC/DEC value	–	

Command							Usage
Command Category	Command Type	Command Name	CMD_GP (Relative/Absolute)	PARAM0	PARAM1	PARAM2	
CHU Function Control	Inc/Dec command	hyper_gamma_select	0x20/0x21	0x16	INC/DEC value	–	
		user_gamma_select		0x17	INC/DEC value	–	
		blk_gamma_RGB_low_range		0x18	INC/DEC value	–	Bit5-0 00: Low Range 01: Lower Middle Range 02: Higher Middle Range 03: High Range
		low_key_sat_low_range		0x1d	INC/DEC value	–	Bit5-0 00: Low Range 01: Lower Middle Range 02: Higher Middle Range 03: High Range
		sls_select	0x20/0x21	0x20	INC/DEC value	–	Bit5-0 00: 1F 01: 2F 02: 3F 03: 4F 04: 5F 05: 6F 06: 7F 07: 8F 08: 11F 09: 12F 0A: 15F 0B: 16F 0C: 22F 0D: 24F 0E: 25F 0F: 30F 10: 32F 11: 45F 12: 48F 13: 50F 14: 60F 15: 64F 16: 90F 17: 96F 18: 100F 19: 120F 1A: 128F 1B: 180F 1C: 192F 1D: 200F 1E: 240F 1F: 256F

Command							Usage
Command Category	Command Type	Command Name	CMD_GP (Relative/Absolute)	PARAM0	PARAM1	PARAM2	
CHU Function Control	Inc/Dec command	acg_max_gain	0x20/0x21	0x21	INC/DEC value	–	Bit5-0 00: -6dB 01: -3dB 02: 0dB 03: 3dB 04: 6dB 05: 9dB 06: 12dB 07: 15dB 08: 18dB 09: 21dB 0A: 24dB 0B: 27dB 0C: 30dB 0D: 33dB 0E: 36dB 0F: 39dB 10: 42dB 11: 45dB 12: 48dB 13: 51dB 14: 54dB 15: 57dB 16: 60dB
		digital_extender		0x27	INC/DEC value	–	Bit5-0 00: x1.0 (OFF) 01: x1.5 02: x2.0 03: x2.5 04: x3.0 05: x3.5 06: x4.0 07: x4.5 08: x5.0 09: x5.5 0A: x6.0 0B: x6.5 0C: x7.0 0D: x7.5 0E: x8.0
		flicker_reduce_area_select		0x28	INC/DEC value	–	* Only for HDC3300.
		compensation		0x29	INC/DEC value	–	

Command							Usage
Command Category	Command Type	Command Name	CMD_GP (Relative/Absolute)	PARAM0	PARAM1	PARAM2	
CHU Function Control	Inc/Dec command	ns_level_mode	0x20/0x21	0x2a	INC/DEC value	—	Bit5-0 00: 0% (OFF) 01: 5% 02: 10% 03: 15% 04: 20% 05: 25% 06: 30% 07: 35% 08: 40% 09: 45% 0A: 50% 0B: 55% 0C: 60% 0D: 65% 0E: 70% 0F: 75% 10: 80% 11: 85% 12: 90% 13: 95% 14: 100%
		flicker_reduce_ave_mode		0x2d	INC/DEC value	—	* Only for HDC3300.
		3D_camera_select		0x2e	LEFT/RIGHT/BOTH	—	LEFT=0x00, RIGHT=0x01. BOTH=0x02 *Only for HDFA-200
	Bit command	chu_function_01		0x81	ON/OFF bit value	—	Bit 7: Knee Saturation 6: Auto Knee 5: Knee 4: Gamma 3: Flare 2: S-EVS 1: ECS 0: Shutter
		chu_function_02		0x82	ON/OFF bit value	—	Bit 7: Detail Level Depend 6: Detail 5: User Matrix 4: Preset Matrix 3: V Mod Saw 2: Black Gamma 1: White Clip 0: Knee Aperture
		chu_function_03		0x83	ON/OFF bit value	—	Bit 7: Slim Detail 6: Multi Matrix 5: N/A 4: Matrix 3: Auto Iris 2: Skin Gate 1: Skin Detail 0: Iris Close
		chu_function_04		0x84	ON/OFF bit value	—	Bit 7: N/A 6: ATW 5-0: N/A

Command							Usage
Command Category	Command Type	Command Name	CMD_GP (Relative/Absolute)	PARAM0	PARAM1	PARAM2	
CHU Function Control	Bit command	chu_system_mode	0x20/0x21	0x85	ON/OFF bit value	–	Bit 7: CHU Saturation Enable * If your system (works as Camera) has Saturation control function, your system should send this command with bit7=1 to Sony Control Panel.  6: ECS Display Type 5-2: N/A 1: SD/HD 0: NTSC/PAL
		test_signal_select		0x86	ON/OFF bit value	–	Bit 7: CHU Bars 6-3: N/A 2: Test3 10 step 1: Test2 3 or 10 step 0: Test1 Saw
		chu_function_05		0x87	ON/OFF bit value	–	Bit 7-6: N/A 5: N/A 4: Knee Max 3: N/A 2: 5600K 1: N/A 0: Filter Remote/Local Select  * If your system's filter can be controlled remotely, your system should send this command with bit0 = 0 (Filter Remote) to Sony Control Panel.
		chu_function_06		0x89	ON/OFF bit value	–	Bit 7-5: N/A 4: Slow Shutter 3-0: N/A
		chu_function_07		0x8b	ON/OFF bit value	–	Bit 7: N/A 6: Flicker Reduction 5-1: N/A 0: Low Key Matrix
		skin_detail_ch		0x8d	ON/OFF bit value	–	Bit 7-4: N/A 3: Natural Skin Detail 2: CHU Skin Detail CH3 1: CHU Skin Detail CH2 0: CHU Skin Detail CH1
		skin_detail_gate_ch		0x8e	ON/OFF bit value	–	Bit 7-3: N/A 2: CHU Skin Gate CH3 1: CHU Skin Gate CH2 0: CHU Skin Gate CH1
		chu_function_08		0x94	ON/OFF bit value	–	Bit 7-6: N/A 5: Select FPS 4-3: N/A 2: Zoom/Focus Remote On 1: N/A 0: Saturation

Command							Usage
Command Category	Command Type	Command Name	CMD_GP (Relative/Absolute)	PARAM0	PARAM1	PARAM2	
CHU Function Control	Bit command	flicker_reduction_power_frequency	0x20/0x21	0x99	ON/OFF bit value	–	Bit 7-1: N/A 0: 50Hz=0, 60Hz=1
		chu_mode_sw00		0xa0	ON/OFF bit value	–	Bit 7: Adaptive Matrix 6-0: N/A
		chu_mode_sw01		0xa1	ON/OFF bit value	–	Bit 7: N/A 6: Auto ND ON 5: AE ON 4: AGC ON 3: EVS Iris Follow ON 2: Auto Iris Double Mode 1: Filter Local Enable 0: Iris Position Mode
		chu_mode_sw02		0xa2	ON/OFF bit value	–	Bit 7-2: N/A 1: Adaptive Knee Mode 0: N/A
		chu_mode_sw03		0xa3	ON/OFF bit value	–	Bit 7-4: N/A 3: Noise Suppression 2-0: N/A
		chu_mode_sw04		0xa4	ON/OFF bit value	–	Bit 7-2: N/A 1: V Detail Source Mode 0: Freq 1001/1000 1001=0 , 1000=1
				0xc2	ON/OFF bit value	–	Bit 7: N/A 6: SD Detail 5-0: N/A
	Word command	white_R	0x22/0x23	0x01	value H	value L	Effective size = 10bits
		white_G		0x02	value H	value L	
		white_B		0x03	value H	value L	
		master_mod_shd_v_saw		0x04	value H	value L	
		mod_shd_v_saw_R		0x05	value H	value L	
		mod_shd_v_saw_G		0x06	value H	value L	
		mod_shd_v_saw_B		0x07	value H	value L	
		master_flare		0x08	value H	value L	
		flare_R		0x09	value H	value L	
		flare_G		0x0a	value H	value L	
		flare_B		0x0b	value H	value L	
		detail_limiter		0x0c	value H	value L	
		detail_white_limiter		0x0d	value H	value L	

Command							Usage
Command Category	Command Type	Command Name	CMD_GP (Relative/Absolute)	PARAM0	PARAM1	PARAM2	
CHU Function Control	Word command	detail_black_limiter	0x22/0x23	0x0e	value H	value L	Effective size = 10bits
		master_black_gamma		0x10	value H	value L	
		black_gamma_R		0x11	value H	value L	
		black_gamma_G		0x12	value H	value L	
		black_gamma_B		0x13	value H	value L	
		master_knee_point		0x14	value H	value L	
		knee_point_R		0x15	value H	value L	
		knee_point_G		0x16	value H	value L	
		knee_point_B		0x17	value H	value L	
		master_knee_slope		0x18	value H	value L	
		knee_slope_R		0x19	value H	value L	
		knee_slope_G		0x1a	value H	value L	
		knee_slope_B		0x1b	value H	value L	
		master_gamma		0x1c	value H	value L	
		gamma_R		0x1d	value H	value L	
		gamma_G		0x1e	value H	value L	
		gamma_B		0x1f	value H	value L	
		master_white_clip		0x20	value H	value L	
		white_clip_R		0x21	value H	value L	
		white_clip_G		0x22	value H	value L	
		white_clip_B		0x23	value H	value L	
		flicker_reduce_gain_m		0x24	value H	value L	
		flicker_reduce_ofs_m		0x28	value H	value L	
		ecs_frequency		0x41	value H	value L	
		evs_data		0x42	value H	value L	
		skin_detail_phase		0x43	value H	value L	



Command							Usage
Command Category	Command Type	Command Name	CMD_GP (Relative/Absolute)	PARAM0	PARAM1	PARAM2	
CHU Function Control	Word command	skin_detail_width	0x22/0x23	0x44	value H	value L	Effective size = 10bits
		chu_optical_level		0x47	value H	value L	Effective size = 15bits unsigned
		skin_detail2_phase		0x54	value H	value L	Effective size = 10bits
		skin_detail2_width		0x55	value H	value L	
		skin_detail3_phase		0x56	value H	value L	
		skin_detail3_width		0x57	value H	value L	
		iris		0x60	value H	value L	Effective size = 12bits unsigned
		acg_f_value		0x71	value H	value L	Effective size = 12bits unsigned
		ae_max_freq_setting		0x72	value H	value L	Effective size = 10bits
		ae_f_value		0x73	value H	value L	Effective size = 12bits unsigned
		focus_control		0x76	value H	value L	Effective size = 16bits
		focus_value_percent		0x77	value H	value L	Effective size = 16bits
		focus_value_meter		0x78	value H	value L	Effective size = 16bits
		zoom_control		0x79	value H	value L	Effective size = 16bits
		zoom_speed_control		0x7a	value H	value L	Effective size = 16bits
		zoom_value_percent		0x7b	value H	value L	Effective size = 16bits
		zoom_value_milimeter		0x7c	value H	value L	Effective size = 16bits
		detail_level		0x9b	value H	value L	Effective size = 10bits
		detail_crispening		0x9c	value H	value L	
		detail_mix_ratio		0x9d	value H	value L	
		detail_HV_ratio		0x9e	value H	value L	
		H_detail_HL_ratio		0x9f	value H	value L	
		detail_level_depend		0xa0	value H	value L	
		skin_detail_level		0xa1	value H	value L	
		skin_detail_sat		0xa2	value H	value L	

Command							Usage
Command Category	Command Type	Command Name	CMD_GP (Relative/Absolute)	PARAM0	PARAM1	PARAM2	
CHU Function Control	Word command	matrix_GR_R	0x22/0x23	0xa3	value H	value L	Effective size = 10bits
		matrix_BR_R		0xa4	value H	value L	
		matrix_RG_G		0xa5	value H	value L	
		matrix_BG_G		0xa6	value H	value L	
		matrix_RB_B		0xa7	value H	value L	
		matrix_GB_B		0xa8	value H	value L	
		master_black		0xa9	value H	value L	Effective size = 12bits signed
		black_R		0xaa	value H	value L	Effective size = 10bits
		black_G		0xab	value H	value L	
		black_B		0xac	value H	value L	
		knee_sat_slope		0xae	value H	value L	
		knee_aperture		0xaf	value H	value L	
		comb_filter		0xb0	value H	value L	
		low_key_clip_level		0xb7	value H	value L	
		adaptive_knee_point		0xc4	value H	value L	
		adaptive_knee_slope		0xc5	value H	value L	
		slim_detail		0xc6	value H	value L	
		skin_detail2_level		0xc7	value H	value L	
		skin_detail2_sat		0xc8	value H	value L	
		skin_detail3_level		0xc9	value H	value L	
		skin_detail3_sat		0xca	value H	value L	
		chu_saturation		0xd2	value H	value L	
		white_color_temp_ctrl		0xdc	value H	value L	
		chu_color_temp_balance		0xde	value H	value L	
		select_fps		0xdf	value H	value L	
		SD_detail_level		0xe0	value H	value L	
		SD_detail_crispening		0xe1	value H	value L	

Command							Usage
Command Category	Command Type	Command Name	CMD_GP (Relative/Absolute)	PARAM0	PARAM1	PARAM2	
CHU Function Control	Word command	SD_detail_H/V_ratio	0x22/0x23	0xe2	value H	value L	Effective size = 10bits
		SD_detail_limiter		0xe3	value H	value L	
		SD_detail_white_limiter		0xe4	value H	value L	
		SD_detail_black_limiter		0xe5	value H	value L	
		SD_detail_frequency		0xe6	value H	value L	
		SD_detail_level_depend		0xe7	value H	value L	
		SD_detail_detail_comb		0xeb	value H	value L	
		master_white_gain		0xf2	value H	value L	
CHU AutoSetup Control	Other command	auto_setup	0x25	TYPE	EXECUTE / STATUS	–	TYPE 0x00: Status query 0x01: Auto White Balance 0x02: Auto Black Balance 0x03: Auto Level 0x07: Skin Detail Auto Hue(CH1) 0x0A: Skin Detail Auto Hue(CH2) 0x0B: Skin Detail Auto Hue(CH3) EXECUTE / STATUS 0x00: Status query 0x01: Start 0x02: Break 0x03: OK 0x04: NG 0x05: Under execution 0x06: Standby 0x07: Cancel Standby 0x08: Reset Status 0x09: Busy
CHU Scene FileControl	Other command	scene_file_control	0x27	EXECUTE / STATUS	0x03	FILE_NO	EXECUTE / STATUS 0x00: Canceling the operation (Cancel) 0x01: Initialization (Formatting) 0x02: Calling 0x03: Saving 0x04: Erasing 0x05: Canceling the call 0x06: Status request 0x07: File call in progress 0x08: This file contains data that is not called 0x09: There is a file but no data 0x0a: The corresponding file does not exist 0x0b: Transmission of number of files 0x0c: File operation is not possible at present. Or, this command was transmitted while file operation was not possible for some reason. FILE_NO 1-32 (Decimal)

Command							Usage
Command Category	Command Type	Command Name	CMD_GP (Relative/Absolute)	PARAM0	PARAM1	PARAM2	
Utility	Other command	chu_switch_with_mask	0x29	SW_ADDR	SW_DATA	MASK_DATA	Only absolute control. This command helps you to send Bit-type command absolutely. PARAM0-1 are same as an absolute Bit command. PARAM2 is masking datum for PARAM1. Each bit of PARAM1 is enabled when PARAM2 bit set to 1.
CCU Function Control	Bit command	ccu_function 00	0x40/0x41	0x10	ON/OFF bit value	–	Bit 7: N/A 6: CCU Skin Gate 5-2: N/A 1: Chroma 0: CCU Bars
		ccu_function 01		0x12	ON/OFF bit value	–	Bit 7-3: N/A 2: Mono 1-0: N/A
		preview_control		0x31	ON/OFF bit value	–	Bit 7-1: N/A 0: Preview
	Inc/Dec command	SD_letter_box_mode		0x40	INC/DEC value	–	Bit5-0 00: 16:9 01: 15:9 02: 14:9 03: 13:9 04: 12:9
	Bit command	SD_function 02		0xc2	ON/OFF bit value	–	Bit 7: N/A 6: SD Detail 5: SD User Matrix 4: SD Preset Matrix 3-0: N/A
		SD_function 03		0xc3	ON/OFF bit value	–	Bit 7: N/A 6: SD Multi Matrix 5: N/A 4: SD Matrix 3-0: N/A
		crop_control		0xe0	ON/OFF bit value	–	Bit 7-4: N/A 3: HD 16:9 squeeze 2: HD Letter Box 1: HD 4:3 Edge Crop 0: HD Crop Center Lock

Command							Usage
Command Category	Command Type	Command Name	CMD_GP (Relative/Absolute)	PARAM0	PARAM1	PARAM2	
CCU Function Control	Word command	mono_saturation	0x42/0x43	0x07	value H	value L	Effective size = 10bits
		mono_hue		0x08	value H	value L	
		crop_position		0x70	value H	value L	
		SD_detail_limiter		0x8c	value H	value L	
		SD_detail_white_limiter		0x8d	value H	value L	
		SD_detail_black_limiter		0x8e	value H	value L	
		SD_master_gamma		0x9c	value H	value L	
		SD_matrix_GR_R		0xa3	value H	value L	
		SD_matrix_BR_R		0xa4	value H	value L	
		SD_matrix_RG_G		0xa5	value H	value L	
		SD_matrix_BG_G		0xa6	value H	value L	
		SD_matrix_RB_B		0xa7	value H	value L	
		SD_matrix_GB_B		0xa8	value H	value L	
		SD_detail_comb		0xb0	value H	value L	
		SD_detail_level		0xdb	value H	value L	
		SD_detail_crispening		0xdc	value H	value L	
		SD_detail_HV_ratio		0xde	value H	value L	
		SD_detail_frequency		0xdf	value H	value L	
		SD_detail_level_depend		0xe0	value H	value L	
		optical_level		0xf0	value H	value L	Effective size = 15bits unsigned
Utility	Other command	ccu_switch_with_mask	0x49	SW_ADDR	SW_DATA	MASK_DATA	Same as chu_switch_with_mask
System Control	Byte Command	camera_select	0x60/0x61	0x02	CAMERA NO.	—	CAMERA NO. = 1-96 (Decimal) * Available if HZC-MSCN1 optional software is installed
		camera_number	0x60/0x61	0x0a	CAMERA NO.	—	CAMERA NO. = 1-96 (Decimal) * Status Query only
	Other command	address_selector	0x6c	0x02	DESTINATION	COMMAND	DESTINATION = 1-96 (Decimal) COMMAND = Variable length of command * Available if HZC-MSCN1 optional software is installed

Command							Usage
Command Category	Command Type	Command Name	CMD_GP (Relative/ Absolute)	PARAM0	PARAM1	PARAM2	
RCP Assignment control	Other command	request_camera_number_range_info	0x6d	0x48	COMMAND		COMMAND = Variable length of command * Available if HZC-RACN1 optional software is installed
		reply_of_camera_number_range_info		0x88	COMMAND		
		request_camera_status		0x49	COMMAND		
		reply_of_camera_status		0x89	COMMAND		
		request_available_camera_status_list		0x4a	COMMAND		
		reply_of_available_camera_status_list		0x8a	COMMAND		
		request_all_camera_status_list		0x4b	COMMAND		
		reply_of_all_camera_status_list		0x8b	COMMAND		
		request_rcp_number_range_info		0x4c	COMMAND		
		reply_of_rcp_number_range_info		0x8c	COMMAND		
		request_rcp_status		0x4d	COMMAND		
		reply_of_rcp_status		0x8d	COMMAND		
		request_rcp_assignment_status_change		0x6d	COMMAND		
		request_available_rcp_status_list		0x4e	COMMAND		
		reply_of_available_rcp_status_list		0x8e	COMMAND		
		request_all_rcp_status_list		0x4f	COMMAND		

Command							Usage
Command Category	Command Type	Command Name	CMD_GP (Relative/ Absolute)	PARAM0	PARAM1	PARAM2	
RCP Assignment control	Other command	reply_of_all_rcp_status_list	0x6d	0x8f	COMMAND		COMMAND = Variable length of command * Available if HZC-RACN1 optional software is installed
		request_rcp_assignment_reset		0xad	COMMAND		
		request_all_rcp_assignment_reset		0xae	COMMAND		

## Format list

\* If your system works as Camera that need to display a Sutter value on Sony Control Panel, your system must send Format value with these commands in advance.

Video Format	chu_mode04 (0xa4)	format_mode (0x91)						chu_system_mode (0x85)		
	bit0	bit5	bit4	bit3	bit2	bit1	bit0	bit6	bit1	bit0
1035/59.94I	0	*	*	*	*	*	*	0	1	0
1035/60I	1	*	*	*	*	*	*	0	1	0
PAL	*	*	*	*	*	*	*	0	0	1
NTSC	*	*	*	*	*	*	*	0	0	0
NTSC 29.97P	0	0	1	0	0	0	0	1	0	0
NTSC 23.98P	0	0	1	0	0	1	0	1	0	0
NTSC 59.94I	0	0	0	0	0	0	0	1	0	0
PAL 50I	1	0	0	0	0	0	1	1	0	1
PAL 25P	1	0	1	0	0	0	1	1	0	1
1080/60I	1	0	0	0	0	0	0	1	1	0
1080/59.94I	0	0	0	0	0	0	0	1	1	0
1080/30P	1	0	1	0	0	0	0	1	1	0
1080/29.97P	0	0	1	0	0	0	0	1	1	0
1080/50I	1	0	0	0	0	0	1	1	1	0
1080/25P	1	0	1	0	0	0	1	1	1	0
1080/24P	1	0	1	0	0	1	0	1	1	0
1080/23.98P	0	0	1	0	0	1	0	1	1	0
1080/60P	1	0	1	0	1	0	0	1	1	0
1080/59.94P	0	0	1	0	1	0	0	1	1	0
1080/50P	1	0	1	0	1	0	1	1	1	0

