

BellaBox 1000

Smith-Victor - WARRANTY -

Smith-Victor warrants to the first commercial owner of the BellaBox to be free from defects in the material and workmanship for a period of one (1) year from the date of purchase and will repair or replace product found to be defective under normal use. Warranty does not cover damage caused by shipment, by product abuse, accident, modification, disassembly or use beyond intended use specified by Smith-Victor. The BellaBox used with nonstandard Smith-Victor electrical accessories will render this warranty immediately void.

This warranty is the only warranty made to any person by Smith-Victor and is in lieu of all other expressed or implied warranties. The remedies set forth in this warranty shall be the exclusive remedies available to any person for breach of this warranty. Under no circumstances shall Smith-Victor be liable to any person for incidental or consequential damages, whether arising out of breach of warranty or other contract, negligence, strict liability or other tort or otherwise.

Smith-Victor • Photogenic • Dot Line
Quantum • Radiopopper • Photoflex • Cool-Lux
Speedotron • Norman • Logan

Smith-Victor is a division of PromarkBRANDS

1268 Humbracht Circle, Bartlett, IL 60103 U.S.A.

800-348-9862 or 630-830-9200

sales@smithvictor.com | www.smithvictor.com
www.promarkbrands.com



999589 Manual for 401377 BellaBox 1000_1-2018



BellaBox 1000

User Manual



Two Light Kit

Model: BellaBox 1000

Item: 401377

Two Light 1000W LED Daylight Softbox Kit

BellaBox 1000 is the complete light source for beautiful portrait photography and video.



Featuring

LED Bulb
Model: LED60
Item: 401901



Optional Accessory

Bluetooth LED Bulb
Model: SmartLED50
Item: 401625



What's in the Box

BellaBox 1000



Two Light Kit

Model: BellaBox 1000

Item: 401377

Kit includes:

- (2) Quick-Folding 20" x 20" Softboxes
- (2) Sockets with Power Cords
- (2) LED 60W Bulb (500W equivalent each)
- (2) Diffusers
- (2) 6' Light Stands
- (1) Padded Carry/Storage Case

SAFETY WARNING PRECAUTIONS:

- Do NOT plug the unit into an electric socket until the softbox is fully assembled and LED bulbs are in place. Failure to observe this warning could result in electric shock, injury or even death.
- Appliance must only be used with rated voltage and frequency of 100-250V 50/60Hz.
- Avoid unplugging the power by pulling the power cord. Do not touch the power cord with wet hands.
- Never attempt to insert any metal objects into the cooling slots of the lamp.
- Avoid moving the softbox and stand by pulling the power cable.
- Stop usage if the unit has been damaged, especially to the power cord or socket.
- Do not expose to moisture.
- Indoor use only.
- In the event service is needed, contact Smith-Victor.

Set Up of the Kit Components



1- To open BellaBox, use the floor as a support.



2- Center the "O" ring over the bulb socket.



3- Push down until ring locks in place. When "O" ring snaps into place, secure the softbox to the stand by tightening the thumb screw on the stand mount until it is firmly attached to the stand.



4- Mount softbox on stand and screw in LED bulb. Be careful not to cross thread the lamp and the socket.



5- Attach front diffusion panel by sliding black edge of the panel over the outside edge of the softbox until it is secured on all sides. Adjust angle as desired by loosening and tightening the thumbscrew at the base of the softbox.