GEAR | ARTISTS | HISTORY | BLOG | SUPPORT | FIND DEALER | STORE | ORANGE ESSENTIALS | ORANGE LEARN

Q

WELCOME TO ORANGE

Thank you for choosing Orange.

Since 1968, when the company was founded, Orange Amplification has been researched and developed by the guitarist for the guitarist. Today, with a team of the industry's most dedicated engineers, it continues to test the boundaries of conventional pedal design to bring you the latest range of effects.

Orange's commitment to quality control, construction and craftsmanship is long established, and each pedal design passes through a rigorous test procedure before shipping, resulting in complete confidence that you will be delighted with your new purchase, and that it will provide you many years of enjoyment and reliability.

This web page contains valuable technical and safety information. Please take the time to read these instructions and warnings, as the information will enhance the performance and longevity of your pedal.

IMPORTANT SAFETY INSTRUCTIONS (CLICK TO EXPAND)

AMP DETONATOR — INSTRUCTIONS FOR USE



1.A/B SWITCH	SWITCHES BETWEEN EITHER OUTPUT A OR OUTPUT B
2. BOTH (Y) SWITCH	SELECTS BOTH OUTPUT A AND OUTPUT B TOGETHER. SWITCHING OFF REVERTS BACK TO THE LAST SETTING OF THE A/B SWITCH
3. PHASE SWITCH	CONTROLS THE "TONE" OF THE PEDAL, BRINGING IN MORE TREBLE AS THE LEVEL GETS HIGHER
4. OUTPUT A	BUFFERED OUTPUT
5. ОИТРИТ В	BUFFERED TRANSFORMER ISOLATED OUTPUT. OUTPUT A MUST ALSO BE IN USE FOR OUTPUT B TO FUNCTION CORRECTLY.
6. INPUT	CONNECTING A JACK PLUG TO THE INPUT SWITCHES ON THE POWER TO THE PEDAL
7. 9-12V DC INPUT	USE A REGULATED AC-DC ADAPTOR FITTED WITH A CENTRE- NEGATIVE PLUG (2.1MM)
8. LED	INDICATES THE CURRENT OUTPUT SELECTED: GREEN IS OUTPUT A RED IS OUTPUT B BLUE IS BOTH (Y)

IN USE

Always connect Output A first. Output A can be used independently, for example as a transparent signal buffer. Using Output B only may cause noise issues, so always use Output B with Output A connected also. Experiment with the position of the Phase Switch to achieve the optimum sound with both amps selected ("Y" position).

Two amps that are out of phase with each other will sound lifeless, so your ears are the best judge.

REPLACING THE BATTERY

The battery installed at the factory is for testing purposes only. If you notice a drop in performance, replace the battery. To replace the battery, unfasten the four screws on the base and secure the new battery in the battery clip, making sure to observe the battery's polarity. Disconnect the input when not in use to prolong battery life.

IMPORTANT NOTE

The Amp Detonator can be powered by 9 or 12 V DC. Use a regulated AC–DC adaptor fitted with a centre-negative plug (2.1 mm).

ŀ	HELP WITH MY GEAR	SISTER WEBSITES	Join our newsletter
(Contact us	Orange Essentials	
	Register Gear	Orange Learn	Email confirmation is required
(Gear Manuals		Submit

© Orange Amps | Products can change without notice

Cookies & Terms